

















E380/E220 Series

BETTER WORK, BETTER LIFE

Standard Vector Control VFDs



Zhejiang Hechuan Technology Co.LTD https://www.hcfaglobal.com/

Headquarters address

No.9, Fucai Road, Longyou industrial Zone, Quzhou City, Zhejiang Province, P.R.China

Headquarters address

No. 299, Lixin Road, Qingshanhu Sci-Tech City, Lin'an District, Hangzhou City, Hangzhou R&D Centre Zhejiang Province

Association, which is an open field network:

The other products, product names, and product trademarks or registered trademarks described in this manual are owned by each company.





subject to change without notice. Manual No.; June, 2023 Issue No. 1

Due to the delay in updating the paper version, please refer to the official website for the latest product information

Be dedicated to creating values in automation industry









HCF3 Stock code: 688320.SH

R&D Centers

Set up nationally

Sales Office

Sales elites gathering

Global Distributor









■ New design

General-purpose control board, keyboard panel and extension card

■ Powerful function

Excellent overvoltage suppression capability, Fast acceleration/deceleration, Over-current protect function


■ Exquisite appearance

Space reduced by 40%, improve the space utilization

■ Stable performance


Main components' life expectancy greatly increased, Circuit board 100% coating

Performance specifications




Excellent overvoltage suppression capability

0. 5s deceleration time. In the absence of external brake resistor, the current and voltage can be controlled more stably and no overvoltage error occurs during the deceleration.



Fast acceleration/deceleration

Excellent current control technology to realize the superior load capacity. The VFD can operate repeatedly at 0.1s acceleration/deceleration



Over-current protect function


The current is controlled stably with acceleration/deceleration 0.1s start in VF mode. The excellent Over-current protect function can satisfy most applications.

Superior low-frequency torque performance

Output 150% torque at 0.5Hz in VF mode; Output 160% torque at 0.25Hz in SVC mode; Output 180% torque at 0.25Hz in FVC mode.

/// Hardware features

Flexible use of space



More reliable

Extend main parts' life, 100%PCB coating.



Conformal coating Greatly improve the capability of insulation, moisture-proof, leakage prevention, dustproof, anti-corrosion, anti-aging, anti-mildew etc.



Independent heat dissipation channel
Effectively prevent environmental impact
on products and extend products' lifetime
greatly.



Compact and integrated design

Whole series share common parts for control panel, key board and extension card, reduce the inventory and cut down the cost greatly.

Optimize drive board design

Optimize the drive board layout, thermal design, EMC design, and 100% routing ability.

Technical specifications


	Items		Specifications			
Power input	Rated voltage	Single-phase 220V: Constant voltage fluctuation $\pm 10\%$, transient fluctuation $-15\%\sim+10\%$ Three-phase 220V: Constant voltage fluctuation $\pm 10\%$, transient fluctuation $-15\%\sim+10\%$ Three-phase 380V: Constant voltage fluctuation $\pm 10\%$, transient fluctuation $-15\%\sim+10\%$ That is 323 \sim 437V; Voltage imbalance $<$ 3 $\%$, the distortion rate in accordance with IEC61800-2.				
두	Rated input current	Refer to 2-1				
	Rated frequency	50Hz/60Hz, fluctuation range ±5	%			
Po	Applicable motor	Refer to 2-1				
wer	Rated capacity	Refer to 2-1				
Power output	Rated current	Refer to 2-1				
out.	Output voltage	Three-phase, 0V to the rated volta	ge, error less than ±3%			
	Max. frequency	0Hz~500Hz, 0Hz~3000Hz, can be o	customized according to customer needs			
	Carrier frequency	1. 0kHz~16. 0kHz, can be adjusted automatically				
	Input frequency resolution	0.01Hz (Digital setting)				
	Control mode	Speed control (SVC), torque control (SVC), speed control (FVC), torque control (FVC), V/F control				
	Startup torque	0.25Hz/150% (SVC)	0Hz/180% (FVC)			
	Speed range	1:100 (SVC)	1:1000 (FVC)			
	Speed stability accuracy	±0.5% (SVC)	±0.02% (FVC)			
	Torque control accuracy	±5% (FVC) ★				
Basic functions	Overload capacity	G models: 60s for 150% rated curr	ent, 1s for 200% rated current			
c fu	Torque boost	Automatic boost; Customized boo	ost 0.1 % to 30.0 %			
nctio	Acceleration/deceleration curve		s of acceleration/deceleration time, range : 0. 0s~6500. 0s			
sno	DC injection braking	DC injection braking frequency: 0Hz to m Current level of DC injection braking: 0%	nax. frequency, DC injection braking active time: 0.0s to 60.0s. to 100%			
	Jog running		r~P00.08, Acceleration/Deceleration time of jog running:0.0s to 6500.0s			
	Onboard multiple preset speeds	The VFD can realize up to 16 speeds	by using simple PLC function or by using digital input signals			
	Onboard PID	The VFD can realize proportional-in	tegral-derivative (PID) function in the closed-loop control			
	Automatic voltage regulation (AVR)	The system maintains a constant of	output voltage automatically when the grid voltage			
	Overcurrent stall control	The VFD can limit the output curre	ent automatically when the load changes in V/F operation			
	Overcurrent fast prevention		nt overcurrent faults to guarantee the VFD operates normally			
	Overvoltage stall control	The system limits the energy feedback at trips when frequency changes	utomatically during operation to prevent frequent or excessive			
	Oscillation suppression	, , , , , , , , , , , , , , , , , , , ,	ression to keep the stable operation			



Technical specifications

	Items	Specifications
Inc	Power dip ride-through	Load feedback energy compensates for any voltage reduction, allowing the VFD to continue to operate for a short time during power dips
livid	Timing control	Timing control: Time setting range 0.0min~6500.0min
Individualized functions	Dual-motor switchover	The VFD have two groups of motor parameters and can control up to two motors
ed fu	Multiple fieldbus supported	Multiple fieldbus: Modbus-RTU、CANopen
nctic	Motor overheat protection	Optional I/O extension card★, analog input ,Al3 can accept motor temperature sensor input (PT100/PT1000)★
Suc	Multiple encoder types supported	Support incremental encoders
	Command source Main frequency reference setting channel Auxiliary frequency reference setting channel	Different methods of switching, such as Operating panel, Terminal I/O control, Serial communication Supports up to 10 frequency reference setting channels and allows different methods of switching: Digital setting, Analog voltage reference, Analog current reference, Pulse reference, Communication reference Supports 9 auxiliary frequency sources, and allows fine tuning of the auxiliary frequency and main&auxiliary calculation
RUN	Input terminals	Standard: 7 digital input (DI) terminals, one of which supports up to 100kHz high-speed pulse input. 3 analog input (AI) terminals: AI1: Support 0 to 10V voltage input AI2: Support 0 to 10V voltage input or 0 to 20mA current input AI3: Support -10 to 10V voltage input Extension capacity★: Can be customized according to customer needs
	Output terminals	Standard: 2 analog output terminal, support 0 to 10V voltage output or 0(or 4) to 20mA current output 2 digital output terminal, one of which supports high-speed pulse output terminal for a square-wave signal output in the frequency 0 to 100kHz 1 relay output terminal Extension capacity★: Can be customized according to customer needs
Disp	LED display	Display and operating panel
Display and operating panel	LCD display	Can be selected according to user needs
ndop	Parameter copy	The parameters can be quickly copied through the LCD operation panel
perati	Key locking and function selection	Keys on the LCD control panel can be locked or partially locked electronically to prevent accidental operation. The range of some functions can be limited to a permitted range to prevent incorrect settings
ingp	Protection function	Short-circuit protection, Input/output phase loss protection, Overcurrent protection, Overvoltage protection, Undervoltage protection, Overheat protection, Overload protection
anel	Optional accessories	LCD operation panel, brake components, I/O extension card★, CANopen communication card, incremental encoder PG card
	Installation location	Install the VFD indoors and protected from direct sunlight, dust, corrosive or combustible gases, oil smoke, vapour, ingress from water or any other liquid, and salt
ᄧ	Altitude	Below 1000 m (If the altitude exceeds 1000 m, de-rate the VFD)
Environment	Operation temperature	-10°C \sim \pm 40 °C (If the ambient temperature is 40°C to 50 °C, de-rate the VFD)
ımeı	Humidity	Less than 95%RH, non-condensing
1	Vibration	Less than 5.9m/s² (0.6g)
	Storage temperature	-20°C~+60°C
	Protection level	IP20
	Cooling method	Forced air cooling

/// Naming rules




Product specifications table 2-1


	Classifications	Madalmania	Power capacity		OutputcurrentA	Applicable motor	
	Classifications	Model name	kVA	Input current A	Output current A	kW	HP
	Single-phase power	E220-0.75G3BE-00	1.5	8.2	4	0.75	1
	220V(-15%~+10%), 50/60Hz	E220-1.5G3BE-00	3	14	7	1.5	2
		E220-2.2G3BE-00	4	23	9.6	2.2	3
E220V		E220-0.75G3BE-00	3	5	4	0.75	1
	Three-phase power	E220-1.5G3BE-00	4	8	7	1.5	2
	220V(-15%~+10%), 50/60Hz	E220-2.2G3BE-00	6	10.5	9.6	2.2	3
		E220-3.7G3BE-00	8.9	14.6	13	3.7	5
	Three-phase power	E380-0.75G3BE-00	1.5	3.4	2.1	0.75	1
		E380-1.5G3BE-00	3	5	3.7	1.5	2
		E380-2.2G3BE-00	4	5.8	5	2.2	3
		E380-3.7G3BE-00	5.9	10.5	9	3.7	5
		E380-5.5G3BE-00	8.9	14.6	13	5.5	7.5
		E380-7.5G3BE-00	11	20.5	17	7.5	10
E380V		E380-11G3BE-00	17	26	25	11	15
E360V	380V(-15%~+10%),50/60Hz	E380-15G3BE-00	21	35	32	15	20
		E380-18.5G3BE-00	24	38.5	37	18.5	25
		E380-22G3BE-00	30	46.5	45	22	30
		E380-30G3NE-00	40	62	60	30	40
		E380-37G3NE-00	50	76	75	37	50
		E380-30G3BE-00	40	62	60	30	40
		E380-37G3BE-00	50	76	75	37	50



Main structures diagram




External dimensions



Product installation size


	Classifications	Madelman	Mounti	ng hole	External dimensions mm		ns mm	Mounting	Weight
	Classifications	Model name	W1	H1	н	W	D	hole mm	kg
		E220-0.75G3BE-00	60	131	(wall-mounting)	72	143	5.2	2
	Single-phase 220V, 50/60Hz	E220-1.5G3BE-00							
E220V		E220-2.2G3BE-00	75	146	(wall-mounting)	87	153	5.2	3
		E220-3.7G3BE-00							
		E220-0.75G3BE-00	60	131	(wall-mounting)	72	143	5.2	2
	Three-phase 220V, 50/60Hz								
	1111ee-priase 220v, 50/00112	E220-2.2G3BE-00	75	75 146	(wall-mounting)	87	153	5.2	3
		E220-3.7G3BE-00							
		E380-0.75G3BE-00	60	131	142 (wall-mounting)	72	143	5.2	2
		E380-1.5G3BE-00	00	131	(wall-mounting)	12	143	5.2	
		E380-2.2G3BE-00	75	146	(wall-mounting)	87	153	5.2	3
		E380-3.7G3BE-00				01	133	5.2	3
		E380-5.5G3BE-00	101	101 195	.95 (wall-mounting)	113	155	5.2	5
E380V		E380-7.5G3BE-00	101			113	155	5.2	
23004	Three-phase 380V, 50/60Hz	E380-11G3BE-00	118	239	(wall-mounting)	130	185	5.5	8
	1111cc priase 300v, 30, 00112	E380-15G3BE-00	110	200	(vvali-i i ioui iui ig	150	103	5.5	
		E380-18.5G3BE-00	150	201	(wall-mounting)	170	100	0.4	10
		E380-22G3BE-00	158	281	(wall-mounting)	178	192	8.4	10
		E380-30G3NE-00					192	6	
		E380-37G3NE-00	195	335	350	225			15
		E380-30G3BE-00	133	333	(wall-mounting)	ZZJ		0	13
		E380-37G3BE-00							

/// Operation panel introduction






External dimension for operation panel



Remove and reinstall the operation panel



Remove the operation panel: Put the middle finger to the slot at the upper side of operation panel and press inwards on both sides to release the operation panel.

Reinstall the operation panel: Locate the mounting hook of operation panel to the mounting slot, and press on the upper side with middle finger until the side latches are in place.

Press inwards on both sides to release the panel

△Warning

- The machine is equipped with LED panel and support external extension. Note whenpurchasing and the external extension cable can be provided
- LCD panel is optional and can be extended externally

Selection guide of braking unit

Resistance selection

The motor and load's regenerative energy is almost completely consumed on the braking resistor when braking.

According to the formula U*U/R=BR:
U refers to the braking voltage at system stable braking.

Different systems select different braking voltages. The 380 VAC system usually selects 700 V braking voltage.
The 220 VAC system usually selects 380 V braking voltage BR refers to the braking power

Single-phase 220V 50/	60HZ			
E220-0.75G3BE-00	150W	≥80Ω		
E220-1.5G3BE-00	150W	≥50Ω	Built-in brake	No special description
E220-2.2G3BE-00	250W	≥50Ω		

Three-phase 220V 50/	60HZ			
E220-0.75G3BE-00	150W	≥80Ω		
E220-1.5G3BE-00	150W	≥50Ω	Built-in brake	No special description
E220-2.2G3BE-00	250W	≥50Ω	Duilt-III blake	No special description
E220-3.7G3BE-00	300W	≥30Ω		

Selection of power of braking resistor

is consistent with the braking power.
But in consideration that the de-rating is 70%, you can calculate the power of the braking resistor according to the formula 0. 7*Pr=BR*D. Pr refers to the power of resistor D refers to the braking frequency (percentage of the regenerative process to the whole working process)
Elevator---20%-30%
Winding and unwinding----20%-30%
Centrifuge---50%-60%

In theory, the power of the braking resistor

Three-phase 380V 50/6	60HZ			
E380-0.75G3BE-00	150W	≥150Ω		
E380-1.5G3BE-00	150W	≥150Ω		
E380-2.2G3BE-00	250W	≥100Ω		
E380-3.7G3BE-00	300W	≥80Ω		
E380-5.5G3BE-00	400W	≥40Ω		
E380-7.5G3BE-00	500W	≥30Ω	Built-in brake	No special description
E380-11G3BE-00	800W	≥25Ω		
E380-15G3BE-00	1000W	≥25Ω		
E380-18.5G3BE-00	1300W	≥20Ω		
E380-22G3BE-00	1500W	≥20Ω		
E380-30G3NE-00	2500W	≥16Ω	Cotomo el level de en cuelt	No an acial decariation
E380-37G3NE-00	3700W	≥16Ω	External braking unit	No special description
E380-30G3BE-00	2500W	≥16Ω	De ille in lengths	No see stable and stable
E380-37G3BE-00	3700W	≥16Ω	Built-in brake	No special description

∆Warning


Occasional braking load---5% General application---10%

- **The Table above provides data for reference. You can select different resistance and power based on actual needs. However, the resistance must not be lower than the recommended value. The power may be higher than the recommended value.
- **The braking resistor model is dependent on the generation power of the motor in the actual system and is also related to the system inertia, deceleration time and potential energy load.
- **For systems with high inertia, and/or rapid deceleration times, or frequent braking sequences, the braking resistor with higher power and lower resistance value should be selected.



VFD installation

Install the VFD indoors, with good ventilation, and generally vertically. The installation clearance that need to be reserved is shown as below.



Installation environment


- ■The ambient temperature should be around -10°C~40°C. Whentemperature exceeds 40°C, the external forced cooling or de-rating is required.
- ■Install the VFD on the surface of an incombustible object, and ensure that there is sufficient space around for heat dissipation.
- ■Free from the direct sun.
- ■Free from the location with high humidity and condensation, humidity less than 95%
- \blacksquare Free from the vibration(less than 5.9 m/s² (0.6g)
- ■Free from oil dirt, dust and metal powder
- \blacksquare Free from corrosive, explosive and combustible gas.


Precautions for installation


- When single VFD installed: Do not consider the dearance A when power is less than 15kW. Clearance A should be greater than 50mm if power exceed 15kW.
- ■When installed on another VFD: If VFD needs to be installed above another one, install an insulation guide plate.

Power class	When installed on another VFD				
Fower class	В	А			
≤15kW	≥100mm				
18.5kW—30kW	≥200mm	≥50mm			
≥37kW	≥300mm				

Standard wiring










Selection Guide


Model name	Power	Input voltage	Input terminal	Function description
E220-0.75G3BE-00	0.75kW	Three-phase 220V		1) Control mode: No PG vector speed control, No PG vector torque control *, PG
E220-1.5G3BE-00	1.5kW	(-15%~+10%) 50/60Hz [Models of 2.2kW or	Standard:	vector speed control ★, PG vector torque control ★, V/F control 2) Timing control function: 0.0–6500.0 minutes
E220-2.2G3BE-00	2.2kW	less support single	7 digital input terminals,	3) Instantaneous power-failure: Load feedback energy compensates for any voltage
E220-3.7G3BE-00	3.7kW	phase operation]	one terminal support at	reduction, allowing the drive to continue to operate for a short time during power dips
E380-0.75G3BE-00	0.75kW		most 100kHz high-speed	4) Multi-motor switchover: The drive have two groups of motor parameters and can
E380-1.5G3BE-00	1.5kW		pulse input, 3 analog input	control up to two motors. 5) Motor overheat protection: The optional I/O extension card ★enables Al3 to
E380-2.2G3BE-00	2.2kW		terminals;	receive the motor temperature sensor input (PT100, PT1000) ★ so as to realize
E380-3.7G3BE-00	3.7kW		All supports 0V~10V	motor overheat protection 6) Overload capacity: G models: 60s for 150% rated current, 1s for 200% rated current
E380-5.5G3BE-00	5.5kW		voltage input; AI2 supports 0V~10V	7) Torque boost: Automatic boost; manual boost 0.1 % to 30.0 % 8) Acceleration/deceleration curve: Straight-line or S-curve. Four kinds of acceleration
			voltage input or	/deceleration time, range: 0.0s~6500.0s
E380-7.5G3BE-00	7.5kW	Three-phase 380V	0/4mA~20mA current	9) DC braking: DC braking frequency: 0Hz to max. frequency, DC injection braking active time: 0.0s to 60.0s. Current level of DC injection braking: 0% to 100%
E380-11G3BE-00	11kW	(-15%~+10%)	,	10) Simple PLC, multi-stage operation: It implements up to 16 speeds via the simple
E380-15G3BE-00	15kW	50/60HZ	input;	PLC function or combination of DI terminal states
E380-18.5G3BE-00	18.5kW		Al3 supports -10V~+10V	11) Onboard PID: It realizes process-controlled closed loop control system easily. 12) Overcurrent suppression: The system limits the output current automatically
E380-22G3BE-00	22kW		voltage input;	when the load changes in V/F operation.
E380-30G3BE-00	30kW		Extension abilities★:	13) Rapid current limit: The function helps to avoid frequent overcurrent faults to guarantee the VFD operate normally
E380-37G3BE-00	37kW		Can be customized	14) Overvoltage stall control: The system limits the energy feedback automatically
E380-30G3NE-00	30kW		according to customer	during operation to prevent frequent or excessive trips when frequency changes. 15) Oscillation suppression: Optimize the V/F oscillation suppression to keep the stable
E380-37G3NE-00	37kW		needs	operation

PG card appearance and installation

Installation drawing



PG card



PG card installation

Model name	Power	
E380-PG2	Differential input	
E380-PG3	Open collector, push-pull input	

Model name	Description	Notes
E380-PG2	Encoder signal input terminal	Refer to Pin definition of encoder signal input terminal
E380-PG3	Encoder power supply selection jumper, 5V or 15V output can be selected	Factory default: 5V

Specifications


Items	Specifications
Encoder power supply	5V/200mA, 15V/200mA
Encoder interface type	Support differential and open collector
AWG	For specific wire gauge of 16~26AWG, please refer to the manual
Terminal pitch	3.5mm
Terminal screw	Slotted
Terminal type	Oblique terminal block

/// Pins definition


Items	Specifications				
Pins No.	1	2	3	4	
Terminal name	A+	A-	B+	B-	
Description	Encoder output A signal positive	Encoder outputA signal negative	Encoder output B signal positive	Encoder output A signal positive	
Pins No.	5	6	7	8	9
Terminal name	Z+	Z-	5/15	\bigcirc	PE
Description	Encoder output Z signal positive	Encoder output Z signal negative	Encoder 5V/15V powersupply	Encoder power supply grounding	Shielded terminal




Differential input wiring diagram



Collector input wiring diagram



Push-pull input wiring diagram



Step 1: If it is a push-pull differential output encoder, please connect the encoder output A-/B-/Z-phase to the A-/B-/Z- of the PG card input terminal respectively, and no connection for the encoder output A+/B+/Z+ phase: If it is a push-pull single-ended signal output, please connect the encoder signal A-/B-/Z-phase to the A-/B-/Z- of the PG card input terminal respectively; then connect the encoder's power to 5V /15V,

Step 2: Select the power supply mode of the PG card encoder according to the power supply voltage of the encoder (5V or

Step 3: Connect the shielding layer of the encoder cable to the

For encoders of push-pull differential output type, the A+/B+/Z+ signal of the push-pull output cannot be connected to the A+/B+/Z+ terminal of the PG card and must be left disconnected,



III Relationship between encoder cable length and cables

The longer the encoder cable, the greater the cable resistance, so the encoder power supply and encoder signal voltage drop across the cable resistance will be greater.

For long-distance applications, if the wire gauge selection is unreasonable, the encoder and PG will not work normally due to the signal attenuation caused by the cable resistance.


Please refer to the table below to select the appropriate wire gauge based on the length of the on-site cable (wire gauge: the standard for distinguishing wire diameters, here use AWG).

Cable length (unit: m)	AWG	Cable length (unit: m)	AWG
10	<20	60	≤22
20	≤26	70	≤21
30	<24	80	
40	≤24	90	< 20
50	≤22	100	<20

EMC directives

- 1. For installing and debugging, separate the signal line (such as the encoder cable) and the power cable into different trunking. It is strictly forbidden to bundle the encoder cable and the power cable together, otherwise it may cause encoder interference;
- 2. The servo motor shell must be connected to the ground terminal (PE terminal) of the VFD, and the ground wire on the side of the motor shell must be well connected; otherwise, a good grounding effect will not be achieved
- 3. For some large equipment, the VFD is far away from the servo motor, and the motor cable is very long (>10m). The cable inductance will affect the grounding effect and the grounding effect will be worse. At this time, the encoder shield cannot be connected to the VFD grounding terminal (PE terminal).

E380-CAN1 extension card installation instructions




E380-CAN1 network connection

Communication network interface definition

The network port of this product uses the standard RJ45 interface 8-pin network port.


Pins	Definition
1	CAN_H
2	CAN_L
3	CAN_GND
4	N/A
5	N/A
6	N/A
7	N/A
8	N/A



Terminal resistance setting


In order to facilitate the on-site use, the E380-CAN1 card is equipped with terminal resistors, which can be set by the jumper .

When the jumper cap is close to the OFF end, it means the terminal resistance (120Ω) is not connected, and when the jumper cap is close to the ON end, it means the terminal resistance (120Ω) is connected.



Terminal resistance jumper

Extension cable for E380(E220) series operation panel



Model name	Specifications
CAB-E380FQV001-1M	operation panel extension cable
CAB-E380FQV001-3M	operation panel extension cable
CAB-E380FQV001-5M	operation panel extension cable
CAB-E380FQV001-10M	operation panel extension cable
CAB-E380FQV001-20M	operation panel extension cable
CAB-E380FQV001-50M	operation panel extension cable