



SV730W

**Multi-Axis
Advanced Servo**

EtherCAT Bus

User Manual

※ Preface

Thank you for choosing this product. This operation manual provides information related to the 730W series servo system—EtherCAT bus servo drives and motors. Please follow this manual to ensure correct operation. Improper use or handling may not only prevent the product from achieving its full performance but could also lead to accidents and reduce the product's service life.

Please read this instruction manual carefully and use the product correctly.

About the instruction manual

- ① While every effort has been made to ensure the accuracy of the contents in this instruction manual, any questions or concerns regarding the information should be directed to the company.
- ② The following items should be specified in the instruction manual for the machine incorporating this product.
 - It is high-voltage electrical equipment and poses a hazard.
 - Voltage remains on the terminals and inside the unit after power is turned off, posing a hazard.
 - Localized high-temperature areas.
 - Dismantling is strictly prohibited.
- ③ Product specifications and functions are subject to change or addition at any time without prior notice, due to reasons such as performance upgrades.
- ④ For equipment incorporating this product, if safety standard certification is planned, the company should be consulted in advance.
- ⑤ To extend the service life of the motor and drive, they should be used under correct operating conditions. Detailed usage must follow the instructions in this manual.
- ⑥ The instruction manual is updated to contain the latest information whenever possible; therefore, its contents are subject to frequent change. A new version of the instruction manual can be obtained by contacting the company.
- ⑦ Reproduction of part or all of the contents of this instruction manual is prohibited without the consent of the company.

Unboxing confirmation

- Whether the physical product matches your order.
- Whether there is any damage incurred during transportation.
- If any issues are found, please contact your distributor.

Read before use

Thank you for using the 730W series EtherCAT bus servo drive. This operation manual provides information for the 730W series EtherCAT bus servo drives and motors. Please be sure to refer to this manual when installing, operating, and maintaining the 730W series products. Incorrect operation or handling may not only prevent the product from achieving its full performance and reduce its service life, but may also lead to accidents.

Please keep this manual in a safe place for future reference.

Terminology

| Terminology | Description |
|-------------|--------------------------------------|
| Servo motor | X2 series, X6 series servo motors |
| Servo drive | 730W series EtherCAT bus servo drive |

| | |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Servo system | A complete system composed of a servo drive, host device, and peripheral equipment. |
| Servo ON | Motor powered |
| Servo OFF | Motor not powered |
| Base block (BB) | A non-powered state formed by cutting off the base current of the power transistor in the current amplifier. |
| Servo lock | The state where the motor is stopped by a zero position command in the position loop. |
| Main circuit cable | Cable connected to the main circuit terminals (e.g., main circuit power cable, control power cable, servo motor power cable). |

Target readers

This manual is intended for:

- Personnel with a basic understanding of electrical knowledge.
- Personnel responsible for the transportation and storage of the 730W series EtherCAT bus servo drives or related products.
- Personnel responsible for the installation, connection, commissioning, and maintenance of the 730W series EtherCAT bus servo drives or related products.

Products range

Certain specifications or limitations for the products covered in this manual may be described in other manuals. Details are listed in the table below:

This manual primarily provides information for the following products:

730W series EtherCAT bus servo drives

Manual revision notes

| Version | Revision content |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| V1.0 | First edition |
| V1.1 | Revised naming rules and specification parameters; updated Chapter 5 Servo Basic Functions and Chapter 11 Parameter List; added notes and corrected some errors. |

Other notes

- The content of this manual may be updated in accordance with hardware or software modifications made by Zhejiang Hechuan Technology Co., Ltd. Any changes to product specifications or related information will be posted on the HCFA official website: www.hcfa.cn, without prior notice.
- This manual has been compiled based on product information and customer requirements. If you have any questions or find any errors in the manual, please call HCFA or send an email to 400@hcfa.cn, and kindly provide the version number indicated on the cover for reference.
- Reproduction or copying of any part or the entirety of this manual is strictly prohibited.

Trademark notices



- EtherCAT® is a registered trademark of Beckhoff Automation GmbH and is an open-fieldbus network.
- Other products, product names, trademarks or registered trademarks mentioned in this manual are the property of their respective owners and are not products of our company.

※ Safety precautions


Safety precautions


Please always pay attention to the following safety precautions during acceptance, inspection, installation, wiring, operation, and maintenance.

- ◆ The safety instruction levels, which may be caused by the neglect of the instruction or incorrect use of this product, are classified and described in the following table.

| | |
|--------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| DANGER  | Indicates that incorrect handling may result in death or severe injury. |
| CAUTION  | Indicates that incorrect handling may result in injury or property damage. |



- ◆ The following graphical symbols are used to indicate items that must be observed.

 Indicates what must not be done.

 Indicates what must be done.

DANGER

Installation and wiring

| | | |
|----------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
|  | Do not connect the motor directly to a commercial power. | Otherwise, it may cause fire or malfunction. |
| | Do not place any combustibles near the servo motor and drive. | Otherwise, it may cause a fire. |
|  | Please place the drive within a protective case, and leave specified clearances between the drive and control enclosure walls or other equipment. | Otherwise, it may cause an electric shock, fire, or malfunction. |
| | Please install the drive in a place that frees from excessive dust, water, and oil. | Otherwise, it may cause an electric shock, fire, malfunction, or damage. |
| | Please install the drive to incombustible, such as metal. | Otherwise, it may cause a fire. |
| | The wiring must be done by a professional electrician. | Otherwise, it may cause an electric shock. |
| | The FG terminal of the motor or the drive must be grounded. | Otherwise, it may cause an electric shock. |
| | Please cut off the upper circuit breaker before wiring. | Otherwise, it may cause an electric shock, injury, malfunction, or damage. |
| Please ensure a good connection of the cable with its electrified part being well insulated. | Otherwise, it may cause an electric shock, fire, or malfunction. | |

Operation and running

| | | |
|------------------------------------------------|---------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------|
| | Do not touch the internal parts of the drive. | Otherwise, it may cause burns or an electric shock. |
| | The cables must not be excessively damaged, stressed, loaded, or pinched. | Otherwise, it may cause an electric shock or malfunction. |
| | Do not touch the rotating parts of the servo motor during operation. | Otherwise, it may cause injury. |
| | Do not use in wet areas, environments containing corrosive or flammable gases, or near combustible materials. | Otherwise, it may cause a fire. |
| | Do not use in locations subject to severe vibration or impact. | Otherwise, it may cause an electric shock, injury, or fire. |
| | Do not immerse the cables in oil or water during operation. | Otherwise, it may cause an electric shock, injury, or fire. |
| | Do not conduct wiring or perform operations with wet hands. | Otherwise, it may cause an electric shock, injury, or fire. |
| | Do not touch the keyway of the motor shaft with bare hands. | Otherwise, it may cause injury. |
| | Do not touch the motor, drive, and heat spreaders since they will heat up during operation. | Otherwise, it may cause burns or component damage. |
| Do not connect the motor to an external power. | Otherwise, it may cause a fire. | |

Other safety precautions

| | | |
|--|-------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|
| | Please ensure equipment safety after earthquakes. | Otherwise, it may cause an electric shock, injury, or fire. |
| | Ensure a correct installation and setting to prevent fire or personal injury during earthquakes. | Otherwise, it may cause injury, electric shock, fire, malfunction, or damage. |
| | Please provide an external emergency stop circuit to ensure that operation can be stopped and power switched off immediately. | Otherwise, it may cause injury, electric shock, fire, malfunction, or damage. |

Maintenance and inspection



| | | |
|--|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------|
| | As there's dangerous and high-voltage inside the drive, before wiring or inspection, turn off the power and wait for 5 minutes or more until the charge indicator turns off. Do not disassemble the drive. | Otherwise, it may cause an electric shock. |
|--|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------|

CAUTION



Installation and wiring

| | | |
|--|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| | Please install the servo motor and drive following the combinations specified in this manual. | Otherwise, it may cause fire or malfunction. |
| | Do not touch the connector terminals directly. | Otherwise, it may cause an electric shock or malfunction. |
| | Do not block the intake and let any foreign materials enter into the equipment. | Otherwise, it may cause an electric shock or fire. |
| | The test operation must be done with the motor being fixed but separated from the mechanical system. Only after confirming the operation can the motor be installed to the mechanical system. | Otherwise, it may cause injury. |
| | The servo motor must be installed following the specified directions and methods. | Otherwise, it may cause injury and malfunction. |
| | Ensure a proper installation in accordance with the weight and rated output of the equipment. | Otherwise, it may cause injury and malfunction. |


Operation and running

| | | |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
|  | Do not stand or put any heavy objects on the equipment. | Otherwise, it may cause an electric shock, injury, malfunction, or damage. |
| | Do not make extreme gain adjustments or changes, which will result in unstable running. | Otherwise, it may cause malfunction or damage. |
| | Keep it away from the direct sunlight. | Otherwise, it may cause malfunction. |
| | Do not subject the motor and its shaft to heavy impact. | Otherwise, it may cause malfunction. |
| | The electromagnetic brake on the motor is designed to hold its shaft and should not be used for normal braking. | Otherwise, it may cause injury and malfunction. |
|  | When power is restored after an instantaneous power outage, keep away from the machine because it may be restarted suddenly. Set the machine so that it is secured against personal injury if restarted. | Otherwise, it may cause injury. |
| | Do not use any malfunctioning or damaged motor or drive. | Otherwise, it may cause an electronic shock, fire, or injury. |
| | Please confirm that the power supply specification is normal. | Otherwise, it may cause malfunction. |
| | Holding brake is not a safety stopper used for ensuring machine safety. To ensure safety, install a stopper on the machine side. | Otherwise, it may cause injury. |
| | When any alarm has occurred, eliminate its cause, ensure safety, and deactivate the alarm before restarting the operation. | Otherwise, it may cause injury. |
| | The brake relay and the emergency stop relay must be connected in series. | Otherwise, it may cause injury or malfunction. |



Transportation and storage

| | | |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|-------------------------------------------------|
|  | Do not subject the equipment to rain, droplets, toxic gas, or fluid. | Otherwise, it may cause malfunction. |
| | Do not carry the motor by the cables or shaft during transportation. | Otherwise, it may cause injury and malfunction. |
|  | Do not drop or overturn the motor during transportation and installation. | Otherwise, it may cause injury and malfunction. |
| | For long-term storage, please contact HCFA via the contact information listed in this manual. | Otherwise, it may cause malfunction. |
| | Please store in a storage place that complies with the storage environment specified in this manual. | Otherwise, it may cause malfunction. |

Other safety precautions

| | | |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|--|
|  | Please insulate the battery with adhesive tape and dispose of it following the law of each country (area). | |
| | When disposing of the equipment, treat it as an industrial waste. | |

Maintenance and inspection

| | | |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
|  | Please contact HCFA for further instructions on removal, installation, and repair. | Otherwise, it may cause malfunction. |
| | Do not turn on and off the main circuit power switch too frequently. | Otherwise, it may cause malfunction. |
|  | During operation or for a period after power is turned off, the motor, drive heat sink, and regenerative resistor may remain hot. Do not touch them. | Otherwise, burns or electric shock may occur. |
| | When the drive becomes faulty, switch off the control circuit and main power supply. | Otherwise, it may cause a fire. |
| | If the equipment is to be stored for a long time, please switch off the main power supply. | Otherwise, it may cause injury caused by the malfunction of the equipment. |

Maintenance and inspection

< Warranty period >

● The term of warranty for the product is eighteen (18) months from the date of manufacture. However, for the motor with a brake, the warranty period does not exceed the maximum period that the shaft can accelerate or decelerate.

< Warranty coverage >

- This warranty applies only when the condition, method, environment, etc. of use comply with the terms and conditions and instructions that are stated in the manual. However, even during the warranty period, the repair cost will be charged to customers in the following cases.
 - ① A failure caused by improper use, storage, handling, repair, or modification.
 - ② A failure caused by drops after receipt or damages caused during transportation.
 - ③ A failure caused by use beyond product specifications.
 - ④ A failure caused by external factors such as fire, earthquake, thunder and lightning, flooding, wind hazard, salty damage, abnormal voltage fluctuation, and other unavoidable accidents.
 - ⑤ A failure caused by the intrusion of water, oil, metal fragments, or other foreign materials.
- The warranty covers only the delivered product itself. HCFA is not liable for or compensates any consequential damages caused by product malfunctions.

Notation rules


Notation rules for negated signals

In this manual, negated signal names (signals active at low level) are indicated by adding a slash (/) before the signal name.

For example, "BK" is written as "/BK".

Notation rules for parameters

The notation rules differ between "Numeric value setting type" and "Function selection type".



• **Function selection type**

| Parameter | | Meaning | Effective moment | Category |
|-----------|-------------------------------|--------------------------------------------------------------|------------------|---------------|
| Pn002 | n. □ 0 □ □ | Normal use of absolute encoder | After repowering | Basic setting |
| | n. □ 1 □ □ Factory setting | Use absolute encoder as incremental encoder | | |
| | n. □ 2 □ □ | Using the encoder as a single-turn absolute encoder (rotary) | | |

n. □ □ □ □ indicates function selection type, □ represents the setting value of each bit; here, the 2nd bit is "1"


Function selection description

After parameter number change

Parameter category

• **Notation example (Example for Pn002.0)**

N 0 0 0 0



| Bit notation | | Setting value notation | |
|-----------------|----------------------------------|------------------------|-----------------------------------------|
| Notation method | Meaning | Notation method | Meaning |
| Pn002.0 | Indicates bit 0 of the parameter | Pn002.0=X | Indicates bit 0 of the parameter is "x" |
| Pn002.1 | Indicates bit 1 of the parameter | Pn002.1=X | Indicates bit 1 of the parameter is "x" |
| Pn002.2 | Indicates bit 2 of the parameter | Pn002.2=X | Indicates bit 2 of the parameter is "x" |
| Pn002.3 | Indicates bit 3 of the parameter | Pn002.3=X | Indicates bit 3 of the parameter is "x" |

✳ Contents

| | |
|-----------------------------------------------------------------|-----------|
| Preface | 2 |
| About the instruction manual..... | 2 |
| Unboxing confirmation..... | 2 |
| Read before use..... | 2 |
| Terminology | 2 |
| Target readers | 3 |
| Products range..... | 3 |
| Manual revision notes | 3 |
| Other notes | 3 |
| Trademark notices..... | 3 |
| Safety precautions | 4 |
| Safety precautions..... | 4 |
| Notation rules | 7 |
| Contents | 9 |
| Chapter 1 730W Overview | 17 |
| 1.1 730w series product features | 18 |
| 1.2 730W nameplate information | 18 |
| 1.3 730W drive naming rules..... | 19 |
| 1.4 730W servo drive component name | 20 |
| 1.4.1 SIZE A AC220V (1P/3P) servo drive component diagram..... | 20 |
| 1.4.2 SIZE A AC380V (3P+N) servo drive component diagram | 21 |
| 1.4.3 SIZE B AC220V (1P/3P) servo drive component diagram | 22 |
| 1.4.4 SIZE B AC380V (3P+N) servo drive component diagram | 23 |
| 1.5 730W model specifications..... | 24 |
| 1.5.1 Servo model specifications..... | 24 |
| 1.6 730W servo drive ratings & specifications | 24 |
| 1.6.1 AC220V (1P/3P) basic specifications | 24 |
| 1.6.2 AC380V (3P+N) basic specifications | 25 |
| 1.6.3 Environmental specifications..... | 25 |
| 1.6.4 Technical specifications | 26 |
| 1.7 730W servo drive outline dimensions..... | 27 |
| 1.7.1 730W drive configuration table | 27 |
| 1.7.2 730W series drive installation dimensions | 27 |
| 1.7.3 SIZE WA drive outline dimensions | 27 |

| | | |
|----------------------------------------|-----------------------------------------------------------------------------|-----------|
| 1.7.4 | SIZE WB drive outline dimensions..... | 27 |
| 1.8 | Drive installation..... | 28 |
| 1.8.1 | Installation within a control cabinet | 28 |
| 1.8.2 | Mechanical Installation Instructions..... | 28 |
| 1.9 | Maintenance and inspection | 29 |
| Chapter 2 Wiring and Connection | | 30 |
| 2.1 | Precautions..... | 32 |
| 2.1.1 | Symbols..... | 32 |
| 2.1.2 | General wiring precautions | 32 |
| 2.2 | SIZE A AC220V (1P/3P) drive terminal definition diagram..... | 34 |
| 2.3 | SIZE A AC380V (3P+N) drive terminal definition diagram..... | 36 |
| 2.4 | SIZE B AC220V (1P/3P) drive terminal definition diagram..... | 38 |
| 2.5 | SIZE B AC380V (3P+N) servo unit components introduction diagram..... | 40 |
| 2.6 | Main circuit wiring..... | 41 |
| 2.6.1 | Example of main circuit wiring for standard AC220V(3P) power input | 42 |
| 2.6.2 | Example of main circuit wiring for standard AC380V(3P+N) power input | 43 |
| 2.6.3 | Servo drive of single-phase 220V power input | 44 |
| 2.6.4 | Servo unit of DC power input..... | 45 |
| 2.6.5 | Line breaker and fuse capacity | 51 |
| 2.7 | Wiring of regenerative resistor | 51 |
| 2.7.1 | AC 220V(1P/3P) regenerative resistor basic specifications | 52 |
| 2.7.2 | AC380V(3P+N) regenerative resistor basic specifications | 52 |
| 2.8 | Input and output signals (CN1) | 52 |
| 2.8.1 | Pin arrangement of I/O signal (CN1) connector..... | 53 |
| 2.8.2 | Name and function of input signal (CN1) | 53 |
| 2.8.3 | Allocation of input signal | 54 |
| 2.8.4 | Input circuit | 55 |
| 2.8.5 | Name and function of output signal (CN1)..... | 56 |
| 2.8.6 | Allocation of output signal..... | 56 |
| 2.8.7 | Output circuit..... | 57 |
| 2.8.8 | Brake signal..... | 58 |
| 2.9 | Encoder signal (CN2) | 59 |
| 2.9.1 | Name and function of encoder signal (CN2) | 59 |
| 2.9.2 | Wiring the servo drive to encoder..... | 60 |
| 2.10 | Safety function signals STO (CN3) | 61 |
| 2.10.1 | Names and functions of the safety function signal (CN3) | 61 |
| 2.10.2 | Safety input circuit..... | 61 |
| 2.10.3 | Example of Safety Terminal Default Wiring..... | 62 |
| 2.11 | Communication connector (CN6) | 62 |

| | |
|-------------------------------------------------------------|----|
| 2.12 Brake input connection (CN10) | 63 |
| 2.12.1 Brake wiring..... | 63 |
| 2.13 Noise and harmonic countermeasures | 65 |
| 2.13.1 Countermeasures against noise | 65 |
| 2.13.2 Noise filter wiring and connection precautions | 67 |
| 2.13.3 Connection of reactor for harmonic suppression | 69 |

Chapter 3 EtherCAT Communication Introduction 70

| | |
|---------------------------------------------------------|----|
| 3.1 EtherCAT communication protocol introduction | 71 |
| 3.2 Definition of communication network interface | 71 |
| 3.3 Parallel networking of multiple servos..... | 71 |
| 3.4 EtherCAT frame structure..... | 72 |
| 3.4.1 Control modes supported by EtherCAT | 72 |
| 3.4.2 EtherCAT frame structure | 72 |
| 3.4.3 EtherCAT state machine..... | 72 |
| 3.4.4 Process data PDO | 74 |
| 3.4.5 Mailbox data SDO | 76 |
| 3.4.6 Distributed clock | 76 |
| 3.4.7 CiA402 control process introduction..... | 76 |
| 3.4.8 ESI Documents..... | 77 |

Chapter 4 Commissioning and Operation 78

| | |
|----------------------------------------------------------------|----|
| 4.1 Checks and precautions before test run | 79 |
| 4.2 Single-servo motor test run | 79 |
| 4.3 Origin search and positioning (Fn003) | 79 |
| 4.4 Single servo motor test run via host device commands..... | 79 |
| 4.4.1 Input signals connection and parameter modification..... | 80 |
| 4.5 Test run after connecting servo motor to machinery..... | 80 |
| 4.6 Test run of brake-equipped servo motor | 81 |

Chapter 5 Basic Function of Servo 82

| | |
|-----------------------------------------------------|----|
| 5.1 Precaution..... | 85 |
| 5.2 Panel operation procedures and display..... | 85 |
| 5.2.1 Panel operator keys..... | 85 |
| 5.2.2 Changing modes | 86 |
| 5.2.3 Status display and judgment | 86 |
| 5.2.4 Operation of auxiliary function (Fn□□□) | 87 |
| 5.2.5 Parameter setting (Pn□□□)..... | 88 |
| 5.2.6 Numeric settings | 88 |
| 5.2.7 Selecting functions..... | 89 |
| 5.2.8 Operation of monitor display (Un□□□)..... | 89 |

| | | |
|--------|-----------------------------------------------------------------------|-----|
| 5.3 | Automatic detection of connected motor | 89 |
| 5.4 | Basic function settings..... | 89 |
| 5.4.1 | Power settings | 89 |
| 5.4.2 | Setting rotation direction of servo motor | 91 |
| 5.4.3 | Overtravel setting | 92 |
| 5.4.4 | Holding brake | 94 |
| 5.4.5 | Motor stopping methods for servo OFF and alarms..... | 97 |
| 5.4.6 | Operation for momentary power interruptions..... | 99 |
| 5.4.7 | Setting of motor overload detection value..... | 100 |
| 5.4.8 | Regenerative resistor capacity setting..... | 100 |
| 5.5 | Other input and output signals | 101 |
| 5.5.1 | Alarm output (ALM) signal | 101 |
| 5.5.2 | Warning output (/WARN) signal | 101 |
| 5.5.3 | Rotation detection output signal (/TGON) | 102 |
| 5.5.4 | Servo ready output (/S-RDY) signal | 102 |
| 5.6 | Electronic gear ratio..... | 102 |
| 5.7 | Profile position mode, PP | 103 |
| 5.7.1 | Control word in profile position mode (60400010h) | 104 |
| 5.7.2 | Status word in profile position mode (60410010h)..... | 104 |
| 5.7.3 | Related parameter of profile position mode | 105 |
| 5.7.4 | Simple tutorial for profile position mode | 106 |
| 5.8 | Profile velocity mode, PV | 107 |
| 5.8.1 | Profile velocity mode control word setting (60400010h) | 107 |
| 5.8.2 | Status word in profile position mode (60410010h) | 108 |
| 5.8.3 | Related parameter of profile velocity mode..... | 108 |
| 5.8.4 | Simple tutorial for profile velocity mode..... | 109 |
| 5.9 | Profile torque mode, PT | 110 |
| 5.9.1 | Setting of control word in profile torque mode (60400010h) | 110 |
| 5.9.2 | Status word in profile torque mode (60410010h) | 111 |
| 5.9.3 | Related parameter of profile torque mode..... | 111 |
| 5.9.4 | Related parameter of profile torque mode..... | 112 |
| 5.10 | Home mode, HM..... | 112 |
| 5.10.1 | Control Word in Home Mode (60400010h) | 113 |
| 5.10.2 | Status word in home mode (60410010h) | 114 |
| 5.10.3 | Related parameter of home mode | 114 |
| 5.10.4 | Simple tutorial for home mode | 115 |
| 5.10.5 | Home mode introduction..... | 115 |
| 5.10.6 | Instructions for using the homing persistent data memory switch | 141 |
| 5.11 | Cyclic synchronous position mode, CSP | 142 |
| 5.11.1 | Control word in cyclic synchronous position mode (60400010h) | 142 |
| 5.11.2 | Status word in cyclic synchronous position mode (60410010h) | 143 |
| 5.11.3 | Related dictionary objects in cyclic synchronous position mode..... | 143 |

| | | |
|---------------------------------------|-----------------------------------------------------------------------|------------|
| 5.11.4 | Simple tutorial for cyclic synchronous position mode | 144 |
| 5.11.5 | Positioning completion signal | 145 |
| 5.12 | Cyclic synchronous velocity mode, CSV | 146 |
| 5.12.1 | Control word in cyclic synchronous velocity mode (60400010h) | 146 |
| 5.12.2 | Status word in cyclic synchronous velocity mode(60410010h) | 147 |
| 5.12.3 | Related dictionary objects in cyclic synchronous velocity mode | 147 |
| 5.12.4 | Simple tutorial for cyclic synchronous velocity mode | 148 |
| 5.12.5 | Velocity reference filter | 148 |
| 5.13 | Cyclic synchronous torque mode, CST | 149 |
| 5.13.1 | Control word in cyclic synchronous torque mode (60400010h) | 149 |
| 5.13.2 | Status word in cyclic synchronous torque mode (60410010h) | 150 |
| 5.13.3 | Related dictionary objects in cyclic synchronous torque mode | 150 |
| 5.13.4 | Simple tutorial for cyclic synchronous position mode | 151 |
| 5.13.5 | Torque reference filter | 151 |
| 5.13.6 | Internal torque limit | 152 |
| 5.14 | Black box | 152 |
| 5.14.1 | Black box function configuration | 152 |
| 5.14.2 | Black box latching alarm code setting | 153 |
| 5.15 | Write parameters to EEPROM | 153 |
| Chapter 6 Application Function | | 154 |
| 6.1 | Absolute encoder | 156 |
| 6.1.1 | Battery replacement | 156 |
| 6.1.2 | Initialization of absolute encoder (when alarming) | 158 |
| 6.2 | Position comparison output function | 158 |
| 6.2.1 | Function description | 158 |
| 6.2.2 | Related objects | 159 |
| 6.2.3 | Function running | 160 |
| 6.3 | Gravity compensation function | 161 |
| 6.3.1 | Required parameters setting | 162 |
| 6.3.2 | Operating procedure for gravity compensation | 162 |
| 6.3.3 | Operation steps of the automatic update gravity compensation function | 162 |
| 6.4 | Forced DO function | 163 |
| 6.4.1 | Function description | 163 |
| 6.4.2 | Related objects | 163 |
| 6.4.3 | Instructions | 164 |
| 6.5 | Software position limit function | 164 |
| 6.5.1 | Function description | 164 |
| 6.5.2 | Related objects | 164 |
| 6.5.3 | Instructions | 165 |
| 6.6 | Modulus function | 166 |
| 6.7 | Touch probe function | 166 |

| | | |
|-------------------------|-------------------------------------------------------------------------|------------|
| 6.8 | Safety funtion | 168 |
| 6.8.1 | Hard wire base block (HWBB) function..... | 168 |
| 6.8.2 | Validating safety functions..... | 172 |
| 6.8.3 | Safety precautions when using the security function | 173 |
| 6.9 | Soft start | 173 |
| 6.10 | Smooth function | 174 |
| 6.11 | Alarm delay disabling function..... | 175 |
| Chapter 7 Tuning | | 176 |
| 7.1 | About tuning..... | 178 |
| 7.1.1 | Basic tuning method..... | 178 |
| 7.1.2 | Safety precautions at tuning | 179 |
| 7.2 | Tuning-less function | 181 |
| 7.2.1 | About the tuning-less function..... | 181 |
| 7.2.2 | Tuning-less value setting (Fn200)..... | 183 |
| 7.2.3 | Related parameters | 184 |
| 7.3 | Advanced auto-tuning 1 - by HCServoWorks internal position command..... | 184 |
| 7.3.1 | About auto-tuning 1 | 186 |
| 7.3.2 | Precautions for advanced auto-tuning 1 | 188 |
| 7.4 | Advanced auto-tuning 2 - via host controller position commands | 189 |
| 7.4.1 | About advanced auto-tuning 2 | 191 |
| 7.4.2 | Precautions for advanced auto-tuning 2 | 192 |
| 7.5 | One-parameter tuning..... | 193 |
| 7.5.1 | About one-parameter tuning..... | 193 |
| 7.5.2 | Operation steps for one-parameter tuning..... | 194 |
| 7.6 | Supplements for auto-tuning | 194 |
| 7.6.1 | Supplements for function | 194 |
| 7.6.2 | Related parameters | 196 |
| 7.7 | Adjust anti-resonance control function | 197 |
| 7.7.1 | About adjust anti-resonance control function..... | 197 |
| 7.7.2 | Operation steps of anti-resonance control function | 198 |
| 7.7.3 | Related parameters | 198 |
| 7.8 | Vibration suppression function | 198 |
| 7.8.1 | About the vibration suppression function..... | 198 |
| 7.8.2 | Precautions for vibration suppression function | 199 |
| 7.8.3 | Related parameters | 200 |
| 7.9 | Adjustment application function..... | 201 |
| 7.9.1 | Gain switching | 201 |
| 7.9.2 | Manual adjustment of friction compensation..... | 204 |
| 7.9.3 | Current control mode selection function | 205 |
| 7.9.4 | Current gain value setting function..... | 205 |

| | | |
|--------|-----------------------------------------------------------|-----|
| 7.9.5 | Speed detection method selection..... | 206 |
| 7.10 | Other adjustments functions | 206 |
| 7.10.1 | Feedforward..... | 206 |
| 7.10.2 | Setting mode switch (P control/PI control switching)..... | 206 |
| 7.10.3 | Torque command filter..... | 207 |

Chapter 8 Auxiliary Function **210**

| | | |
|------|---------------------------------------------------------------------------------------|-----|
| 8.1 | Auxiliary function list..... | 211 |
| 8.2 | Display of alarm record (Fn000)..... | 211 |
| 8.3 | Simple rigidity selection (Fn001)..... | 212 |
| 8.4 | JOG (Fn002)..... | 214 |
| 8.5 | Origin search (Fn003)..... | 214 |
| 8.6 | JOG program (Fn004)..... | 215 |
| 8.7 | Initialize parameters (Fn005)..... | 217 |
| 8.8 | Clear alarm history (Fn006)..... | 217 |
| 8.9 | Setting (Initialization) of the absolute encoder and encoder alarm reset (Fn008)..... | 218 |
| 8.10 | Auto tuning motor current detection signal offset (Fn00E)..... | 218 |
| 8.11 | Manually adjust motor current detection signal offset (Fn00F)..... | 219 |
| 8.12 | Writing prohibition setting (Fn010)..... | 219 |
| 8.13 | Display servomotor model (Fn011) | 220 |
| 8.14 | Display software version (Fn012)..... | 221 |
| 8.15 | Initialize vibration detection Level (Fn01B)..... | 221 |
| 8.16 | Software reset (Fn030) | 222 |
| 8.17 | Magnetic pole detection (Fn080)..... | 223 |
| 8.18 | Current JOG (Fn082)..... | 223 |
| 8.19 | Tuning-less level setting (Fn200)..... | 223 |
| 8.20 | Advanced auto tuning 1 (Fn201) | 224 |
| 8.21 | Advanced auto tuning 2 (Fn202) | 225 |
| 8.22 | One-parameter tuning (Fn203)..... | 226 |
| 8.23 | EasyFFT (Fn206) | 226 |

Chapter 9 Monitoring Display **228**

| | | |
|-------|------------------------------------------|-----|
| 9.1 | Monitoring display list..... | 229 |
| 9.2 | Monitor display operation example..... | 231 |
| 9.3 | How to read 32-bit decimal display | 231 |
| 9.4 | Input signal monitoring..... | 231 |
| 9.4.1 | Input signal status confirmation..... | 231 |

| | | |
|-----------------------------------------------|-----------------------------------------------------------------------|------------|
| 9.4.2 | Input signal display status determination method..... | 231 |
| 9.4.3 | Input signal display example..... | 232 |
| 9.5 | Output signal monitoring..... | 232 |
| 9.5.1 | Output signal status confirmation..... | 232 |
| 9.5.2 | Output signal display status determination method..... | 232 |
| 9.5.3 | Output signal display example..... | 233 |
| 9.6 | Monitoring display at Power-ON..... | 233 |
| Chapter 10 Alarm & Warning Display | | 234 |
| 10.1 | Alarm display..... | 235 |
| 10.1.1 | Alarm list..... | 235 |
| 10.1.2 | Causes and troubleshooting..... | 238 |
| 10.2 | Warning display..... | 252 |
| 10.2.1 | Warning list..... | 252 |
| 10.2.2 | Causes and troubleshooting..... | 254 |
| 10.3 | Causes and troubleshooting based on the operation and conditions..... | 260 |
| Chapter 11 Parameter List | | 266 |
| 11.1 | Auxiliary Function List..... | 267 |
| 11.2 | Parameter List..... | 268 |
| 11.3 | Parameter List for Object Dictionary 2000H..... | 306 |
| 11.4 | Object dictionary 6000H group common parameter list..... | 319 |
| 11.5 | Detailed description of 6000H object dictionary..... | 321 |
| Chapter 12 Application examples | | 341 |
| 12.1 | Connection example with HCFA Q series..... | 342 |
| 12.1.1 | Project creation..... | 342 |
| 12.1.2 | Host communication settings..... | 343 |
| 12.1.3 | Project editing..... | 344 |
| 12.1.4 | Trial operation..... | 349 |
| 12.2 | Connection example with Omron PLC NJ-501-1300..... | 350 |
| 12.2.1 | Connecting to Omron PLC..... | 350 |
| 12.2.2 | Adding HCFA servo drive..... | 352 |
| 12.2.3 | Setting EtherCAT related parameters..... | 353 |
| 12.2.4 | Trial operation..... | 358 |
| 12.3 | Connection example with Beckhoff PLC CX5130..... | 361 |
| 12.3.1 | Creating connection..... | 361 |
| 12.3.2 | Setting EtherCAT related parameters..... | 366 |

Chapter 1 730W Overview

| | | |
|-------|-----------------------------------------------------------|----|
| 1.1 | 730w series product features | 18 |
| 1.2 | 730W nameplate information | 18 |
| 1.3 | 730W drive naming rules..... | 19 |
| 1.4 | 730W servo drive component name | 20 |
| 1.4.1 | SIZE A AC220V (1P/3P) servo drive component diagram..... | 20 |
| 1.4.2 | SIZE A AC380V (3P+N) servo drive component diagram | 21 |
| 1.4.3 | SIZE B AC220V (1P/3P) servo drive component diagram | 22 |
| 1.4.4 | SIZE B AC380V (3P+N) servo drive component diagram | 23 |
| 1.5 | 730W model specifications..... | 24 |
| 1.5.1 | Servo model specifications..... | 24 |
| 1.6 | 730W servo drive ratings & specifications | 24 |
| 1.6.1 | AC220V (1P/3P) basic specifications | 24 |
| 1.6.2 | AC380V (3P+N) basic specifications | 25 |
| 1.6.3 | Environmental specifications..... | 25 |
| 1.6.4 | Technical specifications | 26 |
| 1.7 | 730W servo drive outline dimensions..... | 27 |
| 1.7.1 | 730W drive configuration table | 27 |
| 1.7.2 | 730W series drive installation dimensions | 27 |
| 1.7.3 | SIZE WA drive outline dimensions | 27 |
| 1.7.4 | SIZE WB drive outline dimensions..... | 27 |
| 1.8 | Drive installation | 28 |
| 1.8.1 | Installation within a control cabinet | 28 |
| 1.8.2 | Mechanical Installation Instructions | 28 |
| 1.9 | Maintenance and inspection | 29 |

1.1 730w series product features

The HCFA 730W Series High-Performance Servo System is equipped with a new control algorithm platform that provides exceptional drive performance. It also includes a comprehensive suite of bus and expansion functions to meet the diverse control needs of customers across various industries. This system features seven core strengths: higher dynamic response, improved positioning accuracy, enhanced reliability, faster speeds, user-friendliness, and tuning-free functionality. These strengths collectively support customers in their industrial upgrades, ultimately enhancing the value and efficiency of machine tools. Let us join hands with you to redefine your machine's performance.

For EtherCAT product applications, please refer to the 730W Series Servo System EtherCAT Bus Technical Manual.

1.2 730W nameplate information

Version information for the 730W series servo drives can be found on the label on the product side.





Figure 1-1 730W nameplate diagram

Table 1-1 Label description

| Item | Function description |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Product model | Displays the product model |
| Input/Output power | Displays the product's input/output power INPUT: Current phase, rated input voltage/current/frequency OUTPUT: Current phase, output voltage range, maximum output current, maximum output power |
| Serial number | Displays the product's serial number S/N: Internal serial number P/N: Internal serial number |

1.3 730W drive naming rules

SV730 W B A - CCCC - 0000 - 000



1.4 730W servo drive component name

1.4.1 SIZE A AC220V (1P/3P) servo drive component diagram




Figure 1-2 SIZE A AC220V(1P/3P) servo drive component diagram

1.4.2 SIZE A AC380V (3P+N) servo drive component diagram




Figure 1-3 SIZE A AC380V(3P+N) servo drive component diagram

1.4.3 SIZE B AC220V (1P/3P) servo drive component diagram




Figure 1-4 SIZE B AC220V(1P/3P) servo drive component diagram

1.4.4 SIZE B AC380V (3P+N) servo drive component diagram




Figure 1-5 SIZE B AC380V(3P+N) servo drive component diagram

1.5 730W model specifications

1.5.1 Servo model specifications

| Axis A | | Axis B | | Axis C | | Axis D | | Drive power supply | Control power supply | Communication method | Model |
|------------|-------------|------------|-------------|------------|-------------|------------|-------------|--------------------|----------------------------------|----------------------|---------------|
| Power (kW) | Current (A) | Power (kW) | Current (A) | Power (kW) | Current (A) | Power (kW) | Current (A) | | | | |
| 0.4 | 2.8 | 0.4 | 2.8 | 0.4 | 2.8 | 0.4 | 2.8 | AC220V 1P/3P | AC220V | EtherCAT | SV730WBA-CCCC |
| 0.4 | 2.8 | 0.4 | 2.8 | 0.4 | 2.8 | 0.4 | 2.8 | AC380V 3P+N | Common main circuit power supply | EtherCAT | SV730WBN-CCCC |
| 1 | 7.6 | 1 | 7.6 | 1 | 7.6 | 1 | 7.6 | AC220V 1P/3P | AC220V | EtherCAT | SV730WBA-GGGG |
| 1 | 7.6 | 1 | 7.6 | 1 | 7.6 | 1 | 7.6 | AC380V 3P+N | Common main circuit power supply | EtherCAT | SV730WBN-GGGG |

1.6 730W servo drive ratings & specifications

The servo drive's ratings and specifications are shown below.

1.6.1 AC220V (1P/3P) basic specifications

| Item | | Specification | |
|---------------------------------------------------------|-------------------------------------------------|------------------------------------------------|------|
| SV730W*A-**** | | C | G |
| Maximum applicable motor capacity (kW) | | 1.6 | 4 |
| Number of axes | | 4 | 4 |
| Single-axis power (kW) | | 0.4 | 1 |
| Single-axis continuous output current (Arms) | | 2.8 | 7.6 |
| Single-axis instantaneous maximum output current (Arms) | | 9.3 | 17 |
| Main circuit | Power supply voltage (Vrms) | Single-phase/Three-phase AC200 ~ 240V, 50/60Hz | |
| | Current (Arms) | 7.6 | 19.2 |
| Control power supply | | Single-phase AC200 ~ 240V, 50/60Hz | |
| Power loss | Main circuit power loss (W) | 80 | 195 |
| | Control circuit power loss (W) | 15 | 17 |
| | Built-in regenerative resistor power loss (W) | — | — |
| | Total power loss (W) | 95 | 212 |
| Regenerative resistor | Built-in resistor | Resistance value (Ω) | — |
| | | Capacity (W) | — |
| | Minimum allowable external resistance value (Ω) | 12 | 12 |
| Overvoltage category | | III | |

1.6.2 AC380V (3P+N) basic specifications

| Item | | Specification | |
|---------------------------------------------------------|-------------------------------------------------|---------------------------------------------|------|
| SV730W*N-**** | | C | G |
| Maximum applicable motor capacity (kW) | | 1.6 | 4 |
| Number of axes | | 4 | 4 |
| Single-axis power (kW) | | 0.4 | 1 |
| Single-axis continuous output current (Arms) | | 2.8 | 7.6 |
| Single-axis instantaneous maximum output current (Arms) | | 9.3 | 17 |
| Main circuit | Power supply voltage (Vrms) | Three-phase, four-wire AC 330-440V, 50/60Hz | |
| | Current (Arms) | 9.3 | 21.9 |
| Control power supply | | Common DC busbar | |
| Power loss | Main circuit power loss (W) | 80 | 195 |
| | Control circuit power loss (W) | 15 | 17 |
| | Built-in regenerative resistor power loss (W) | — | — |
| | Total power loss (W) | 95 | 212 |
| Regenerative resistor | Built-in resistor | Resistance value (Ω) | — |
| | | Capacity (W) | — |
| | Minimum allowable external resistance value (Ω) | 12 | 12 |
| Overvoltage category | | III | |

1.6.3 Environmental specifications

| Item | Specification |
|-----------------------------|-------------------------------------------------------------------------------------------------------------|
| Ambient temperature | 0 ~ +55°C (for temperature above 45°C , derate by 10% for every 5 degrees increase in ambient temperature) |
| Storage temperature | -20 to 85° C (Maximum rated temperature: 80° C for 72 hours, non-condensing) |
| Ambient humidity | 20% to 85% RH, non-condensing |
| Storage humidity | 20% to 85% RH, non-condensing |
| Vibration | 5.88 m/s ² (0.6G) max., 10-60Hz (avoid operation at resonant points) |
| Shock resistance | Acceleration: 19.8 m/s ² max. (X, Y, Z axes) |
| Protection class | IP20 |
| Cleanliness | • Free from corrosive and flammable gases |
| | • Free from splashing water, oil, or chemicals |
| Altitude | <1000m (for altitudes between 1000m and 2000m, use with derated specifications) |
| Pollution degree (PD) | 2 |
| Overvoltage category | III |
| Fault short-circuit current | 5Ka |
| Other | No electrostatic interference, strong electric field, strong magnetic field, radiation, etc. |

1.6.4 Technical specifications


| Item | | | Specification | |
|------------------------------------------------|-------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------|
| Speed/ Torque control mode | Perfor- mance | Speed varia- tion rate | Load variation rate | 0~100% load: ≤ 0.5% (at rated speed) |
| | | | Voltage variation rate | Rated voltage ±10%: 0.5% (at rated speed) |
| | | | Temperature variation rate | 25±25°C : ≤ 0.5% (at rated speed) |
| | Speed control range | | 1:10000 (lower limit: motor does not stop under rated torque load) | |
| | Torque control accuracy | | ±1% | |
| | Input signal | Speed com- mand input | EtherCAT communi- cation mode | CSV/PV mode |
| Torque com- mand input | | EtherCAT communi- cation mode | CST/PT mode | |
| Position control mode | Perfor- mance | Feedforward compensation | 0~100.0% (setting resolution: 0.1%) | |
| | | Timing window | 1~65535 encoder units | |
| | Input signal | EtherCAT communication mode | CSP mode/PP mode/HM mode | |
| Input/ Output signal | Sequential control input signal | Input signal function selection | 21-channel DI DI1~DI21: General-purpose DI (100µs input delay on rising edge (signal transition from high to low at 24V input); 50µs input delay on falling edge (signal transition from low to high at 24V input); voltage: 21.6V~26.4V) DI functions are as follows: positive overtravel switch (POT), negative overtravel switch (NOT), home switch (DEC), probe 0 (LATCH_0), probe 1 (LATCH_1), emergency stop (FSTP), positive torque limit (P_CL), negative torque limit (N_CL), servo enable (S-ON), alarm reset signal (ALMCLR), power down signal (PWR-DOWN), user-defined signals 1~7 (USER1~7) | |
| | Sequential control output signal | Output signal function selection | 8-channel DO DO load capacity: 50mA; voltage range: 5V~30V DO functions are as follows: positioning complete (COIN), speed coincidence (V_CMP), motor running (TGON), servo ready (S_RDY), torque limit (CLT), velocity limit (VLT), brake (BK), warning (WARN), position proximity (NEAR), position comparison outputs 1~4 (POSCMP1~4), alarm signal (ALM), userdefined signals 1~7 (USER1~7) | |
| Built-in function | Overtravel (OT) limit function | | Immediate stop when P-OT/N-OT actuates. | |
| | Electronic gear ratio | | $0.001 \leq B/A \leq \text{Encoder resolution} * 0.4$ | |
| | Protection function | | Overcurrent, overvoltage, undervoltage, overload, main circuit detection anomaly, heatsink overheating, power phase loss, overspeed, encoder anomaly, CPU anomaly, parameter anomaly, others | |
| | Safety function | Safety function type | STO | |
| | | Applicable standard | IEC 61800-5-2:2016 | |
| | LED display function | | Main power CHARGE status displayed on 6-digit LED | |
| | Vibration suppression function | | 5 notch filters (50Hz ~ 5000Hz), including 2 adaptive ones | |
| | Ease-of-use function | | One-touch parameter adjustment, adaptive parameter adjustment, speed observer, model tracking | |
| | Commu- nication function | Background debugging | | Type_C |
| | | Multi-station communication protocol | | EtherCAT |
| Number of axes for multi-station communication | | Maximum number of slave stations: 65535 | | |
| Axis address setting | | No physical knobs; configured via software (0 ~ 65535) | | |
| Function | | Status display, user parameter setting, monitoring display, alarm tracing display, JOG operation, auto-tuning, communication & motion control command input | | |
| Other | | Gain adjustment, alarm recording, JOG operation | | |

1.7 730W servo drive outline dimensions

1.7.1 730W drive configuration table


| Servo drive | SIZE WA | SIZE WB |
|--------------|---------------|---------------|
| AC220V 1P/3P | SV730WBA-CCCC | SV730WBA-GGGG |
| AC380V 3P+N | SV730WBN-CCCC | SV730WBN-GGGG |

1.7.2 730W series drive installation dimensions




| Size | L1(mm) | L2(mm) | L3(mm) | L4(mm) | H1(mm) | H2(mm) | H3(mm) | Hole diameter (φ) | Screw hole | Locking torque (Nm) | Weight (kg) |
|---------|--------|--------|--------|--------|--------|--------|--------|-------------------|------------|---------------------|-------------|
| SIZE WA | 65 | 170 | 26.3 | 52.5 | 183 | 190 | 182.3 | 5.5 | 3-M5 | 3.5N·M | 0.76 |
| SIZE WB | 100 | 170 | 43.3 | 86.5 | 183 | 190 | 182.3 | 5.5 | 3-M5 | 3.5N·M | 1.01 |

1.7.3 SIZE WA drive outline dimensions



1.7.4 SIZE WB drive outline dimensions



1.8 Drive installation

1.8.1 Installation within a control cabinet

Precautions

- Do not block the servo drive's air inlets/outlets or place it upside down; otherwise, malfunctions may occur.
- To ensure the cooling fans have low air resistance for effective heat dissipation, follow the recommended installation spacing when installing one or more drives.
- Avoid vertical stacking, as the heat generated by the lower drive during operation rises, which can cause an unnecessary temperature increase in the upper drive.




Figure 1-6 Schematic diagram of 730w servo drive installation within a control cabinet

1.8.2 Mechanical Installation Instructions




Figure 1-7 730W servo unit mechanical installation diagram

Note: Use M5 * 20 screws to mount the drive to the cabinet backplate. Tightening torque: 3.5 Nm.

1.9 Maintenance and inspection

The following describes the maintenance and inspection of servo drives.


Inspection of servo motors

Servo drives do not require daily inspections, but the following items must be inspected at least once a year.

| Inspection item | Inspection interval | Inspection key point | Troubleshooting |
|-----------------------|----------------------|-----------------------------------------------------------------|-------------------------------------------|
| Appearance inspection | At least once a year | No garbage, dust, oil stains, etc. | Wipe with a cloth or blow with an air gun |
| Screw looseness check | | No looseness in terminal block, connector mounting screws, etc. | Tighten screws further |

Chapter 2 Wiring and Connection

| | | |
|-------|----------------------------------------------------------------------------|----|
| 2.1 | Precautions..... | 32 |
| 2.1.1 | Symbols..... | 32 |
| 2.1.2 | General wiring precautions | 32 |
| 2.2 | SIZE A AC220V (1P/3P) drive terminal definition diagram..... | 34 |
| 2.3 | SIZE A AC380V (3P+N) drive terminal definition diagram..... | 36 |
| 2.4 | SIZE B AC220V (1P/3P) drive terminal definition diagram..... | 38 |
| 2.5 | SIZE B AC380V (3P+N) servo unit components introduction diagram..... | 40 |
| 2.6 | Main circuit wiring..... | 41 |
| 2.6.1 | Example of main circuit wiring for standard AC220V(3P) power input | 42 |
| 2.6.2 | Example of main circuit wiring for standard AC380V(3P+N) power input | 43 |
| 2.6.3 | Servo drive of single-phase 220V power input | 44 |
| 2.6.4 | Servo unit of DC power input | 45 |
| 2.6.5 | Line breaker and fuse capacity | 51 |
| 2.7 | Wiring of regenerative resistor | 51 |
| 2.7.1 | AC 220V(1P/3P) regenerative resistor basic specifications | 52 |
| 2.7.2 | AC380V(3P+N) regenerative resistor basic specifications | 52 |
| 2.8 | Input and output signals (CN1) | 52 |
| 2.8.1 | Pin arrangement of I/O signal (CN1) connector..... | 53 |
| 2.8.2 | Name and function of input signal (CN1) | 53 |
| 2.8.3 | Allocation of input signal | 54 |
| 2.8.4 | Input circuit | 55 |
| 2.8.5 | Name and function of output signal (CN1)..... | 56 |
| 2.8.6 | Allocation of output signal..... | 56 |
| 2.8.7 | Output circuit..... | 57 |
| 2.8.8 | Brake signal..... | 58 |






| | | |
|-------------|---------------------------------------------------------------|-----------|
| 2.9 | Encoder signal (CN2) | 59 |
| 2.9.1 | Name and function of encoder signal (CN2) | 59 |
| 2.9.2 | Wiring the servo drive to encoder..... | 60 |
| 2.10 | Safety function signals STO (CN3) | 61 |
| 2.10.1 | Names and functions of the safety function signal (CN3) | 61 |
| 2.10.2 | Safety input circuit..... | 61 |
| 2.10.3 | Example of Safety Terminal Default Wiring | 62 |
| 2.11 | Communication connector (CN6) | 62 |
| 2.12 | Brake input connection (CN10) | 63 |
| 2.12.1 | Brake wiring..... | 63 |
| 2.13 | Noise and harmonic countermeasures | 65 |
| 2.13.1 | Countermeasures against noise | 65 |
| 2.13.2 | Noise filter wiring and connection precautions | 67 |
| 2.13.3 | Connection of reactor for harmonic suppression | 69 |

2.1 Precautions

2.1.1 Symbols

Table 2-1 Precaution Symbols

| Name | Function |
|-------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| DANGER  | Indicates hazards that may cause death or serious injury |
| CAUTION  | Indicates precautions that may cause injury or property damage |
|  | Indicates the mandatory content that must be implemented |

2.1.2 General wiring precautions



Points

Please use a circuit breaker or fuse for wiring to protect the main circuit.

- The servo unit is directly connected to the industrial frequency power supply without using a transformer for insulation. In order to prevent accidents of mixed contact between the servo system and the outside, be sure to use a circuit breaker or fuse for wiring.
- Please install an earth leakage circuit breaker. The servo unit does not have a built-in ground short-circuit protection circuit. In order to build a safer system, install an earth leakage circuit breaker for both overload and short circuit protection, or combine it with a circuit breaker for wiring and install an earth leakage circuit breaker for ground short circuit protection.
- Please avoid turning ON/OFF power frequently
- Frequently turn ON/OFF power will cause elements in servo drive to deteriorate, so do not use it for applications that require to turn ON/OFF power frequently.
- After you have started actual operation(normal operation), allow at least one hour between turning the power supply ON and OFF.

To ensure safe, stable application of the servo system, please observe the following precautions when wiring.

I. Use the cables specified by HCFA. Design and arrange the system so that each cable is as short as possible.

- Use twisted-pair wires or multi-core twisted-pair shielded wires for I/O signal cables and encoder cables.
- The wiring length of the input and output signal cables is up to 3m, and the length of the main circuit cable of the servo motor and the encoder cable is up to 10m each.

II. Observe the following precautions when wiring the ground cable.

- Use a ground cable as thick as possible(2.0 mm² or more).
- Please ground 220V servo unit to a resistance of 100Ω or less, and ground 380V servo unit with a resistance of 10Ω or less.
- Be sure to ground at one point only.
- Ground the servo motor directly if the servo motor is insulated from the machine.

III. The signal cable conductors are as thin as 0.2 mm or 0.3 mm. Do not subject them to excessive bending stress or tension.

Wiring points:

※ The control circuit power supply and the main circuit power supply should be wired from the same AC220V main power supply.

- ※ When the user I/O cable is longer than 50cm, please use twisted pair with shielded wire.
- ※ Encoder cable length is 20m or less.

Note: 1. There is high voltage in the circuit in the solid line. Be careful when wiring and handling.

2. The dotted part of the wiring diagram indicates a non-hazardous voltage circuit.

This section also explains the general precautions when wiring and the precautions in special use environments.

Table 2-2 Precautions for Special Use Environment

| Item | Description |
|------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| External machine configuration | In order to comply with European EC standards, after selecting a machine with applicable specifications, please set it according to the system diagram. |
| Environment | The driver is installed in an environment of pollution degree 2 or pollution degree 1 specified in IEC60664-1. |
| Power supply 1 : AC200 ~ 240V main circuit and control circuit power supply) | This product is used in an overvoltage category II power supply environment in accordance with IEC60664-1. |
| Power supply 2: DC24V · I/O power · Release the power supply of the motor brake | The DC24V external power supply must meet the following conditions: Use SELV power supply (※), the capacity is below 150W (this is the condition when corresponding to European CE); Safe low voltage/non-hazardous voltage, hazardous voltage require reinforced insulation (Attention). |
| Wiring | Motor power cables, AC220V input cables, FG cables, and main circuit power distribution cables composed of multiple axes: Please use AWG18 / 600V withstand voltage wires below 750W , and use AWG14 / 600V withstand voltage wires above 1kW . |
| Leakage circuit breakers | To protect the power line, the circuit is cut off when an overcurrent flows. Between the power supply and the noise filter, be sure to use an IEC standard and UL- approved circuit breaker. To comply with EMC standards, please use a standard circuit brake with leakage detection function. |
| Noise filter | Prevent noise interference from power lines (Use standard noise filtering for EMC compliance). |
| Electromagnetic contactor | Switch (ON/OFF) the main power supply (please use it with a surge protector connected). |
| Surge absorber | To comply with EMC regulations, please use standard surge absorbers. |
| Signal Line Noise Filter / Ferrite Core | To comply with EMC standards, please use standard noise filters. |
| Regenerative resistor | If the smoothing capacitor inside the power unit cannot sufficiently absorb and process regenerative power, it is necessary to install a regenerative resistor outside. For reference, check the setting panel for regenerative discharge status, and use a regenerative resistor when regenerative voltage warning occurs. Regenerative resistor reference specification: Please refer to external braking resistor selection. Use the built-in thermostat, and set the overheat protection circuit. |
| Grounding | Our products have protection settings because they are suitable for Class 1 equipment. The grounding of our products requires protective ground terminal, and is carried out through a protective box and an electrical box that have implemented EMC countermeasures. The protective ground terminal is indicated by the standard FG mark. |

Note: ※SELV: safety extra low voltage.

2.2 SIZE A AC220V (1P/3P) drive terminal definition diagram





Figure 2-1 SIZE A AC220V (1P/3P) Drive Terminal Wiring Diagram

Table 2-3 Terminal Symbols and Terminal Names for SIZE A AC220V (1P/3P)

| Terminal name | Terminal symbols | Signal name/ pin number | Content |
|-----------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Regenerative resistor | B1/B2 | B1 | External regenerative resistor interface , main circuit bus+ |
| | | B2 | External regenerative resistor interface |
| Main circuit bus | N- | N- | Main circuit bus- |
| AC main circuit power input | L1/L2/L3 | L1 | AC220V(1P/3P) model: AC200~240V (50/60Hz) Note: Please confirm the drive power specification when wiring |
| | | L2 | |
| | | L3 | |
| AC control power input | LC1/ LC2 | LC1 | AC220V(1P) model: AC200~240V (50/60Hz) Note: Please confirm the drive power specification when wiring |
| | | LC2 | |
| Motor power output | U/V/W | U | Motor power U phase output |
| | | V | Motor power V-phase output |
| | | W | Motor power W phase output |
| Encoder | CN2 | 1 | Encoder power supply 5V output |
| | | 2 | Signal Ground |
| | | 3 | — |
| | | 4 | — |
| | | 5 | Encoder signal: serial data+ |
| | | 6 | Encoder signal: serial data- |
| | | Shell | The shield wire is connected to the connector shell |
| Communication | CN6A/CN6B | - | EtherCAT communication interface |
| User I/O | CN1 | Refer to 2.6 Input and output signal (CN1) wiring details | |
| Brake | CN10 | 1 | Brake + 24V power supply |
| | | 2 | Brake 0V |
| | | 3 | BKA+ |
| | | 4 | BKA- |
| | | 5 | BKB+ |
| | | 6 | BKB- |
| Ground terminal |  | Connect to the ground terminal of the power supply and the servo motor for grounding. | |

Note: Do not short-circuit B1/B2, the servo unit may be damaged.

2.3 SIZE A AC380V (3P+N) drive terminal definition diagram





Figure 2-2 SIZE A AC380V (3P+N) Drive Terminal Wiring Diagram

Table 2-4 Terminal Symbols and Terminal Names for SIZE A AC380V (3P+N)

| Terminal name | Terminal symbols | Signal name/ pin number | Content |
|-----------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| Regenerative resistor | B1/B2 | B1 | External regenerative resistor interface , main circuit bus+ |
| | | B2 | External regenerative resistor interface |
| Main circuit bus | N- | N- | Main circuit bus- |
| AC main circuit power input | L1/L2/L3/LN | L1 | AC380V(3P+N) model: AC330~440V (50/60Hz) Note: Please confirm the drive power specification when wiring |
| | | L2 | |
| | | L3 | |
| | | LN | |
| Motor power output | U/V/W | U | Motor power U phase output |
| | | V | Motor power V-phase output |
| | | W | Motor power W phase output |
| Encoder | CN2 | 1 | Encoder power supply 5V output |
| | | 2 | Signal Ground |
| | | 3 | — |
| | | 4 | — |
| | | 5 | Encoder signal: serial data+ |
| | | 6 | Encoder signal: serial data- |
| | | Shell | The shield wire is connected to the connector shell |
| Communication | CN6A/CN6B | - | EtherCAT communication interface |
| User I/O | CN1 | Refer to 2.6 Input and output signal (CN1) wiring details | |
| Brake | CN10 | 1 | Brake + 24V power supply |
| | | 2 | Brake 0V |
| | | 3 | BKA+ |
| | | 4 | BKA- |
| | | 5 | BKB+ |
| | | 6 | BKB- |
| Ground terminal |  | Connect to the ground terminal of the power supply and the servo motor for grounding. | |

Note: Do not short-circuit B1/B2, the servo unit may be damaged.

2.4 SIZE B AC220V (1P/3P) drive terminal definition diagram





Figure 2-3 SIZE B AC220V (1P/3P) Drive Terminal Wiring Diagram

Table 2-5 Terminal Symbols and Terminal Names for SIZE B AC220V (1P/3P)

| Terminal name | Terminal symbols | Signal name/ pin number | Content |
|-----------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------|
| Regenerative resistor | B1/B2/B3 | B1 | External regenerative resistor interface , main circuit bus+ |
| | | B2 | External regenerative resistor interface |
| | | B3 | Built-in regenerative resistor interface |
| Main circuit bus | N-/P | N- | Main circuit bus - |
| | | P | Main circuit bus+ |
| AC main circuit power input | L1/L2/L3 | L1 | AC220V(1P/3P) model: AC200~240V (50/60Hz) Note: Please confirm the drive power specification when wiring |
| | | L2 | |
| | | L3 | |
| AC control power input | LC1/ LC2 | LC1 | AC220V(1P) model: AC200~240V (50/60Hz) Note: Please confirm the drive power specification when wiring |
| | | LC2 | |
| Motor power output | U/V/W | U | Motor power U phase output |
| | | V | Motor power V-phase output |
| | | W | Motor power W phase output |
| Encoder | CN2 | VCC | Encoder power supply 5V output |
| | | GND | Signal Ground |
| | | — | — |
| | | — | — |
| | | D+ | Encoder signal: serial data+ |
| | | D- | Encoder signal: serial data- |
| Communication | CN6A/CN6B | - | EtherCAT communication interface |
| User I/O | CN1 | Refer to 2.6 Input and output signal (CN1) wiring details | |
| Brake | CN10 | 1 | Brake + 24V power supply |
| | | 2 | Brake 0V |
| | | 3 | BKA+ |
| | | 4 | BKA- |
| | | 5 | BKB+ |
| | | 6 | BKB- |
| Ground terminal |  | Connect to the ground terminal of the power supply and the servo motor for grounding. | |

Note: Do not short-circuit B1/B2, the servo unit may be damaged.

2.5 SIZE B AC380V (3P+N) servo unit components introduction diagram





Figure 2-4 SIZE B AC380V (3P+N) Drive Terminal Wiring Diagram

Table 2-6 Terminal Symbols and Terminal Names for SIZE A AC380V (3P+N)

| Terminal name | Terminal symbols | Signal name/ pin number | Content |
|-----------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| Regenerative resistor | B1/B2/B3 | B1 | External regenerative resistor interface , main circuit bus+ |
| | | B2 | External regenerative resistor interface |
| | | B3 | Built-in regenerative resistor interface |
| Main circuit bus | N-/P | N- | Main circuit bus - |
| | | P | Main circuit bus+ |
| AC main circuit power input | L1/L2/L3/LN | L1 | AC380V(3P+N) model: AC330~440V (50/60Hz) Note: Please confirm the drive power specification when wiring |
| | | L2 | |
| | | L3 | |
| | | LN | |
| Motor power output | U/V/W | U | Motor power U phase output |
| | | V | Motor power V-phase output |
| | | W | Motor power W phase output |
| Encoder | CN2 | VCC | Encoder power supply 5V output |
| | | GND | Signal Ground |
| | | — | — |
| | | — | — |
| | | D+ | Encoder signal: serial data+ |
| | | D- | Encoder signal: serial data- |
| Communication | CN6A/CN6B | - | EtherCAT communication interface |
| | | | |
| User I/O | CN1 | Refer to 2.6 Input and output signal (CN1) wiring details | |
| Brake | CN10 | 1 | Brake + 24V power supply |
| | | 2 | Brake 0V |
| | | 3 | BKA+ |
| | | 4 | BKA- |
| | | 5 | BKB+ |
| | | 6 | BKB- |
| Ground terminal |  | Connect to the ground terminal of the power supply and the servo motor for grounding. | |

Note: Do not short-circuit B1/B2, the servo unit may be damaged.

2.6 Main circuit wiring

When turning on the power, please consider the following points.

- Please ensure the following design when the power is turned on: After outputting the signal of "servo alarm", turn OFF the main circuit power supply.
- When the control power supply is turned on, the ALM signal is output (relay: OFF) for up to 5.0 seconds. Please take it into consideration when designing the power-on sequence, and turn off the main circuit power connected to the servo unit through the relay.




Figure 2-5 Servo Alarm Signal Timing Chart


- The power rating of the components must match the input power supply.

Points

- Turn ON the control power supply before the main circuit power supply or turn ON the control power supply and the main circuit power supply at the same time. Turn OFF the main circuit power supply first, and then turn OFF the control power supply.

2.6.1 Example of main circuit wiring for standard AC220V(3P) power input

Model name: SV730WBA-CCCC, SV730WBA-GGGG



- | | |
|---------------------------------------------|----------------------|
| 1QF: Circuit breaker for wiring | 1RY: Relay |
| FIL: Noise filter | 1PL: Indicator |
| 1KM: Magnetic contactor(Main circuit power) | 1SUS: Surge absorber |
| 2KM: Magnetic contactor(Control power) | 2SUS: Surge absorber |
| Ω: Brake resistor | 1D: Flywheel diode |

Figure 2-6 AC220V 3P Wiring

2.6.2 Example of main circuit wiring for standard AC380V(3P+N) power input

Model Name: SV730WBN-CCCC, SV730WBN-GGGG




Figure 2-7 AC380V 3P+N Wiring

2.6.3 Servo drive of single-phase 220V power input

The 730W series 220V power supply input type servo unit has a three-phase power input specification, and there are also models that can be used under a single-phase 220V power supply. When using the main circuit power supply of the above servo unit under the single-phase 220V power supply, please change it to Pn00B.2=1 (support single-phase power input).

I. Parameter setting for single-phase power input

Table 2-7 Parameter Setting for Single-phase Power Input

| Parameter | Meaning | When enabled | Classification |
|-----------|-------------------------------|---------------|----------------|
| Pn00B | n. □ 0 □ □ [Default value] | After restart | Setup |
| | n. □ 1 □ □ | | |

Please observe the following precautions when using.

DANGER

- When using a servo unit that supports single-phase 220V power input, if you directly input single-phase power without changing the parameter setting to Pn00B.2=1 (supporting single-phase power input), a power phase loss alarm (A.F10) will be detected.
- Single-phase power input is not supported, except for servo units that are suitable for single-phase 220V power input. Otherwise power phase loss alarm (A.F10) will be detected.
- When using single-phase 220V power input, the torque/speed characteristics of the servo motor sometimes cannot meet the characteristics of three-phase power input.

II. Main circuit power input

When the power supply is single-phase 220V, please connect it to the L1 and L2 terminals. The power specifications other than the main circuit power input are the same as three-phase power input.


Table 2-8 Main Circuit Power Input Terminal

| Terminal | Name | Function, rating |
|----------|-----------------------------------|------------------------------------|
| L1, L2 | Main circuit power input terminal | Single-phase 200V ~ 240V (50/60Hz) |
| L3 | — | N/A |

Note: Do not connect to L3 terminal.

III. Wiring example for single-phase 220V(1P) power input

Model name: SV730WBA-CCCC, SV730WBA-GGGG



- 1QF: Circuit breaker for wiring
- FIL: Noise filter
- 1KM: Magnetic contactor(Main circuit power)
- 2KM: Magnetic contactor(Control power)
- Ω: Brake resistor
- 1RY: Relay
- 1PL: Indicator
- 1SUP: Surge absorber
- 2SUP: Surge absorber
- 1D: Flywheel diode

Figure 2-8 Signal-phase 220V Wiring

2.6.4 Servo unit of DC power input

I. Parameter setting for DC power input

Before using the servo unit with DC power input, be sure to change the parameter to Pn001.2 =1 (support DC power input)

Table 2-9 DC Power Supply Settings

| Parameter | Meaning | When enabled | Classification |
|-----------|-------------------------------|---------------|----------------|
| Pn001 | n. □ 0 □ □ [Default value] | After restart | Setup |
| | n. □ 1 □ □ | | |

Please observe the following precautions when using.

DANGER

- Both 220V and 380V servo unit support AC/DC power input. Please ensure to set Pn001.2=1(Support DC power input) before inputting the power supply.
- Otherwise it will cause the elements in servo unit to burn out and result in fire or device damage.
- Even after you turn OFF the power supply, a high residual voltage may still remain in the servo unit. To prevent electric shock, do not touch the power supply terminals after you turn OFF the power. Make sure to discharge after the power is cut off.
- Please install a fuse on the power wiring when DC power is input.
- The servo motor returns regenerative energy to the power supply. If you use a servo unit with a DC power supply input, regenerative energy is not processed. Process the regenerative energy at the power supply.
- If you use a DC power supply input, externally connect an inrush current limiting circuit. Otherwise will cause damage to the servo unit.

II. Main circuit and control power input

AC220V 730W series

Model name: SV730WBA-CCCC

Table 2-10 DC310V SV730WBA-CCCC Power Input Terminals

| Terminal | Name | Specification |
|----------|-------------------------------------|---------------|
| B1 | Main circuit positive side terminal | DC280 ~ 360V |
| N- | Main circuit negative side terminal | 0V |
| LC1, LC2 | Control power terminal | AC220V |

Model name: SV730WBA-GGGG

Table 2-11 DC310V SV730WBA-GGGG Power Input Terminals

| Terminal | Name | Specification |
|----------|-------------------------------------|---------------|
| P | Main circuit positive side terminal | DC280 ~ 360V |
| N- | Main circuit negative side terminal | 0V |
| LC1, LC2 | Control power terminal | AC220V |

AC380V(3P+N) 730W series

Model name: SV730WBN-CCCC

Table 2-12 DC310V SV730WBN-CCCC Power Input Terminals

| Terminal | Name | Specification |
|----------|-------------------------------------|---------------|
| B1 | Main circuit positive side terminal | DC280 ~ 360V |
| N- | Main circuit negative side terminal | 0V |

Model name: SV730WBN-GGGG


Table 2-13 DC310V SV730WBN-GGGG Power Input Terminals

| Terminal | Name | Specification |
|----------|-------------------------------------|---------------|
| P | Main circuit positive side terminal | DC280 ~ 360V |
| N- | Main circuit negative side terminal | 0V |

III. Wiring example for DC power input

Wiring for SV730WBA-□□□□ DC310V power input type servo unit


Model name: SV730WBA-CCCC



- | | |
|---------------------------------------------|----------------------|
| 1QF: Circuit breaker for wiring | 1RY: Relay |
| FIL: Noise filter | 1PL: Indicator |
| 1KM: Magnetic contactor(Main circuit power) | 1SUP: Surge absorber |
| 2KM: Magnetic contactor(Control power) | 2SUP: Surge absorber |
| Ω: Brake resistor | 1D: Flywheel diode |
| 1FU:Fuse | |

Figure 2-9 DC310V Input SV730WBA-CCCC Wiring

Model name: SV730WBA-GGGG



- | | |
|---------------------------------------------|----------------------|
| 1QF: Circuit breaker for wiring | 1RY: Relay |
| FIL: Noise filter | 1PL: Indicator |
| 1KM: Magnetic contactor(Main circuit power) | 1SUP: Surge absorber |
| 2KM: Magnetic contactor(Control power) | 2SUP: Surge absorber |
| Ω: Brake resistor | 1D: Flywheel diode |
| 1FU:Fuse | |

Figure 2-10 DC310V Input SV730WBA-GGGG Wiring

Note: The terminals are different according to the model of the servo unit. Please refer to the table in "(2) Main circuit, control power input".

Wiring for SV730WBN- □□□□ DC310V power input type servo unit

Model name: SV730WBN-CCCC




Figure 2-11 DC310V Input SV730WBN-CCCC Wiring

Model name: SV730WBN-GGGG




Figure 2-12 DC310V Input SV730WBN-GGGG Wiring

2.6.5 Line breaker and fuse capacity

Table 2-14 Circuit Breaker and Fuse Capacity Table for Servo Unit Wiring

| Main circuit power supply | Maximum applicable motor capacity (kW) | Servo Drive 730W | Power supply capacity for single servo unit (kVA) | Current capacity | | Impulse current | |
|---------------------------|----------------------------------------|------------------|---------------------------------------------------|-------------------|----------------------|-------------------|----------------------|
| | | | | Main circuit Arms | Control loop Arms | Main circuit Ap-p | Control loop Ap-p |
| AC220V 1P/3P | 1.6 | CCCC | 3.2 | 7.3 | 0.25 | 33 | 33 |
| | 4 | GGGG | 7.6 | 19.2 | 0.4 | 33 | 33 |
| AC380V 3P+N | 1.6 | CCCC | 3.2 | 7.3 | Same as main circuit | 33 | Same as main circuit |
| | 4 | GGGG | 8.5 | 21.9 | Same as main circuit | 33 | Same as main circuit |

Note: 1. In order to meet the low voltage standard, please be sure to connect a fuse on the input side for protection when a fault is caused by a short circuit. Please select the fuse or circuit breaker for the input side to meet the UL standard products. In addition, the current capacity and inrush current in the above table are net values. Please select a fuse and a circuit breaker for wiring that satisfy the following conditions for breaking characteristics.

2. Main circuit and control circuit: When the current value is 3 times the value in the above table, the circuit shall not be disconnected within 5s.

Table 2-15 Restrictions to Comply with UL Standard

| Servo Drive SV730WB□-□□□□ | Usage restrictions |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CCCC | Rated current value of circuit breaker for wiring: 40A or less. |
| GGGG | The rated current value of circuit breaker for wiring: 60A or less. The rated current value of fast-acting fuse and time-delay fuse: below 60A. The rated current value of the time-delay fuse: below 35A. |

2.7 Wiring of regenerative resistor

When the processing capacity of regenerative energy is insufficient, connect an external regenerative resistor according to the following method, and set the regenerative resistor capacity (Pn600) for details.

Note: Please connect the regenerative resistor unit correctly. Do not short-circuit B1/B2. Doing so may result in damage to the regenerative resistor or the servo unit and cause fire.

Generally, directly connect regenerative resistor between B1/B2 terminals. After connecting, please set the regenerative resistor capacity.

The unit with the model HN -Y7 □□ 040A-S does not have a built-in regenerative resistor. If the processing capacity of regenerative energy is insufficient, an external regenerative resistor must be connected.




Figure 2-13 SIZE A Regenerative Resistor Wiring




Figure 2-14 SIZE B Regenerative Resistor Wiring (With B3)

2.7.1 AC 220V(1P/3P) regenerative resistor basic specifications

Table 2-16 AC 220V(1P/3P) regenerative resistor basic specifications

| Item | | Specification | |
|-----------------------|-------------------------------------------------|----------------------|----|
| Model SV730W*A-**** | | C | G |
| Regenerative resistor | Built-in resistor | Resistance value (Ω) | — |
| | | Capacity (W) | — |
| | External minimum allowable resistance value (Ω) | 12 | 12 |

2.7.2 AC380V(3P+N) regenerative resistor basic specifications

Table 2-17 AC380V(3P+N) regenerative resistor basic specifications

| Item | | Specification | |
|-----------------------|-------------------------------------------------|----------------------|----|
| Model SV730W*N-**** | | C | G |
| Regenerative resistor | Built-in resistor | Resistance value (Ω) | — |
| | | Capacity (W) | — |
| | External minimum allowable resistance value (Ω) | 12 | 12 |

Points

- If using an external regenerative resistor at a normal rated load factor, the temperature of the resistor reaches 200° C to 300° C, please be sure to derate before using it. For the load characteristics of the resistor, please consult the manufacturer
- To ensure safety, recommend to use external regenerative resistor with temperature-controlled switch.

2.8 Input and output signals (CN1)




Figure 2-15 CN1 External View

2.8.1 Pin arrangement of I/O signal (CN1) connector

Table 2-18 Pin arrangement of I/O signal (CN1) connector

| NO | Signal | Function | IO | NO | Signal | Function | IO |
|----|--------|------------------------------------|----|----|--------|------------------------------------|----|
| 1 | COM- | Output common 1 | P | 2 | COM+ | Input common 1 | P |
| 3 | DO8 | D-axis alarm signal | O | 4 | DO7 | D-axis servo ready | O |
| 5 | DO6 | C-axis alarm signal | O | 6 | DO5 | C-axis servo ready | O |
| 7 | DO4 | B-axis alarm signal | O | 8 | DO3 | B-axis servo ready | O |
| 9 | DO2 | A-axis alarm signal | O | 10 | DO1 | A-axis servo ready | O |
| 11 | DI21 | Emergency stop | I | 12 | DI20 | D-axis home switch | I |
| 13 | DI19 | D-axis probe1 | I | 14 | DI18 | D-axis probe 0 | I |
| 15 | DI17 | D-axis negative over travel switch | I | 16 | DI16 | D-axis positive over travel switch | I |
| 17 | COM- | Output common 1 | P | 18 | 24V | 24V input | — |
| 19 | DI15 | C-axis home switch | I | 20 | DI14 | C-axis probe 1 | I |
| 21 | DI13 | C-axis probe 0 | I | 22 | DI12 | C-axis negative over travel switch | I |
| 23 | DI11 | C-axis positive over travel switch | I | 24 | DI10 | B-axis home switch | I |
| 25 | DI9 | B-axis probe 1 | I | 26 | DI8 | B-axis probe 0 | I |
| 27 | DI7 | B-axis negative over travel switch | I | 28 | DI6 | B-axis positive over travel switch | I |
| 29 | COM+ | Input common 1 | P | 30 | DI5 | A-axis home switch | I |
| 31 | DI4 | A-axis probe 1 | I | 32 | DI3 | A-axis probe 0 | I |
| 33 | DI2 | A-axis negative over travel switch | I | 34 | DI1 | A-axis positive over travel switch | I |

Note:

1. I/O pin functions are assignable.
2. When using the input function, 24V must be connected to COM+, and the input pins must be connected to 24V ground (0V).
3. When using the output function, pin 18 must be connected to 24V, COM- must be connected to 24V ground (0V). The output pins can be connected to pin 18 via a relay or a parallel resistor.
4. The probe function can only be assigned to pins 13, 14, 20, 21, 25, 26, 31, and 32.

2.8.2 Name and function of input signal (CN1)

Table 2-19 Input signal (CN1) name and function list

| Control Method | Signal | A-axis pin No. | B-axis pin No. | C-axis pin No. | D-axis pin No. | Function |
|--------------------|------------|----------------|----------------|----------------|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Any Control Method | HomeSwitch | 30 | 24 | 19 | 12 | Homing signal drive input |
| | LATCH0 | 32 | 26 | 21 | 14 | Probe 0 |
| | P-OT | 34 | 28 | 23 | 16 | Prohibition of forward drive Prohibition of reverse drive When the mechanical movement exceeds the movable range, the drive of the servo motor is stopped (overtravel prevention function). |
| | N-OT | 33 | 27 | 22 | 15 | |
| | LATCH1 | 31 | 25 | 20 | 13 | Probe 1 |
| | DI(COM+) | 2/29 | | | | (Note)Available when the control power supply is used for the input signal. Operable voltage range: +11V ~ +25V (+24V power supply is not provided by HCFA). |

Note: The input signal distribution of P-OT, N-OT and probe is changeable, please refer to 2.8.3 "Allocation of input signal " for details.

2.8.3 Allocation of input signal



Points

- If you change the default polarity settings for the P-OT (Positive Overtravel Switch), or N-OT (Reverse Overtravel Switch) signal, the main circuit power supply will not be turned OFF and the overtravel function will not operate if there are signal line disconnections or other problems. If you must change the polarity of one of these signals, verify operation and make sure that no safety problems will exist.
- If you allocate two or more signals to the same input circuit, a logical OR of the inputs will be used and all of the allocated signals will operate accordingly. This may result in unexpected operation.

The servo allows the allocation of input signals to be changed.

Table 2-20 Input signal allocation

| Default axis number | Signal | Related parameters | CN1 pin numbers and corresponding parameter assignments (n.□□xx) | | | | | Polarity control (n.□x□□) | | | | Axis select (n.x□□□) | | | | |
|---------------------|------------|--------------------|------------------------------------------------------------------|----|----|----|----|---------------------------|---|--------------|----------------|----------------------|--------|--------|--------|----------|
| | | | 30 | 31 | 32 | 33 | 34 | Active level | | Always valid | Always invalid | A-axis | B-axis | C-axis | D-axis | All axes |
| | | | | | | | | H | L | | | | | | | |
| A-axis | HomeSwitch | Pn594 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | LATCH1 | Pn593 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | LATCH0 | Pn592 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | N-OT | Pn591 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | P-OT | Pn590 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| Default axis number | Signal | Related parameters | CN1 pin numbers and corresponding parameter assignments (n.□□xx) | | | | | Polarity control (n.□x□□) | | | | Axis select (n.x□□□) | | | | |
| | | | 24 | 25 | 26 | 27 | 28 | Active level | | Always valid | Always invalid | A-axis | B-axis | C-axis | D-axis | All axes |
| | | | | | | | | H | L | | | | | | | |
| B-axis | HomeSwitch | Pn599 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | LATCH1 | Pn598 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | LATCH0 | Pn597 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | N-OT | Pn596 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | P-OT | Pn595 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| Default axis number | Signal | Related parameters | CN1 pin numbers and corresponding parameter assignments (n.□□xx) | | | | | Polarity control (n.□x□□) | | | | Axis select (n.x□□□) | | | | |
| | | | 19 | 20 | 21 | 22 | 23 | Active level | | Always valid | Always invalid | A-axis | B-axis | C-axis | D-axis | All axes |
| | | | | | | | | H | L | | | | | | | |
| C-axis | HomeSwitch | Pn59E | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | LATCH1 | Pn59D | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | LATCH0 | Pn59C | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | N-OT | Pn59B | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | P-OT | Pn59A | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |

| Default axis number | Signal | Related parameters | CN1 pin numbers and corresponding parameter assignments (n.□□xx) | | | | | Polarity control (n.□x□□) | | | | Axis select (n.x□□□) | | | | |
|---------------------|------------|--------------------|------------------------------------------------------------------|----|----|----|----|---------------------------|---|--------------|----------------|----------------------|--------|--------|--------|----------|
| | | | 12 | 13 | 14 | 15 | 16 | Active level | | Always valid | Always invalid | A-axis | B-axis | C-axis | D-axis | All axes |
| | | | | | | | | H | L | | | | | | | |
| D-axis | HomeSwitch | Pn5A3 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | LATCH1 | Pn5A2 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | LATCH0 | Pn5A1 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | N-OT | Pn5A0 | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |
| | P-OT | Pn59F | 01 | 02 | 03 | 04 | 05 | 0 | 1 | 3 | 2 | 1 | 2 | 3 | 4 | 5 |

Note:

1. □ in table indicates default setting


2.If you allocate two or more signals to the same input circuit, a logical OR of the inputs will be used and all of the allocated signals will operate accordingly. This may result in unexpected operation.

2.8.4 Input circuit

The following describes terminals 3 to 10 of the CN1 port

I. Relay/collector input circuit


The connection is made via a relay or an open-collector transistor circuit. When using a relay connection, please choose a relay for small current; if you do not use a relay for small current, it will cause poor contact



Note: The external power supply (DC24V) must be a capacity of 50mA or more.

II. Photocoupler input circuit

The input circuit of the servo unit uses a bidirectional photocoupler. Please choose NPN connection or PNP connection according to the specifications of the machine.



Note: Please note that the ON/OFF polarity is different between NPN circuit connection and PNP circuit connection.

2.8.5 Name and function of output signal (CN1)

Table 2-21 Names and functions of output signals (CN1)

| Control Method | Signal | A-axis pin No. | B-axis pin No. | C-axis pin No. | D-axis pin No. | Function |
|--------------------|--------|----------------|----------------|----------------|----------------|------------------------------------------------------------------------------------------|
| Any control method | S_RDY | 10 | 8 | 6 | 4 | The Servo Ready output signal is also user-assignable. |
| | ALM | 9 | 7 | 5 | 3 | The Alarm output signal is also user-assignable. |
| | FG | Shell | | | | Ground is already performed if IO signal is connected to the shell with shield of cables |

2.8.6 Allocation of output signal

Points

- The signals that are not detected are considered to be OFF. For example, the /COIN (Positioning Completion) signal is considered to be OFF during speed control.
- Reversing the polarity of the /BK (Brake) signal, i.e., changing it to positive logic, will prevent the holding brake from operating if its signal line is disconnected. If you must change the polarity of this signal, verify operation and make sure that no safety problems will exist.
- If you allocate more than one signal to the same output circuit, a logical OR of the signals will be output.

The allocation of the output signals is shown in the table below:

Table 2-22 Output signal parameter allocation

| | Bit0~1 Signal allocation definition | | Bit2 Polarity control definition | | Bit3 Axis selection definition | |
|----------|-------------------------------------|---------------------------|----------------------------------|-------------------------------------|-------------------------------------|----------|
| | Pn5B0~Pn5B7 | n. □□ 00 | Not defined | n. □ 0 □□ | Signal not inverted (Same polarity) | n.0 □□□ |
| n. □□ 01 | | Positioning completion | n. □ 1 □□ | Signal inverted (Opposite polarity) | n.1 □□□ | A-axis |
| n. □□ 02 | | Speed coincidence match | n. □ 2 □□ | Force inactive | n.2 □□□ | B-axis |
| n. □□ 03 | | Motor rotation | n. □ 3 □□ | Force active | n.3 □□□ | C-axis |
| n. □□ 04 | | Servo ready | | | n.4 □□□ | D-axis |
| n. □□ 05 | | Torque limiting | | | n.5 □□□ | All axes |
| n. □□ 06 | | Speed limiting | | | | |
| n. □□ 07 | | Brake | | | | |
| n. □□ 08 | | Warning | | | | |
| n. □□ 09 | | Position near | | | | |
| n. □□ 10 | | Position compare output 1 | | | | |
| n. □□ 11 | | Position compare output 2 | | | | |
| n. □□ 12 | | Position compare output 3 | | | | |
| n. □□ 13 | | Position compare output 4 | | | | |
| n. □□ 14 | | Alarm signal | | | | |
| n. □□ 15 | | User-defined signal 1 | | | | |
| n. □□ 16 | | User-defined signal 2 | | | | |
| n. □□ 17 | | User-defined signal 3 | | | | |

If you allocate more than one signal to the same output circuit, a logical OR of the signals will be output.

Reversing the polarity of the /BK (Brake) signal, i.e., changing it to positive logic, will prevent the holding brake from operating if its signal line is disconnected. If you must change the polarity of this signal, verify operation and make sure that no safety problems will exist.

Note: Output signals above are only for example. Please self-allocate as appropriate.

2.8.7 Output circuit

The signal output circuits of the servo unit are the following one type.


Points

- Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures. If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.

(一). Photocoupler output circuit

Photocoupler output circuits are used for the ALM (Servo Alarm) and other sequence output signals. Connect a photocoupler output circuit to a relay circuit.

Example of a Relay Circuit



Note: 1. The specifications of the photocoupler output circuit are as follows:

- Maximum allowable voltage: DC30V
- Current range: DC5mA ~ DC50mA

2. High-speed output: D01,3,5,7; General output: D02,4,6,8

2.8.8 Brake signal




Figure 2-16 Brake signal connection

Note: 1. The /BK (Brake) signal cannot be used with the default settings. You must allocate the output signal. Please use "brake signal (/BK) distribution" to set.

2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is Common, the I/O signals may malfunction.

2.9 Encoder signal (CN2)

The following describes the name, function and connection example of encoder signal(CN2).

2.9.1 Name and function of encoder signal (CN2)




Figure 2-17 Pin arrangement of encoder connector

Table 2-23 Name and function table of encoder signal (CN2)

| Signal name | Pin number | Function |
|-------------|------------|-------------------|
| PG 5V | 1 | Encoder Power +5V |
| PG 0V | 2 | Encoder Power 0V |
| — | 3 | — |
| — | 4 | — |
| PS | 5 | Serial Data (+) |
| /PS | 6 | Serial Data (-) |
| Shield | Shell | — |

2.9.2 Wiring the servo drive to encoder

The wiring example of the encoder, servo drive and host device is shown below.

(一). Incremental encoder





Figure 2-18 Incremental encoder and servo drive connection diagram

Note: *1. The connector wiring pin number of the incremental encoder varies depending on the servo motor used.

*2. Indicates shielded twisted-pair wire.

◆ Incremental encoder cable — SVCAB-ENC075CA-***L-05:



| End B | | Form End A to End B | | | |
|-------|--------------------|---------------------|-----------------------|------------|-------------|
| | End A | Type | Color | End B | Signal name |
| | 1 | AWG 26 | Orange (red dotted) | 1 | VCC |
| | 2 | | Orange (black dotted) | 2 | GND |
| | 3 | | White (black dotted) | 3 | — |
| | 4 | | White (red dotted) | 6 | — |
| | 5 | | — | 4 | -DO |
| | 6 | | Iron shell | Iron shell | SHLELD |
| 7 | White (red dotted) | | 5 | +DO | |

2.10 Safety function signals STO (CN3)

The following describes the name, function and connection example of the safety function signal (CN3).

2.10.1 Names and functions of the safety function signal (CN3)




Figure 2-19 Names and functions of the safety function signal (CN3)


Table 2-24 Name and function list of safety function use signal (CN3)

| Signal name | Pin number | Function |
|-------------|------------|----------------------------------------------------------------------------------------------------------------|
| — | 1 | Do not make any connections |
| — | 2 | |
| /HWBB1- | 3 | For a hard wire base block input. The base block (motor power turned OFF) is in effect when the signal is OFF. |
| /HWBB1+ | 4 | |
| /HWBB2- | 5 | |
| /HWBB2+ | 6 | |
| — | 7 | — |
| — | 8 | — |

2.10.2 Safety input circuit

Use a 0-V common to connect the safety function signals. You must connect redundant input signals.

Example of input signal connection



2.10.3 Example of Safety Terminal Default Wiring

If the safety terminal (CN3) is to be used, please connect it as illustrated in the following figure:




Figure 2-20 Safety terminal wiring

2.11 Communication connector (CN6)




Figure 2-21 CN6 RJ45 Interface pin arrangement

Table 2-25 Name and function of EtherCAT communication connectors

| Connector | Signal | Pin (Pin) | Meaning |
|---------------|--------|-----------|---------------|
| CN6A (In) | TD+ | 1 | Send data + |
| | TD- | 2 | Send data - |
| | RD+ | 3 | Receive data+ |
| | - | 4 and 5 | - |
| | RD- | 6 | Receive data- |
| | - | 7 and 8 | - |
| CN6B (Out) | TD+ | 1 | Send data + |
| | TD- | 2 | Send data - |
| | RD+ | 3 | Receive data+ |
| | - | 4 and 5 | - |
| | RD- | 6 | Receive data- |
| | - | 7 and 8 | - |

2.12 Brake input connection (CN10)




Figure 2-22 CN10 Brake input interface pin arrangement

Table 2-26 Name and function of brake interfaces

| Signal name | Pin number | Function |
|-------------|------------|-----------------------------|
| 24V | 1 | Brake external power supply |
| 0V | 2 | |
| BKA+ | 3 | Brake A input |
| BKA- | 4 | |
| BKB+ | 5 | Brake B input |
| BKB- | 6 | |

2.12.1 Brake wiring

The brake is a mechanism that prevents the servo motor shaft from moving when the servo drive is not running, and keeps the motor locked in position, so that the moving parts of the machine will not move due to its own weight or external force.

The connection of the brake input signal has no polarity, please install a separate power supply for the 24-VDC power supply from other power supplies. The standard wiring example of the brake signal BK and the brake power supply is as follows:




Figure 2-23 SV730W Brake CN10 connection wiring

Note: It is forbidden for the brake to share the power supply with other electrical appliances to prevent the voltage or current from decreasing due to the work of other electrical appliances, which will eventually cause the brake to malfunction.

2.13 Noise and harmonic countermeasures

Noise and harmonic countermeasures

2.13.1 Countermeasures against noise

Note: 1. As the servo unit is designed as an industrial device, no measures provided to prevent radio interference.

2. The Servo unit uses high-speed switching elements in the main circuit. Therefore, external devices may be affected by switching noise. If the equipment is to be used near private houses or if radio interference is a problem, take countermeasures against noise.

This servo unit uses microprocessor. Therefore, there may be noise interference from its externals.

In order to prevent mutual noise interference between the servo unit and its external equipment, take the following countermeasures against noise interference as required.

- Install the input reference device and noise filter as close to the servo unit as possible
- Always install a surge absorber for relays, solenoids, and magnetic contactor coils.
- Do not place the main circuit cables and I/O signal cables/encoder cables in the same duct or bundle them together.

Also, separate the cables from each other by at least 30 cm.

- Do not share the power supply with an electric welder or electrical discharge machine. If the servo unit is placed near a high-frequency generator, install Noise Filters on the input side on the main circuit power supply cable and control power supply cable even if the same power supply is not Common with the high-frequency generator. For the connection method of the noise filter, refer to "(1) Noise filter".

- Please implement suitable grounding measures, refer to "(2) Grounding".

I. Noise filter

Connect the noise filter to an appropriate place to avoid adverse effects of noise on the servo unit.

The following is an example of wiring for countermeasures against noise.




Figure 2-24 Wiring example of noise countermeasure

Note: * 1. For the ground wire, use a wire with a thickness of at least 2.0 mm² (preferably, flat braided copper wire).

* 2. Please use twisted-pair wires for wiring

* 3. Regarding the use of noise filters, please observe the precautions in 2.13.1 "Noise and its countermeasures"

(二). Grounding

In order to prevent malfunction due to the influence of noise, the proper grounding method is as below.

Motor Frame Ground

If you ground the servo motor through the machine, switching noise current can flow from the main circuit of the servo unit through the stray capacitance of the servo motor. To prevent this, always connect the FG terminal of the servo motor main circuit cable connected to the servo motor to the ground terminal on the servo unit. Also be sure to ground the ground terminal on servo unit.

Noise on I/O Signal Cables

Implement one-point grounding on the 0V line (SG) of the I/O signal cable . When the main circuit cable of the servo motor is covered with a metal sleeve, be sure to ground at one point for the metal sleeve and the junction box.

2.13.2 Noise filter wiring and connection precautions

I. Noise filter for brake power supply

Use a noise filter for the brake power input for a servo motor of 400W or less with brake.

II. Precautions for noise filter installation and wiring

Please observe the following precautions when installing and wiring the noise filter.

Note: Depending on the model, some noise filters have a large leakage current. In addition, due to the different grounding conditions, the leakage current will also change greatly. Please consider the grounding conditions and the leakage current of the filter, etc., and choose to use leakage detectors and leakage circuit breakers. For details, please consult the filter manufacturer.

Separate input lines from output lines. Do not place input lines and output lines in the same duct or bundle them together.




Figure 2-25 Noise filter wiring

Separate the noise filter ground wire from the output lines. Do not place the noise filter ground wire, output lines, and other signal lines in the same duct or bundle them together.




Figure 2-26 Noise filter grounding

Connect the ground wire of the noise filter to the grounding plate separately. Do not connect other ground wires.




Figure 2-27 Noise filter grounding

If a noise filter is located inside a control panel, first connect the Noise Filter ground wire and the ground wires from other devices inside the control panel to the grounding plate for the control panel, then ground the plate.





Figure 2-28 Noise filter and control panel grounding

2.13.3 Connection of reactor for harmonic suppression

When it is necessary to take countermeasures against high-order harmonics, a reactor for suppressing high-order harmonics can be connected to the servo unit.

Example of input signal connection



Note: * 1. Connection terminals 1 and 2 for a DC Reactor are connected when the servo unit is shipped. Remove the lead wire and connect a DC Reactor.

* 2. The reactor is optional (need to be equipped separately).

Chapter 3 EtherCAT Communication Introduction

| | | |
|-------|-----------------------------------------------------|----|
| 3.1 | EtherCAT communication protocol introduction | 71 |
| 3.2 | Definition of communication network interface | 71 |
| 3.3 | Parallel networking of multiple servos..... | 71 |
| 3.4 | EtherCAT frame structure..... | 72 |
| 3.4.1 | Control modes supported by EtherCAT | 72 |
| 3.4.2 | EtherCAT frame structure | 72 |
| 3.4.3 | EtherCAT state machine..... | 72 |
| 3.4.4 | Process data PDO | 74 |
| 3.4.5 | Mailbox data SDO | 76 |
| 3.4.6 | Distributed clock | 76 |
| 3.4.7 | CiA402 control process introduction..... | 76 |
| 3.4.8 | ESI Documents..... | 77 |

3.1 EtherCAT communication protocol introduction

EtherCAT is a high-speed real-time Ethernet technology developed by Beckhoff in Germany. Its features include low hardware cost, simple and convenient application, simple network topology, and uses standard Ethernet physics. It can be used for high-speed IO interconnection and data interaction in industrial sites. Its basic communication mode is master-slave communication, single master and multi-slave communication. The master station can be realized by the ordinary network card of the computer or a dedicated master station PLC, and the slave station is generally composed of ET1100 provided by Beckhoff or an authorized third-party integrated slave station ASIC.

Basic features:

I. High speed:

Precise synchronization is achieved by distributed clocks

II. Fast data refresh:

30 μs processing 1000 digital I/Os

100μs processing 100 servo axes

III. High efficiency, maximizing the use of Ethernet bandwidth for user data transmission

IV. Good synchronization performance, each node slave device can achieve a synchronization accuracy of less than 1us

3.2 Definition of communication network interface

Definition of Communication Network Interface is shown in the table below:

Table 3-1 EtherCAT communication network interface definition

| CiA402 control mode | Supported or not |
|-----------------------------------|------------------|
| Cyclic synchronous position (CSP) | Supported |
| Cyclic synchronous velocity (CSV) | Supported |
| Cyclic synchronous torque (CST) | Supported |
| Profile position mode (PP) | Supported |
| Profile velocity mode (PV) | Supported |
| Profile torque mode (PT) | Supported |
| Home mode (HM) | Supported |

3.3 Parallel networking of multiple servos

EtherCAT servo drive:

When multiple EtherCAT servo drives are networked, the network cables must be inserted in strict accordance with the order of the top-in and bottom-out network ports (note that no terminal resistors are added). As for whether to set the servo station number, it is determined by the host controller.

The EtherCAT servo drive supports a fixed communication rate of 100M bit/s, and the maximum communication length between 2 stations is 100 meters.

Note: 1. The bus servo drive network cable should be separated from other cables when routing in the electric cabinet, especially the strong current line, and should be kept away from interference sources (such as transformers, frequency converters, cabinet fans, etc.) as much as possible.

2. The network cable of the bus servo driver should be twisted-pair network cable to improve the resistance to high-frequency magnetic field noise interference and reduce the external radiation of the cable.

3. Bus servo drive grounding is separated from other grounding as much as possible, separate grounding treatment.

3.4 EtherCAT frame structure

3.4.1 Control modes supported by EtherCAT

The 730W drive EtherCAT is based on the CANOpen application layer profile CiA402 servo and motion control profile. Support the following modes of CiA 402, which is shown in the table below.

Table 3-2 Table 29. CiA402 mode supported by EtherCAT servo drives

| CiA402 control mode | Supported or not |
|-----------------------------------|------------------|
| Cyclic synchronous position (CSP) | Supported |
| Cyclic synchronous velocity (CSV) | Supported |
| Cyclic synchronous torque (CST) | Supported |
| Profile position mode (PP) | Supported |
| Profile velocity mode (PV) | Supported |
| Profile torque mode (PT) | Supported |
| Home mode (HM) | Supported |

3.4.2 EtherCAT frame structure

The frame structure of EtherCAT consists of EtherCAT frame header + more than one EtherCAT sub-message + frame check sequence (FCS), as shown in the figure below:




Figure 3-1 EtherCAT frame structure

3.4.3 EtherCAT state machine

The EtherCAT slave device requires the above four basic states to facilitate data interaction between the master and the slave to manage the state machine of the slave application. It is shown in the figure below:

- Init (I): Initialization state
- Pre-Operational (P): Pre-operational state
- Safe-Operational (S): Safe operational state
- Operational (O): Operational state




Figure 3-2 EtherCAT state machine

The initialization of the slave station to the operational state follows the rule of switching from the pre-operational state, then the safe operational state, and then to the operational state. The operational state can be directly switched back to other various state.

EtherCAT status transition operations are shown in the table below:

Table 3-3 EtherCAT state transition

| State transition | Operation |
|------------------------|-----------|
| (Init) | Yes |
| Init To Pre-OP(IP) | Yes |
| (Pre-OP) | Yes |
| Pre-OP To Safe- OP(PS) | Yes |
| (Safe-OP) | Yes |
| Safe-OP To Op(SO) | Yes |
| (Op) | Yes |

A brief introduction is shown in the table below:

Table 3-4 EtherCAT states profile

| States | Communication operation | | | Description |
|----------------------|-------------------------|-------|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | SDO | TxPDO | RxPDO | |
| Initialization (I) | NO | NO | NO | Communication initialization; There is no communication in the application layer, the master station can only read and write the ESC register |
| IP | NO | NO | NO | The master station configures the slave station address; Configures the mailbox channel; Configures the DC distributed clock; Requests the "Pre-Operational" state |
| Pre-Operational (P) | YES | NO | NO | Application layer mailbox data communication (SDO) |
| PS | YES | NO | NO | The master station uses SDO to initialize the process data mapping; The master station configures the SM channel used for process data communication; The master station configures FMMU; Request " Safe-Operational" staes |
| Safe-Operational (S) | YES | NO | YES | SDO and TxPDO can be used, distributed clock mode can be used |

| | | | | |
|-----------------|-----|-----|-----|----------------------------------------------------------------------------------------------------------|
| SO | YES | NO | YES | Master sends output data to request "Operational" states |
| Operational (O) | YES | YES | YES | Normal operating state; All inputs and outputs are enabled; Email communication is still available |

3.4.4 Process data PDO

Periodic process data is used for periodic control data interaction between the master station and the slave station. The servo drive uses the SM2 (0x1C12) channel to map RxPDO data, and uses the SM3 (0x1C13) channel to map TxPDO data.

The servo driver supports one slave station, and each slave station supports 4 slots. Each slot is configured with one group of PDO. In each PDO group, RxPDO and TxPDO support a maximum of 12 mapping objects each. Among them, TxPDO1 and RxPDO1 support remapping. It is shown in the table below.

Table 3-5 EtherCAT default PDO mapping configuration

| RxPDO | Mapping object | RxPDO Configuration |
|----------------------------|-----------------------------------------------------|---------------------|
| 1600h (RxPDO1) (13Byte) | Control word (6040h) | 60400010 |
| | Control mode (6060h) | 60600008 |
| | Target position (607Ah) | 607A0020 |
| | Touch probe function (60B8h) | 60B80010 |
| | Target velocity (60FFh) | 607A0020 |
| 1610h (RxPDO2) (13Byte) | Control word (6840h) | 68400010 |
| | Control mode (6860h) | 68600008 |
| | Target position (687Ah) | 687A0020 |
| | Touch probe function (68B8h) | 68B80010 |
| | Target velocity (68FFh) | 68FF0020 |
| 1620h (RxPDO3) (13Byte) | Control word (7040h) | 70400010 |
| | Control mode (7060h) | 70600008 |
| | Target position (707Ah) | 707A0020 |
| | Touch probe function (70B8h) | 70B80010 |
| | Target velocity (70FFh) | 707A0020 |
| 1630h (RxPDO4) (13Byte) | Control word (7840h) | 78400010 |
| | Control mode (7860h) | 78600008 |
| | Target position (787Ah) | 787A0020 |
| | Touch probe function (78B8h) | 78B80010 |
| | Target velocity (78FFh) | 787A0020 |
| TxPDO | Mapping object | TxPDO Configuration |
| 1A00h (TxPDO2) (31Byte) | Error code(603Fh) | 603F0010 |
| | Status word (6041h) | 60410010 |
| | Control mode display (6061h) | 60610008 |
| | Position feedback (6064h) | 60640020 |
| | Velocity value feedback (606Ch) | 606C0020 |
| | Touch probe status (60B9h) | 60B90010 |
| | Touch probe 1 rising edge position feedback (60BAh) | 60BA0020 |
| | Touch probe 2 rising edge position feedback (60BCh) | 60BC0020 |
| | Position offset value (60F4h) | 60F40020 |
| | DI status (60FDh) | 60FD0020 |

| TxPDO | Mapping object | TxPDO Configuration |
|----------------------------|-----------------------------------------------------|---------------------|
| 1A10h (TxPDO2) (31Byte) | Error code (683Fh) | 683F0010 |
| | Status word (6841h) | 68410010 |
| | Control mode display (6861h) | 68610008 |
| | Position feedback (6864h) | 68640020 |
| | Velocity value feedback (686Ch) | 686C0020 |
| | Touch probe status (68B9h) | 68B90010 |
| | Touch probe 1 rising edge position feedback (68BAh) | 68BA0020 |
| | Touch probe 2 rising edge position feedback (68BCh) | 68BC0020 |
| | Position offset value (68F4h) | 68F40020 |
| | DI status (68FDh) | 68FD0020 |
| 1A20h (TxPDO3) (31Byte) | Error code (703Fh) | 703F0010 |
| | Status word (7041h) | 70410010 |
| | Control mode display (7061h) | 70610008 |
| | Position feedback (7064h) | 70640020 |
| | Velocity value feedback (706Ch) | 706C0020 |
| | Touch probe status (70B9h) | 70B90010 |
| | Touch probe 1 rising edge position feedback (70BAh) | 70BA0020 |
| | Touch probe 2 rising edge position feedback (70BCh) | 70BC0020 |
| | Position offset value (70F4h) | 70F40020 |
| | DI status (70FDh) | 70FD0020 |
| 1A30h (TxPDO4) (31Byte) | Error code (783Fh) | 783F0010 |
| | Status word (7841h) | 78410010 |
| | Control mode display (7861h) | 78610008 |
| | Position feedback (7864h) | 78640020 |
| | Velocity value feedback (786Ch) | 786C0020 |
| | Touch probe status (78B9h) | 78B90010 |
| | Touch probe 1 rising edge position feedback (78BAh) | 78BA0020 |
| | Touch probe 2 rising edge position feedback (78BCh) | 78BC0020 |
| | Position offset value (78F4h) | 78F40020 |
| | DI status (78FDh) | 78FD0020 |

I. Synchronously manage PDO configuration

In 730W, each axis supports only one fixed RxPDO and one fixed TxPDO configuration. As shown in the table below.

Table 3-6 PDO supported by EtherCAT servo drive

| Index | Subindex | Mapping object |
|--------|----------|------------------------------------------------------------------|
| 0x1C12 | 0 | Each axis is assigned a fixed RxPDO from the range 1600 to 1630. |
| 0x1C13 | 0 | Each axis is assigned a fixed TxPDO from the range 1A00 to 1A30. |

II. PDO mapping management

The PDO mapping content contains the information that needs to receive or send PDO, including index, sub-index and data length. Its sub-index 0 indicates the number of PDO mapping objects, and sub-indexes 1 to n represent the content represented by the first to n elements of the PDO. Each PDO mapping object can map a data object containing 4 bytes at most, and one PDO can contain up to 4*n data lengths.

The mapping content consists of 2 bytes representing the index of the object, one byte representing the sub-index, and one byte representing the data length, as shown in the table below:

Table 3-7 Mapping content structure

| Bytes | Bytes 3~2 | Bytes 1 | Bytes 0 |
|---------|-----------|----------|-------------|
| Meaning | Index | Subindex | Data length |

The index and sub-indexes determine the positional information of the object in the object dictionary, and the data length indicates how many bits make up the object. The length information generally has byte (8bit), word (16bit), double word (32bit) three types, specific by the actual length of the object which consists of a hexadecimal string.

For example: an object mapping content of 60400010h means that the index of the object is 0x6040, the sub-index is 0x00, the length of 16bit that is a word.

3.4.5 Mailbox data SDO

SDO parameters are CoE-defined non-periodic data communication, and the master realizes non-periodic data interaction through the read/write mailbox data SM channel. 730W drives can modify drive parameters through SDO.

3.4.6 Distributed clock

The Distributed Clock (DC, Distributed Clock, 64bit) allows all EtherCAT settings to have the same system time, thus controlling the synchronized execution of the tasks of the devices. The slave devices can be used to trigger synchronous updates of the slave data at the same time, based on the synchronization signals generated by the synchronized system clock. The Y7S drive supports the synchronized clock mode, which currently supports the synchronization signals generated by SYNC0 and Free Run.

3.4.7 CiA402 control process introduction

The state machine related to the power control of the servo drive is shown in the figure below. The power status of each phase of the PDS state machine is shown in the table below.

Table 3-8 PDS state machine power status in different phase

| PDS Phase | Control power | Power supply | Drive status |
|-----------|---------------|--------------|--------------|
| Phase 1 | OK | NO | NO |
| Phase 2 | OK | OK | NO |
| Phase 3 | OK | OK | OK |




Figure 3-3 CiA402 control process state machine

3.4.8 ESI Documents

The ESI file (.XML file) contains information about the 730W Servo Drive's EtherCAT slave, and the master generates an ENI based on the ESI to form an EtherCAT network, so the ESI file (.XML file) provided by our company needs to be saved in a folder specified by the master for normal communication. Therefore, the ESI file (.XML form) provided by our company should be saved in the folder specified by the master in order to communicate properly.

Chapter 4 Commissioning and Operation

| | | |
|-------|-----------------------------------------------------------|----|
| 4.1 | Checks and precautions before test run | 79 |
| 4.2 | Single-servo motor test run | 79 |
| 4.3 | Origin search and positioning (Fn003) | 79 |
| 4.4 | Single servo motor test run via host device commands..... | 79 |
| 4.4.1 | Input signals connection and parameter modification..... | 80 |
| 4.5 | Test run after connecting servo motor to machinery..... | 80 |
| 4.6 | Test run of brake-equipped servo motor | 81 |

4.1 Checks and precautions before test run

To ensure safe and correct test run, check and confirm the following items in advance.

I. Servo motor inspection

Check and confirm the following items for the servo motor—address any issues

- Check whether the settings and wiring are correct.
- Check whether fasteners are loose.

Note: For motors with oil seals: Check whether the oil seal is damaged; Check whether oil has been applied. For long-stored servo motors, follow the manufacturer's maintenance and inspection guidelines during test run.

II. Servo drive status inspection

Check and confirm the following items for the servo drive—address any issues properly before test run:

- Check whether the settings and wiring are correct.
- Check whether the power supply voltage to the servo drive is normal.

4.2 Single-servo motor test run

Please refer to Auxiliary function Fn002 in Chapter 8 for trial operation of Servo motor.

4.3 Origin search and positioning (Fn003)

Origin search is a function that determines the position of the origin pulse (C-phase) of the incremental encoder and stops the motor at that position. This function is used when positioning the motor shaft and mechanical components is required.

Origin search can be executed under the following conditions:

- S-ON input is not present.

Motor speed during execution is 60 rpm.

Points

- Perform origin search with the coupling disconnected.
- During origin search, forward drive prohibition (P-OT) and reverse drive prohibition (N-OT) are disabled.

Please refer to Auxiliary function Fn003 in Chapter 8 for the operation.

4.4 Single servo motor test run via host device commands

When performing a single servo motor test run via host device commands, confirm the following items:

- Confirm that the servo motor movement commands and input/output signals from the host device to the servo drive are correctly set.
- Confirm that the wiring between the host device and the servo drive is correct.
- Confirm that the operation settings of the servo drive are correct.

DANGER

- When performing a single servo motor test run via host device commands, to prevent accidents, conduct the test with the servo motor unloaded (single-unit state with couplings, belts, etc., disconnected).

4.4.1 Input signals connection and parameter modification

Connect the input signal circuits required for the test run to the input/output signal port (CN1). The following conditions apply during connection.

Modify the following parameters:

- ① No parameter changes are needed for absolute encoders. For incremental encoders, set "Pn002.2=1".
- ② For single-phase power input, set "Pn00B.2=1".

4.5 Test run after connecting servo motor to machinery

The following describes the test run method after connecting the servo motor to the machinery. This example assumes the single-servo motor test run is complete.

CAUTION

- When performing a single servo motor test run via host device commands, to prevent accidents, conduct the test with the servo motor unloaded (single-unit state with couplings, belts, etc., disconnected).



Points

- During the single-servo motor test run, overtravel signals (P-OT, N-OT) are set to OFF. Set them to ON now to activate protection functions.

Table 4-1 Test run steps

| Step | Operation | Reference |
|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| 1 | Connect the control power supply and main circuit power supply. Set up protective functions related to safety functions, overtravel, brakes, etc. <ul style="list-style-type: none">• When using a servo motor with a brake, before confirming the brake's operation, first take measures to prevent the machinery from falling naturally or vibrating due to external forces. Then confirm that the servo motor and the brake operate normally. | "5.4.3 Setting of Overtravel" "5.4.4 Brakes " |
| 2 | With the power in the OFF state, connect the servo motor and the machinery using couplings or similar means. | — |
| 3 | After confirming the servo drive is in servo - OFF status, turn on the power supply of the machinery (host device). Then recheck whether the protective functions set in step 1 operate normally. (Note) To avoid abnormalities during subsequent operations, keep the equipment in a state where it can be emergency-stopped. | "5.4.5 How to stop the motor when the servo is OFF and an alarm occurs" |
| 4 | Recheck that the parameter settings match each control mode. Then confirm if the servo motor's operation meets the mechanical operation specifications. | — |
| 5 | Adjust the servo gain as required to improve the response characteristics of the servo motor. During test runs, there may be a mismatch between the servo motor and the machinery; ensure sufficient break-in operation is done. | "Chapter 7 Tuning" |

4.6 Test run of brake-equipped servo motor

Follow these precautions for test runs of brake-equipped servo motors:

- Before confirming brake operation, take measures to prevent the machinery from falling naturally or vibrating due to external forces.
- First, confirm the operation of the servo motor and brake in the separated state (servo motor disconnected from machinery). If no issues arise, reconnect the servo motor and repeat the test run.

Use the servo drive's brake interlock output (/BK) signal to control the brake operation of the brake-equipped servo motor. Please refer to " 5.4.4 Brake " for wiring and related parameter setting.

Chapter 5 Basic Function of Servo



| | | |
|-------|------------------------------------------------------|-----|
| 5.1 | Precaution..... | 85 |
| 5.2 | Panel operation procedures and display..... | 85 |
| 5.2.1 | Panel operator keys..... | 85 |
| 5.2.2 | Changing modes | 86 |
| 5.2.3 | Status display and judgment | 86 |
| 5.2.4 | Operation of auxiliary function (Fn□□□) | 87 |
| 5.2.5 | Parameter setting (Pn□□□)..... | 88 |
| 5.2.6 | Numeric settings | 88 |
| 5.2.7 | Selecting functions..... | 89 |
| 5.2.8 | Operation of monitor display (Un□□□)..... | 89 |
| 5.3 | Automatic detection of connected motor | 89 |
| 5.4 | Basic function settings..... | 89 |
| 5.4.1 | Power settings | 89 |
| 5.4.2 | Setting rotation direction of servo motor | 91 |
| 5.4.3 | Overtravel setting | 92 |
| 5.4.4 | Holding brake | 94 |
| 5.4.5 | Motor stopping methods for servo OFF and alarms..... | 97 |
| 5.4.6 | Operation for momentary power interruptions..... | 99 |
| 5.4.7 | Setting of motor overload detection value..... | 100 |
| 5.4.8 | Regenerative resistor capacity setting..... | 100 |
| 5.5 | Other input and output signals | 101 |
| 5.5.1 | Alarm output (ALM) signal | 101 |
| 5.5.2 | Warning output (/WARN) signal..... | 101 |
| 5.5.3 | Rotation detection output signal (/TGON) | 102 |
| 5.5.4 | Servo ready output (/S-RDY) signal..... | 102 |

| | | |
|-------------|-----------------------------------------------------------------------|------------|
| 5.6 | Electronic gear ratio..... | 102 |
| 5.7 | Profile position mode, PP | 103 |
| 5.7.1 | Control word in profile position mode (60400010h) | 104 |
| 5.7.2 | Status word in profile position mode (60410010h)..... | 104 |
| 5.7.3 | Related parameter of profile position mode | 105 |
| 5.7.4 | Simple tutorial for profile position mode | 106 |
| 5.8 | Profile velocity mode, PV | 107 |
| 5.8.1 | Profile velocity mode control word setting (60400010h) | 107 |
| 5.8.2 | Status word in profile position mode (60410010h) | 108 |
| 5.8.3 | Related parameter of profile velocity mode | 108 |
| 5.8.4 | Simple tutorial for profile velocity mode | 109 |
| 5.9 | Profile torque mode, PT | 110 |
| 5.9.1 | Setting of control word in profile torque mode (60400010h) | 110 |
| 5.9.2 | Status word in profile torque mode (60410010h) | 111 |
| 5.9.3 | Related parameter of profile torque mode | 111 |
| 5.9.4 | Related parameter of profile torque mode..... | 112 |
| 5.10 | Home mode, HM | 112 |
| 5.10.1 | Control Word in Home Mode (60400010h) | 113 |
| 5.10.2 | Status word in home mode (60410010h) | 114 |
| 5.10.3 | Related parameter of home mode | 114 |
| 5.10.4 | Simple tutorial for home mode | 115 |
| 5.10.5 | Home mode introduction..... | 115 |
| 5.10.6 | Instructions for using the homing persistent data memory switch | 141 |
| 5.11 | Cyclic synchronous position mode, CSP | 142 |
| 5.11.1 | Control word in cyclic synchronous position mode (60400010h) | 142 |
| 5.11.2 | Status word in cyclic synchronous position mode (60410010h) | 143 |
| 5.11.3 | Related dictionary objects in cyclic synchronous position mode..... | 143 |
| 5.11.4 | Simple tutorial for cyclic synchronous position mode..... | 144 |
| 5.11.5 | Positioning completion signal | 145 |

| | |
|-----------------------------------------------------------------------------|------------|
| 5.12 Cyclic synchronous velocity mode, CSV | 146 |
| 5.12.1 Control word in cyclic synchronous velocity mode (60400010h) | 146 |
| 5.12.2 Status word in cyclic synchronous velocity mode(60410010h) | 147 |
| 5.12.3 Related dictionary objects in cyclic synchronous velocity mode | 147 |
| 5.12.4 Simple tutorial for cyclic synchronous velocity mode..... | 148 |
| 5.12.5 Velocity reference filter | 148 |
| 5.13 Cyclic synchronous torque mode, CST | 149 |
| 5.13.1 Control word in cyclic synchronous torque mode (60400010h) | 149 |
| 5.13.2 Status word in cyclic synchronous torque mode (60410010h)..... | 150 |
| 5.13.3 Related dictionary objects in cyclic synchronous torque mode..... | 150 |
| 5.13.4 Simple tutorial for cyclic synchronous position mode..... | 151 |
| 5.13.5 Torque reference filter | 151 |
| 5.13.6 Internal torque limit | 152 |
| 5.14 Black box | 152 |
| 5.14.1 Black box function configuration..... | 152 |
| 5.14.2 Black box latching alarm code setting | 153 |
| 5.15 Write parameters to EEPROM..... | 153 |

5.1 Precaution

Table 5-1 Signal table

| Name | Function |
|-------------------------------------------------------------------------------------------|----------------------------------------------------|
|  DANGER | Indicates that may cause death or serious injury |
|  CAUTION | Indicates that may cause injury or property damage |

5.2 Panel operation procedures and display

The user can confirm the servo status through the panel display of the servo unit.

modify and monitor the Utility function (Fn □□□), parameter setting (Pn □□□) and monitoring function (Un □□□) through the operator keys. Also, when an alarm or warning occurs, the corresponding alarm/warning number is displayed.

5.2.1 Panel operator keys




Figure 5-1 Panel buttons

| Key number | Key name | Function |
|------------|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| » | Axis switch key | After switching axes, you can perform basic mode operations on the corresponding axis |
| ∧ | UP | (1) Increase the set value. (2) It is used as the forward rotation start key when JOG is running in the Auxiliary function mode. |
| ∨ | DOWN | (1) Decrease the setting value. (2) It is used as the reverse start key when the JOG is running in the Auxiliary function mode. |
| M | MODE (Mode and confirmation key) | (1) Switch the basic mode: Utility function, parameter setting, monitoring function. (2) Confirm the set value: After modifying the parameters, short press the key to confirm the set value. The effect is consistent with the SET key. |
| S | SET | (1) Long press this key for more than 1 s to display the set value of each parameter. (2) After modifying the parameters, press and hold this key for more than 1 s to confirm the set value. (3) Short press this key to move the digit to the left by one digit (when the digit is flashing). If the data length exceeds the four digits displayed on the panel, press it four times to switch the panel display to the middle four digits, and then press four times to switch to the top two. |

| Status light | Meaning |
|-----------------|-------------------------------|
| Off | Current axis disabled |
| Solid white | Current axis enabled |
| Solid yellow | Current axis warning occurred |
| Flashing yellow | Current axis alarm occurred |

5.2.2 Changing modes

Table 5-2 Modes switching table

| Function | MODE key | Long press the SET key |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------|------------------------|
| Initial status | <pre> graph TD A[A.10rdy] --> B[A.Fn000] B --> C[A.Pn000] C --> D[A.Un000] D --> A </pre> | — |
| Auxiliary function | | A.0. 9b3 |
| Parameter setting | | A.n.0000 |
| Monitoring function | | A.n. 000 |

Note: Press the MODE key to switch modes, it will cycle from top to bottom according to the table

5.2.3 Status display and judgment

After the power is turned on, the normal state display is shown in figure below. The first data bit is used for EtherCAT communication status display. The second data bit is used for judging signal status, and the short codes are for motor status.




Table 5-3 Data bit interpreting table

| Serial number | Display | Control mode | Meaning |
|-------------------------|---------|--------------|-------------------------------------------|
| First data bit display | A888888 | — | Currently displayed axis number is A axis |
| | b888888 | — | Currently displayed axis number is B axis |
| | c888888 | — | — |
| | d888888 | — | — |
| Second data bit display | 8188888 | — | Initialization status |
| | 8288888 | — | Pre-operation status |
| | 8488888 | — | Safe running status |
| | 8888888 | — | Running status |













| | | | |
|------------------------|--------|----------------------------------|---|
| Third data bit display | 880888 | No mode | — |
| | 881888 | Profile position mode | — |
| | 883888 | Profile speed mode | — |
| | 884888 | Profile torque mode | — |
| | 886888 | Homing mode | — |
| | 888888 | Cyclic synchronous position mode | — |
| | 889888 | Cyclic synchronous speed mode | — |
| | 88A888 | Cyclic synchronous torque mode | — |

Table 5-4 Code interpreting table

| Display | Meaning |
|---------|---------------------------------------------------------------------------------------------------------------------|
| 888rdy | Base block active Indicates the servo is OFF. |
| 888run | Operation in progress Indicates the servo is ON. |
| 888Not | Reverse drive prohibited Indicates that the N-OT (reverse drive prohibit) signal is open. |
| 888Pot | Forward drive prohibited Indicates that the P-OT (forward drive prohibit) signal is open. |
| 8888ot | Forward/reverse drive prohibited status Positive and negative limit signals input simultaneously |
| 888Sto | Security function Indicates the safety function is activated and the servo is in the hardware base block status. |
| 888FSt | Emergency stop function Servo is in emergency stop status |
| 888C90 | Alarm log Indicates the alarm number. |

5.2.4 Operation of auxiliary function (Fn□□□)

The auxiliary function is used for the functional operation of the servo unit, take the origin search "Fn003" operation as an example.

- ① Press  key to switch to the desired axis number.
- ② Press  key to switch to utility mode "Fn000" is displayed.
- ③ Press  or  key to select to "Fn003".
- ④ Press  after pressing the key for 1 second, Fn003 is displayed (origin search) execution screen "", the duration is about 1 second.
- ⑤ First press  key to enable the servo, and then press and hold  (the motor rotates forward) or  (motor reverse rotation) to search for the origin, the search direction of the servo motor rotation origin changes according to the setting of Pn000.0. Keep pressing  (motor forward) or  (motor reverse) key until the servo motor stops, and the panel displays "", at this time, the motor searches for the origin.

⑤ After the origin search is completed, press **(M)** key to disable the motor, and the panel displays "**- .CSR**".

⑥ After pressing **(S)** key for 1 second, return to the utility function menu "**Fn003**" (origin search function).

5.2.5 Parameter setting (Pn□□□)

There are two types of parameter setting for Pn □□□ .

The first type "Numerical setting type": Set a specific value.

The second type "Function selection type": Select the application function.

The setting methods of "Numerical setting type" and "Function selection type" are introduced respectively below.

Note: When the panel displays incomplete parameters, please modify the parameter "Pn00B.0" to "1: Display all parameters".

In the default setting, only the parameters for setting are displayed, and the parameters for adjustment are not displayed. To display all parameters, please set Pn00B = n. □□□ 1 (display all parameters).

Table 5-5 Pn00B = n. □□□ 1 parameter settings

| Parameter | Meaning | When enabled | Classification |
|----------------------------------------------------|-----------------------------|---------------|----------------|
| Pn00B (Function selection application switch B) | n. □□□ 0 | After restart | Setup |
| | n. □□□ 1 (Default value) | | |

5.2.6 Numeric settings

Take the electronic gear ratio (numerator): "Pn78C" changed to 8388608 as an example.

① Press **(>>)** key to switch to the desired axis number.

② Press **(M)** key to switch to parameter setting mode "**Pn000**" is displayed.

③ Press **(S)** after selecting the digit to be changed, press **(^)** or **(v)** key to select "**Pn78C**".

④ Press and hold **(S)** key for about 1 second, and the current setting value of "Pn20E" shown on the screen will be displayed "**_0001**".

⑤ Press **(S)** key to move the flashing digit left and right, and then press **(^)** or **(v)** key to set the last four digits 8608, and the panel displays "**_8608**".

⑥ Press **(S)** key to move the flashing number to the leftmost, and press **(S)** key again to switch to the first four-digit setting page, and the panel displays "**-0000**".

⑦ Press **(S)** key to move the flashing digit left and right, and then press **(^)** or **(v)** key, set the first four digits to 0838, the panel will display "**-0838**".

⑧ So far Pn20E is the first four digits + last four digits = 08388608.

⑨ After pressing **(S)** key for about 1 second, the set value is confirmed. Return to parameter setting "**Pn78C**" (electronic gear ratio numerator) panel, the value on the panel flashes three times quickly.

Note: 1. When the last four digits are selected, the first data bit d is on, and when the middle four digits are selected, the first data bit g is on.

2. When the first two digits are selected, the first data bit a lights up. If you want to set more than four digits, the method is the same.

5.2.7 Selecting functions

Take the function selection basic switch 0: " Pn000 " as an example to select " Pn000.1 " as the control mode to change from speed control to position control.

- ① Press **▶▶** key to switch to the desired axis number.
- ② Press **M** key to switch to parameter setting mode " **Pn0000** " is displayed.
- ③ Press and hold **S** key to display the original set value of "Pn000" shown on the screen , and the panel displays " **n00000** " .
- ④ Press **S** key for once to move the digit to the left by one (flashing) to select Pn000.1 , and the panel displays " **n00000** ".
- ⑤ Press **▲** or **▼** key to change the setting value to "N.0010" , and the panel display is " **n0010** " .
- ⑥ After pressing **S** key for about 1 second, the set value is confirmed.
Return to the Pn000 menu, the panel is set to " **Pn0000** " and the value on the panel flashes three times quickly.
- ⑦ In order to make the setting effective, please reconnect the power supply of the servo unit.

5.2.8 Operation of monitor display (Un□□□)

The monitoring display is used to monitor the status of the servo unit, take the "Un000 " motor speed monitoring operation as an example.

- ① Press **▶▶** key to switch to the desired axis number.
- ② Press **M** key to switch to utility mode " **Un0000** " is displayed.
- ③ Press and hold **S** key for 1 second, the current motor speed will be displayed " **0000** " (display 0000 means the speed is 0).
- ④ Press and hold **S** key for about 1 second , return to " **Un0000** " menu.

5.3 Automatic detection of connected motor

When the servo unit is connected to a standard rotating motor, it will automatically determine which type of servo motor connected. Therefore, you normally do not need to specify the servo motor type.

5.4 Basic function settings

5.4.1 Power settings

I. AC/DC power input setting

The servo unit supports AC/DC power input, which can be set by parameter Pn001 = n. □ X □ □ .

Table 5-6 Pn001 =n. □ X □ □ parameter setting table

| Parameter | | Meaning | When enabled | Classification |
|-------------------------------------------------|-------------------------------|------------------------------------------------------------------------------------------------|---------------|----------------|
| Pn001 (Function select application switch 1) | n. □ 0 □ □ (Default value) | Use an AC power supply input:input AC power from L1, L2, L3 terminals | After restart | Setup |
| | n. □ 1 □ □ | Use a DC power supply input.: directly input DC power from B1 to N or input DC power from P, N | | |

Note: 1. When the set value is Pn001 = n. □ X □ □ , if it is inconsistent with the actual power input specifications, A.330 (main circuit power supply wiring error) will occur.

2. Please connect the AC power supply to the L1/L2/L3 terminals and LC1/LC2 terminals of the servo unit.

3. Please connect the DC power supply to the B1 (P) terminal and N (N1) terminal of the servo unit, and connect LC1/LC2 to the AC power supply. Otherwise may result in malfunction or fire.

4. Always specify a DC power supply input (Pn001 = n. □ 1 □ □) before you input DC power for the main circuit power supply.

If you input DC power without specifying a DC power supply input (i.e., without setting Pn001 to n. □ 1 □ □), the servo unit's internal elements may burn and may cause fire or damage to the equipment.

5. With a DC power supply input, time is required to discharge electricity after the main power supply is turned OFF. A high residual voltage may remain in the servo unit after the power supply is turned OFF. Be careful not to get an electric shock.

6. When DC power is input, please install a fuse on the power supply line.

7. The servo motor returns regenerative energy to the power supply. If you use a servo unit with a DC power supply input, regenerative energy is not processed. Process the regenerative energy at the power supply.

8. When using the SV730W series with DC power input, connect an inrush current prevention circuit externally and implement standard power ON/OFF sequence control.

II. Single-phase/three-phase AC power input setting

Servo drive units support single-phase AC power input, which can be set by parameter Pn00B = n. □ X □ □ .

Table 5-7 Pn00B = n. □ X □ □ parameter setting table

| Parameter | | Meaning | When enabled | Classification |
|-------------------------------------------------------|-------------------------------|----------------------------------------------------------------------------|---------------|----------------|
| Pn00B (Function selection application switch B) | n. □ 0 □ □ (Default value) | Use a three-phase power supply input. | After restart | Setup |
| | n. □ 1 □ □ | Use a three-phase power supply input as a single-phase power supply input. | | |





Note: 1. If you use a single-phase power supply input without specifying a single-phase AC power supply (Pn00B = n. □ 1 □ □), an A.F10 alarm (Power supply line open phase) will occur.

2. When using single-phase 220V power input, do not connect the L3 terminal.

5.4.2 Setting rotation direction of servo motor

The rotation direction of the servo motor can be reversed through Pn000.0 without changing the PLC command. This causes the rotation direction of the servo motor to change, but the polarity of the signals, such as encoder output pulses, output from the servo unit do not change.

Table 5-8 Pn000 servo motor rotation direction switching table

| Parameter | Forward / reverse command | Motor rotation direction | Applicable over-travel signal (OT) |
|-----------|-------------------------------------------------------------------------|--------------------------------------------------------------------------------------|------------------------------------|
| Pn000 | n. □□□ 0 Use CCW as the forward direction. (Default value) |  | P-OT |
| | |  | N-OT |
| | n. □□□ 1 Use CW as the forward direction. (Reverse rotation mode) |  | P-OT |
| | |  | N-OT |

Note: The "forward rotation direction" under the default setting is "counterclockwise rotation (CCW)" viewed from the load side of the servo motor.


5.4.3 Overtravel setting

Overtravel is a function of the servo unit that forces the servo motor to stop in response to a signal input from a limit switch that is activated when a moving part of the machine exceeds the safe range of movement.

For rotary applications such as round tables and conveyors, the overtravel function may not be required, and in this case, the input signal wiring for overtravel is also unnecessary.

NOTE

• Limit switch installation



• Precautions when external force are applied to servo motor shaft during overtravel:

1. The /BK (Brake) signal will remain ON (the brake will be released) when overtravel occurs. This may result in the workpiece falling when overtravel occurs. To prevent the workpiece from falling, set Pn001 to n. 1 to place the servo motor in a zero-clamped state when it stops.

2. A base block state is entered after stopping for overtravel. This may cause the servo motor to be pushed back by an external force on the load shaft. To prevent the servo motor from being pushed back, set Pn001 to n. 1 to place the servo motor in zero-clamped state when it stops.

Note: When the servo motor stops due to overtravel during position control, the position deviation is held. You must input the CLR (Clear) signal to clear the position deviation.

I. Forward/reverse overtravel (P-OT, NOT) signal setting

Table 5-9 Forward/reverse overtravel (P-OT, N-OT) setting table

| Pn590~Pn5A4 | Bit0~1 signal assignment definition | | Bit2 polarity control definition | | Bit3 axis selection definition | |
|---------------------------------------------------------|---------------------------------------------------------|---------------------------------------------------------------------------------|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------|--------------------------------------------------------------------------------|----------|
| | n. <input type="checkbox"/> <input type="checkbox"/> 00 | Undefined | n. <input type="checkbox"/> 0 <input type="checkbox"/> <input type="checkbox"/> | No inversion (same polarity) | n.0 <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Not used |
| n. <input type="checkbox"/> <input type="checkbox"/> 01 | Positive overtravel switch (/POT) | n. <input type="checkbox"/> 1 <input type="checkbox"/> <input type="checkbox"/> | Signal inversion (reverse polarity) | n.1 <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | A axis | |
| n. <input type="checkbox"/> <input type="checkbox"/> 02 | Negative overtravel switch (/NOT) | n. <input type="checkbox"/> 2 <input type="checkbox"/> <input type="checkbox"/> | Forced invalid | n.2 <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | B axis | |
| — | — | n. <input type="checkbox"/> 3 <input type="checkbox"/> <input type="checkbox"/> | Forced valid | n.3 <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | C axis | |
| — | — | — | — | n.4 <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | D axis | |
| — | — | — | — | n.5 <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | All axes | |

II. Motor stopping method for overtravel

When overtravel occurs, you can choose any of the following three methods to stop the servo motor through Pn001:

- ① Dynamic brake (DB) stop: By short-circuiting the electrical circuit, the servo motor is stopped urgently.
- ② Deceleration to stop: Deceleration to stop by emergency stop torque.
- ③ Coasting to stop stop: stop naturally due to friction when the motor rotates.

After stopping, there are the following two states:

① Coasting to stop status: The state of natural stop due to friction when the motor rotates.

② Zero position fixed state: the state of maintaining the zero position in the position loop.

Table 5-10 Pn001=n. □□ X □ stop method setting table for overtravel

| Parameter | Motor stop method | State after motor stops | When enabled | Classification | |
|-------------------------------------------------|-------------------|-------------------------|------------------|----------------|-------|
| Pn001 (Function select application switch 1) | n. □□ 0 □ | Dynamic brake | Lock | After restart | Setup |
| | n. □□ 1 □ | | Coasting to stop | | |
| | n. □□ 2 □ | Coasting to stop | | | |
| | n. □□ 3 □ | Maximum torque stop | Lock | | |
| | n. □□ 4 □ | | Coasting to stop | | |
| | n. □□ 5 □ | Decelerate to stop | Lock | | |
| | n. □□ 6 □ | | Coasting to stop | | |

Note: Deceleration to stop is not possible in torque control. With the setting of Pn001.0, the status of servo motor is coasting to stop after the servo motor stops performing DB or coasting to stop.

When the motor stop method is selected as deceleration stop:

Set Pn406 (Emergency stop torque) to stop the servo motor by setting emergency stop torque, the default setting is 800%. And it will actually stop according to the maximum torque of the motor.

Table 5-11 Pn406 deceleration stop setting table

| Pn406 | Emergency stop torque | Speed | Position | Torque | When enabled | Classification |
|-------|-----------------------|-------|---------------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | Immediately | Setup |
| | 0~800 | 1% | 800% | | | |

III. Overtravel warning function

You can set the system to detect an A.9A0 warning (Overtravel) if overtravel occurs while the servo is ON. This allows the servo unit to notify the host controller with a warning even when the overtravel signal is input only momentarily. It can be set by Pn00D = n. X □□□. Overtravel warnings are also synchronized to error code 603Fh and servo error codes to 213Fh.

Table 5-12 Pn00D=n. X □□□ overtravel warning setting table

| Parameter | Meaning | When enabled | Classification |
|----------------------------------------------------|------------------------------------------------------------------|--------------|----------------|
| Pn00D (Function selection application switch D) | n.0 □□□ (Default value) Do not detect overtravel warnings | Immediately | Setup |
| n.1 □□□ Detect overtravel warnings, | | | |




Figure 5-2 Overtravel detected timing chart

Information:

1. Warnings are detected for overtravel in the same direction as the reference.
2. Warnings are not detected for overtravel in the opposite direction from the reference.
3. A warning can be detected in either the forward or reverse direction if there is no command.
4. A warning will not be detected when the servo is OFF even if overtravel status exists.

5. A warning will not be detected when the servo is turned ON even if overtravel status exists.

6. The warning status will be held for one second after the overtravel status no longer exists and it will then be cleared automatically.

Note: The overtravel warning function is only the action of detecting the warning. It will not affect the stop processing of the overtravel and the motion control of the PLC device. But the motor has not reached the PLC command position, so please check the PLC command.

5.4.4 Holding brake

Since the gravity in the Z-axis direction will cause the mechanism to slide down, the holding brake is more often used in the Z-axis direction. Using the brake can prevent the moving part from falling down, and also prevent the servo motor from continuously exerting a large resistance (if the servo continues to exert force, a large amount of heat will be generated, which will reduce the service life of the motor). The electromagnetic brake will cause unnecessary malfunction, and the brake must be applied after the servo is turned off. The brake is controlled by DO (/BK signal), and the user can use Pn506, Pn507 and Pn508 to set the relevant delay time.

The holding brake is used in the following cases:




Figure 5-3 Cases for holding brake

Electromagnetic brake control timing chart:

Please consider the brake release delay and set the parameters in the timing sequence as shown in the figure below.




Figure 5-4 Electromagnetic brake timing chart

Note: 1. Before you output a reference from the host controller to the servo unit, wait for at least 50 ms plus the brake release delay time after you turn ON the /S-ON signal.

2. Please set the brake operate and servo OFF time through Pn506, Pn507 and Pn508.

3. It can only be used for holding and not for braking. Please use it with the servo OFF.

I. Brake signal

Output signal that controls the brake. The brake signal is not assigned at the factory. Assign it via "(3) Brake signal (/BK) assignment".

When servo is OFF or an alarm is detected, /BK turns OFF (brake operates). Adjust the OFF time via Pn506.

When servo is ON, /BK turns ON (brake not operated).

Note: In overtravel state, the /BK signal remains ON and the brake remains released.

The brake signal (/BK) is not assigned at the factory. Assign it using Pn676=n. □□□□ .

Table 5-13 Pn676=n. □□□□ internal brake configuration setting table

| Parameter | | Meaning | When enabled | Classification |
|-----------------------------------------|------------------------------|---------------------------------------|---------------|----------------|
| Pn676 (Internal brake configuration) | n. □□□ 0 (Default value) | BK signal not used | After restart | Setup |
| | n. □□□ A | Brake A used | | |
| | n. □□□ B | Brake B used | | |
| | n.0 □□□ (Default value) | BK signal not used | | |
| | n.1 □□□ | BK signal output in forward direction | | |
| | n.2 □□□ | BK signal output in reverse direction | | |

Note: If you allocate more than one signal to the same output connector pin, a logical OR of the signals is output. Allocate the /BK signal to its own output connector pin, i.e., do not use the same output terminal for another signal.

II. Output timing of brake signal (/BK) (when the motor stops)

When the servo motor stops, the brake (/BK) signal and the servo ON (/S-ON) signal are OFF at the same time. By setting Pn506, the time from the servo ON (/S-ON) signal OFF to the motor entering the non-energized state can be changed.

Table 5-14 Pn506 brake signal (/BK) setting table

| Pn506 | Brake command - Servo OFF delay time | | | When enabled | Classification |
|-------|--------------------------------------|------|---------------|--------------|----------------|
| | Setting range | Unit | Default value | | |
| | 0~100 | 10ms | 20 | | |




Figure 5-5 Brake signal (/BK) output timing chart (Servo motor stops)

Note: 1. When the servo motor is used to control a vertical axis, the machine moving part may move slightly due to gravity or an external force. You can eliminate this slight motion by setting the servo OFF delay time so that power supply to the motor is stopped after the brake is applied.

2. When an alarm occurs, the servo motor immediately enters a unpowered state regardless of the setting. Therefore, due to the self-weight or external force of the mechanical moving part, the machine sometimes will move before the brake operates.

III. Output timing of brake signal (/BK) (when the motor is operating)

If an alarm occurs while the servo motor is operating, the servo motor will start stopping and the /BK signal will be turned OFF. You can adjust the timing of /BK signal output by setting the brake command output speed level Pn507 and the servo OFF-Brake Command Waiting Time (Pn508).

Note: The stop method when the alarm occurs is the setting of the electronic gear. After the motor is stopped by the zero-speed command, follow the output sequence of " 5.3.6 (2) Brake signal (/BK) (when motor is stopped)".

The brake operates when either of the following conditions is satisfied:

1. When the motor speed goes below the level set in Pn507 for a servo motor after the power supply to the motor is stopped.




Figure 5-6 Signal brake (/BK) output timing chart 1 (When motor is operating)

2. When the time set in Pn508 elapses after the power supply to the motor is stopped.




Figure 5-7 Signal brake (/BK) output timing chart 2 (When motor is operating)

Table 5-15 Pn507/ Pn508 brake operating table

| Pn507 | Brake command output speed level | | | When enabled | Classification | |
|-------|----------------------------------|-------|---------------|--------------|----------------|--------|
| | | Speed | Position | | | Torque |
| | Setting range | Unit | Default value | | | |
| | — | — | — | Immediately | Setup | |

| Pn508 | Servo OFF-brake command waiting time | | | When enabled | Classification | |
|-------|--------------------------------------|-------|---------------|--------------|----------------|--------|
| | | Speed | Position | | | Torque |
| | Setting range | Unit | Default value | | | |
| | 10-100 | 10ms | 50 | Immediately | Setup | |

5.4.5 Motor stopping methods for servo OFF and alarms

CAUTION

- The dynamic brake is used for emergency stops. The dynamic brake circuit will operate frequently if the power supply is turned ON and OFF or the servo is turned ON and OFF while a reference input is applied to start and stop the servo motor. This may result in deterioration of the internal elements in the servo unit. Use speed input references or position references to start and stop the servo motor.
- If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the servo motor stopping method depends on the servo unit model as shown in the following table.
- If the servo motor must be stopped by coasting rather than with the dynamic brake when the main circuit power supply or the control power supply is turned OFF before the servo is turned OFF, combine the sequence signals externally to disconnect the wiring (U, V, W) of the servo motor.
- To minimize the coasting distance of the servo motor to come to a stop when an alarm occurs, zero-speed stopping is the default method for alarms to which it is applicable. However, depending on the application, stopping with the dynamic brake may be more suitable than zero-speed stopping.

E
• Basic Function of Servo

I. Stopping method for servo OFF

Table 5-16 Pn001 stopping setting table (When servo is OFF)

| Parameter | Motor stop method | State after motor stops | When enabled | Classification | |
|-------------------------------------------------|-----------------------------|-------------------------|---------------|----------------|------------------|
| Pn001 (Function select application switch 1) | n. □□□ 0 | DB | After restart | Setup | |
| | n. □□□ 1 | | | | Coasting to stop |
| | n. □□□ 2 | Coasting to stop | | | Coasting to stop |
| | n. □□□ 3 | Maximum torque stop | | | DB |
| | n. □□□ 4 | | | | Coasting to stop |
| | n. □□□ 5 | Decelerate to stop | | | DB |
| | n. □□□ 6 (Default value) | | | | Coasting to stop |

II. Stopping method for Alarms

According to the stop method when the alarm occurs, there are two types of alarms BM. 1 and BM. 2 which are selected by Pn001.0 and Pn00B.1.

When BM.1 alarm occurs, the servo motor will stop according to the setting of Pn001.0.

When BM.2 alarm occurs, the servo motor will stop according to the setting of Pn00B.1.

Please refer to the following tables to check BM.1 alarm or BM.2 alarm.

Table 5-17 Parameter setting table when BM.1 alarm occurs (Same as servo OFF)

| Parameter | | Motor stop method | State after motor stops | When enabled | Classification |
|-------------------------------------------------|-----------------------------|-------------------|-------------------------|---------------|----------------|
| Pn00A (Function select application switch A) | n. □□□ 0 (Default value) | DB | DB | After restart | Setup |
| | n. □□□ 1 | | Coasting to stop | | |
| | n. □□□ 2 | Coasting to stop | Coasting to stop | | |

Table 5-18 Parameter setting table when BM.2 alarm occurs

| Parameter | | Motor stop method | State after motor stops | When enabled | Classification |
|-------------------------------------------------|-----------------------------|---------------------|-------------------------|---------------|----------------|
| Pn00B (Function select application switch B) | n. □□□ 0 | DB | DB | After restart | Setup |
| | n. □□□ 1 | | Coasting to stop | | |
| | n. □□□ 2 | Coasting to stop | Coasting to stop | | |
| | n. □□□ 3 (Default value) | Maximum torque stop | DB | | |
| | n. □□□ 4 | | Coasting to stop | | |
| | n. □□□ 5 | Decelerate to stop | DB | | |
| | n. □□□ 6 | | Coasting to stop | | |

III. Stop method during forced stop

Table 5-19 Stop method during forced stop

| Parameter | | Motor stop method | State after motor stops | When enabled | Classification |
|-------------------------------------------------|------------------------------|-------------------|-------------------------|---------------|----------------|
| Pn00A (Function select application switch A) | n. □□ 0 □ (Default value) | DB | DB | After restart | Setup |
| | n. □□ 1 □ | | Coasting to stop | | |
| | n. □□ 2 □ | Coasting to stop | Coasting to stop | | |

IV. Deceleration time for decelerating to stop

Set the time required for the motor to decelerate from its maximum speed to 0 rpm during the stopping process.

Table 5-20 Setting table for Pn31A (Set deceleration time)

| Pn30A | Deceleration time for decelerating to stop | | | When enabled | Classification |
|-------|--------------------------------------------|------|---------------|--------------|----------------|
| | Setting range | Unit | Default value | | |
| | 0~10000 | 1ms | 100 | | |

Deceleration time for decelerating to stop = Target speed / Rated speed × Soft start (Deceleration time Pn31A)




Figure 5-8 Deceleration time diagram for decelerating to stop

5.4.6 Operation for momentary power interruptions

Even if the main power supply to the servo unit is interrupted momentarily, power supply to the motor (servo ON status) will be maintained for the time set in Pn509 (Momentary power interruption hold time).

Table 5-21 Pn509 (Momentary power interruption hold time) setting table

| Pn509 | Momentary power failure holding time | Speed | Position | Torque | When enabled | Classification |
|-------|--------------------------------------|-------|---------------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | |
| | 20-50000 | 1ms | 20 | | | |

If the momentary power interruption time is equal to or less than the setting of Pn509, power supply to the motor will be continued. If it is longer than the setting, power supply to the motor will be stopped. Power will be supplied to the motor again when the main circuit power supply recovers.




Figure 5-9 Main circuit power supply and servo motor power status (Pn509 value \geq momentary power interruption time)




Figure 5-10 Main circuit power supply and servo motor power status (Pn509 value \leq momentary power interruption time)

Information:

1. If the momentary power interruption time exceeds the setting of Pn509, the /S-RDY (Servo Ready) signal will turn OFF and servo is OFF.
2. If uninterruptible power supplies are used for the control power supply and main circuit power supply, the servo unit can withstand a power interruption that lasts longer than 1,000 ms.
3. The holding time of the servo unit control power supply is approximately 100 ms. If control operations become impossible during a momentary power interruption of the control power supply, the setting of Pn509 will be ignored and the same

operation will be performed as for when the power supply is turned OFF normally.

When performing the same operation, the setting of Pn509 will be ignored.

5.4.7 Setting of motor overload detection value

The motor overload detection value is the value (threshold value) at which an overload warning and an overload alarm are detected when a continuous load exceeding the rated value of the servo motor is applied.

It prevents the servo motor from overheating.

The servo unit is able to change the detection time of A.910 (overload warning) and A.720 (overload (continuous maximum) alarm). However, the detection value of A.710 (overload characteristics and overload (instantaneous maximum) alarm) cannot be changed.

Detection time of overload warning (A.910)

With the default setting for overload warnings, an overload warning is detected in 20% of the time required to detect an overload alarm. You can change the time required to detect an overload warning by changing the setting of the overload warning level (Pn52B). You can increase safety by using overload warning detection as an overload protection function matched to the system

For example, if the overload warning value (Pn52B) is changed from 20% to 50%, an overload warning is detected in half of the time required to detect an overload alarm.

Table 5-22 Pn52B (Overload warning level) setting table

| Pn52B | Overload warning level | | Speed | Position | Torque | When enabled | Classification |
|-------|------------------------|------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 1 ~ 100 | 1% | 20 | | | Immediately | Setup |

Detection Timing for Overload Alarms (A.720)

If servo motor heat dissipation is insufficient (e.g., if the heat sink is too small), you can lower the overload alarm detection level to help prevent overheating.

To reduce the overload alarm detection level, change the setting of Pn52C (Base Current Derating at Motor Overload Detection)

Table 5-23 Pn52C (Base current derating at motor overload detection) setting table

| Pn52C | Base current derating at motor overload | | Speed | Position | Torque | When enabled | Classification |
|-------|-----------------------------------------|------|---------------|----------|--------|---------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 10 ~ 100 | 1% | 100 | | | After restart | Setup |

An A.720 alarm (Continuous overload) can be detected earlier to protect the servo motor from overloading.

5.4.8 Regenerative resistor capacity setting

If an external regenerative resistor is connected, you must set Pn600.

If you set Pn600=0 with external regenerative resistor connected, A.320 alarms (Regenerative overload) will not be detected correctly, and the external regenerative resistor may be damaged or personal injury or fire may result.

Table 5-24 Pn600 (Regenerative resistor capacity) setting table

| Pn600 | Regenerative resistor capacity | | Speed | Position | Torque | When enabled | Classification |
|-------|----------------------------------------------------|------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 0 - Servo unit's maximum applicable motor capacity | 10W | 0 | | | Immediately | Setup |

The setting of regenerative resistance capacity depends on the way of external cooling.

1. For self-cooling (natural convection cooling): Set the parameter to a maximum 20% of the capacity (W) of the actually installed regenerative resistor.
2. For forced air cooling: Set the parameter to a maximum 50% of the capacity (W) of the actually installed regenerative resistor.

(Example) For a self-cooling 50W external regenerative resistor, set Pn600 to 1 ($\times 10$ W) ($50 \text{ W} \times 20\% = 10 \text{ W}$).

Note: 1. When an external regenerative resistor is used at the normal rated load ratio, the resistor temperature increases to between 200° C and 300° C. Always apply derating. Consult the manufacturer for the resistor's load characteristics.

2. For safety, use an External Regenerative Resistor with a thermoswitch.

Table 5-25 Setting table for Pn630 (Resistance value of external regenerative resistance)

| Pn630 | Resistance value of external regenerative | | | When enabled | Classification |
|-------|-------------------------------------------|--------------------------|---------------|---------------|----------------|
| | Setting range | Unit | Default value | | |
| | 0~65535 | 220V: 10mΩ 380V: 10mΩ | 0 | After restart | Setup |

5.5 Other input and output signals

5.5.1 Alarm output (ALM) signal

This signal is output when the servo unit detects an error. The connection terminal can be self-allocated.

Table 5-26 Alarm signal output

| Type | Signal | A axis connector pin No. | B axis connector pin No. | B axis connector pin No. | B axis connector pin No. | Status | Meaning |
|--------|--------------------|--------------------------|--------------------------|--------------------------|--------------------------|-------------|-------------------|
| Output | Alarm output (ALM) | CN1-9 | CN1-7 | CN1-5 | CN1-3 | ON (closed) | Normal status |
| | | | | | | OFF (open) | Servo drive alarm |

5.5.2 Warning output (/WARN) signal

Both alarms and warnings are generated by the servo unit. Alarms indicate errors in the servo unit for which operation must be stopped immediately. Warnings indicate situations that may result in alarms but for which stopping operation is not yet necessary.

Table 5-27 Warning signal output

| Type | Signal | Connector pin No. | Status | Meaning |
|--------|------------------------|-------------------|-------------|-------------------|
| Output | Warning output (/WARN) | Must be allocated | ON (closed) | Normal status |
| | | | OFF (open) | Servo drive alarm |

5.5.3 Rotation detection output signal (/TGON)

This signal is output when the shaft of the servo motor rotates faster than the setting of Pn502.

Table 5-28 Rotation detection output

| Type | Signal | Connector pin No. | Status | Meaning |
|--------|------------------------------------------|-------------------|-------------|---------------------------------------------------------------|
| Output | Rotation detection output signal (/TGON) | Self-allocated | ON (closed) | The Servo motor is operating faster than the setting of Pn502 |
| | | | OFF (open) | The Servo motor is operating slower than the setting of Pn502 |

Rotation detection output (/TGON) parameters:

Use the following parameter to set the speed detection level at which to output the /TGON signal.

Table 5-29 Pn502 (Rotation detection level) parameter setting

| Pn502 | Rotation detection level | | | Speed | Position | Torque | When enabled | Classification |
|-------|--------------------------|-------------|---------------|-------|----------|-------------|--------------|----------------|
| | Setting range | Immediately | Default value | | | | | |
| | 0-10000 | rpm | 20 | | | Immediately | Setup | |

5.5.4 Servo ready output (/S-RDY) signal

The /S-RDY (Servo ready) signal turns ON when the servo unit is ready to accept the /S-ON (Servo ON) input signal.

Table 5-30 Servo ready signal output

| Type | Signal | A axis connector pin No. | B axis connector pin No. | B axis connector pin No. | B axis connector pin No. | Status | Meaning |
|--------|-----------------------------|--------------------------|--------------------------|--------------------------|--------------------------|-------------|--------------------------------------------------|
| Output | Servo ready output (/S-RDY) | CN1-10 | CN1-8 | CN1-6 | CN1-4 | ON (closed) | Ready to receive the /S-ON (Servo ON) signal |
| | | | | | | OFF (open) | Not ready to receive the /S-ON (Servo ON) signal |

Note: The /S-RDY signal is turned ON when the main circuit power is ON, there is no hard wire base block state, and there are no alarms.

5.6 Electronic gear ratio

The essential of electronic gear ratio is the corresponding travel distance of motor for a load shaft travel distance of 1 reference unit (Unit: encoder unit)

The gear ratio consists of the numerator 6091-01h and the denominator 6091-02h. The gear ratio establishes a proportional relationship between the load shaft travel distance (reference unit) and the travel distance (encoder unit): Motor travel distance = Load shaft travel distance × Gear ratio

The motor is connected to the load parts by means of gearbox and other mechanical transmissions. Therefore, the gear ratio is related to the mechanical reduction ratio, mechanical dimensions, and the resolution of the motor. The calculation method is as follows

Gear ratio = Motor resolution / Load shaft resolution;

Gear ratios are used to establish a specified ratio of load shaft travel distance to motor shaft travel distance.

Table 5-31 Electronic gear ratio settings

| Pn78C | Electronic gear ratio numerator | | | Position | When enabled | Classification |
|-------|---------------------------------|------|---------------|-------------|--------------|----------------|
| | Setting range | Unit | Default value | | | |
| | 1-4294967295 | — | 1 | After start | Setup | |

| Pn78E | Electronic gear ratio denominator | | | Position | When enabled | Classification |
|-------|-----------------------------------|------|---------------|----------|--------------|----------------|
| | Setting range | Unit | Default value | 1 | After start | Setup |
| | 1-4294967295 | — | | | | |

If the gear ratio between servo motor shaft and the load is given as n/m:

$$\text{Electronic gear ratio } \frac{B}{A} = \frac{\text{Pn78C}}{\text{Pn78E}} = \frac{\text{Encoder resolution}}{\text{Pluses per load shaft revolution}} \times \frac{m}{n}$$

The encoder resolution can be checked by the motor model as follows:

X6 series- □□□□□□□□

Table 5-32 Encoder resolution selection table

| Code | Specification | Encoder resolution |
|------|-----------------------------------|----------------------------|
| A | 17-bit absolute type (multi-turn) | 131072 (2 ¹⁷) |
| D | 23-bit absolute type (multi-turn) | 8388608 (2 ²³) |

Note: Electronic gear ratio setting range: $0.001 \leq \text{electronic gear ratio (B/A)} \leq \text{Encoder resolution} * 0.4$, if it is not within the range, "parameter setting abnormality (A.040) alarm" will occur.

5.7 Profile position mode, PP

In the Profile Position Mode, there are absolute positioning and relative positioning for drive controlling the motor. The host controller is able to set target position, start velocity, stop velocity and acceleration(deceleration). Set object 6060H to 1 to enable Profile Position Mode. The control block diagram and input/output are shown in the following two figures.




Figure 5-11 Blocking diagram for profile position mode




Figure 5-12 Profile position mode input/output

5.7.1 Control word in profile position mode (60400010h)

In profile position mode, the meaning of control word(6040h) is as the table below. The item in dark background indicates the dedicated control reference in profile position mode.

Table 5-33 Description of control word in profile position mode

| Bit | Name | Description |
|-------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Switch on | Must be set to 1 when enable the servo |
| 1 | Enable voltage | Must be set to 1 when enable the servo |
| 2 | Quick stop | Must be set to 1 when enable the servo, if set to 0 then quick stop |
| 3 | Operation enable | Must be set to 1 when enable the servo |
| 4 | Update position reference | When 0 → 1, load the next positioning operation(including target position or position increment, start velocity, operation velocity and acceleration(deceleration)) |
| 5 | Update immediately | 0: Starts the next positioning operation after the current positioning operation is completed 1: Stop the current operation and starts the next positioning operation immediately |
| 6 | Position reference type | 0: absolute position reference, 1: relative position reference |
| 7 | Fault reset | When 0 → 1 executes alarm reset for once. If multiple resets are required, multiple changes from 0 → 1 are required. When it is set to 1, other control reference is disabled. |
| 8 | Halt | 0: disabled, 1: enabled. When enabled the operation is halted. |
| 9 | PP mode reserved | - |
| 10 | Reserved | - |
| 11~15 | Customized | - |

5.7.2 Status word in profile position mode (60410010h)

The meaning of status word(6041h) is as the table below in profile position mode. The item in dark background indicates the dedicated control reference in profile position mode.

Table 5-34 Status word description in profile position mode

| Bit | Name | Description |
|-----|--------------------|--------------------------------------------------------------------------|
| 0 | Ready to switch on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |

| | | |
|----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | Switched on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 2 | Operation enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo has been enabled. |
| 3 | Fault | 0: No fault, 1: Fault |
| 4 | Voltage enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 5 | Quick stop | 0: Quick stop enabled, 1: Quick stop disabled |
| 6 | Switch on disabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 7 | Warning | 0: No warning, 1: Warning |
| 8 | Customized | - |
| 9 | Remote | 0: Disabled, 1: Enabled. When enabled it indicates control words has been enabled. |
| 10 | Target reached | 60400010h bit 8 (halt)=0, 0: Target position is not reached 1: Target position is reached; 60400010h bit 8 (halt)=1, 0: Decelerating, 1: Velocity is 0 |
| 11 | Internal software limit active | 0: Software limit position is not reached. 1: Software limit position is reached |
| 12 | Received status of new position reference | 0: Position reference can be updated. 1: Position reference cannot be updated. |
| 13 | Position offset error | 0: Position offset value 在规 Setting range 之内 (6065h) 1: Position offset value 超过 Setting range (6065h) |
| 14 | Customized | - |
| 15 | Homing completed | 0: Position offset value is in the set range(6065h) 1: Position offset value is out of the set range(6065h) |

5.7.3 Related parameter of profile position mode

Table below shows related objects dictionary in profile position mode.

Table 5-35 Object Dictionary List of Profile Torque Mode

| Index | Subindex | Name | Access | Data type | Default value |
|-------|----------|---------------------------------------------|--------|------------|---------------|
| 6040h | — | Control word | rw | unsigned16 | 0 |
| 6041h | — | Status word | ro | unsigned16 | 0 |
| 6060h | — | Control mode | rw | integer8 | 0 |
| 6061h | — | Control mode display | ro | integer8 | 0 |
| 6062h | — | User position reference | ro | integer32 | 0 |
| 6063h | — | Motor position feedback | ro | integer32 | 0 |
| 6064h | — | User position feedback | ro | integer32 | 0 |
| 6065h | — | User position offset threshold | rw | unsigned32 | 0 |
| 6067h | — | Position threshold | rw | unsigned32 | 50 |
| 6068h | — | Position reaching time | rw | unsigned16 | 0 |
| 606Bh | — | Velocity demand value | ro | integer32 | 0 |
| 606Ch | — | Velocity actual value | ro | integer32 | 0 |
| 607Ah | — | Target position | rw | integer32 | 0 |
| 607Ch | — | Home offset | rw | integer32 | 0 |
| 607Dh | 01h | Software position limit: min position limit | rw | integer32 | -2147483648 |
| | 02h | Software position limit: max position limit | rw | integer32 | 2147483647 |
| 607Eh | — | Reference polarity | rw | unsigned8 | 0 |

| | | | | | |
|-------|---|-----------------------------------|----|------------|------------|
| 607Fh | — | Max profile velocity | rw | unsigned32 | 2147483647 |
| 6080h | — | Max profile velocity | rw | unsigned32 | 10000 |
| 6081h | — | Profile velocity | rw | unsigned32 | 0 |
| 6083h | — | Profile acceleration | rw | unsigned32 | 10485760 |
| 6084h | — | Profile deceleration | rw | unsigned32 | 10485760 |
| 60F4h | — | User Position offset | ro | integer32 | 0 |
| 60FCh | — | Motor position reference feedback | ro | integer32 | 0 |

5.7.4 Simple tutorial for profile position mode

I. Parameter setting in servo drive

Table 5-36 Parameter of servo drive for operating profile position mode

| Parameter | Set value | Description |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------|
| Pn002.2 | 1 | Take absolute encoder as incremental. No need to change the parameter in absolute system. |
| Pn00B.2 | 1 | Change the power supply to single-phase. If using three-phase power supply, then no need to change the parameter. |

II. The host controller connects to servo drive and set configuration PDO

III. Run the host controller.

Table 5-37 Profile position mode startup and operation

| Address | Name | Value setting (decimal value) |
|---------------------------|--------------------------------------------------|-------------------------------------------|
| 60600008h | Control mode | 1 |
| 607A0020h | Demand position | Set by user |
| 60810020h | Demand velocity in profile position loop | -2147483648~2147483647 |
| 60400010h Control word | Enable | Any number → 6 → 7 → 15/47/79/111 |
| | Alarm clear | Any number → 128 (Enabled on rising edge) |
| | Demand absolute position(Not update immediately) | 6 → 7 → 15 → 31 |
| | Demand absolute position(Update immediately) | 6 → 7 → 47 → 63 |
| | Demand relative position(Not update immediately) | 6 → 7 → 79 → 95 |
| | Demand relative position(Update immediately) | 6 → 7 → 111 → 127 |
| 60830020h | Profile acceleration | -2147483648~2147483647 |
| 60840020h | Profile deceleration | -2147483648~2147483647 |
| 607F0020h | Max. profile velocity | -2147483648~2147483647 |

5.8 Profile velocity mode, PV

In the Profile Velocity Mode, target acceleration and deceleration can be set by host controller. When profile velocity mode is enabled, 6060H is set to 3. It is available for EtherCAT. The control block diagram and input/output are shown in the following two figures.




Figure 5-13 Block diagram for profile velocity mode




Figure 5-14 Profile velocity mode input/output

5.8.1 Profile velocity mode control word setting (60400010h)

In profile velocity mode, the meaning of control word is shown as the table below. The item in dark background indicates the dedicated control reference in profile velocity mode.

Table 5-38 Description of control word in profile velocity mode

| Bit | Name | Description |
|-------|----------------------|-----------------------------------------------------------------------|
| 0 | Switch on | Must be set to 1 when enable the servo |
| 1 | Enable voltage | Must be set to 1 when enable the servo |
| 2 | Quick stop | Must be set to 1 when enable the servo. When set to 0 then quick stop |
| 3 | Operation enable | Must be set to 1 when enable the servo |
| 4 ~ 6 | Reserved for PV Mode | - |

| | | |
|-------|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7 | Fault reset | When 0 → 1 executes alarm reset for once. If multiple resets are required, multiple changes from 0 → 1 are required. When it is set to 1, other control reference is disabled. |
| 8 | Halt | 0: Disabled, 1: Enabled. When disabled reference is executed, When enabled then halt. |
| 9 | Reserved for PV Mode | - |
| 10 | Reserved | - |
| 11~15 | Customized | - |

5.8.2 Status word in profile position mode (60410010h)

In profile velocity mode, the meaning of bit of status word is shown as table below. The item in dark background indicates the dedicated control reference in profile velocity mode.

Table 5-39 Description of status word in profile velocity mode

| Bit | Name | Description |
|---------|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Ready to switch on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 1 | Switched on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 2 | Operation enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo has been enabled. |
| 3 | Fault | 0: No fault, 1: Fault |
| 4 | Voltage enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 5 | Quick stop | 0: Quick stop enabled, 1: Quick stop disabled |
| 6 | Switch on disabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 7 | Warning | 0: No warning, 1: Warning |
| 8 | Customized | - |
| 9 | Remote | 0: Disabled, 1: Enabled. When enabled it indicates control words has been enabled. |
| 10 | Target reached | 60400010h bit 8 (halt)=0, 0: Target velocity is not reached, 1: Target velocity is reached 60400010h bit 8 (halt)=1, 0: Decelerating, 1: Velocity is 0 |
| 11 | Internal software limit active | 0: Software limit position is not reached. 1: Software limit position is reached |
| 12 | Zero velocity status | 0: Velocity is not 0, 1: Velocity is 0 |
| 13 | Reserved for PV mode | - |
| 14 ~ 15 | Customized | - |

5.8.3 Related parameter of profile velocity mode

As shown in the table below, the object dictionaries involved in profile position mode are listed.

Table 5-40 Object dictionary list of profile torque mode

| Index | Subindex | Name | Access | Data type | Default value |
|-------|----------|-------------------------------|--------|------------|---------------|
| 6040h | — | Control word | rw | unsigned16 | 0 |
| 6041h | — | Status word | ro | unsigned16 | 0 |
| 6060h | — | Control mode | rw | integer8 | 0 |
| 6061h | — | Control mode display | ro | integer8 | 0 |
| 6063h | — | Motor position feedback | ro | integer32 | 0 |
| 6064h | — | User position feedback | ro | integer32 | 0 |
| 606Bh | — | User velocity reference value | ro | integer32 | 0 |

| | | | | | |
|-------|-----|---------------------------------------------|----|------------|-------------|
| 606Ch | — | User actual velocity feedback | ro | integer32 | 0 |
| 606Dh | — | Velocity threshold | rw | unsigned16 | 10 |
| 606Eh | — | Velocity reaching time | rw | unsigned16 | 0 |
| 607Ch | — | Home offset | rw | integer32 | 0 |
| 607Dh | 01h | Software position limit: min position limit | rw | integer32 | -2147483648 |
| | 02h | Software position limit: max position limit | rw | integer32 | 2147483647 |
| 607Eh | — | Reference polarity | rw | unsigned8 | 0 |
| 607Fh | — | Max profile velocity | rw | unsigned32 | 2147483647 |
| 6080h | — | Max motor velocity | rw | integer32 | 10000 |
| 6083h | — | Profile acceleration | rw | unsigned32 | 10485760 |
| 6084h | — | Profile deceleration | rw | unsigned32 | 10485760 |
| 60FFh | — | Target velocity | rw | integer32 | 0 |

5.8.4 Simple tutorial for profile velocity mode

I. Parameter setting in servo drive

Table 5-41 Parameter of servo drive for operating profile velocity mode

| Parameter | Set value | Description |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------|
| Pn002.2 | 1 | Take absolute encoder as incremental. No need to change the parameter in absolute system. |
| Pn00B.2 | 1 | Change the power supply to single-phase. If using three-phase power supply, then no need to change the parameter. |

II. The host controller connects to servo drive and set configuration PDO

III. Run the host controller

Table 5-42 Profile velocity mode startup and operation

| Address | Name | Value setting (decimal value) |
|---------------------------|---------------------------|------------------------------------------|
| 60600008h | Control mode | 3 |
| 60FF0020h | Demand profile velocity | -2147483648~2147483647 |
| 60400010h Control word | Enable | Any number → 6 → 7 → 15 |
| | Alarm clear | Any number → 128(Enabled on rising edge) |
| | Motor rotation | Demand velocity reference after enabled |
| 60830020h | Profile acceleration | -2147483648~2147483647 |
| 60840020h | Profile deceleration | -2147483648~2147483647 |
| 607F0020h | Max. profile acceleration | -2147483648~2147483647 |

5.9 Profile torque mode, PT

In profile torque mode, the host controller is able to set the target torque and torque reference change rate (torque ramp). To enable the profile torque mode, set 6060H to 4. It is available for EtherCAT. The control block diagram and input/output are shown in the following two figures.




Figure 5-15 Block diagram for profile torque mode




Figure 5-16 Profile torque mode input and output

5.9.1 Setting of control word in profile torque mode (60400010h)

In profile position mode, the meaning of control word (6040h) is as the table below. The item in dark background indicates the dedicated control reference in profile torque mode.

Table 5-43 Description of control word in profile torque mode

| Bit | Name | Description |
|-----|----------------|---------------------------------------------------------------------|
| 0 | Switch on | Must be set to 1 when enable the servo |
| 1 | Enable voltage | Must be set to 1 when enable the servo |
| 2 | Quick stop | Must be set to 1 when enable the servo, if set to 0 then quick stop |

| | | |
|-------|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 3 | Operation enable | Must be set to 1 when enable the servo |
| 4 ~ 6 | Reserved for PT mode | - |
| 7 | Fault reset | When 0 → 1 executes alarm reset for once. If multiple resets are required, multiple changes from 0 → 1 are required. When it is set to 1, other control reference is disabled. |
| 8 | Halt | 0: disabled, 1: enabled. When enabled the operation is halted. |
| 9 | Reserved for PT mode | - |
| 10 | Reserved | - |
| 11~15 | Customized | - |

5.9.2 Status word in profile torque mode (60410010h)

In profile torque mode, the meaning of control word(6040h) is as the table below. The item in dark background indicates the dedicated control reference in profile torque mode.

Table 5-44 Description of control word in profile torque model

| Bit | Name | Description |
|---------|-------------------------------|------------------------------------------------------------------------------------|
| 0 | Ready to switch on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 1 | Switched on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 2 | Operation enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo has been enabled. |
| 3 | Fault | 0: No fault, 1: Fault |
| 4 | Voltage enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 5 | Quick stop | 0: Quick stop enabled, 1: Quick stop disabled |
| 6 | Switch on disabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 7 | Warning | 0: No warning, 1: Warning |
| 8 | Customized | - |
| 9 | Remote | 0: Disabled, 1: Enabled. When enabled it indicates control words has been enabled. |
| 10 | Target Torque reached | 0: Target torque is not reached, 1: Target torque is reached. |
| 11 | Internal software limit activ | 0: Software limit position is not reached. 1: Software limit position is reached |
| 12, 13 | Reserved for PT mode | - |
| 14, 15 | Customized | - |
| 14 ~ 15 | Customized | - |

5.9.3 Related parameter of profile torque mode

As shown in the table below, the object dictionaries involved in profile torque mode are listed.

Table 5-45 Object dictionaries related to profile torque mode

| Index | Subindex | Signal | Access | Data type | Default value |
|-------|----------|-------------------------------|--------|------------|---------------|
| 603Fh | — | Error code | ro | unsigned16 | 0 |
| 6040h | — | Control word | rw | unsigned16 | 0 |
| 6041h | — | Status word | ro | unsigned16 | 0 |
| 6060h | — | Control mode | rw | integer8 | 0 |
| 6061h | — | Control mode display | ro | integer8 | 0 |
| 606Ch | — | User actual velocity feedback | ro | integer32 | 0 |
| 6071h | — | Target torque | rw | integer16 | 0 |
| 6074h | — | Demand torque | ro | integer16 | 0 |

| | | | | | |
|-------|-----|------------------------------------------------|----|------------|-------------|
| 6077h | — | Actual torque feedback | ro | integer16 | 0 |
| 607Dh | 01h | Software position limit: min position limit | rw | integer32 | -2147483648 |
| | 02h | Software position limit: max position limit | rw | integer32 | 2147483647 |
| 607Fh | — | Max. profile velocity | rw | unsigned32 | 2147483647 |
| 6080h | — | Max. motor velocity | rw | unsigned32 | 10000 |
| 6087h | — | Torque ramp | rw | unsigned32 | 0 |

5.9.4 Related parameter of profile torque mode

I. Parameter setting in servo drive

Table 5-46 Parameter of servo drive for operating profile velocity mode

| Parameter | Set value | Description |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------|
| Pn002.2 | 1 | Take absolute encoder as incremental. No need to change the parameter in absolute system. |
| Pn00B.2 | 1 | Change the power supply to single-phase. If using three-phase power supply, then no need to change the parameter. |

II. The host controller connects to servo drive and set configuration PDO parameters.

III. Run the host controller.

Table 5-47 Profile torque mode startup and operation

| Address | Name | Value setting (decimal value) |
|---------------------------|-----------------------------------------|-------------------------------------------------------------------|
| 60600008h | Control mode | 4 |
| 60800020h | Max. speed limit in profile torque mode | Set by user |
| 60710010h | Demand profile torque | Set by user |
| 60400010h Control word | Enable | Any number → 6 → 7 → 15 |
| | Alarm clear | Any number → 128 (Enabled on rising edge) |
| | Motor operates | Demand reference after enabled |
| 60870020h | Torque ramp | Set by user(Torque reference acceleration in profile torque mode) |
| 607F0020h | Max profile velocity | -2147483648~2147483647 |

5.10 Home mode, HM

According to home switch signal, limit switch signal and encoder Z signal, CiA402 protocol defines 31 methods of homing. To enabled home mode, set object 6060H to 6. It is available in EtherCAT.

Table 5-48 Table 84. Input signal corresponding servo functions and terminal configuration table

| Input signal description | Function | Connector |
|-------------------------------|-------------|------------|
| Homing signal | Home switch | SI0(PIN40) |
| Positive position limit input | P-OT | SI2(PIN42) |
| Negative position limit input | N-OT | SI3(PIN43) |




Figure 5-17 Block diagram for home mode




Figure 5-18 Home mode input and output

5.10.1 Control Word in Home Mode (60400010h)

When selecting homing mode, the meaning of each bit of the control word (6040h) is shown in the table below. The bits with dark background are control commands dedicated to homing mode.

Table 5-49 Table 5-53 Description of control word in home mode

| Bit | Name | Description |
|------|------------------------|------------------------------------------------------------------------------------------------------------------|
| 0 | Switch on | Must be set to 1 when enable the servo |
| 1 | Enable voltage | Must be set to 1 when enable the servo |
| 2 | Quick stop | Must be set to 1 when enable the servo, if set to 0 then quick stop |
| 3 | Operation enable | Must be set to 1 when enable the servo |
| 4 | Home enable | 0: Disabled, 1: Enabled. When enabled the homing is started. If switch to disabled then stop the homing process. |
| 5, 6 | Reserved for home mode | - |

| | | |
|-------|------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7 | Fault reset | When 0 → 1 executes alarm reset for once. If multiple resets are required, multiple changes from 0 → 1 are required. When it is set to 1, other control reference is disabled. |
| 8 | Halt | 0: disabled, 1: enabled. When enabled the operation is halted. |
| 9 | Reserved for home mode | - |
| 10 | Reserved | - |
| 11~15 | Customized | - |

5.10.2 Status word in home mode (60410010h)

When selecting homing mode, the meaning of each bit of the status word (6041h) is shown in the table below. The bits with dark background are statuses dedicated to homing mode.

Table 5-50 Description of status word in home mode

| Bit | Name | Description |
|-----|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Ready to switch on | 0: Disabled, 1: Enabled. When enabled it indicates servo can be enabled |
| 1 | Switched on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 2 | Operation enabled | 0: Disabled, 1: Enabled. When enabled it indicates servo has been enabled |
| 3 | Fault | 0: No fault, 1: Fault |
| 4 | Voltage enabled | 0: Disabled, 1: Enabled. When enabled it indicates servo can be enabled |
| 5 | Quick stop | 0: Quick stop enabled, 1: Quick stop disabled |
| 6 | Switch on disabled | 0: Disabled, 1: Enabled. When enabled it indicates servo cannot be enabled |
| 7 | Warning | 0: No warning, 1: Warning |
| 8 | Customized | - |
| 9 | Remote | 0: Disabled, 1: Enabled. When enabled it indicates control words has been enabled. |
| 10 | Target position reached | 60400010h bit 8 (Halt)=0, 0: Position is not reached, 1: Position is reached; 60400010h bit 8 (Halt)=1, 0: Decelerating, 1: Velocity is 0 |
| 11 | Internal software limit active | 0: Software limit position is not reached. 1: Software limit position is reached |
| 12 | Homing complete output | 0: Homing is not completed, 1: Homing is completed |
| 13 | Homing error | 0: No error, 1: Homing error |
| 14 | Customized | - |
| 15 | Homing completed | 0: Disabled, 1: Homing has been completed. For absolute system, after setting Pn781.3=1, Bit15 value will be saved after homing is completed(retained when power failure) |

5.10.3 Related parameter of home mode

As shown in the table below, the object dictionaries involved in homing mode are listed.

Table 5-51 Object dictionaries related to homing mode

| Index | Subindex | Signal | Access | Data type | Default value |
|-------|----------|----------------------|--------|------------|---------------|
| 603Fh | — | Error code | ro | unsigned16 | 0 |
| 6040h | — | Control word | rw | unsigned16 | 0 |
| 6041h | — | Status word | ro | unsigned16 | 0 |
| 6060h | — | Control mode | rw | integer8 | 0 |
| 6061h | — | Control mode display | ro | integer8 | 0 |

| | | | | | |
|-------|-----|---------------------------------------------------|----|------------|-------------|
| 6062h | — | User position reference | ro | integer32 | 0 |
| 6063h | — | Motor position feedback | ro | integer32 | 0 |
| 6064h | — | User position feedback | ro | integer32 | 0 |
| 6065h | — | User position offset threshold | rw | unsigned32 | 0 |
| 6067h | — | Position reaching threshold | rw | unsigned32 | 50 |
| 6068h | — | Position reaching time | rw | unsigned16 | 0 |
| 606Bh | — | User velocity value | ro | integer32 | 0 |
| 606Ch | — | Actual velocity feedback | ro | integer32 | 0 |
| 607Ch | — | Home offset | rw | integer32 | 0 |
| 607Dh | 01h | Software position limit: min position limit | rw | integer32 | -2147483648 |
| | 02h | Software position limit: max position limit | rw | integer32 | 2147483647 |
| 6098h | — | Home mode | rw | integer8 | 0 |
| 6099h | 01h | Speed during search for deceleration point signal | rw | unsigned32 | 50000 |
| | 02h | Speed during search for switch | rw | unsigned32 | 10000 |
| 609Ah | — | Homing acceleration | rw | unsigned32 | 1000 |

5.10.4 Simple tutorial for home mode

I. Parameter setting in servo drive

Table 5-52 Parameter of servo drive for operating home mode

| Parameter | Set value | Description |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------|
| Pn002.2 | 1 | Take absolute encoder as incremental. No need to change the parameter in absolute system. |
| Pn00B.2 | 1 | Change the power supply to single-phase. If using three-phase power supply, then no need to change the parameter. |

II. The host controller connects to servo drive and set configuration PDO parameters.

III. Run the host controller.

Table 5-53 Home mode startup and operation

| Address | Name | Value setting (decimal value) |
|---------------------------|---------------------------------------------------|------------------------------------------|
| 60600008h | Control mode | 6 |
| 60980008h | Home mode | 1~35 |
| 60400010h Control word | Alarm clear | Any number → 128(Enabled on rising edge) |
| | Homing | 6 → 7 → 15 → 31(Always 31 when homing) |
| 60990120h | Speed during search for deceleration point signal | 0~3000rpm |
| 60990220h | Speed during search for switch | 0~3000rpm |
| 609A0020h | Homing acceleration | 0~1000rpm |

5.10.5 Home mode introduction

CiA402 internally defines 31 kinds of methods for homing (applicable for EtherCAT), which is shown below.

In the following description, HSW represents the signal of the origin position sensor, NL represents the negative limit signal, and PL represents the positive limit signal. ON indicates the enabled status of the signal, and OFF indicates the disabled

status of the signal. OFF → ON means the transition edge of the signal from enabled status to disabled status, ON → OFF means the transition edge of the signal from enabled status to disabled status. The following introduces the running tracks and signal status changes of various home modes respectively. The meanings of the icons in the diagrams of various homing modes are shown in Figure 5-19:

Table 5-54 Home mode startup and operation

| Homing method Description | Description |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | No homing |
| 1 | Homing starts in negative direction. Change to low speed when encounter OFF → ON status of NL and then go back to find nearest Z pulse position as the origin. |
| 2 | Homing starts in positive direction. Change to low speed when encounter OFF → ON status of PL and then go back to find nearest Z pulse position as the origin. |
| 3 | If HSW is inactive then homing starts in positive direction, otherwise in negative direction Change to low speed when encounter ON → OFF status of HSW when running in negative direction and then keep running in negative direction to find nearest Z pulse position as the origin. |
| 4 | If HSW is inactive then homing starts in positive direction, otherwise in negative direction Change to low speed when encounter OFF → ON status of HSW when running in positive direction and then keep running in positive direction to find nearest Z pulse position as the origin. |
| 5 | If HSW is inactive then homing starts in negative direction, otherwise in positive direction Change to low speed when encounter ON → OFF status of HSW when running in positive direction and then keep running in positive direction to find nearest Z pulse position as the origin. |
| 6 | If HSW is inactive then homing starts in negative direction, otherwise in positive direction Change to low speed when encounter ON → OFF status of HSW when running in negative direction and then keep running in negative direction to find nearest Z pulse position as the origin. |
| 7 | If HSW is inactive then homing starts in positive direction, otherwise in negative direction Change to low speed when encounter ON → OFF status of HSW when running in negative direction and then keep running in negative direction to find nearest Z pulse position as the origin. |
| 8 | If HSW is inactive then homing starts in positive direction, otherwise in negative direction Change to low speed when encounter OFF → ON status of HSW when running in positive direction and then keep running in positive direction to find nearest Z pulse position as the origin. |
| 9 | Homing always starts in positive direction no matter HSW is inactive or active. Change to low speed when encounter OFF → ON status of HSW when running in negative direction and then keep running in negative direction to find nearest Z pulse position as the origin. |
| 10 | Homing always starts in positive direction no matter HSW is inactive or active. Change to low speed when encounter ON → OFF status of HSW when running in positive direction and then keep running in positive direction to find nearest Z pulse position as the origin. |
| 11 | If HSW is inactive then homing starts in negative direction, otherwise in positive direction Change to low speed when encounter ON → OFF status of HSW when running in positive direction and then keep running in positive direction to find nearest Z pulse position as the origin. |
| 12 | If HSW is inactive then homing starts in negative direction, otherwise in positive direction Change to low speed when encounter OFF → ON status of HSW when running in negative direction and then keep running in negative direction to find nearest Z pulse position as the origin. |
| 13 | Homing always starts in negative direction no matter HSW is inactive or active. Change to low speed when encounter OFF → ON status of HSW when running in positive direction and then keep running in positive direction to find nearest Z pulse position as the origin. |
| 14 | Homing always starts in negative direction no matter HSW is inactive or active. Change to low speed when encounter ON → OFF status of HSW when running in negative direction and then keep running in negative direction to find nearest Z pulse position as the origin. |
| 15 | Reserved |
| 16 | Reserved |

| | |
|----|------------------------------------------------------------------------------------------------------------------------------------------------|
| 17 | Similar to Method 1, but not to find Z pulse position. The position when encountering OFF → ON status of NL as origin in negative direction. |
| 18 | Similar to Method 2, but not to find Z pulse position. The position when encountering OFF → ON status of PL as origin in positive direction. |
| 19 | Similar to Method 3, but not to find Z pulse position. The position when encountering ON → OFF status of HSW as origin in negative direction. |
| 20 | Similar to Method 4, but not to find Z pulse position. The position when encountering OFF → ON status of HSW as origin in positive direction. |
| 21 | Similar to Method 5, but not to find Z pulse position. The position when encountering ON → OFF status of HSW as origin in positive direction. |
| 22 | Similar to Method 6, but not to find Z pulse position. The position when encountering OFF → ON status of HSW as origin in negative direction. |
| 23 | Similar to Method 7, but not to find Z pulse position. The position when encountering ON → OFF status of HSW as origin in negative direction. |
| 24 | Similar to Method 8, but not to find Z pulse position. The position when encountering OFF → ON status of HSW as origin in positive direction. |
| 25 | Similar to Method 9, but not to find Z pulse position. The position when encountering OFF → ON status of HSW as origin in negative direction. |
| 26 | Similar to Method 10, but not to find Z pulse position. The position when encountering ON → OFF status of HSW as origin in positive direction. |
| 27 | Similar to Method 11, but not to find Z pulse position. The position when encountering ON → OFF status of HSW as origin in positive direction. |
| 28 | Similar to Method 12, but not to find Z pulse position. The position when encountering OFF → ON status of HSW as origin in negative direction. |
| 29 | Similar to Method 13, but not to find Z pulse position. The position when encountering OFF → ON status of HSW as origin in positive direction. |
| 30 | Similar to Method 14, but not to find Z pulse position. The position when encountering ON → OFF status of HSW as origin in negative direction. |
| 31 | Reserved |
| 32 | Reserved |
| 33 | After starting, find the nearest Z pulse position in negative direction |
| 34 | After starting, find the nearest Z pulse position in positive direction |
| 35 | Set the current position as origin |
| 36 | When not enabled, set the current position as origin |




Figure 5-19 Meaning of icons in home mode

In general, it is recommended to apply home mode 3~6, 19~22 to the situation where OFF/ON status of HSW just divided the entire mechanical allowable travel range into two parts. Because in these 8 modes, whenever NL or PL is encountered, operation will stop and alarm and not automatically search for the origin in reverse

It is recommended to apply home mode 7~14, 23~30 to the whole mechanical allowable travel range which is exactly just the range of HSW ON status.

In the case where the travel range is divided into three parts, the range of ON status only occupies only a small part of the whole allowable travel range (ON status is transient)

The above is just suggestion and not mandatory.

I. Mode 1, find negative limit switch and Z pulse, deceleration point: reverse overtravel switch

Starts in negative direction at high speed if deceleration point signal is inactive. Decelerate to stop after encountering OFF → ON status of negative limit switch and running in positive direction at a low speed. After encountering ON → OFF status of negative limit switch, keep running in positive direction to find the nearest Z pulse position as the origin.

Starts in positive direction at a low speed if deceleration point signal is active. After encountering ON → OFF status of negative limit switch, keep running in positive direction to find the nearest Z pulse position as the origin.




Figure 5-20 Home mode 1 trajectory and signal status

II. Mode 2, find positive limit switch and Z pulse, deceleration point: positive overtravel switch

Starts in positive direction at high speed if deceleration point signal is inactive. Decelerate to stop after encountering OFF → ON status of positive limit switch and running in negative direction at a low speed. After encountering ON → OFF status of positive limit switch, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in negative direction at a low speed if deceleration point signal is active. After encountering ON → OFF status of positive limit switch, keep running in negative direction to find the nearest Z pulse position as the origin.




Figure 5-21 Home mode 2 trajectory and signal status

III. Mode 3, find HW ON→OFF position when running in negative direction and Z pulse, deceleration point: Home switch

Starts in positive direction at high speed if HW is inactive. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, keep running in negative direction to find the nearest Z signal position as the origin.

Starts in negative direction at a low speed if HW is active. After encountering ON → OFF status of positive limit switch, keep running in negative direction to find the nearest Z pulse position as the origin.




Figure 5-22 Home mode 3 trajectory and signal status

IV. Mode 4, find HW OFF→ON position when running in positive direction and Z pulse, deceleration point: Home switch

Starts in positive direction at a low speed if HW is inactive. After encountering OFF → ON status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

Starts in negative direction at high speed if HW is active. Decelerate to stop after encountering ON → OFF status of HW and running in positive direction at a low speed. After encountering OFF → ON status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

As shown in the figure below.




Figure 5-23 Home mode 4 trajectory and signal status

V. Mode 5, find HW ON→OFF position when running in positive direction and Z pulse, deceleration point: Home switch

Starts in negative direction at high speed if HW is inactive. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, keep running in positive direction to find the nearest Z pulse position as the origin

Starts in positive direction at a low speed if HW is active. After encountering ON → OFF status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

As shown in the figure below.




Figure 5-24 Home mode 5 trajectory and signal status

VI. Mode 6, find HW OFF→ON position when running in negative direction and Z pulse, deceleration point: Home switch

Starts in negative direction at a low speed if HW is inactive. After encountering OFF → ON status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in positive direction at high speed if HW is active. Decelerate to stop after encountering ON → OFF status of HW and running in negative direction at a low speed. After encountering OFF → ON status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

As shown in the figure below.




Figure 5-25 Home mode 6 trajectory and signal status

VII. Mode 7, find HW ON→OFF position when running in negative direction and Z pulse, when encountering positive limit switch, running in reverse direction automatically, deceleration point: Home switch

Starts in positive direction at high speed if HW is inactive and not encounters positive limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in negative direction at high speed if HW is inactive and encounters positive limit switch. Decelerate after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in negative direction at a low speed if HW is active. After encountering ON → OFF status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

As shown in the figure below.




Figure 5-26 Home mode 7 trajectory and signal status

VIII. Mode 8, find HW OFF→ON position when running in positive direction and Z pulse, when encountering positive limit switch, running in reverse direction automatically, deceleration point: Home switch

Starts in positive direction at high speed if HW is inactive and not encounters positive limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, decelerates to stop and running in positive direction to find the nearest Z pulse position as the origin.

Starts in negative direction at high speed if HW is inactive and encounters positive limit switch. Decelerate after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, decelerates to stop and running in positive direction to find the nearest Z pulse position as the origin.

Starts in negative direction at a low speed if HW is active. After encountering ON → OFF status of HW, decelerate to stop and running in positive direction. After encounter OFF → ON status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

As shown in the figure below.




Figure 5-27 Home mode 8 trajectory and signal status

IX. Mode 9, find HW OFF→ON position when running in negative direction and Z pulse, when encountering positive limit switch, running in reverse direction automatically, deceleration point: Home switch

Starts in positive direction at high speed if HW is inactive and not encounters positive limit switch. Decelerate after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, decelerates to stop and running in negative direction. After encountering OFF → ON status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in negative direction at high speed if HW is inactive and encounters positive limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, decelerates to stop and running in negative direction at a low speed. After encountering OFF → ON of HW, running in negative direction to find the nearest Z pulse position as the origin.

Starts in positive direction at a low speed if HW is active. After encountering ON → OFF status of HW, decelerate to stop and running in negative direction. After encounter OFF → ON status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

As shown in the figure below.




Figure 5-28 Home mode 9 trajectory and signal status

X. Mode 10, find HW ON→OFF position when running in positive direction and Z pulse, when encountering positive limit switch, running in reverse direction automatically, deceleration point: Home switch

Starts in positive direction at high speed if HW is inactive and not encounters positive limit switch. Decelerate after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

Starts in negative direction at high speed if HW is inactive and encounters positive limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

Starts in positive direction at a low speed if HW is active. After encountering ON → OFF status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

As shown in the figure below.




Figure 5-29 Home mode 10 trajectory and signal status

XI. Mode 11, find HW ON→OFF position when running in positive direction and Z pulse, when encountering negative limit switch, running in reverse direction automatically, deceleration point: Home switch

Starts in negative direction at high speed if HW is inactive and not encounters negative limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

Starts in positive direction at high speed if HW is inactive and encounters negative limit switch. Decelerate after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

Starts in positive direction at a low speed if HW is active. After encountering ON → OFF status of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

As shown in the figure below.




Figure 5-30 Home mode 11 trajectory and signal status

XII. Mode 12, find HW OFF→ON position when running in negative direction and Z pulse, when encountering negative limit switch, running in reverse direction automatically, deceleration point: Home switch

Starts in negative direction at high speed if HW is inactive and not encounters negative limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, decelerate to stop and running in negative direction. After encountering OFF → ON of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in positive direction at high speed if HW is inactive and encounters negative limit switch. Decelerate after encountering OFF → ON status of HW and running in positive direction at a low speed. After encountering ON → OFF status of HW, decelerate to stop and running in negative direction at a low speed. After encountering OFF → ON status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in positive direction at a low speed if HW is active. After encountering ON → OFF status of HW and running in negative direction at a low speed. After encountering OFF → ON of HW, keep running in negative direction to find the nearest Z pulse position as the origin. As shown in the figure below.




Figure 5-31 Home mode 12 trajectory and signal status

XIII. Mode 13, find HW OFF→ON position when running in positive direction and Z pulse, when encountering negative limit switch, running in reverse direction automatically, deceleration point: Home switch

Starts in negative direction at high speed if HW is inactive and not encounters negative limit switch. Decelerate after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, decelerate to stop and running in positive direction. After encountering OFF → ON of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

Starts in positive direction at high speed if HW is inactive and encounters negative limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, decelerate and running in negative direction at a low speed. After encountering OFF → ON status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in negative direction at a low speed if HW is active. After encountering ON → OFF status of HW and running in positive direction at a low speed. After encountering OFF → ON of HW, keep running in positive direction to find the nearest Z pulse position as the origin. As shown in the figure below.




Figure 5-32 Home mode 13 trajectory and signal status

XIV. Mode 14, find HW ON→OFF position when running in negative direction and Z pulse, when encountering negative limit switch, running in reverse direction automatically, deceleration point: Home switch

Starts in negative direction at high speed if HW is inactive and not encounters negative limit switch. Decelerate after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, decelerate to stop and running in positive direction. After encountering OFF → ON of HW, keep running in positive direction to find the nearest Z pulse position as the origin.

Starts in positive direction at high speed if HW is inactive and encounters negative limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, keep running in negative direction to find the nearest Z pulse position as the origin.

Starts in negative direction at a low speed if HW is active. After encountering ON → OFF status of HW, keep running in negative direction at a low speed. As shown in the figure below.




Figure 5-33 Home mode 14 trajectory and signal status

XV. Mode 15, reserved, please do not set.

XVI. Mode 16, reserved, please do not set.

XVII. Mode 17, find negative limit switch, deceleration point: reverse overtravel switch

Starts in negative direction at high speed if negative limit switch is inactive. Decelerate to stop after encountering OFF → ON status of negative limit switch and running in positive direction at a low speed. After encountering ON → OFF status of negative limit switch, decelerate to stop and the stop position is the origin.

Starts in positive direction at low speed if negative limit switch is active. Decelerate to stop after encountering ON → OFF status of negative limit switch and the stop position is the origin.

As shown in the figure below. Refer to Table 5-51.




Figure 5-34 Origin mode 17 trajectory and signal status

XVIII. Mode 18, find positive limit switch, deceleration point: Overtravel switch

Starts in positive direction at high speed if positive limit switch is inactive. Decelerate to stop after encountering OFF → ON status of positive limit switch and running in negative direction at a low speed. After encountering ON → OFF status of negative limit switch, decelerate to stop and the stop position is the origin.

Starts in negative direction at low speed if positive limit switch is active. Decelerate to stop after encountering ON → OFF status of positive limit switch and the stop position is the origin. As shown in the figure below.




Figure 5-35 Home mode 18 trajectory and signal status

XIX. Mode 19, find home switch ON→OFF position when running in negative direction, deceleration point: home switch

Starts in positive direction at high speed if HW is inactive. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at a low speed. After encountering ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in negative direction at high speed if HW is active. Decelerate to stop after encountering ON → OFF status of HW and the stop position is the origin.

As shown in the figure below.




Figure 5-36 Home mode 19 trajectory signal and status

XX. Mode 20, find home switch OFF→ON position when running in positive direction, deceleration point: home switch

Starts in positive direction at low speed if HW is inactive. Decelerate to stop after encountering OFF → ON status of HW and the stop position is the origin.

Starts in negative direction at high speed if HW is active. Decelerate to stop after encountering ON → OFF status of HW and running at a low speed in positive direction. After encountering OFF → ON status of HW, decelerate to stop and the stop position is the origin. As shown in the figure below.




Figure 5-37 Home mode 20 trajectory signal and status

XXI. Mode 21, find home switch ON→OFF position when running in positive direction, deceleration point: home switch

Starts in negative direction at high speed if HW is inactive. Decelerate to stop after encountering OFF → ON status of HW and running at low speed in positive direction. After encountering ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at low speed if HW is active. Decelerate to stop after encountering ON → OFF status of HW and the stop position is the origin. As shown in the figure below.




Figure 5-38 Home mode 21 trajectory signal and status

XXII. Mode 22, find home switch OFF→ON position when running in negative direction, deceleration point: home switch

Starts in negative direction at low speed if HW is inactive. Decelerate to stop after encountering OFF → ON status of HW and the stop position is the origin.

Starts in positive direction at high speed if HW is active. Decelerate to stop after encountering ON → OFF status of HW and running in negative direction at low speed. After encountering the OFF → ON status of HW, decelerate to stop the stop position is the origin. As shown in the figure below.




Figure 5-39 Home mode 22 trajectory signal and status

XXIII. Mode 23, find home switch OFF→ON position when running in negative direction, when encounters positive limit switch, running in reverse direction automatically. deceleration point: home switch

Starts in positive direction at high speed if HW is inactive and not encounters positive limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at low speed. After encountering ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in negative direction at high speed if HW is inactive and encounters positive limit switch. Decelerate after encountering OFF → ON status of HW and running in negative direction at low speed. After encountering the ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in negative direction if HW is active. Decelerate to stop after encountering ON → OFF status of HW and the stop position is the origin. As shown in the figure below.




Figure 5-40 Home mode 23 trajectory and signal status

XXIV. Mode 24, find home switch OFF→ON position when running in positive direction, when encounters positive limit switch, running in reverse direction automatically. deceleration point: home switch

Starts in positive direction at high speed if HW is inactive and not encounters positive limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at low speed. After encountering ON → OFF status of HW, decelerate to stop and running in positive direction at low speed. After encountering the OFF → ON status, decelerate to stop and the stop position is the origin.

Starts in negative direction at high speed if HW is inactive and encounters positive limit switch. Decelerate after encountering OFF → ON status of HW and running in negative direction at low speed. After encountering the ON → OFF status of HW, decelerate to stop and running in positive direction at low speed. After encountering the OFF → ON status of HW, decelerate to stop and the stop position is the origin.

Starts in negative direction at low speed if HW is active. Decelerate to stop and running in positive direction after encountering ON → OFF status of HW. After encountering OFF → ON status of HW, decelerate to stop and the stop position is the origin. As shown in the figure below.




Figure 5-41 Home mode 24 trajectory and signal status

XXV.Mode 25, find home switch OFF→ON position when running in negative direction, when encounters positive limit switch, running in reverse direction automatically. deceleration point: home switch

Starts in positive direction at high speed if HW is inactive and not encounters positive limit switch. Decelerate after encountering OFF → ON status of HW and running in positive direction at low speed. After encountering ON → OFF status of HW, decelerate to stop and running in negative direction at low speed. After encountering the OFF → ON status, decelerate to stop and the stop position is the origin.

Starts in negative direction at high speed if HW is inactive and encounters positive limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at low speed. After encountering the ON → OFF status of HW, decelerate to stop and running in negative direction at low speed. After encountering the OFF → ON status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at low speed if HW is active. Decelerate to stop and running in positive direction after encountering ON → OFF status of HW. After encountering OFF → ON status of HW, decelerate to stop and the stop position is the origin. As shown in the figure below.




Figure 5-42 Home mode 25 trajectory and signal status

XXVI. Mode 26, find home switch ON→OFF position when running in positive direction, when encounters positive limit switch, running in reverse direction automatically. deceleration point: home switch

Starts in positive direction at high speed if HW is inactive and not encounters positive limit switch. Decelerate after encountering OFF → ON status of HW and running in positive direction at low speed. After encountering ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in negative direction at high speed if HW is inactive and encounters positive limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at low speed. After encountering the ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at low speed if HW is active. Decelerate to stop and the stop position is the origin after encountering ON → OFF status of HW.




Figure 5-43 Home mode 26 trajectory and signal status

XXVII. Mode 27, find home switch ON→OFF position when running in positive direction, when encounters negative limit switch, running in reverse direction automatically. deceleration point: home switch

Starts in negative direction at high speed if HW is inactive and not encounters negative limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at low speed. After encountering ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at high speed if HW is inactive and encounters negative limit switch. Decelerate after encountering OFF → ON status of HW and running in positive direction at low speed. After encountering the ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at low speed if HW is active. Decelerate to stop and the stop position is the origin after encountering ON → OFF status of HW.

As shown in the figure below.




Figure 5-44 Home mode 27 trajectory and signal status

XXVIII.Mode 28, find home switch OFF→ON position when running in negative direction, when encounters negative limit switch, running in reverse direction automatically. deceleration point: home switch

Starts in negative direction at high speed if HW is inactive and not encounters negative limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in positive direction at low speed. After encountering ON → OFF status of HW, decelerate to stop and running in negative direction at low speed. After encountering OFF → ON status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at high speed if HW is inactive and encounters negative limit switch. Decelerate after encountering OFF → ON status of HW and running in positive direction at low speed. After encountering the ON → OFF status of HW, decelerate to stop and running in the negative direction at low speed. After encountering the OFF → ON status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at low speed if HW is active. Decelerate to stop and running in the negative direction at low speed after encountering the ON → OFF status of HW. After encountering OFF → ON status of HW, decelerate to stop and the stop position is the origin. As shown in the figure below.




Figure 5-45 Home mode 28 trajectory 28 and signal status

XXIX. Mode 29, find home switch OFF→ON position when running in positive direction, when encounters negative limit switch, running in reverse direction automatically. deceleration point: home switch

Starts in negative direction at high speed if HW is inactive and not encounters negative limit switch. Decelerate after encountering OFF → ON status of HW and running in negative direction at low speed. After encountering ON → OFF status of HW, decelerate to stop and running in positive direction at low speed. After encountering OFF → ON status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at high speed if HW is inactive and encounters negative limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at low speed. After encountering the ON → OFF status of HW, decelerate to stop and running in the positive direction at low speed. After encountering the OFF → ON status of HW, decelerate to stop and the stop position is the origin.

Starts in negative direction at low speed if HW is active. Decelerate to stop and running in the positive direction at low speed after encountering the ON → OFF status of HW. After encountering OFF → ON status of HW, decelerate to stop and the stop position is the origin. As shown in the figure below.




Figure 5-46 Home mode 29 trajectory and signal status

XXX. Mode 30, find home switch OFF→ON position when running in negative direction, when encounters negative limit switch, running in reverse direction automatically. deceleration point: home switch

Starts in negative direction at high speed if HW is inactive and not encounters negative limit switch. Decelerate after encountering OFF → ON status of HW and running in negative direction at low speed. After encountering ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in positive direction at high speed if HW is inactive and encounters negative limit switch. Decelerate to stop after encountering OFF → ON status of HW and running in negative direction at low speed. After encountering the ON → OFF status of HW, decelerate to stop and the stop position is the origin.

Starts in negative direction at low speed if HW is active. Decelerate to stop after encountering the ON → OFF status of HW and the stop position is the origin.

As shown in the figure below.




Figure 5-47 Home mode 30 trajectory and signal status

XXXI. Mode 31, reserved, please do not set.

XXXII. Mode 32, reserved, please do not set.

XXXIII. Mode 33, find the nearest Z pulse when running in negative direction.




Figure 5-48 Home mode 33 trajectory and signal status

XXXIV. Mode 34, find the nearest Z pulse when running in positive direction

Starts in positive direction at low speed and find the nearest Z pulse as the origin.




Figure 5-49 Home mode 34 trajectory and signal status

XXXV. Mode 35, set the current position as origin

After triggering homing to zero, set the current position as origin.




Figure 5-50 Home mode 35 trajectory and signal status

XXXVI. Mode 36, when not enabled, set the current position as the home position

After triggering homing to zero, set the current position as origin.




Figure 5-51 Home mode 36 trajectory and signal status

5.10.6 Instructions for using the homing persistent data memory switch

Normally, after a successful homing operation, bit 15 of the status word 6041 is set to 1. After a power-off, it switches to 0. If users need bit 15 of the status word 6041 to remain 1 after a power-off, it is necessary to set Pn781.3.

1. Set Pn781.3 = 1 to enable the homing persistent data memory function.
2. After a successful homing operation, the value of bit 15 of the status word 6041 is stored (saved during power-off).
3. After powering on again, bit 15 of the status word 6041 is 1.

5.11 Cyclic synchronous position mode, CSP

In Cyclic synchronous position mode, host controller is to plan the start velocity and the stop velocity, the acceleration(deceleration) to reach the target position and absolute value of target position in each synchronous cycle. Servo drive follows the target position. To enable CSP mode, set object 6060H to 8. It is available in EtherCAT. The control block diagram and input/output are shown in the following two figures.




Figure 5-52 Cyclic synchronous position mode block diagram




Figure 5-53 Cyclic synchronous position mode input and output

5.11.1 Control word in cyclic synchronous position mode (60400010h)

The meaning of each bit of control word in cyclic synchronous position mode is shown as the table below.

Table 5-55 Description of control word in cyclic synchronous position mode

| Bit | Name | Description |
|-----|------------------|---------------------------------------------------------------------|
| 0 | Switch on | Must be set to 1 when enable the servo |
| 1 | Enable voltage | Must be set to 1 when enable the servo |
| 2 | Quick stop | Must be set to 1 when enable the servo, if set to 0 then quick stop |
| 3 | Operation enable | Must be set to 1 when enable the servo |

| | | |
|-------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4 ~ 6 | CSP mode reserved | - |
| 7 | Fault reset | When 0 → 1 executes alarm reset for once. If multiple resets are required, multiple changes from 0 → 1 are required. When it is set to 1, other control reference is disabled. |
| 8 | Halt | 0: disabled, 1: enabled. When enabled the operation is halted. |
| 9 | CSP mode reserved | - |
| 10 | Reserved | — |
| 11~15 | Customized | - |

5.11.2 Status word in cyclic synchronous position mode (60410010h)

The meaning of each bit of status word in cyclic synchronous position mode is shown as table 5-56. The item in dark background indicates the dedicated control reference in cyclic synchronous position mode.

Table 5-56 Description of status word in cyclic synchronous position mode

| Bit | Name | Description |
|-----|-------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Ready to switch on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 1 | Switched on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 2 | Operation enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo has been enabled. |
| 3 | Fault | 0: No fault, 1: Fault |
| 4 | Voltage enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 5 | Quick stop | 0: Quick stop enabled, 1: Quick stop disabled |
| 6 | Switch on disabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 7 | Warning | 0: No warning, 1: Warning |
| 8 | Customized | - |
| 9 | Remote | 0: Disabled, 1: Enabled. When enabled it indicates control words has been enabled. |
| 10 | Position reached | 60400010h bit 8 (Halt)=0, 0: Position is not reached, 1: Position is reached; 60400010h bit 8 (Halt)=1, 0: Decelerating, 1: Velocity is 0 |
| 11 | Internal software limit active | 0: Software limit position is not reached. 1: Software limit position is reached |
| 12 | Whether to follow target position | 0: Target position is not followed, 1: Target position is followed |
| 13 | Alarm for position following offset | 0: No position offset alarm, 1: Position offset alarm |
| 14 | Customized | - |
| 15 | Origin completed | 0: Disabled, 1: Homing has been completed. For absolute system, after setting Pn781.3=1, Bit15 value will be saved after homing is completed(retained when power failure) |

5.11.3 Related dictionary objects in cyclic synchronous position mode

Table 5-57 Related dictionary objects in cyclic synchronous position mode

| Index | Subindex | Signal | Access | Data type | Default value |
|-------|----------|----------------------|--------|------------|---------------|
| 6040h | — | Control word | rw | unsigned16 | 0 |
| 6041h | — | Status word | ro | unsigned16 | 0 |
| 6060h | — | Control mode | rw | integer8 | 0 |
| 6061h | — | Control mode display | ro | integer8 | 0 |

| | | | | | |
|-------|-----|---------------------------------------------|----|------------|-------------|
| 6062h | — | User position reference | ro | integer32 | 0 |
| 6063h | — | Motor position feedback | ro | integer32 | 0 |
| 6064h | — | User position feedback | ro | integer32 | 0 |
| 6065h | — | User position offset | rw | unsigned32 | 0 |
| 6067h | — | Position reaching threshold | rw | unsigned32 | 0 |
| 6068h | — | Position reaching time | rw | unsigned16 | 0 |
| 606Bh | — | User velocity reference | ro | integer32 | 0 |
| 606Ch | — | User velocity feedback | ro | integer32 | 0 |
| 607A | — | Target position | rw | integer32 | 0 |
| 607Ch | — | Home offset | rw | integer32 | 0 |
| 607Dh | 01h | Software position limit: min position limit | rw | integer32 | -2147483648 |
| | 02h | Software position limit: max position limit | rw | integer32 | 2147483647 |
| 6080h | — | Max motor speed | rw | unsigned32 | 10000 |
| 60B0h | — | Position offset | rw | integer32 | 0 |
| 60B1h | — | Velocity offset | rw | integer32 | 0 |
| 60B2h | — | Torque offset | rw | integer32 | 0 |
| 60F4h | — | User position offset | ro | integer32 | 0 |
| 60FCh | — | Motor position feedback | ro | integer32 | 0 |

5.11.4 Simple tutorial for cyclic synchronous position mode

I. Set parameter in servo drive

Table 5-58 Servo drive parameter for cyclic synchronous position mode

| Parameter | Set value | Description |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------|
| Pn002.2 | 1 | Take absolute encoder as incremental. No need to change the parameter in absolute system. |
| Pn00B.2 | 1 | Change the power supply to single-phase. If using three-phase power supply, then no need to change the parameter. |

II. The host controller connects to servo drive and set the communication parameter(communication of synchronous cycle time, axis parameter, etc.)

III. Run the host controller

Table 5-59 Cyclic synchronous position mode startup and operation

| Address | Name | Value setting (decimal value) |
|---------------------------|--------------------------|------------------------------------------------------------------------|
| 60600008h | Control mode | 8 |
| 60400010h Control word | Enable | Any number → 6 → 7 → 1 or MC_Power |
| | Alarm clear | Any number → 128 (Enable on rising edge) |
| | Axis error reset | Set by host controller or by reference MC_Reset from PLC |
| 607A0020h | Demand position | Set by host controller (including acceleration and deceleration, etc.) |
| | Analog velocity control | Set by host controller, or by reference MC_MoveVelocity from PLC |
| | Demand relative position | Set by host controller, or by reference MC_MoveRelative from PLC |
| | Demand additive position | Set by host controller, or by reference MC_MoveAdditive from PLC |
| 607A0020h | Demand absolute position | Set by host controller, or by reference MC_MoveAbsolute from PLC |
| | Axis decelerate to stop | Set by host controller, or by reference MC_Stop from PLC |
| | Cyclic synchronous time | Set by host controller (DC-SYn-chro) |

5.11.5 Positioning completion signal

In position control, it indicates the reference pulse output by the host controller and the current position offset of the servo motor is less than the setting value of Pn522, which is for host controller to confirm the positioning is completed.

Table 5-60 Positioning completion signal input

| Type | Name | Connector | Status | Meaning |
|-------|-------|------------|-------------|------------------------------|
| Input | /COIN | CN1-25, 26 | ON (closed) | Positioning is completed |
| | | | OFF (open) | Positioning is not completed |

Table 5-61 Positioning completion signal parameter setting

| Pn78C | Electronic gear ratio numerator | | Position | When enabled | Classification |
|-------|---------------------------------|------|---------------|--------------|----------------|
| | Setting range | Unit | Default value | After start | Setup |
| | 1-1073741824 | — | 1 | | |

Note: 1. No effect on final positioning accuracy.

2. If the parameter is set to a value that is too large, the /COIN signal may be output when the position deviation is low during a low-speed operation. Please set this parameter in a reasonable range.




Figure 5-54 /COIN signal output timing chart

If the position deviation is always low and a narrow positioning completed width is used, change the setting of Pn207.3.

Table 5-62 /COIN output timing parameter setting

| Parameter | Signal | Meaning | When enabled | Classification |
|-----------------------------------------------------------|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|----------------|
| Pn207 (Position control command form selection switch) | n. 0 □□□ (Default value) | Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 | After restart | Setup |
| | n. 1 □□□ | Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 and the command after the position command filter is 0. | | |
| | n. 2 □□□ | Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 and the command input is 0. | | |

5.12 Cyclic synchronous velocity mode, CSV

In Cyclic Synchronous Velocity Mode, the host controller is to plan the acceleration(deceleration) to reach the target velocity and target velocity in each synchronous cycle. Servo drive follows the target velocity. To enable CSV mode, set object 6060H to 9. It is available in EtherCAT. The control block diagram and input/output are shown in the following two figures.




Figure 5-55 Cyclic synchronous velocity mode input and output




Figure 5-56 Cyclic synchronous velocity mode input and output

5.12.1 Control word in cyclic synchronous velocity mode (60400010h)

The meaning of each bit of control word(6040h) in cyclic synchronous velocity mode is shown as the table below.

| Bit | Name | Description |
|-------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Switch on | Must be set to 1 when enable the servo |
| 1 | Enable voltage | Must be set to 1 when enable the servo |
| 2 | Quick stop | Must be set to 1 when enable the servo, if set to 0 then quick stop |
| 3 | Operation enable | Must be set to 1 when enable the servo |
| 4 ~ 6 | CSV mode reserved | - |
| 7 | Fault reset | When 0 → 1 executes alarm reset for once. If multiple resets are required, multiple changes from 0 → 1 are required. When it is set to 1, other control reference is disabled. |
| 8 | Halt | 0: disabled, 1: enabled. When enabled the operation is halted. |
| 9 | CSV mode reserved | - |

| | | |
|-------|------------|---|
| 10 | Reserved | - |
| 11~15 | Customized | - |

5.12.2 Status word in cyclic synchronous velocity mode(60410010h)

The meaning of each bit of status word in cyclic synchronous velocity mode is shown as the table below. The item in dark background indicates the dedicated control reference in cyclic synchronous velocity mode.

Table 5-63 Description of status word in cyclic synchronous velocity mode

| Bit | Name | Description |
|---------|-----------------------------------|------------------------------------------------------------------------------------|
| 0 | Ready to switch on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 1 | Switched on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 2 | Operation enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo has been enabled. |
| 3 | Fault | 0: No fault, 1: Fault |
| 4 | Voltage enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 5 | Quick stop | 0: Quick stop enabled, 1: Quick stop disabled. |
| 6 | Switch on disabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 7 | Warning | 0: No warning, 1: Warning |
| 8 | Customized | - |
| 9 | Remote | 0: Disabled, 1: Enabled. When enabled it indicates control words has been enabled. |
| 10 | CSV mode reserved | - |
| 11 | Internal software limit active | 0: Software limit position is not reached. 1: Software limit position is reached |
| 12 | Whether to follow target velocity | 0: Target velocity is not followed, 1: Target velocity has been followed. |
| 13 | CSV mode reserved | - |
| 14 ~ 15 | Customized | - |

5.12.3 Related dictionary objects in cyclic synchronous velocity mode

Table 5-64 Related dictionary objects in cyclic synchronous velocity mode

| Index | Subindex | Signal | Access | Data type | Default value |
|-------|----------|---------------------------------------------|--------|------------|---------------|
| 603Fh | — | Error code | ro | unsigned16 | 0 |
| 6040h | — | Control word | rw | unsigned16 | 0 |
| 6041h | — | Status word | ro | unsigned16 | 0 |
| 6060h | — | Control mode | rw | integer8 | 0 |
| 6061h | — | Control mode display | ro | integer8 | 0 |
| 6063h | — | Motor position feedback | ro | integer32 | 0 |
| 6064h | — | User position feedback | ro | integer32 | 0 |
| 606Bh | — | User velocity demand vaule | ro | integer32 | 0 |
| 606Ch | — | User actual velocity feedback | ro | integer32 | 0 |
| 606Dh | — | Velocity threshold | rw | unsigned16 | 0 |
| 606Eh | — | Velocity reaching time | rw | unsigned16 | 0 |
| 607Ch | — | Home offset | rw | integer32 | 0 |
| 607Dh | 01h | Software position limit: min position limit | rw | integer32 | -2147483648 |
| | 02h | Software position limit: max position limit | rw | integer32 | 2147483647 |
| 607Eh | — | Reference polarity | rw | unsigned8 | 0 |

| | | | | | |
|-------|---|----------------------|----|------------|-------|
| 6080h | — | Max. motor speed | rw | unsigned32 | 10000 |
| 6083h | — | Profile acceleration | rw | unsigned32 | 1000 |
| 6084h | — | Profile deceleration | rw | unsigned32 | 1000 |
| 60B1h | — | Speed offset | rw | unsigned32 | 0 |
| 60B2h | — | Target velocity | Rw | unsigned32 | 0 |
| 60FFh | — | Target velocity | rw | integer32 | 0 |

5.12.4 Simple tutorial for cyclic synchronous velocity mode

I. Set parameter in servo drive

Table 5-65 Servo drive parameter for cyclic synchronous velocity mode

| Parameter | Set value | Description |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------|
| Pn002.2 | 1 | Take absolute encoder as incremental. No need to change the parameter in absolute system. |
| Pn00B.2 | 1 | Change the power supply to single-phase. If using three-phase power supply, then no need to change the parameter. |

II. The host controller connects to servo drive and set the communication parameter (communication of synchronous cycle time, axis parameter, etc.)

III. Run the host controller

Table 5-66 Cyclic synchronous velocity mode startup and operation

| Parameter | Set value | Description |
|---------------------------|-------------------------|-----------------------------------------------------------------|
| 60600008h | Control mode | 9 |
| 60400010h Control word | Enable | Any number → 6 → 7 → 15 or MC_Power |
| | Alarm clear | Any number → 128(Enable on rising edge) |
| | Axis error reset | Set by host controller or by reference MC_Reset from PLC |
| 60FF0020h | Demand velocity | Set by host controller or by reference MC_MoveVelocity from PLC |
| | Axis decelerate to stop | Set by host controller or by reference MC_Stop from PLC |
| | Cyclic synchronous time | Set by host controller (DC-Syn-chro) |

5.12.5 Velocity reference filter

The velocity reference filter is a primary delay filter that is applied to the V-REF (Speed Command Input) signal to smooth the velocity reference.

Note: It is normally not necessary to change this parameter. If the setting is too high, the response to the speed reference may be slowed down.

Table 5-67 Velocity reference filter time constant parameter setting table

| Pn307 | Velocity reference filter time constant | | | Speed | Position | Torque | When enabled | Classification |
|-------|-----------------------------------------|--------|---------------|-------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | | |
| | 0-65535 | 0.01ms | 0 | | | | | |

5.13 Cyclic synchronous torque mode, CST

In Cyclic Synchronous Torque Mode, the host controller is to plan the torque ramp rate to reach the target torque and target torque in each synchronous cycle. Servo drive follows the target torque. To enable CST mode, set object 6060H to 10. It is available in EtherCAT. The control block diagram and input/output are shown in the following two figures.




Figure 5-57 Cyclic synchronous torque mode input and output




Figure 5-58 Cyclic synchronous torque mode input and output

5.13.1 Control word in cyclic synchronous torque mode (60400010h)

The meaning of each bit of control word(6040h) in cyclic synchronous torque mode is shown as the table below.

Table 5-68 Description of control word in cyclic synchronous torque mode

| Bit | Name | Description |
|-------|-------------------|---------------------------------------------------------------------|
| 0 | Switch on | Must be set to 1 when enable the servo |
| 1 | Enable voltage | Must be set to 1 when enable the servo |
| 2 | Quick stop | Must be set to 1 when enable the servo, if set to 0 then quick stop |
| 3 | Operation enable | Must be set to 1 when enable the servo |
| 4 ~ 6 | CSV mode reserved | - |

| | | |
|-------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 7 | Fault reset | When 0 → 1 executes alarm reset for once. If multiple resets are required, multiple changes from 0 → 1 are required. When it is set to 1, other control reference is disabled. |
| 8 | Halt | 0: disabled, 1: enabled. When enabled the operation is halted. |
| 9 | CSV mode reserved | - |
| 10 | Reserved | - |
| 11~15 | Customized | - |

5.13.2 Status word in cyclic synchronous torque mode (60410010h)

The meaning of each bit of status word in cyclic synchronous torque mode is shown as the table below. The item in dark background indicates the dedicated control reference in cyclic synchronous torque mode.

Table 5-69 Description of status word in cyclic synchronous torque mode

| Bit | Name | Description |
|---------|---------------------------------|------------------------------------------------------------------------------------|
| 0 | Ready to switch on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 1 | Switched on | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 2 | Operation enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo has been enabled. |
| 3 | Fault | 0: No fault, 1: Fault |
| 4 | Voltage enabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 5 | Quick stop | 0: Quick stop enabled, 1: Quick stop disabled |
| 6 | Switch on disabled | 0: Disabled, 1: Enabled. When enabled it indicates Servo can be enabled. |
| 7 | Warning | 0: No warning, 1: Warning |
| 8 | Customized | - |
| 9 | Remote | 0: Disabled, 1: Enabled. When enabled it indicates control words has been enabled. |
| 10 | Reserved | - |
| 11 | Internal software limit active | 0: Software limit position is not reached. 1: Software limit position is reached |
| 12 | Whether to follow target torque | 0: Target torque is not followed, 1: Target torque has been followed. |
| 13 | CST mode reserved | - |
| 14 ~ 15 | Customized | - |

5.13.3 Related dictionary objects in cyclic synchronous torque mode

Table 5-70 Related dictionary objects in cyclic synchronous torque mode

| Index | Subindex | Signal | Access | Data type | Default value |
|-------|----------|-------------------------------|--------|------------|---------------|
| 603Fh | — | Error code | ro | unsigned16 | 0 |
| 6040h | — | Control word | rw | unsigned16 | 0 |
| 6041h | — | Status word | ro | unsigned16 | 0 |
| 6060h | — | Control mode | rw | integer8 | 0 |
| 6061h | — | Control mode display | ro | integer8 | 0 |
| 606Ch | — | User actual velocity feedback | ro | integer32 | 0 |
| 6071h | — | Target torque | rw | integer16 | 0 |
| 6074h | — | User demand torque | ro | integer16 | 0 |
| 6077h | — | Actual torque feedback | ro | integer16 | 0 |

| | | | | | |
|-------|-----|---------------------------------------------|----|------------|-------------|
| 607Dh | 01h | Software position limit: min position limit | rw | integer32 | -2147483648 |
| | 02h | Software position limit: max position limit | rw | integer32 | 2147483647 |
| 607Eh | — | Reference polarity | rw | unsigned8 | 0 |
| 607Fh | — | Max profile velocity | rw | unsigned32 | 2147483647 |
| 6087h | — | Torque ramp time | rw | unsigned32 | 0 |

5.13.4 Simple tutorial for cyclic synchronous position mode

I. Set parameter in servo drive

Table 5-71 Servo drive parameter for cyclic synchronous torque mode

| Parameter | Set value | Description |
|-----------|-----------|-------------------------------------------------------------------------------------------------------------------|
| Pn002.2 | 1 | Take absolute encoder as incremental. No need to change the parameter in absolute system. |
| Pn00B.2 | 1 | Change the power supply to single-phase. If using three-phase power supply, then no need to change the parameter. |

II. The host controller connects to servo drive and set the communication parameter (communication of synchronous cycle time, axis parameter, etc.)

III. Run the host controller

Table 5-72 Cyclic Synchronous Torque Mode Startup and Operation

| Parameter | Set value | Description |
|---------------------------|-------------------------|-----------------------------------------------------------|
| 60600008h | Control mode | 10(In hexadecimal is A) |
| 60710010h 607F0020h | Demand torque/velocity | Set by reference MC_TorqueControl from PLC |
| 60400010h Control word | Enable | Any number → 6 → 7 → 15/MC_Power |
| | Alarm clear | Any number → 128(Enable on rising edge) |
| | Axis error reset | Set by host controller, or by reference MC_Reset from PLC |
| | Cyclic synchronous time | Set by host controller(DC-SYn-chro) |
| 607F0020h | Max profile velocity | -2147483648~2147483647 |

5.13.5 Torque reference filter

A function to smooth the torque reference by applying a primary delay filter to the torque reference input.

Note: It is normally not necessary to change this parameter. If the setting is too high, the response to the speed reference may be slowed down.

Table 5-73 Parameters for torque command filter

| Pn415 | T-REF filter time constant | | Speed | Position | Torque | When enabled | Classification |
|-------|----------------------------|--------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 0-65535 | 0.01ms | 0 | | | Immediately | Setup |

5.13.6 Internal torque limit

The internal torque limit is a limiting method that limits the maximum output torque.


The setting unit is the motor rated torque percentage.

If the value is too low, it will cause insufficient torque during acceleration and deceleration.

Table 5-74 Internal torque limit parameter setting

| Pn752 | Forward torque limit | | Speed | Position | Torque | When enabled | Classification |
|-------|----------------------|------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 0-65535 | 0.1% | 8000 | | | | |
| Pn753 | Reverse torque limit | | Speed | Position | Torque | When enabled | Classification |
| | Setting range | Unit | Default value | | | | |
| | 0-65535 | 0.1% | 8000 | | | | |

The torque waveform is as follows:



5.14 Black box

5.14.1 Black box function configuration

The black box function can capture the data at the moment of a fault occurrence or under specified conditions and automatically save it. It can be read and uploaded through the background so that users can analyze and handle the causes of problems. The black box function of the 730W series is not enabled by default.

Table 5-75 Parameter setting table of Pn640 (Black box function configuration)

| Pn640 | Black box function configuration | | | When enabled | Classification |
|-------|----------------------------------|------|---------------|--------------|----------------|
| | Setting range | Unit | Default value | | |
| | 0000 ~ FFFF | - | 0011 | | |

Note: When Bit0 = 0: The black box function is turned off.

When Bit0 = 1: The black box function is turned on, and any alarm or warning is used as the trigger.

When Bit0 = 3: The black box function is turned off, and the alarm set in PN641 is used as the trigger.

I. Black Box Alarm Data Latching Function

Table 5-76 Parameter setting table of Pn640=n. X (Black box function configuration)

| Parameter | Meaning | When enabled | Classification |
|-----------------------------------------------|----------------------------------------------------------------------------------------------------|---------------|----------------|
| Pn640.1 (Black box function configuration) | n. <input type="checkbox"/> <input type="checkbox"/> 0 <input type="checkbox"/> (Default value) | After restart | Setup |
| | n. <input type="checkbox"/> <input type="checkbox"/> 1 <input type="checkbox"/> | | |
| | n. <input type="checkbox"/> <input type="checkbox"/> 2 <input type="checkbox"/> | | |

Note: After an alarm, it is necessary to connect to the host computer to read the black box data.

5.14.2 Black box latching alarm code setting

Table 5-77 Parameter setting table of Pn641 (Black box latching alarm code setting)

| Pn641 | Black box latching alarm code setting | | | When enabled | Classification |
|-------|---------------------------------------|------|---------------|---------------|----------------|
| | Setting range | Unit | Default value | | |
| | 0000 ~ FFFF | - | 0000 | After restart | Setup |

Example of the use of black box latching alarm code:

Set the corresponding alarm code. If it is A.C90, write C90 into PN641; if it is F10, write F10 into PN641.

5.15 Write parameters to EEPROM

Table 5-78 Parameter setting table of Pn790=n.X □□□ (Writing parameters to EEPROM switch)

| Parameter | Meaning | When enabled | Classification |
|--------------------------------------------------|------------------------------|---------------|----------------|
| Pn790.3 (Writing parameters to EEPROM switch) | n. □□ 0 □ (Default value) | After restart | Setup |
| | n. □□ 1 □ | | |
| | n. □□ 2 □ | | |


When Pn790.3 = 0, the commonly used parameters except for the group with the address of 6000H can be written into the device (writing parameters of group 6000 is invalid).

When Pn790.3 = 1, writing all parameters into the device is invalid.

When Pn790.3 = 2, all parameters can be written into the device.

Chapter 6 Application Function

| | | |
|-------|-----------------------------------------------------------------------------|-----|
| 6.1 | Absolute encoder | 156 |
| 6.1.1 | Battery replacement..... | 156 |
| 6.1.2 | Initialization of absolute encoder (when alarming)..... | 158 |
| 6.2 | Position comparison output function | 158 |
| 6.2.1 | Function description | 158 |
| 6.2.2 | Related objects | 159 |
| 6.2.3 | Function running | 160 |
| 6.3 | Gravity compensation function | 161 |
| 6.3.1 | Required parameters setting | 162 |
| 6.3.2 | Operating procedure for gravity compensation..... | 162 |
| 6.3.3 | Operation steps of the automatic update gravity compensation function | 162 |
| 6.4 | Forced DO function | 163 |
| 6.4.1 | Function description | 163 |
| 6.4.2 | Related objects | 163 |
| 6.4.3 | Instructions | 164 |
| 6.5 | Software position limit function..... | 164 |
| 6.5.1 | Function description | 164 |
| 6.5.2 | Related objects..... | 164 |
| 6.5.3 | Instructions..... | 165 |
| 6.6 | Modulus function..... | 166 |
| 6.7 | Touch probe function | 166 |



| | | |
|-------------|-----------------------------------------------------------|------------|
| 6.8 | Safety function | 168 |
| 6.8.1 | Hard wire base block (HWBB) function..... | 168 |
| 6.8.2 | Validating safety functions..... | 172 |
| 6.8.3 | Safety precautions when using the security function | 173 |
| 6.9 | Soft start | 173 |
| 6.10 | Smooth function | 174 |
| 6.11 | Alarm delay disabling function..... | 175 |

6.1 Absolute encoder

With a system that uses an absolute encoder, the host controller can monitor the current position.

Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

To save the position data of the absolute encoder, a battery unit is required. Install the battery on the encoder cable with the battery unit. When not using an encoder cable with a battery unit, install a battery in the host controller

Prohibition: Do not install batteries on both sides of the host controller and the battery unit (If installed on both sides at the same time, a short circuit will be formed between the batteries, which is very dangerous).

When using an absolute encoder, set Pn002.2=0 (Default value).

Table 6-1 Absolute encoder parameter setting

| Parameter | | Meaning | When enabled | Classification |
|-----------|-------------------------------|------------------------------------------------------------|---------------|----------------|
| PN002 | n. □ 0 □ □ | Use the absolute encoder normally | After restart | Setup |
| | n. □ 1 □ □ (Default value) | Use the absolute encoder as an incremental encoder | | |
| | n. □ 2 □ □ | Use the encoder as a single-turn absolute encoder (rotary) | | |

6.1.1 Battery replacement

If the battery voltage drops to approximately 3.0 V or less, an A.830 alarm (Encoder battery alarm) or an A.930 warning (Absolute encoder battery error) will be displayed. When the above alarm or warning appears, please follow the steps below to replace the battery.

Whether to display an A.830 alarm or a A.930 warning is determined by the setting of Pn008.

Table 6-2 Alarm display parameter setting

| Parameter | | Meaning | When enabled | Classification |
|-----------|-------------------------------|------------------------------------------------|---------------|----------------|
| PN002 | n. □ □ □ 0 (Default value) | Output alarm (A.830) for low battery voltage | After restart | Setup |
| | n. □ □ □ 1 | Output warning (A.930) for low battery voltage | | |

◆ When Pn008.0=0 is set

The ALM signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored for four seconds. No alarm will be displayed even if the battery voltage drops below the specified value after these four seconds.

◆ When Pn008.0=1 is set

The ALM signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored continuously.






Figure 6-1 Alarm display timing chart

Battery replacement procedure when using an encoder cable with a battery unit:


- (1) Only turn on the control power supply of the servo unit.
- (2) Open the cover of the battery unit.



- (3) Remove the old battery and mount a new battery.



- (4) Close the cover of battery unit.



- (5) Turn OFF the power supply to the servo drive to clear the A.830 alarm(Encoder battery alarm).
- (6) Turn on the power supply to servo unit again.
- (7) Make sure that the alarm has been cleared and that the servo unit operates normally.

Note: If you remove the Battery or disconnect the encoder cable while the control power supply to the servo unit is OFF, the absolute encoder data will be lost.

6.1.2 Initialization of absolute encoder (when alarming)

CAUTION

- After performing the absolute encoder setting, the rotation amount data will be set to a value within the range of -2 to +2 rotations. As the reference position of the mechanical system will change, determine the reference position of the host controller based on the new position after the setting.
- If the machine is started without adjusting the position in the host controller, unexpected operation may cause personal injury or damage to the machine.

In the following cases, reset the absolute encoder:

- When starting the system for the first time.
- When "Encoder backup alarm (A.810)" occurs .
- When "Encoder checksum alarm (A.820)" occurs .
- When initializing the serial data of the absolute encoder rotation amount.

Perform basic initialization setting using Fn008.

• Initial setting steps:

- ① Press on the **(M)** panel key to select the Utility function Fn000, and the panel displays "**Fn000**".
- ② Press the **(↑)** or **(↓)** key , the panel displays "**Fn008**".
- ③ Press the **(S)** key for about 1 second, the panel displays "**PGCLI**".
- ④ Press the **(↑)** key until the bread shows "**PGCLS**". (If you press wrong key operation in the process, the panel will display "**□□□P**" flashing for about 1 second, and then returns to the utility function mode. Then please restart the operation from the beginning)
- ⑤ Press **(M)** key to start resetting the absolute encoder. After the resetting is completed, the panel will display "**□□□F**" flashing for about 1 second .
- ⑥ Return and the panel displays "**PGCLS**".
- ⑦ To make the setting active, please turn on the power again.

6.2 Position comparison output function

6.2.1 Function description

The position comparison function is to use the instantaneous position data to compare with the value stored in the data group in advance. When the comparison condition is satisfied, it will immediately output a DO signal with an adjustable pulse width for subsequent motion control.

Position comparison function: It can be selected to enable DO terminal output at high/low level. When enabled at high level, it is enabled when the corresponding DO terminal is connected to the common terminal, and it is disabled when it is disconnected from the common terminal; When enabled at low level, it is disabled when the corresponding DO terminal is connected

to the common terminal, and enabled when it is disconnected. There are a total of 4 DO outputs on the 730W.

Table 6-3 Function description

| Operating conditions of the position comparison output function | |
|-----------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| Control mode | All control modes |
| Other | The elements besides the control parameters are properly set, and the motor is operating normally |

6.2.2 Related objects

Table 6-4 Description table of related objects

| Parameter | Name | Unit | Description |
|-----------|-------------------------------------------------|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PN610 | Position comparison output function | — | 0: OFF (default setting); 1: Positive comparison; 2: Negative comparison; 3: Two-way comparison; |
| PN611 | First set position | Pulse | -1073741824~1073741823 |
| PN613 | Second set position | Pulse | -1073741824~1073741823 |
| PN615 | Third set position | Pulse | -1073741824~1073741823 |
| PN617 | 4th set position | Pulse | -1073741824~1073741823 |
| PN619 | Effective time of first position output signal | ms | 0~65535 |
| PN61A | Effective time of second position output signal | ms | 0~65535 |
| PN61B | Effective time of third position output signal | ms | 0~65535 |
| PN61C | Effective time of 4th position output signal | ms | 0~65535 |
| PN5B0.0~1 | DO1 output signal setting, signal assignment | — | 0: Undefined 10: Position compare output 1 (POSCMP1) 11: Position compare output 2 (POSCMP2) 12: Position compare output 3 (POSCMP3) 13: Position compare output 4 (POSCMP4) |
| PN5B.10~1 | DO2 output signal setting, signal assignment | — | 0: Undefined 10: Position compare output 1 (POSCMP1) 11: Position compare output 2 (POSCMP2) 12: Position compare output 3 (POSCMP3) 13: Position compare output 4 (POSCMP4) |
| PN5B2.0~1 | DO3 output signal setting, signal assignment | — | 0: Undefined 10: Position compare output 1 (POSCMP1) 11: Position compare output 2 (POSCMP2) 12: Position compare output 3 (POSCMP3) 13: Position compare output 4 (POSCMP4) |
| PN5B3.0~1 | DO4 output signal setting, signal assignment | — | 0: Undefined 10: Position compare output 1 (POSCMP1) 11: Position compare output 2 (POSCMP2) 12: Position compare output 3 (POSCMP3) 13: Position compare output 4 (POSCMP4) |
| PN5B4.0~1 | DO5 output signal setting, signal assignment | — | 0: Undefined 10: Position compare output 1 (POSCMP1) 11: Position compare output 2 (POSCMP2) 12: Position compare output 3 (POSCMP3) 13: Position compare output 4 (POSCMP4) |

| | | | |
|-----------|----------------------------------------------|---|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PN5B5.0~1 | DO6 output signal setting. signal assignment | — | 0: Undefined 10: Position compare output 1 (POSCMP1) 11: Position compare output 2 (POSCMP2) 12: Position compare output 3 (POSCMP3) 13: Position compare output 4 (POSCMP4) |
| PN5B6.0~1 | DO7 output signal setting. signal assignment | — | 0: Undefined 10: Position compare output 1 (POSCMP1) 11: Position compare output 2 (POSCMP2) 12: Position compare output 3 (POSCMP3) 13: Position compare output 4 (POSCMP4) |
| PN5B7.0~1 | DO8 output signal setting. signal assignment | — | 0: Undefined 10: Position compare output 1 (POSCMP1) 11: Position compare output 2 (POSCMP2) 12: Position compare output 3 (POSCMP3) 13: Position compare output 4 (POSCMP4) |

6.2.3 Function running

I. Function principle

Position comparison COMPARE is to use the instantaneous position data fed back by the servo to compare with the value stored in the target position array in advance. When the comparison condition is satisfied, it will immediately output a DO pulse signal (Number of DO and the pulse width can be configured), used for the follow-up motion control. Since the comparison is done inside the FPGA, no software data communication delay, and accurate comparison can also be done for high-speed motion axes.

Position comparison output function: When the value 0 of the position comparison output function Pn610 changes to 1/2/3, the comparison starts. When Pn610 becomes 0, the comparison ends immediately, and the current comparison status is cleared.

Position comparison output width: When the position comparison condition is satisfied, output DO active level signal, the width of the active level signal can be set through Pn619/Pn61A/Pn61B/Pn61C. Setting range: 0 ~ 65535 × 0.125 ms.

Target position comparison point: There are 4 target position comparison points in total, and the target position comparison value needs to be set to the Pn611/Pn613/Pn615/Pn617 target parameters in advance.

II. Functional operation




Figure 6-2 Operation chart

When Pn610 is set to 1- positive comparison output, when the axis passes the target position comparison point and the position relationship changes from low to high, DO outputs position comparison signal.

When Pn610 is set to 2- negative comparison output, when the axis passes the target position comparison point and the position relationship changes from low to high, DO outputs position comparison signal.

When Pn610 is set as 3- two-way comparison output, the signal output is independent of passing direction of the axis. When the target position comparison point is passed and the position relationship changes, DO outputs a position comparison signal.

6.3 Gravity compensation function

When the Servo motor is used with a vertical axis, gravity compensation prevents the moving part from falling due to the machine's own weight when the brake is released.




Figure 6-3 Operating diagram

A timing chart for when the moving part is raised then lowered is provided below.

For details of the brake operating time, please refer to the following chart.




Figure 6-4 Brake application timing chart

6.3.1 Required parameters setting

To use the gravity compensation function, the following parameters are required.

Table 6-5 Parameter setting

| Parameter | Function | | | When enabled |
|---------------|------------------------------|------|---------------|----------------|
| PN 609.bit5=0 | Disable gravity compensation | | | After restart |
| PN 609.bit5=1 | Enable gravity compensation | | | |
| PN 476 | Setting range | Unit | Default value | Classification |
| | -1000 ~ 1000 | 0.1% | 0 | Immediately |

6.3.2 Operating procedure for gravity compensation

The operating procedure of the gravity compensation function are as follows:

1. Set Pn609.1 = 2 (Enable gravity compensation).
2. To enable changes to the settings, turn the power of the servo unit OFF and ON again.
3. Use the Y7 host controller software HCServoWorks.Y7 to find the torque command value when the motor is stopped with the servo ON
4. Set the torque command value found in step 3 in Pn476 (Gravity Compensation Torque).
5. Turn servo ON/servo OFF several times, and fine-tune Pn476, so that the moving part of machine does not fall.

6.3.3 Operation steps of the automatic update gravity compensation function

The operation steps of the automatic update gravity compensation function are as follows:

| Parameter | Function | | | When enabled |
|---------------|--------------------------------------------------------------------------|------|---------------|----------------|
| PN 609.bit5=0 | Do not use the gravity compensation function | | | After restart |
| PN 609.bit5=1 | Do not update automatically | | | |
| PN631.0=0 | Do not update automatically | | | Immediately |
| PN631.0=1 | Update automatically, and the data will be stored when the power is off. | | | |
| PN631.0=2 | Update automatically, and the data will be stored when the power is off. | | | |
| PN 476 | Setting range | Unit | Default value | Classification |
| | -1000 ~ 1000 | 0.1% | 0 | Immediately |

1. Set PN609 = H0020;
When Bit5 = 0, the gravity compensation function is turned off.
When Bit5 = 1, the gravity compensation function is turned on.
Then set PN476 (Gravity compensation value: -1000 - 1000).
2. Set PN631.0 = 0: Do not automatically update PN476 (the default value is 0).
3. Set PN631.0 = 1: Automatically update. When power is on, automatically update the gravity compensation value of PN476, and when power is off, it will be re-initialized to the set value.
4. Set PN630.0 = 2: Automatically update. When power is on, automatically update the gravity compensation value of PN476, and store the value when power is off.

6.4 Forced DO function

6.4.1 Function description

There's two offline DO default options for EtherCAT forced DO state in non-OP state (including offline).

1. Offline holding state: The servo is switched to non-OP state and the DO is forced to maintain the state before disconnection.
2. Initialization state: When the servo is in non-OP state, disable the DO.

When the network is switched to OP, the forced DO is jointly determined by 60FE.01h/60FE.02h.

Select the forced DO function by bit. Select DO bit by bit as EtherCAT forced DO, which supports part of DO is local function, and part of is EtherCAT forced output function. Y7S has 4 forced DO outputs, which can be monitored through the panel Un006, and DO status can also be monitored through the monitoring panel of the host computer.

6.4.2 Related objects

Table 6-6 Parameter table of related objects

| Parameter No. | Signal | Setting range | Unit | Default value | When enabled | Classification | Reference | |
|----------------------------------------------------------|---------------------------|-------------------------------------|--------|---------------|---------------|----------------|-----------|--|
| Pn080 (2080h) | DO1 output signal setting | 0000H - 53FFH | — | 1004H | After restart | Setup | — | |
| | | | | | | | | |
| | Signal Assignment | | | | | | | |
| | 15 | User-defined signal 1 (USER1) | | | | | | |
| | 16 | User-defined signal 2 (USER2) | | | | | | |
| | 17 | User-defined signal 3 (USER3) | | | | | | |
| | Polarity Control | | | | | | | |
| | 0 | Signal not inverted (same polarity) | | | | | | |
| | 1 | Signal inverted (opposite polarity) | | | | | | |
| | 2 | Forced inactive | | | | | | |
| 3 | Forced active | | | | | | | |
| Not used | | | | | | | | |
| 0 | Not used | | | | | | | |
| 1 | A axes | | | | | | | |
| 2 | B axes | | | | | | | |
| 3 | C axes | | | | | | | |
| 4 | D axes | | | | | | | |
| 5 | All axes | | | | | | | |
| Pn5B1 | DO2 output signal setting | 10 ~ 20000 | 0.1Hz | 400 | Immediately | Tuning | — | |
| Same as PN5B0 DO1 input signal setting signal assignment | | | | | | | | |
| Pn5B2 | DO3 output signal setting | 15 ~ 51200 | 0.01ms | 2000 | Immediately | Tuning | — | |
| Same as PN5B0 DO1 input signal setting signal assignment | | | | | | | | |
| Pn5B3 | DO4 output signal setting | 10 ~ 20000 | 0.1/s | 400 | Immediately | Tuning | — | |
| Same as PN5B0 DO1 input signal setting signal assignment | | | | | | | | |

| | | | | | | | |
|-------|----------------------------------------------------------|------------|--------|------|-------------|--------|---|
| Pn5B4 | DO5 output signal setting | 0 ~ 20000 | 1% | 100 | Immediately | Tuning | — |
| | Same as PN5B0 DO1 input signal setting signal assignment | | | | | | |
| Pn5B5 | DO6 output signal setting | 10 ~ 20000 | 0.1Hz | 400 | Immediately | Tuning | — |
| | Same as PN5B0 DO1 input signal setting signal assignment | | | | | | |
| Pn5B6 | DO7 output signal setting | 15 ~ 51200 | 0.01ms | 2000 | Immediately | Tuning | — |
| | Same as PN5B0 DO1 input signal setting signal assignment | | | | | | |
| Pn5B7 | DO8 output signal setting | 10 ~ 20000 | 0.1/s | 400 | Immediately | Tuning | — |
| | Same as PN5B0 DO1 input signal setting signal assignment | | | | | | |

6.4.3 Instructions

1. Set the bit of Pn5B0~Pn5B7 to select the corresponding DO output.
2. Configure 60FE.01h/60FE.02h as RPDO and operate bit0~bit3(Set bit0 to 1 as USER1 output, Set bit 2 to 1 as USER2 output, set bit3 to 1 as USER3 output) to control DO output.

6.5 Software position limit function

6.5.1 Function description

In the traditional way, the limit position can only be given by an external signal, by connecting the external sensor signal to the CN1 interface of the servo drive.

Table 6-7 Comparison of advantages and disadvantages of hardware limit and software limit

| Software limit | | Software limit | |
|----------------|-------------------------------------------------------------------------------|----------------|--------------------------------------------------------------------------------------------------|
| 1 | Can be only limited to linear motion, single-turn rotary motion | 1 | Can be used not only in linear motion but also in rotary mode |
| 2 | Requires external equipment to install mechanical limit switches | 2 | No hardware wiring is required to prevent the poor contact of the line from causing misoperation |
| 3 | Unable to judge mechanical slippage abnormality | 3 | Internal position comparison to prevent movement caused by mechanical slippage abnormal |
| 4 | When power off, unable to judge or alarm after machine moves out of the limit | | |

The software limit function refers to the comparison between the internal position feedback of the drive and the set limit value, and when the limit value is exceeded, a warning will be issued immediately and the shutdown operation will be executed. This function is available in both absolute position mode and incremental position mode.

6.5.2 Related objects

Table 6-8 Related objects parameters

| PN781.bit0 | Signal | Unit | Value range | Default value | When enabled |
|-------------------------|-----------------------|------|-------------|---------------|---------------|
| | Software limit switch | — | 0-1 | 0 | After restart |
| 0: Disabled; 1: Enabled | | | | | |

Table 6-9 Software limit description

| Object 607Dh: Software limit | | | |
|------------------------------|-------------------|---------------------------|-----------------|
| Objects description | | Objects entry description | |
| Item | Value | Item | Value |
| Index | 607D _n | Subindex | 00 _h |

| | | | |
|----------------|-----------------------------------|------------------|-------|
| Signal | Number of software limit subindex | Access | Rw |
| Data structure | / | PDO mapping type | RxPDO |
| Data type | Uint8 | Data range | 0~512 |
| Control mode | ALL | Default value | 2 |

| Objects description | | Objects entry description | |
|---------------------|------------------------------|---------------------------|------------------------|
| Item | Value | Item | Value |
| Index | 607D _n | Subindex: | 01 _h |
| Signal | Min. Software position limit | Access | Rw |
| Data structure | / | PDO mapping type | RxPDO |
| Data type | Sint32 | Data range | -2147483648~2147483647 |
| Control mode | ALL | Default value | -2147483648 |

Software limit function:

Bit0 of Pn781 is software limit switch;

0: Disabled;

1: Enabled;

Software limit function is enabled After restart;

Set the min. Value of software absolute position limit. When set to -2147483648, indicates no min software limit in negative direction = (607D-01h).

| Item | Value | Item | Value |
|----------------|------------------------------|------------------|------------------------|
| Index | 607D _n | Subindex: | 02h |
| Signal | Max. software position limit | Access | Rw |
| Data structure | / | PDO mapping type | RxPDO |
| Data type | Sint32 | Data range | -2147483648~2147483647 |
| Control mode | ALL | Default value | -2147483648 |

Software limit function:

Bit0 of Pn781 is software limit switch;

0: Disabled;

1: Enabled;

Software limit function is enabled After restart;

Set the max. Value of software absolute position limit. When set to 2147483648, indicates no max software limit in positive direction = (607D-02h).

6.5.3 Instructions

The software limit function refers to the comparison between the internal position feedback and the set limit value, when the limit value is exceeded, a warning will be issued immediately and shutdown will be executed. In the profile position mode, cyclic synchronous position mode, when the target position setting value is out of the software limit value, bit11 of the status word 06041 becomes TRUE and the drive runs with the limit value as the target position and prompts positive limit (..POT)/negative limit(..NOT) warning, the drive stops according to the set overtravel stop mode. In other modes, when the position feedback 6064 is out of the software limit value, the drive will prompt a limit warning in the corresponding direction, and stops according to the set overtravel mode.

When 2781h=0, software limit function cannot be enabled.

When 2781h=1, software limit function is enabled After restart.

(607D-01h) min. software absolute position limit;

(607D-01h) max. software absolute position limit;

Note: 1. Ensure $607D-01 \leq 607D-02$, if $607D-01 > 607D-02$ is set, .9B0 error (max. software position limit less than the min.) will be prompted on drive.

2. Ensure the value of 607C (home offset) is in the range of max. software limit and min. software limit, otherwise .9B1 error(home offset is out of the software limit) will be prompted on drive.

6.6 Modulus function

In absolute system, if Pn781.1=1, modulus mode is enabled. Meanwhile set the max. value of the modulus position of Pn78A, then the count value of 6064 can only be counted from 0 to the set value. It is enabled After restart.

Table 6-10 Modulus function description

| | Signal | Unit | Value range | Default value | When enabled |
|------------|--------------------------------------|------|--------------|---------------|-----------------|
| PN781.bit1 | Modulus switch | — | 0~1 | 0 | After power off |
| | | | | | |
| PN78A | Modules function max. position limit | — | 0-2147483648 | 0 | After restart |




Figure 6-5 6064 waveform diagram after modulus enabled

Instructions:

1. When PN781.1 = 1, the modulo function is enabled. Consequently, the calculated value of 6064 can only be counted within the range from 0 to one less than the upper limit of the modulo value.
2. Set PN002.2 = 0 to utilize an absolute encoder.
3. The upper limit value of the modulo function for PN78A ranges from 0 to 4294967296. This setting will come into effect after power-off.
4. When PN790.3 = 2, all parameters should be written to the EEPROM. This measure is taken to prevent the position from changing after powering off and then on again. Such a change might occur due to the loss of the value of 607C when homing is carried out under the circumstance of multi-turn value overflow while the modulo function is in use.

6.7 Touch probe function

Touch probe function is for the servo drive records the position information and saves it to the designated register when the servo driver changes according to the externally specified DI signal or the motor Z signal. 730W servo drive supports 8 touch probes function(2 touch probes each axis). The falling edge of the Z signal is not currently supported.

The steps to use touch probe function are as follows:

1. Set the touch probe trigger DI signal: 730W servo drive designates A axis: DI3, DI4, B axis: DI8, DI9, C axis: DI3, DI4 and D axis: DI8, DI9 as the input DI of probe 0 and probe 1 for each axis, and the corresponding DI pins of probe 0 and probe 1 are D axis: 13, 14, C axis: 20, 21, B axis: 25, 26 and A axis: 31, 32 respectively;

2. Set the touch probe function(60B8h) code

The meanings of each bit of touch probe function (60B8h) and touch probe status word (60B9h) are shown in Table 6-17.

Table 6-11 Touch probe function code

| Bit | Touch probe function (60B8h) | Touch probe status word (60B9h) |
|-----|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Enable touch probe 0 0: Disabled 1: Enabled | Enable touch probe 0 0: Disabled 1: Enabled |
| 1 | Touch probe 0 trigger mode 0: Trigger for once(60B8h need to set to 0) 1: Continuous triggering | Touch probe 0 rising edge latch 0: Rising edge latch of touch probe 0 not implemented 1: Rising edge latch of touch probe 0 is implemented |
| 2 | Touch probe 0 trigger signal selection 0: Triggered by DI3 1: Triggered by Z signal | Touch probe 1 falling edge latch 0: Falling edge latch not implemented 1: Falling edge latch is implemented |
| 3 | Reserved | Reserved |
| 4 | Touch probe 0 rising edge latch 0: Disabled 1: Enabled | Reserved |
| 5 | Touch probe 0 falling edge latch 0: Disabled 1: Enabled | Reserved |
| 6 | Reserved | Touch probe 0 trigger signal selection 0: Triggered by DI3 1: Triggered by Z signal |
| 7 | Reserved | Touch probe 0 trigger DI level selection 0: DI3 is low level 1: DI4 is high level |
| 8 | Enable touch probe 1 0: Disabled 1: Enabled | Enable touch probe 1 0: Disabled 1: Enabled |
| 9 | Touch probe 1 trigger mode 0: Trigger for once(60B8h need to set to 0) 1: Continuous triggering | Touch probe 1 rising edge latch 0: Rising edge latch of touch probe 1 not implemented 1: Rising edge latch of touch probe 1 is implemented |
| 10 | Touch probe 1 trigger signal selection 0: Triggered by DI4 1: Triggered by Z signal | Touch probe 1 falling edge latch 0: Falling edge latch of touch probe 1 not implemented 1: Falling edge latch of touch probe 1 is implemented |
| 11 | Reserved | Reserved |
| 12 | Touch probe 1 rising edge latch 0: Disabled 1: Enabled | Reserved |
| 13 | Touch probe 1 falling edge latch 0: Disabled 1: Enabled | Reserved |
| 14 | Reserved | Touch probe 1 trigger signal selection 0: Triggered by DI5 1: Triggered by Z signal |

| | | |
|----|----------|-----------------------------------------------------------------------------------------|
| 15 | Reserved | Touch probe 1 trigger DI level selection 0: DI4 is low level 1: DI4 is high level |
|----|----------|-----------------------------------------------------------------------------------------|

For example, to use axis A probe 0 and probe 1 with both rising and falling edges, with DI (taking DI3 and DI4 as examples) single trigger, set 60B8h = 3131h (decimal representation: 12593). Then, on the rising edge of the DI3 and DI4 signals, the values of 60BAh and 60BCh will be updated; on the falling edge of the DI3 and DI4 signals, the values of 60BBh and 60BDh will be updated.

Note: If you wish to trigger again, you need to set 60B8h = 0, then set 60B8h = 3131h again. Commonly used object dictionaries for the probe function are shown in Table 6-18.

Table 6-12 Related touch probe function

| Object dictionary | Meaning |
|-------------------|----------------------------------------------|
| 60B8h | Touch probe function |
| 60B9h | Touch probe status word |
| 60BAh | Touch probe 0 rising edge position feedback |
| 60BBh | Touch probe 0 falling edge position feedback |
| 60BCh | Touch probe 1 rising edge position feedback |
| 60BDh | Touch probe 1 falling edge position feedback |

6.8 Safety function

◆ Safe torque off (STO)

To protect operator from injured by moving parts and lowering the risk of operating the machine, the servo unit is built in with safety function. Especially in the case that the shield must be opened during the maintenance, the safety function is able to prevent the machine from making dangerous movements.

6.8.1 Hard wire base block (HWBB) function

The hard wire base block function (hereinafter referred to as HWBB function) refers to the safety function of shutting off the motor current through hard wire circuit.

The drive signals to the Power Module that controls the motor current are controlled by the circuits that are independently connected to the two input signal channels to turn OFF the power module and shut OFF the motor current. Please refer to the figure in the following.




Figure 6-6 Hard wire base block function

Note: For safety function signal connections, the input signal is the 0-V common and the output signal is a source output. This is opposite to other signals described in this manual. To avoid confusion, the ON and OFF status of signals for the safety function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

I. Risk assessment

Using the HWBB function, be sure to perform a risk assessment of the equipment to confirm that the safety level of the standards is satisfied.

Even if the HWBB function is effective, the following risks still exist, please be sure to consider the safety of the following factors in the risk assessment.

- The servo motor will move if an external force is applied to it (for example, gravity on a vertical axis). Implement measures to hold the servo motor, such as installing a separate mechanical brake.
- If a failure occurs such as a power module failure, the servo motor may move within an electric angle of 180. Check if there's a risk of danger.

The rotational angle or travel distance depends on the type of servo motor as follows.

Rotary servo motor: 1/6 rotation max (rotational angle calculated at the motor shaft).

Direct drive motor: 1/20 rotation max (rotational angle calculated at the motor shaft).

- The HWBB does not shut OFF the power to the servo unit or electrically isolate it. Implement measures to shut OFF the power supply to the servo unit before you perform maintenance on it.

II. Hard wire base block state (HWBB state)

The status of the servo unit when the hard wire base block function is running is as follows. When the /HWBB1 or /HWBB2 signal is OFF, the HWBB function of the servo unit will operate and the servo unit will enter the hard wire base block state (hereinafter referred to as the HWBB state).




Figure 6-7 Hard wire base block state timing chart

III. Resetting the HWBB state

Normally, after the /S-ON signal is turned OFF and power is no longer supplied to the servo motor, the /HWBB1 and /HWBB2 signals will turn OFF and the servo unit will enter the HWBB state. If you turn ON the /HWBB1 and /HWBB2 signals in this state, the servo unit will enter a base block (BB) state and will be ready to acknowledge the /S-ON signal.




Figure 6-8 Hard wire base block state timing chart

If the /HWBB1 and /HWBB2 signals are OFF and the /S-ON signal is input, the HWBB state will be maintained even after the /HWBB1 and /HWBB2 signals are turned ON.

Turn OFF the /S-ON signal to place the servo unit in the BB state and then turn ON the /S-ON signal again.




Figure 6-9 State reset timing chart

Note: 1. If the servo unit is placed in the BB state while the main circuit power supply is OFF, the HWBB state will be maintained until the /S-ON (Servo ON) signal is turned OFF.

2. If the /S-ON (Servo ON) signal is set to be always active(Pn50A.1), you cannot reset the HWBB state. Do not set this value if you are using the HWBB.

IV. Detecting errors in HWBB signal

If only the /HWBB1 or /HWBB2 signal is input, a safety function signal input timing error (A.Eb1) alarm will occur. This makes it possible to detect failures, such as disconnection of an HWBB signal.

Note: The A.Eb1 alarm (Safety function signal input timing error) is not a safety-related element. Keep this in mind when you design the system.

(五). Connection example and specifications of input signal (HWBB signal)

The input signal must be connected to the two input signal channels. The connection example and specifications of the input signal (HWBB signal) are as follows:

Note: For safety function signal connections, the input signal is the 0-V common and the output signal is a source output. This is opposite to other signals described in this manual. To avoid confusion, the ON and OFF status of signals for the safety function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

Input signal (HWBB signal) connection example:




Figure 6-10 HWBB input signal connection example


Table 6-13 Input signal (HWBB signal) specifications

| Type | Name | Connector | Remarks | Meaning |
|-------|--------|-----------|-------------|------------------------------------------------------------------|
| Input | /HWBB1 | CN3-4 | ON (closed) | HWBB function is not active (normal) |
| | | CN3-3 | OFF (open) | HWBB function is active (requires to shut OFF the motor current) |
| | /HWBB2 | CN3-6 | ON (closed) | HWBB function is not active (normal) |
| | | CN3-5 | OFF (open) | HWBB function is active (requires to shut OFF the motor current) |

Table 6-14 Input signal (HWBB signal) electrical characteristics

| Item | Characteristic | Remarks |
|-----------------------|----------------|---------------------------------------------------------------------|
| Internal resistance | 4.7kΩ | - |
| Working voltage range | +11V ~ +25V | - |
| Maximum delay time | 20ms | The interval between /HWBB1 and /HWBB2 OFF and HWBB function starts |

If an HWBB is requested by turning OFF the two HWBB input signal channels (/HWBB1 and /HWBB2), the power supply to the servo motor will be turned OFF within 20 ms.



Note: 1. The OFF status is not recognized if the OFF interval of the /HWBB1 or /HWBB2 signal is 0.5 ms or shorter.

2. You can check the status of the input signals by using monitor displays. For details, refer to "Safety input signal monitoring".

VI. When running through the utility function

The HWBB function is also available when running through Utility functions.

However, under the following Utility functions, the /HWBB1 and /HWBB2 signals are OFF. Even if the /HWBB1 and /HWBB2 signals are turned ON during the operation of the Utility functions, the operation will not work. Please exit utility function and enter again to restart

- Jogging(Fn002)
- Origin search (Fn003)
- Program jogging (Fn004)
- Advanced auto tuning (Fn201)
- EasyFFT (Fn206)
- Adjustment of motor current detection signal offset (Fn00E)

VII. Servo ready output (/S-RDY) signal

The /S-ON (Servo ON) signal will not be acknowledged in the HWBB state, so the servo ready output will turn OFF.

The servo ready output signal will turn ON if both the /HWBB1 and /HWBB2 signals are ON and the /S-ON signal is turned OFF.

An example is provided below for when the main circuit power supply is ON and the SEN signal turns ON when there is no servo alarm. (An absolute encoder is used in this example.)




Figure 6-11 Servo ready output (/S-RDY) timing chart

(八). Brake signal (/BK)

If the HWBB operates when the /HWBB1 or /HWBB2 signal is OFF, the /BK (Brake) signal will turn OFF. At that time, the setting in Pn506 (Brake reference - servo OFF delay time) will be disabled. Therefore, the servo motor may be moved by external force until the actual brake becomes effective after the /BK signal turns OFF.

Note: Since the brake signal output is not a safety function, please ensure that no danger will occur even if the brake signal fails in the HWBB state when designing the system. In addition, please note that the brake of the servo motor is for fixing but not stopping the motor.

IX. Dynamic brake

When activate dynamic brake through Selection of Stopping Method at Servo OFF (Pn001.0), the dynamic brake will stop the servo motor after the /HWBB1 or /HWBB2 signal is OFF and the HWBB function is operating.

Note: 1. The dynamic brake is not a safety-related element. You must design the system so that a hazardous condition does not occur even if the servo motor coasts to a stop in the HWBB state. Normally, we recommend that you use a sequence that returns to the HWBB state after stopping for a reference.

2. If the application frequently uses the HWBB, stopping with the dynamic brake may result in the deterioration of elements in the servo unit. To prevent internal elements from deteriorating, use a sequence in which the HWBB state is returned to after the servo motor has come to a stop.

X. Servo alarm output signal (ALM)

The servo alarm output signal (ALM) cannot be output in the HWBB state.

6.8.2 Validating safety functions

When you commission the system or perform maintenance or servo unit replacement, you must always perform the following validation test on the HWBB function after completing the wiring

When the /HWBB1 and /HWBB2 signals turn OFF, confirm that the panel operator displays "9b8" and that the servo motor does not operate.

Monitor the ON/OFF status of the /HWBB1 and /HWBB2 signals via Un015.

If the ON/OFF status of the signals do not coincide with the display, the following must be considered: an error in the external device, disconnection of the external wiring, short-circuiting in the external wiring, or a failure in the servo unit. Find the cause and correct the problem.

Confirm that the EDM1 signal is OFF while in normal operation by using the feedback circuit input display of the connected device.

6.8.3 Safety precautions when using the security function

• To confirm that the HWBB function satisfies the safety requirements of the system, you must conduct a risk assessment of the system. Incorrect use of safety function may cause injury.

• The servo motor will move if there is an external force (e.g., gravity on a vertical axis) even when the HWBB function is operating. Use a separate means, such as a mechanical brake, that satisfies the safety requirements. Incorrect use of the safety function may cause injury.

• While the HWBB function is operating, the servo motor may move within an electric angle of 180° or less as a result of a servo drive failure. Use the HWBB function for an application only after confirming that movement of the servo motor will not result in a hazardous condition. Incorrect use of the safety function may cause injury.

• Dynamic brake • The dynamic brake and the brake signal are not safety-related elements. You must design the system so that servo drive failures will not cause a hazardous condition while the HWBB function is operating. Incorrect use of the safety function may cause injury.

• Connect devices that satisfy the safety standards for the signals for safety functions. Incorrect use of the safety function may cause injury.

When using the HWBB function as an emergency stop function, please use an electrical mechanical part separately to cut off the power to the motor. Incorrect use of the safety function may cause injury.

• The HWBB function does not shut OFF the power to the servo drive or electrically isolate it. Implement measures to shut OFF the power supply to the servo drive before you perform maintenance on it. There is a risk of electric shock.

6.9 Soft start

The soft start function takes a stepwise speed command input and applies the specified acceleration/deceleration rates to convert it to a trapezoidal speed reference. Acceleration time and deceleration time can be set.




Figure 6-12 Soft start speed command and servo motor rate

Table 6-15 Soft start parameter setting table

| PN305 | Soft start acceleration time | | | Speed | When enabled | Classification |
|-------|------------------------------|------|---------------|-------------|--------------|----------------|
| | Setting range | Unit | Default value | | | |
| | 0-65535 | 1ms | 0 | Immediately | | |
| PN306 | Soft start deceleration time | | | Speed | When enabled | Classification |
| | Setting range | Unit | Default value | | | |
| | 0-65535 | 1ms | 0 | Immediately | | |

Pn305: The time required for the servo motor to accelerate from a stopped state to the maximum motor speed.

Pn306: The time required for the servo motor to decelerate from the maximum motor speed to a stopped state.

The actual acceleration and deceleration time is calculated by the following formula.

Actual acceleration time = Target speed / 1000 x Soft start(Acceleration speed Pn305)

Actual deceleration time = Target speed / 1000 x Soft start(Acceleration speed Pn306)




Figure 6-13 Pn305 and Pn306 command acceleration/deceleration time


6.10 Smooth function

Apply a filter to the pulse input command to make command smoother.

| | | | | | |
|-------|------------------------------------------------------------|-------|---------------|--------------|----------------|
| Pn216 | Position reference acceleration/deceleration time constant | | Speed | When enabled | Classification |
| | Setting range | Unit | Default value | Immediately | Setup |
| | 0-65535 | 0.1ms | 0 | | |
| Pn217 | Position command moving average time | | Speed | When enabled | Classification |
| | Setting range | Unit | Default value | Immediately | Setup |
| | 0-10000 | 0.1ms | 0 | | |

Pn216 and Pn217 functions are as follows:

Table 6-16 Timing difference between Pn216 and Pn217



6.11 Alarm delay disabling function

After the servo alarms, the delay disabling switch can be turned on by setting pn609.bit7 to 1. Then, the time can be set via PN60D to delay the disabling.

Table 6-17 Parameters table of alarm delay disabling function

| Parameter | | Meaning | When enabled | Classification | |
|----------------------------------------------|-----------------------------|----------|---------------|----------------|----------------|
| PN609.bit7 (Alarm delay disabling switch) | 0 (Default value) | Turn off | After restart | Setup | |
| | 1 | Turn on | | | |
| PN60D | Alarm delay disabling count | | | When enabled | Classification |
| | Setting range | Unit | Default value | After restart | Setup |
| | 0-200 | 2ms | 0 | | |

Steps:

1. Set PN609 = H0080.


When Bit7 = 0, the delay disabling function is turned off.

When Bit7 = 1, the delay disabling function is turned on.

2. Set the disabling delay time in PN60D: The value ranges from 0 to 200, with the unit being 2 ms. Set it according to the actual situation.

Chapter 7 Tuning

| | | |
|-------|-------------------------------------------------------------------------|-----|
| 7.1 | About tuning..... | 178 |
| 7.1.1 | Basic tuning method..... | 178 |
| 7.1.2 | Safety precautions at tuning..... | 179 |
| 7.2 | Tuning-less function..... | 181 |
| 7.2.1 | About the tuning-less function..... | 181 |
| 7.2.2 | Tuning-less value setting (Fn200)..... | 183 |
| 7.2.3 | Related parameters..... | 184 |
| 7.3 | Advanced auto-tuning 1 - by HCServoWorks internal position command..... | 184 |
| 7.3.1 | About auto-tuning 1..... | 186 |
| 7.3.2 | Precautions for advanced auto-tuning 1..... | 188 |
| 7.4 | Advanced auto-tuning 2 - via host controller position commands..... | 189 |
| 7.4.1 | About advanced auto-tuning 2..... | 191 |
| 7.4.2 | Precautions for advanced auto-tuning 2..... | 192 |
| 7.5 | One-parameter tuning..... | 193 |
| 7.5.1 | About one-parameter tuning..... | 193 |
| 7.5.2 | Operation steps for one-parameter tuning..... | 194 |
| 7.6 | Supplements for auto-tuning..... | 194 |
| 7.6.1 | Supplements for function..... | 194 |
| 7.6.2 | Related parameters..... | 196 |
| 7.7 | Adjust anti-resonance control function..... | 197 |
| 7.7.1 | About adjust anti-resonance control function..... | 197 |
| 7.7.2 | Operation steps of anti-resonance control function..... | 198 |
| 7.7.3 | Related parameters..... | 198 |



| | | |
|-------------|------------------------------------------------------------|------------|
| 7.8 | Vibration suppression function | 198 |
| 7.8.1 | About the vibration suppression function | 198 |
| 7.8.2 | Precautions for vibration suppression function | 199 |
| 7.8.3 | Related parameters | 200 |
| 7.9 | Adjustment application function..... | 201 |
| 7.9.1 | Gain switching | 201 |
| 7.9.2 | Manual adjustment of friction compensation..... | 204 |
| 7.9.3 | Current control mode selection function | 205 |
| 7.9.4 | Current gain value setting function | 205 |
| 7.9.5 | Speed detection method selection..... | 206 |
| 7.10 | Other adjustments functions | 206 |
| 7.10.1 | Feedforward | 206 |
| 7.10.2 | Setting mode switch (P control/PI control switching) | 206 |
| 7.10.3 | Torque command filter..... | 207 |

7.1 About tuning

Tuning is used to optimize the response of the servo system through multiple parameters (speed loop gain, position loop gain, filter, friction compensation, moment of inertia ratio, etc.). Therefore, when setting the servo gain, you have to consider the balance between the setting values of various parameters.

The default setting of the servo gain is stable. According to the status of the user's machine, the following auxiliary functions can be used to adjust the servo gain to further improve response. Advanced auto-tuning function is the latest gain control algorithm of 730W series servo drive. After using this function, the above-mentioned parameters will be automatically adjusted.

Therefore, it is usually not necessary to adjust separately.

7.1.1 Basic tuning method

The table below provides a description of the auxiliary functions related to the adjustment. Please select according to the status and operating conditions of the machine you are using.

Table 7-1 Auxiliary functions

| Auxiliary functions | Overview | Available control mode | Operating tool | |
|-----------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|----------------|--------------|
| | | | Panel operator | HCServoWorks |
| Tuning-less (Fn200) | The setting of this function is invalid by default. If need to use this function, please set Pn170.0=1. Stable response can be obtained regardless of the type of machinery and load fluctuations. | Speed control Position control | √ | √ |
| Advanced auto-tuning 1 (Internal command) | When the automatic gain tuning function 1 is on, the servo drive will perform the following automatic adjustments. (recommended to use this function) <ul style="list-style-type: none"> • Moment of inertia ratio • Gain (position loop gain, speed loop gain, etc.) • Filter (torque command filter, notch filter) • Friction compensation • Adjust Anti-resonance Control • vibration suppression | Speed control Position control | x | √ |
| Advanced auto-tuning 2 (Host controller command) | When the automatic gain tuning function 2 is on, the position command is input from the upper device, and the following automatic adjustments are performed. <ul style="list-style-type: none"> • Gain (position loop gain, speed loop gain, etc.) • Filter (torque command filter, notch filter) • Friction compensation • Adjust Anti-resonance Control • vibration suppression | Position control | x | √ |
| One-parameter tuning | Input the position command or speed command from the host device, and perform the following adjustments. <ul style="list-style-type: none"> • Gain (position loop gain, speed loop gain, etc.) • Filter (torque command filter, notch filter) • Friction compensation • Adjust Anti-resonance Control | Speed control Position control | △ | √ |

| | | | | |
|----------------------------------------|-----------------------------------------------------|-----------------------------------|---|---|
| Adjust anti-resonance control function | To suppress vibration of 100~1000Hz | Speed control Position control | x | √ |
| Vibration suppression function | To suppress aftershock generated during positioning | Position control | x | √ |

√ : Operable △ : Operable, but some functions are limited × : Not operable

7.1.2 Safety precautions at tuning

When making adjustments, be sure to observe the following precautions.

- Do not touch the rotating part of the motor while the servo is ON and the servo motor is running.
- When the servo motor is running, please make sure it can be stopped in an emergency at any time.
- Make adjustments after confirming that the test run is completed normally.
- To ensure safety, install a stop device on the machine side.

When making adjustments, please set the protection functions shown in the following items (1) to (5) under appropriate conditions.

(1) Overtravel setting

Please set the overtravel. For details, refer to "Section 5.4.3 Overtravel setting".

(2) Torque limit setting

The torque limit function is a function that calculates the torque required for machine operation and limits the output torque so that it does not exceed the setting range. Shock can be reduced in the event of mechanical failure such as interference or collision. If the torque is lower than the value required for operation, overshoot or vibration may occur.

(3) Set the alarm value of excessive position deviation

The excessive position deviation alarm is an effective protection function when the servo drive is used for position control.

When the servo motor action does not match the command, by setting an appropriate alarm value for excessive position deviation, the error can be detected and the servo motor will stop running.

The position deviation refers to the difference between the value of position command and the actual position.

Relationship between the position loop gain (Pn102) and the motor speed below.

① Please refer to "Section 5.6 Electronic gear ratio".

The calculation example when Pn102=400 Pn78C / Pn78E = 1 / 1

$Pn520 = 600 / 60 \times 1048576 / (400 / 10) \times 1 / 1 \times 2 = 2621440 \times 2$

$= 5242880 (Pn520 \text{ Default value}) \times (1.2 \sim 2)$

② When confirming the setting value of Pn102, please set the parameter display to "Display all parameters" (Pn00B.0 = 1).

Position deviation "Command unit" = Max. Motor speed[rpm] / 60 × Encoder resolution*1 / ((Pn102 [0.1 / s]) / 10 * 2) × Pn78C / Pn78E

Alarm value for excessive position deviation (Pn 520) [setting unit: 1 command unit]

$Pn520 > \text{Max. Motor speed[rpm]} / 60 \times \text{Encoder resolution} * 1 / (Pn102 [0.1 / s] / 10 * 2) \times Pn78C / Pn78E \times (1.2 \sim 2)$

" ×(1.2 ~ 2)" in the double underlined part is the surplus coefficient to avoid frequent occurrence of excessive position deviation alarm (A.d00).

As long as make the setting as above, the excessive position deviation alarm will not occur during normal operation.

When a position deviation occurs because the motor action does not match the command, an abnormal situation will be detected and the motor will stop running.

When the acceleration and deceleration of the position command exceeds the tracking capability of the servo motor, the position deviation cannot satisfy the above relational expression. Please reduce the acceleration and deceleration of the position command to the value that the motor can track, or increase the alarm value of excessive position deviation.

Table 7-2 Parameters for setting the alarm value of excessive position deviation

| Pn520 | Position deviation overflow alarm level | | | When enabled | Classification |
|-------|-----------------------------------------|----------------|---------------|--------------|----------------|
| | Setting range | Unit | Default value | | |
| | 1 ~ 1073741823 | 1 command unit | 219895614 | | |

Table 7-3 Alarm No.

| Alarm number | Name | Content |
|--------------|-----------------------------|--------------------------------------------------------------------------------------------------------------|
| A.d00 | Position deviation overflow | The alarm displayed when the position deviation exceeds the position deviation overflow alarm level (Pn520). |

(4) Set the vibration detection function

Set an appropriate value for the vibration detection function. For details, refer to "Section 8.14 Initialize vibration detection level (Fn01B)".

(5) Set the position deviation excessive alarm value when the servo is ON

If the position deviation is accumulating and turn on the servo, the servo motor will return to the original position in order to make the position deviation "0", which will cause danger. In order to avoid this kind of situation, the alarm value of excessive position deviation can be set when the servo is ON.

The relevant parameters and alarms are shown below.

Table 7-4 Set the parameters of excessive position deviation when the servo is ON

| | | | | | |
|-------|-----------------------------------------------------|----------------|---------------|--------------|----------------|
| Pn526 | Position deviation overflow alarm level at servo ON | | | When enabled | Classification |
| | Setting range | Unit | Default value | | |
| | 1 ~ 1073741823 | 1 command unit | 5242880 0 | | |
| Pn528 | Position deviation overflow alarm level at servo ON | | | When enabled | Classification |
| | Setting range | Unit | Default value | | |
| | 10 ~ 100 | 1% | 100 | | |
| Pn529 | Speed limit level at servo ON | | | When enabled | Classification |
| | Setting range | Unit | Default value | | |
| | 0 ~ 10000 | rpm | 10000 | | |

Table 7-5 Alarm No.

| Alarm number | Name | Content |
|--------------|-----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.d01 | Position deviation overflow alarm at servo ON | This is an alarm displayed when trying to turn on the servo while the position deviation is greater than the setting value of Pn526 during servo OFF. |

| | | |
|-------|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.d02 | Position deviation overflow alarm for speed limit at servo ON | If the servo is ON while the position deviation is accumulating, the speed will be limited by the speed limit level at servo ON (Pn529) at servo ON. Input the command pulse in this state, and the alarm will be displayed when the setting value of position deviation overflow alarm level (Pn520) is exceeded. |
|-------|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

7.2 Tuning-less function

Tuning-less function is set to "Invalid" at the default setting. If you use the Tuning-less function, please set Pn170.0=1. When resonance sound or vibration occurs, please change the rigidity value (Pn170.2) and load value (Pn170.3) through "Section 7.2.2 Operation steps of tuning-less level setting (Fn200)".

Note: 1. The tuning-less function is set to "invalid" at the factory. If you use the tuning-less function, please set Pn170.0=1. After the servo drive is installed on the machine, there will be a momentary sound when the servo is turned ON for the first time. This is the sound when the automatic notch filter is set, and it is not a malfunction. There will be no sound when the servo is turned ON next time. For details on the automatic notch filter, refer to "(3) About setting the automatic notch filter".

2. The servo motor may vibrate when used beyond the allowable moment of inertia of the load. At this time, please set Mode = 2 through Fn200, or lower the tuning value.

7.2.1 About the tuning-less function

The tuning-less function is to obtain a stable response through automatic adjustment regardless of the type of machine or load fluctuations.

(1) Set the tuning-less function to be valid/invalid

Tuning-less function can be set by the following parameters.

Table 7-6 Parameters of the tuning-less function

| Parameter | | Contents | When enabled | Classification |
|-----------|------------------------------|-------------------------------------|--------------------------------|----------------|
| Pn170 | n. □□□ 0 (Default value) | Disable the tuning-less function | After restart the power supply | Setup |
| | n. □□□ 1 | Enable the tuning-less function | | |
| | n. □□ 0 □ (Default value) | Used as speed control | | |
| | n. □□ 1 □ | For speed control, position control | | |

(2) Restrictions on usage

The tuning-less function is valid for position control and speed control, but invalid during torque control.

Meanwhile, when the tuning-less function is enabled, the control functions shown in the table below are partially restricted.

Table 7-7 Parameters of the tuning-less function

| Function name | Executable/not executable | Executable conditions and remarks |
|----------------------------------------------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Initialize vibration detection level (Fn01B) | √ | — |
| Advanced auto tuning 1 | △ | Can be selected only at estimated moment of inertia. To be invalid at the tuning-less function executed, and becomes effective after tuning-less function ends. |
| Advanced auto tuning 2 | x | — |
| One-parameter tuning | x | — |

| | | |
|---------------------------------------------------------------------|---|----------------------------------------------------------------|
| Anti-resonance control adjustment | x | — |
| Vibration suppression function | x | — |
| EasyFFT | √ | — |
| Friction compensation | x | — |
| Gain switching | x | — |
| Estimated off-line moment of inertia (operated via HCServoWorks) | x | Operate after disable the tuning-less function (Pn170.0 = 0) . |
| Mechanical analysis (operated via HCServoWorks) | √ | Operate after disable the tuning-less function (Pn170.0 = 0) . |

√ : Operable △ : Operable, but some functions are limited × : Inoperable

(3) About setting the automatic notch filter

Generally, set it to "Automatic adjustment" (by default).

At "Automatic adjustment", vibration will be detected automatically when the tuning-less function is enabled, and the notch filter will be set.

Please set it to "Do not adjust automatically" only when you do not change the notch filter setting.

Table 7-8 Setting automatic notch filter parameters

| Parameter | | Contents | When enabled | Classification |
|-----------|-------------------------------|--------------------------------------------------------------------------|--------------|----------------|
| Pn460 | n. □ 0 □ □ | Automatic adjustment of the 2nd notch filter without auxiliary functions | Immediately | Setup |
| | n. □ 1 □ □ (Default value) | Automatic adjustment of the 2nd notch filter by auxiliary function | | |

(4) About the tuning-less value

The tuning-less values: "Rigidity value" and "Load value". The adjustment value can be selected using the auxiliary function (Fn200) or the parameter setting (Pn170) .

Table 7-9 Rigidity values

| Parameter | Meaning | When enabled | Classification | |
|------------|----------------------------|--------------|----------------|------------------------|
| Pn170 | n. □ 0 □ □ | Immediately | Setup | |
| | Rigidity value 0 (Level0) | | | |
| | n. □ 1 □ □ | | | Rigid value 1 (Level1) |
| | n. □ 2 □ □ | | | Rigid value 2 (Level2) |
| | n. □ 3 □ □ | | | Rigid value 3 (Level3) |
| | n. □ 4 □ □ (Default value) | | | Rigid value 4 (Level4) |
| | n. □ 5 □ □ | | | Rigid value 5 (Level5) |
| | n. □ 6 □ □ | | | Rigid value 6 (Level6) |
| n. □ 7 □ □ | Rigid value 7 (Level7) | | | |

Table 7-10 Rigidity values

| Parameter | Contents | When enabled | Classification | |
|-----------|-------------------------------|--------------|----------------|----------------------------|
| Pn170 | n. 0 □ □ □ | Immediately | Setup | |
| | n. 1 □ □ □ (Default value) | | | Load value- lower (Mode0) |
| | n. 2 □ □ □ | | | Load value- medium (Mode1) |
| | Load value - higher (Mode2) | | | |

7.2.2 Tuning-less value setting (Fn200)

The procedure for setting the tuning-less value is as follows.

The tuning-less value can be set by the operational panel or HCServoWorks.

(1) Confirmation before execution

Please confirm the following settings before performing tuning-less value. If the setting is not satisfied, " NO_OP " will be displayed during operation.

- Select tuning-less to be valid (Pn170.0 = 1).
- The write prohibition setting (Fn010) is disabled.

(2) Operations steps via the operation panel

- ① Press **(M)** key to switch to auxiliary function mode "**Fn000**".
- ② Press **(▲)** or **(▼)** key to "**Fn200**".
- ③ After long-pressing **(S)** for 1 sec., switch to the load value of tuning-less "**d 1**".
- ④ Press **(M)** key to switch to the rigidity setting screen of tuning-less "**L 4**".
- ⑤ Press **(▲)** or **(▼)** key to select the rigidity value. The higher the value, the higher the gain and the higher the response.
(Default value:4)
- Vibration may occur when the rigidity value is too large. At this time, lower the rigidity value.
- When a high tone occurs, press **(S)** to automatically adjust the frequency of the notch filter to the vibration frequency.
- ⑥ Press **(M)** key, the status display will change to "**done**" and flashes for about 1 sec., then displays "**L0004**". And the setting will be stored in the servo drive.
- ⑦ Press **(S)** for about 1 sec., then return to "**Fn200**".

Note: If overshoot occurs in the waveform, or when the load moment of inertia exceeds the allowable load (not subject to product warranty), press the key to change the load value to "2".

(3) Alarm and treatment method

When a resonance sound occurs or a large vibration occurs in position control, an auto-tuning alarm (A.521) may appear. In this case, perform the following steps.

- When resonance sound occurs
Decrease the setting value of Mode or Level through Fn200.

- When large vibration occurs during position control

Increase the setting value of Mode or Level through Fn200. It is also possible to increase the setting value of Pn170.3 or decrease the setting value of Pn170.2 through parameter setting.

(4) Parameters that make tuning-less function become invalid

When the tuning-less function is valid, the parameters Pn100, Pn101, Pn102, Pn103, Pn104, Pn105, Pn106, Pn160, Pn139, and Pn408 in the table below are invalid.

However, when the functions shown in the table below are executed, the above parameters related to gain may become valid.

For example, when Easy FFT is executed when the tuning-less function is valid, the setting values of parameters Pn100, Pn104, Pn101, Pn105, Pn102, Pn106, Pn103 and the manual gain switching are valid, and the setting value of Pn408.3, Pn160.0 and Pn139.0 are invalid.

Table 7-11 Parameters that make tuning-less function become invalid

| Parameters that make tuning-less function become invalid | | | Executed functions and valid parameters | | |
|----------------------------------------------------------|------------------------------------------|---------------|-----------------------------------------|---------|------------------------------------------|
| Items | Parameter | Parameter No. | Torque control | EasyFFT | Mechanical analysis (Vertical axis mode) |
| Gains | Speed loop gain | Pn100 | √ | √ | √ |
| | 2nd speed loop gain | Pn104 | | | |
| | Speed loop integral time constant | Pn101 | x | √ | √ |
| | Second speed loop integral time constant | Pn105 | | | |
| | Position loop gain | Pn102 | x | √ | √ |
| Advanced control | 2nd position loop gain | Pn106 | | | |
| | Moment of inertia ratio | Pn103 | √ | √ | √ |
| | Friction compensation function selection | Pn408.3 | x | x | x |
| Gain switching | Anti-resonance control selection | Pn160.0 | x | x | x |
| | Gain switching selection | Pn139.0 | x | x | x |

√: The parameter setting value is valid x: The parameter setting value is invalid

7.2.3 Related parameters

The following 3 items are shown in the table below.

- Parameters associated with this function

The parameters used or referenced when executing this function.

- Is it possible to change the setting value of the parameter when executing this function?

"No": Parameters cannot be changed through HCServoWorks etc. when executing this function.

"Yes": Parameters can be changed through HCServoWorks etc. when executing this function.

- Whether there is automatic setting of parameters after executing this function

"Yes": After executing this function, the parameter setting value will be automatically set or adjusted.

"No": After executing this function, the parameter setting value will not be automatically set or adjusted.

Table 7-12 Parameters about tuning-less function

| Parameter | Name | Possible to change the setting value | Automatic setting |
|-----------|---------------------------------------------------|--------------------------------------|-------------------|
| Pn170 | Tuning-less function | No | Yes |
| Pn401 | 1st stage 1st torque command filter time constant | No | Yes |
| Pn40C | 2nd stage notch filter frequency | No | Yes |
| Pn40D | 2nd stage notch filter Q value | No | Yes |

7.3 Advanced auto-tuning 1 - by HCServoWorks internal position command

This section explains how to perform adjustments with advanced auto-tuning 1.

Note: 1. Advanced auto-tuning 1 controls the operation of the mechanism through the internal position command of the HCServoWorks software. Pay attention to the safety distance and mechanical collision when using it.

2. When using advanced auto tuning 1, please ensure that the tuning-less function Pn170.0=0.

3. Advanced auto-tuning 1 starts to adjust based on the currently set speed loop gain (Pn100). Therefore, if vibration occurs at the start of adjustment, correct adjustment will not be possible.

At this time, please reduce the speed loop gain (Pn100) until the vibration disappears

4. After performing advanced auto-tuning 1, if the advanced auto-tuning of "Estimated load moment of inertia" is performed again due to changes in the load state and transmission mechanism of the machine, please change the following parameters number, and set all the set values after the last adjustment to be invalid. If advanced auto-tuning 1 is performed without changing the parameters, it may cause mechanical vibration or damage.

- ① Pn00B.0 = 1 (Display all parameters)
- ② Pn140.0 = 0 (Do not use model tracking control)
- ③ Pn160.0 = 0 (Adjust anti-resonance Control is not used)
- ④ Pn408 = n.00 • 0 (Do not use friction compensation, 1st or 2nd notch)

5. The operation of Advanced auto-tuning 1 can be performed through HCServoWorks. This function cannot be operated through the operation panel.

- (1) Execute through the HCServoWorks software on the host computer.
- (2) Execute through the panel buttons (refer to 8.17 Advanced auto-tuning 1 for detailed operation methods).
- (3) Execute via parameter startup, see the table below for parameter details (refer to 5.2.6 Numerical setting type operation for specific operation methods).

Table 7-13 Parameter startup tuning correspondence

| Parameter | | Function |
|----------------------------------------------|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pn6B1 One-key tuning control (Fn201) | 0 | Stop |
| | 1 | Medium rigidity structure, interpolation mode |
| | 2 | Medium rigidity structure, rapid positioning mode |
| | 3 | Medium rigidity structure, standard mode |
| | 4 | Low rigidity structure, interpolation mode |
| | 5 | Low rigidity structure, rapid positioning mode |
| | 6 | Low rigidity structure, standard mode |
| | 7 | High rigidity structure, interpolation mode |
| | 8 | High rigidity structure, rapid positioning mode |
| | 9 | High rigidity structure, standard mode |
| | 11~19 | The function settings are the same as those of 1~9 |
| Pn6B2 Tuning travelling distance | | Range: -32768~32767 |
| Pn6B3 Tuning initial gain level | | 0: No initial value, subject to the speed loop gain (Pn100) 1~5: The larger the value, the greater the gain |
| Pn6B4 Tuning initial estimated inertia | | 0: No initial value, subject to the starting value of moment of inertia estimation (Pn324) 1~3: The larger the value, the higher the inertia level (Only valid when inertia estimation is enabled) |
| Pn6B5 Tuning initial positioning accuracy | | 0: No initial value, subject to the positioning completion range (Pn522) 1~9: The larger the value, the lower the positioning accuracy |
| Pn6B6 Percentage when saving the gain | | Range: 1~100 |
| Pn6B7 Tuning configuration function | n. □□□ 0 | None |
| | n. □□□ 1 | When the tuning starts, automatically adjust and force the initialization of relevant functions (model tracking, type A vibration suppression, notch filter, vibration suppression) |

Table 7-14 Description of tuning mode

| Mode | Content |
|----------------------------------------------------------------|------------------------------------------------------------------------------------------|
| Tuning mode 1 (standard) | Adjust gain, notch filter, A-mode vibration |
| Tuning mode 2 (positioning oriented) | Adjust the gain, model tracking, notch filter, anti-resonance, and vibration suppression |
| Tuning mode 3 (positioning oriented < emphasis on overshoot >) | Adjust gain, notch filter, anti-resonance, and vibration suppression |

Table 7-15 Mechanism selection explanation

| Mechanism selection | Mechanism type |
|---------------------------|--------------------------|
| Low rigidity structure | Conveyor belt structure |
| Medium rigidity structure | Ball screw, linear motor |
| High rigidity structure | Rigid body system |

7.3.1 About auto-tuning 1

Advanced auto-tuning 1 refers to the function that the servo drive automatically adjusts according to the mechanical characteristics when performing automatic operation (forward and reverse reciprocating motion) within the setting range.

Advanced auto-tuning can be performed without connecting a host controller.

The operation specifications of automatic operation are as follows.




Figure 7-1 Automatic operation specification

Maximum speed: Motor rated speed $\times (2/3)$.

- Acceleration torque: About 100% of the rated torque of the motor.
- Acceleration torque will change according to the setting of moment of inertia ratio (Pn103), mechanical friction, and external disturbance.
- Travelling distance: Can be set arbitrarily. The default setting is equivalent to 3 revolutions of the servo motor.
- Items of advanced auto-tuning 1 :
 - Moment of inertia ratio.
 - Gain adjustment (speed loop gain, position loop gain, etc.).
 - Filter adjustment (torque command filter, notch filter).
 - Friction compensation.
 - Anti-resonance control adjustment.
 - Vibration suppression (only when mode = 2 or 3).

Note: Advanced auto-tuning 1 performs adjustments in automatic operation mode, so vibration or overshooting may occur during operation. In order to ensure safety, please execute the advance auto tuning in the state of emergency stop at any time.

Confirmation items before execution

Before performing advanced auto tuning 1, be sure to confirm the following settings. When the following items are not set, the operation will display "NO_OP":

- The main circuit power supply must be ON
- Servo must be OFF

- Forward-rotation prohibition (P-OT), reverse-rotation prohibition (N-OT) must not be in an overtravel state
- The clear signal must be L level (not cleared)
- Not for torque control
- The gain switching selection is manual gain switching (Pn139.0 = 0).
- The 1st gain is selected.
- No servo motor test function selection is invalid (Pn00C.0 = 0).
- No alarms or warnings occurred.
- Hardwired base block function (HWBB) is invalid
- Auto gain switching must be disabled
- Write prohibition should be disabled(Fn010)
- Set the tuning-less function to be invalid (Pn170.0 = 0)

< Supplement >

- When the advanced auto-tuning is performed under speed control, it will automatically switch to position control. And return to speed control after adjustment.

In the following cases, advanced auto tuning 1 cannot be performed normally. Please adjust with advanced auto tuning 2 or One-parameter tuning.

- When a mechanical system can only operate in one direction.
- The range of activity is narrow, and it is below 0.5 circles.

Advanced auto-tuning 2 → refer to "Section 7.4 Advanced auto-tuning 2".

One-parameter tuning → refer to " Section 7.5 One-parameter tuning".

Adjustment with advanced auto tuning 1 cannot be performed smoothly in the following cases. Please adjust with advanced auto tuning 2 or One-parameter tuning.

- When an appropriate range of motion cannot be obtained.
- When the moment of inertia fluctuates within the setting range.
- When the dynamic friction of the machine is large.
- When the rigidity of the machine is low and vibration occurs during the positioning operation.
- When using the position integration function.
- During P (proportional) control.

Note: When set to "Estimated moment of inertia ", "Error" will be displayed during the process of estimated the moment of inertia, or when switching to P control via the /P-CON signal.

- When using the mode switch.

Note: When set to "Estimated moment of inertia", the mode switch function becomes invalid during the process of estimating the moment of inertia, and becomes PI control. Mode switch function becomes valid again after the moment of inertia estimation is completed.

- When speed feedforward and torque feedforward are input.
- When the tuning initial positioning accuracy (Pn6B5) is narrow.

Advanced auto-tuning 2 → Refer to "Section 7.4 Advanced auto-tuning 2".

One-parameter tuning → Refer to " Section 7.5 One-parameter tuning".

Fine-tuning the overshoot without changing the positioning completion width (Pn522) , use the overshoot detection value (Pn561). Since the default setting of Pn561 is 100%, it is allowed to adjust up to the same overshoot as the positioning completion width. If changed to 0%, the adjustment can be performed without overshoot within the positioning completion width.

However, after changing this value, the positioning time may be extended.

Table 7-16 Overshoot detection value parameters

| Pn561 | Overshoot detection value | | Speed | Position | Torque | When enabled | Classification |
|-------|---------------------------|------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 0-100 | 1% | 100 | | | | |

7.3.2 Precautions for advanced auto-tuning 1

When an abnormal operation occurs during the execution of advanced automatic tuning 1, the causes and countermeasures are as follows:

If the advanced automatic tuning 1 fails, deal with it by checking the causes and countermeasures corresponding to the alarm number.

Table 7-17 Tuning alarm number correspondence table

| Alarm No. | Cause | Countermeasure |
|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.9C0 Advanced automatic tuning alarm 1 | Operation status error | - |
| A.9C1 Advanced automatic tuning alarm 2 | When the non-adjustment function is enabled, the moment of inertia estimation has not been executed. | Set "Estimated moment of inertia [Default]" in the HCServoWorks startup mode. Restart the tuning, or set "J. ON" in the operation panel startup mode. Restart the tuning, or set the non-adjustment function to invalid (Pn170.0 = 0). |
| A.9C2 Advanced automatic tuning alarm 3 | The positioning completion signal [COIN] has not been detected for more than 10 seconds. | Increase the initial gain level of the advanced automatic tuning (Pn6B3) by one level, or increase the positioning accuracy of the advanced automatic tuning (Pn6B5) by one level. |
| A.9C3 Advanced automatic tuning alarm 4 | The speed loop gain search has reached the lower limit. Mechanical vibration has occurred. | Decrease the initial positioning accuracy of the automatic tuning (Pn6B5) by one level. The vibration can be suppressed through the type A vibration suppression adjustment function and the vibration suppression function. |
| A.9C4 Advanced automatic tuning alarm 5 | The position loop or model loop gain search has reached the lower limit. When the motor is stopped, the positioning completion signal (/COIN) is unstable and is turning ON/OFF. Mechanical vibration has occurred. | Increase the positioning accuracy of the advanced automatic tuning (Pn6B5) by one level. Set "Positioning correspondence (focus on overshoot)" in the HCServoWorks startup mode. Restart the tuning, or set "L. 3" in the operation panel startup mode to restart the tuning. Suppress the vibration through the type A vibration suppression adjustment function and the vibration suppression function. |
| A.9C5 Advanced automatic tuning alarm 6 | The action of the self-estimation of the moment of inertia has started, but the estimation process has not been executed. | Increase the initial gain level of the automatic tuning (Pn6B3) by one level. Increase the moving distance. |

| | | |
|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.9C6 Advanced automatic tuning alarm 7 | The deviation of the estimation result of the self-estimation of the moment of inertia is too large, and the deviation still has not decreased after 10 times of retries. | The current mechanical inertia cannot be estimated. Manually set the moment of inertia ratio (Pn103) directly according to the mechanical specifications. Set "Do not estimate moment of inertia" in the HCServoWorks startup mode and restart the tuning, or set "J. OFF" in the operation panel startup mode and restart the tuning. |
| A.9C7 Advanced automatic tuning alarm 8 | Low-frequency vibration has been detected during the self-estimation process of the moment of inertia. | Increase the initial inertia level of the advanced automatic tuning (Pn6B4) by one level. |
| A.9C8 Advanced automatic tuning alarm 9 | The torque limit value has been reached. | Increase the limit value when the torque limit is set. Increase the initial inertia level of the advanced automatic tuning (Pn6B4) by one level. |
| A.9C9 Advanced automatic tuning alarm 10 | During the self-estimation process of the moment of inertia, the external input of (/P-CON) has changed the speed loop control mode to P control. | Switch to PI control during the self-estimation of the moment of inertia. |
| A.9CA Advanced automatic tuning alarm 11 | An alarm or warning occurred in the servo during the tuning process. | Eliminate the cause of the alarm or warning and then retry. |
| A.9CB Advanced automatic tuning alarm 12 | The servo main power is not ready during the tuning process. | Connect the main circuit power supply and then retry. |
| A.9CC Advanced automatic tuning alarm 13 | The servo is in an over-travel state during the tuning process. | Eliminate the cause of the over-travel and then retry. |
| A.9CD Advanced automatic tuning alarm 14 | The servo is not enabled during the tuning process. | Do not perform the servo enable OFF operation during the tuning operation. |
| A.9CE Advanced automatic tuning alarm 15 | The currently effective gain of the servo during the tuning process is not the first gain. | Set the automatic gain switching to invalid (Pn139.0 = 0) and the G-SEL to the OFF state. |
| A.9CF Advanced automatic tuning alarm 16 | The servo is in the STO state during the tuning process. | Release the STO state and then retry. |
| A.9D0 Advanced automatic tuning alarm 17 | The magnetic polarity detection has not been carried out before tuning. | Perform the "Magnetic pole detection" operation first and then retry. |
| A.9D1 Advanced automatic tuning alarm 18 | The tuning process has exceeded the maximum time limit. | Confirm the mechanical connection situation and then retry. |
| A.9D2 Advanced automatic tuning alarm 19 | The saving of the gain result failed after the tuning was completed. | Do not perform other parameter writing operations during the tuning process and then retry. |
| A.9D3 Advanced automatic tuning alarm 20 | The downstream command from the host computer timed out during the tuning process. | Check whether the USB connection is good or replace the USB cable and then retry. |

Note: If a tuning-related warning occurs, there is no need to manually clear it. Just restart the tuning.

7.4 Advanced auto-tuning 2 - via host controller position commands

This section describes the adjustment method for advanced auto-tuning 2. This function controls the mechanism through operation commands from the host device, hence it is also called advanced auto-tuning 2.

Note: 1. Advanced auto-tuning 2 is operated by the control mechanism of the host device's operation command (Pulse sequence command). Pay attention to the safety distance and mechanical collision when using.

2. When using advanced auto-tuning 2, please ensure that the tuning-less function Pn170.0=0 is turned off.

3. Advanced auto-tuning 2 starts to adjust based on the currently set speed loop gain (Pn100). Therefore, if vibration occurs at the start of adjustment, correct adjustment will not be possible.

At this time, please reduce the speed loop gain (Pn100) until the vibration disappears.

4. After performing advanced auto-tuning 2, if the "Estimated moment of inertia" is performed again due to changes in the load state and transmission mechanism of the machine, please change the following parameters and set all the set values to be invalid. If advanced auto-tuning 2 is performed without changing the parameters, it may cause mechanical vibration ordamage.

- ① Pn00B.0 = 1 (Display all parameters)
- ② Pn140.0 = 0 (Do not use model tracking control)
- ③ Pn160.0 = 0 (Do not use Adjust Anti-resonance Control)
- ④ Pn408 = n.00 • 0 (Do not use friction compensation, 1st or 2nd notch)

5. The operation of advanced auto-tuning 2 can be performed through HCServoWorks. This function cannot be operated through the operation panel.

- (1) Execute through the HCServoWorks software on the host computer.
- (2) Execute through the panel buttons (refer to 8.18 Advanced auto-tuning 2 for the specific operation method).
- (3) Execute by starting with parameters. See the following table for detailed parameters (refer to 5.2.6 Numeric settings for the specific operation method).

Table 7-18 Parameter startup tuning correspondence

| Parameter | | Function | |
|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|
| Pn6B0 One-key tuning control | 0 | Stop | With offline inertia |
| | 1 | Medium rigidity structure, interpolation mode | |
| | 2 | Medium rigidity structure, rapid positioning mode | |
| | 3 | Medium rigidity structure, standard mode | |
| | 4 | Low rigidity structure, interpolation mode | |
| | 5 | Low rigidity structure, rapid positioning mode | |
| | 6 | Low rigidity structure, standard mode | |
| | 7 | High rigidity structure, interpolation mode | |
| | 8 | High rigidity structure, rapid positioning mode | |
| | 9 | High rigidity structure, standard mode | |
| | 11~19 | The function settings are the same as those of 1~9 | Without offline inertia |
| Pn6B3 Tuning initial gain level | 0: No initial value, subject to the speed loop gain (Pn100) 1~5: The larger the value, the greater the gain | | |
| Pn6B4 Tuning initial estimated inertia | 0: No initial value, subject to the starting value of moment of inertia estimation (Pn324) 1~3: The larger the value, the higher the inertia level (Only valid when inertia estimation is enabled) | | |
| Pn6B5 Tuning initial positioning accuracy | 0: No initial value, subject to the positioning completion range (Pn522) 1~9: The larger the value, the lower the positioning accuracy | | |
| Pn6B6 Percentage when saving the gain | Range: 1~100 | | |
| Pn6B7 Tuning configuration function | n. □□□ 0 | None | |
| | n. □□□ 1 | When the tuning starts, automatically adjust and force the initialization of relevant functions (model tracking, type A vibration suppression, notch filter, vibration suppression) | |

Table 7-19 Mechanism selection explanation

| Mechanism selection | Mechanism type |
|---------------------------|--------------------------|
| Low rigidity structure | Conveyor belt structure |
| Medium rigidity structure | Ball screw, linear motor |
| High rigidity structure | Rigid body system |

7.4.1 About advanced auto-tuning 2

Advanced auto-tuning 2 is a method for automatically performing optimal adjustments to the operation command from the host controller.

Advanced auto-tuning 2 can also be used for additional adjustments after Advanced auto-tuning.

In addition, if the correct moment of inertia ratio is set in Pn103, we don't have to perform advanced auto-tuning and only perform the advanced auto-tuning 2.

Advanced auto-tuning 2 makes adjustments to the following items.

- Gain adjustment (speed loop gain, position loop gain, etc.)
- Filter adjustment (torque command filter, notch filter)
- Friction compensation
- Adjust anti-resonance control




Figure 7-2 Example of automatic operation

Note: Advanced auto-tuning 2 performs automatic adjustment, so vibration or overshoot may occur during operation. To ensure safety, perform advanced tuning in a state where an emergency stop is possible at any time.

Confirmation items before operation

Before perform advanced auto tuning 2, be sure to confirm the following settings. When the following items are not correct, the "NO_OP" will display:

- The main circuit power supply must be ON
- Ther servo must be OFF
- Prohibition of forward-rotation (P-OT), prohibition of reverse-rotation (N-OT) must not be in an overtravel state
- The gain switching selection switch is manual gain switching (Pn139.0 = 0).
- The 1st gain is selected.
- No motor test function selection is invalid (Pn00C.0 = 0).
- No alarms or warnings occurred.
- Hardwired base block function (STO) does not work
- Auto gain switch must be disabled
- Write prohibition should be disabled(Fn010)
- Set the tuning-less function to be invalid (Pn170.0 = 0)
- The servbo motor is in the Position control while the servo ON.

The advanced auto tuning 2 cannot be adjusted smoothly in the following cases. Please adjust by one-parameter tuning.

- When the movement amount indicated by the upper device command is the setting value of the positioning completion width (Pn6B5) or less.

- When the moving speed commanded by the upper device is the setting value of the rotation detection value (Pn502) or less.
- When the stop time (the time during which the positioning complete signal (/COIN) is OFF) is 10ms or less.
- When the rigidity of the machine is low and vibration occurs during the positioning operation.
- When using the position integration function.
- During P (proportional) control.
- When using the mode switch.
- When the positioning completion width (Pn6B5) is narrow.

One-parameter tuning → refer to " Section 7.5 One-parameter Tuning".

Only use the overshoot detection value (Pn561) when fine-tuning the overshoot without changing the positioning completion range (Pn522). Since the default setting of Pn561 is 100%, it is allowed to adjust up to the same overshoot as the positioning completion width. If changed to 0%, the adjustment can be performed without overshoot within the positioning completion width. However, after changing this value, the positioning time may be extended.

Table 7-20 Related parameters about advanced auto resonance 1

| Pn561 | Overshoot detection value | | Speed | Position | Torque | When enabled | Classification |
|-------|---------------------------|------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 0-100 | 1% | 100 | | | Immediately | Setup |

7.4.2 Precautions for advanced auto-tuning 2

When an abnormal operation occurs during the execution of advanced auto-tuning 2, the causes and countermeasures are as follows:

If the advanced auto-tuning 2 fails, deal with it by checking the causes and countermeasures corresponding to the alarm number.

Table 7-21 Parameters about executing advanced auto-tuning 2

| Parameter | Meaning | When enabled | Classification |
|-----------|----------------------------|--------------|----------------|
| Pn160 | n. □ □ 0 □ | Immediately | Tuning |
| | n. □ □ 1 □ (Default value) | | |

Table 7-22 Tuning alarm number correspondence table

| Alarm No. | Cause | Countermeasure |
|--------------------------------------------|------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.9C0 Advanced automatic tuning alarm 1 | Operation status error | - |
| A.9C2 Advanced automatic tuning alarm 3 | The positioning completion signal [COIN] has not been detected for more than 10 seconds. | Increase the initial gain level of the advanced automatic tuning (Pn6B3) by one level, or increase the positioning accuracy of the advanced automatic tuning (Pn6B5) by one level. |
| A.9C3 Advanced automatic tuning alarm 4 | The speed loop gain search has reached the lower limit. | Decrease the initial positioning accuracy of the automatic tuning (Pn6B5) by one level. |
| | Mechanical vibration has occurred. | The vibration can be suppressed through the type A vibration suppression adjustment function and the vibration suppression function. |

| | | |
|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.9C4 Advanced automatic tuning alarm 5 | The position loop or model loop gain search has reached the lower limit. | Increase the positioning accuracy of the advanced automatic tuning (Pn6B5) by one level. |
| | When the motor is stopped, the positioning completion signal (/COIN) is unstable and is turning ON/OFF. | Set "Positioning correspondence (focus on over shoot)" in the HCServoWorks startup mode. Restart the tuning, or set "L. 3" in the operation panel start-up mode to restart the tuning. |
| | Mechanical vibration has occurred. | Suppress the vibration through the type A vibration suppression adjustment function and the vibration suppression function. |
| A.9C8 Advanced automatic tuning alarm 9 | The torque limit value has been reached. | Increase the limit value when the torque limit is set. Increase the initial gain level of the automatic tuning (Pn6B3) by one level. |
| A.9C9 Advanced automatic tuning alarm 10 | During the self-estimation process of the moment of inertia, the external input of (/P-CON) has changed the speed loop control mode to P control. | Switch to PI control during the self-estimation of the moment of inertia. |
| A.9CA Advanced automatic tuning alarm 11 | An alarm or warning occurred in the servo during the tuning process. | Eliminate the cause of the alarm or warning and then retry. |
| A.9CB Advanced automatic tuning alarm 12 | The servo main power is not ready during the tuning process. | Connect the main circuit power supply and then retry. |
| A.9CC Advanced automatic tuning alarm 13 | The servo is in an over-travel state during the tuning process. | Eliminate the cause of the over-travel and then retry. |
| A.9CD Advanced automatic tuning alarm 14 | The servo is not enabled during the tuning process. | Do not perform the servo enable OFF operation during the tuning operation. |
| A.9CE Advanced automatic tuning alarm 15 | The currently effective gain of the servo during the tuning process is not the first gain. | Set the automatic gain switching to invalid (Pn139.0 = 0) and the G-SEL to the OFF state. |
| A.9CF Advanced automatic tuning alarm 16 | The servo is in the STO state during the tuning process. | Release the STO state and then retry. |
| A.9D2 Advanced automatic tuning alarm 19 | The saving of the gain result failed after the tuning was completed. | Do not perform other parameter writing operations during the tuning process and then retry. |
| A.9D3 Advanced automatic tuning alarm 19 | The downstream command from the host computer timed out during the tuning process. | Check whether the USB connection is good or replace the USB cable and then retry. |

Note: If a tuning-related warning occurs, there is no need to manually clear it. Just restart the tuning.

7.5 One-parameter tuning

This section explains how to adjust by one-parameter tuning

7.5.1 About one-parameter tuning

One-parameter tuning is a method of manually adjusting a speed command or a position command from a host device while running.

Adjusting one or two values through One-parameter tuning automatically adjusts the setting value of the associated gain.

One-parameter tuning has the following items.

- Gain adjustment (speed loop gain, position loop gain, etc.).
- Filter adjustment (torque command filter, notch filter).

- Friction compensation.
- Adjust anti-resonance control.

< Supplement >

If the response characteristics cannot be obtained with advanced auto tuning 1 or advanced auto tuning 2, use one-parameter tuning.

In addition, if you want to further fine-tune servo gain after one-parameter tuning, please refer to "Adjustment application function"

Note: Vibration or overshoot may occur during adjustment. To ensure safety, perform advanced tuning in a state where an emergency stop is possible at any time.

Confirmation items before execution:

Before perform one-parameter tuning, be sure to confirm the following settings. When the following items are not set, "NO_OP" will display:

- The test without a motor function must be disabled (Pn00C.0 = 0).
- Write prohibition should be disabled(Fn010).
- Set the tuning-less function to be invalid (Pn170.0 = 0).
- When performing tuning by speed control, set the tuning mode to 0 or 1.

7.5.2 Operation steps for one-parameter tuning

The operation steps of one-parameter tuning are as follows.

According to the selected adjustment mode, there are two operation procedures for One-parameter tuning.

- When Mode = 0 or 1 - Model tracking control is "invalid", and make adjustments except positioning.
- When Mode = 2 or 3 - Model tracking control is "valid", and make adjustments of positioning.

The operation of one-parameter tuning can be executed through the operation panel or HCServoWorks.

However, the operation panel can only be operated when the tuning mode is set to "Mode = 0", "Mode = 1".

Please operate after setting the moment of inertia ratio (Pn103) correctly by advanced auto tuning.

7.6 Supplements for auto-tuning

7.6.1 Supplements for function

Automatic notch filter function:

Normally, please set to "Auto-tuning" (Default value: "Auto-tuning").

When set to "Auto-tuning", vibration will be detected automatically when this function is executed, and the notch filter will be adjusted.

Please set to "No auto-tuning" only when you do not change the notch filter setting.

Table 7-23 Parameters for automatic notch filter

| Parameter | | Meaning | When enabled | Classification |
|-----------|---------------------------|-----------------------------------------------------------------------|--------------|----------------|
| Pn460 | n. □□□ 0 | Auto tuning of the 1st-stage notch filter without auxiliary functions | Immediately | Tuning |
| | n. □□□ 1 (Default value) | Auto tuning of the 1st-stage notch filter by auxiliary function | | |
| | n. □ 0 □□ | Auto tuning of the 2nd-stage notch filter without auxiliary functions | | |
| | n. □ 1 □□ (Default value) | Auto tuning of the 2nd-stage notch filter by auxiliary function | | |

Adjust anti-resonance control function:

Normally, please set to "Auto-tuning" (Default value: "Auto-tuning")

When set to "Auto-tuning ", vibration is automatically detected during advanced auto-tuning, and adjust anti-resonance control is automatically adjusted.

Table 7-24 Parameters about adjust anti-resonance control

| Parameter | | Meaning | When enabled | Classification |
|-----------|---------------------------|--------------------------------------------------------------------------|--------------|----------------|
| Pn160 | n. □□ 0 □ | Auto tuning of adjust anti-resonance control without auxiliary functions | Immediately | Tuning |
| | n. □□ 1 □ (Default value) | Auto tuning of adjust anti-resonance control with auxiliary function | | |

Vibration suppression function:

The vibration suppression function is mainly used to suppress the low-frequency vibration (shaking) of about 1 to 100 Hz caused by the vibration of the machine during positioning.

Normally, please set to "Auto-tuning" (Default value: "Auto-tuning").

When set to "Auto-tuning", vibration is automatically detected during advanced auto-tuning, and vibration suppression control is automatically adjusted.

Set to "No auto-tuning" only when you do not change the vibration suppression control setting that was set before executing advanced auto tuning.

Table 7-25 Parameters about vibration suppression function

| Parameter | | Meaning | When enabled | Classification |
|-----------|---------------------------|---------------------------------------------------------------------------|--------------|----------------|
| Pn140 | n. □ 0 □□ | Auto tuning of vibration suppression function without auxiliary functions | Immediately | Tuning |
| | n. □ 1 □□ (Default value) | Auto tuning of vibration suppression function with auxiliary function | | |

Feedforward function:

- Lubricant viscous resistance changes in machine sliding parts
- Frictional resistance change caused by mechanical assembly deviations
- Frictional resistance change due to aging

The applicable conditions for friction compensation differ depending on the mode . "Mode= 1" follows the setting of "Friction compensation function selection (Pn408.3)". "Mode = 2" or "Mode = 3" has nothing to do with the setting of "Friction compensation function selection (Pn408.3)", and can be adjusted through "Valid friction compensation function " .

Table 7-26 Parameters for friction compensation function

| Friction compensation function selection | | Mode | "Mode = 1" | "Mode = 2" | "Mode = 3" |
|------------------------------------------|--------------------------------------------|-------|-------------------------|----------------------------------------------|--------------------------------------------|
| | | Pn408 | n.0 □□□ (Default value) | Adjust when friction compensation is invalid | Adjust when friction compensation is valid |
| n.1 □□□ | Adjust when friction compensation is valid | | | | |

Feedforward function:

After adjustment by "Mode= 2" and "Mode = 3" in the default setting mode, "Feedforward (Pn109)", "Speed feedforward (V-REF) input" and "Torque feedforward (T- REF) input" will become invalid.

According to the system configuration, if you want to use the "Speed feedforward (V-REF) input" and "Torque feedforward (T-REF) input" and "Model tracking control" from the upper device at the same time, please set Pn140.3 = 1.

Table 7-27 Parameters for feedforward function

| Parameter | | Meaning | When enabled | Classification |
|-----------|-------------------------|-------------------------------------------------------------------------------|--------------|----------------|
| Pn140 | n.0 □□□ (Default value) | Do not use model tracking control and speed/torque feedforward simultaneously | Immediately | Tuning |
| | n.1 □□□ | Using model tracking control and speed/ torque feedforward simultaneously | | |

Note: When using the model tracking control under this function, the model tracking control will have the best feedforward inside the servo. Therefore, usually do not use "Speed feedforward (V-REF) input " and "Torque feedforward (T-REF) input " from the upper device at the same time. However, Model tracking control and "Speed feedforward (V-REF) input" and "Torque feedforward (T-REF) input" can be used at the same time as required. In this cas , if the input feed-forward is not correct, it may cause overshoot, please pay attention.

7.6.2 Related parameters

Related parameters are listed in Table 7-28 below.

- Parameters related to this function

The parameters used or referenced when executing this function.

- Whether to change the setting value of the parameter when executing this function.

"No": When executing this function, parameters cannot be changed through HCServoWorks, etc.

"Yes": Parameters can be changed through HCServoWorks, etc. when executing this function.

- Whether there is automatic setting of parameters after executing this function

"Yes": After executing this function, the parameter setting value will be automatically set or adjusted.

"No": After executing this function, the parameter setting value will not be automatically set or adjusted.

Table 7-28 Parameters related to one-parameter tuning

| Parameter | Name | Is it possible to change the setting value | Automatic setting |
|-----------|--------------------------------------------|--------------------------------------------|-------------------|
| Pn100 | Speed loop gain | No | Yes |
| Pn101 | Speed loop integral time constant | No | Yes |
| Pn102 | Position loop gain | No | Yes |
| Pn103 | Moment of inertia ratio | No | No |
| Pn121 | Friction compensation gain | No | Yes |
| Pn123 | Friction compensation coefficient | No | Yes |
| Pn124 | Friction compensation frequency correction | No | No |

| | | | |
|-------|--------------------------------------------------------|-----|-----|
| Pn125 | Friction compensation gain correction | No | Yes |
| Pn401 | 1st stage 1st torque command filter time constant | No | Yes |
| Pn408 | Torque-related function selections | Yes | Yes |
| Pn409 | 1st stage notch filter frequency | No | Yes |
| Pn40A | 1st stage notch filter Q value | No | Yes |
| Pn40C | 2nd stage notch filter frequency | No | Yes |
| Pn40D | 2nd stage notch filter Q value | No | Yes |
| Pn140 | Model following control-related selections | Yes | Yes |
| Pn141 | Model following control gain | No | Yes |
| Pn142 | Model following control gain correction | No | Yes |
| Pn143 | Model following control bias in the forward direction | No | Yes |
| Pn144 | Model following control bias in the reverse direction | No | Yes |
| Pn145 | Vibration suppression 1 frequency A | No | Yes |
| Pn146 | Vibration suppression 1 frequency B | No | Yes |
| Pn147 | Model following control speed feedforward compensation | No | Yes |
| Pn160 | Anti-resonance control-related selections | Yes | Yes |
| Pn161 | Anti-resonance frequency | No | Yes |
| Pn163 | Anti-resonance damping gain | No | Yes |

7.7 Adjust anti-resonance control function

This section describes the Adjust anti-resonance control function.

7.7.1 About adjust anti-resonance control function

About adjust anti-resonance control function is used to further improve the effect of vibration suppression after the one-parameter tuning.

About adjust anti-resonance control function can effectively suppress the continuous vibration of about 100-1000Hz that occurs when the control gain is increased.

This function will be automatically set by advanced auto-tuning or advanced auto-tuning 2. So use this function only when further fine-tuning is required and when re-adjustment is required due to vibration detection failure.

After executing this function, if want to improve the response, perform one-parameter tuning, etc. Vibration may reoccur after the anti-vibration gain is increased by one-parameter tuning, etc. At this time, please execute this function again to make minor adjustments.

Note: • After executing this function, relevant parameters will be set automatically. Therefore, when this function is executed, the response may change greatly. For the sake of safety, please execute this function in the state of emergency stop at any time.

• Before executing the adjust anti-resonance control function, please correctly set the moment of inertia ratio (Pn103) through advanced auto-tuning, etc. Otherwise, vibration may occur. .

• The vibration frequency range that can be detected by this function is 100Hz to 1,000Hz. Vibration outside the detection range cannot be detected, and "F----" is displayed. In this case, set the notch filter automatically with "Mode = 2" of one-parameter tuning, or use the vibration suppression function.

• Increasing the A-type anti-vibration damping gain (Pn163) can improve the vibration suppression effect, but if the damping gain is too large, the vibration may be increased instead. While checking the vibration suppression effect, gradually increase the damping gain setting value in units of 10% within the range of 0% to 200%. If the vibration suppression effect cannot be obtained even after the damping gain reaches 200%, please stop the setting and reduce the control gain through one-parameter tuning, etc.

Confirmation items before execution:

Before executing adjust anti-resonance control, be sure to confirm the following settings. When the following items are not set, "NO_OP" will display:

- Select tuning-less function to be invalid (Pn170.0 = 0) .

- The test without a motor function must be disabled (Pn00C.0 = 0).
- Torque control is not allowed.
- Write Prohibition should be disabled(Fn010) .

7.7.2 Operation steps of anti-resonance control function

Execute this function when vibration occurs after inputting an action command

Anti-resonance control function can be done through HCServoWorks. This function cannot be operated through the operation panel.

Operation steps of adjust anti-resonance control function are as follows.

- When using the adjust anti-resonance control function for the first time.
- When the vibration frequency is unknown.
- When the vibration frequency is known.
- When making further fine-tuning after using the adjust anti-resonance control function.

7.7.3 Related parameters

Related parameters are shown in table 7-29 below.

- Parameters related to the function.

The parameters used or referenced when executing this function.

- Whether to change the setting value of the parameter when executing this function.

"No": When executing this function, parameters cannot be changed through HCServoWorks, etc.

"Yes": When executing this function, parameters can be changed through HCServoWorks, etc..

- Whether there is automatic setting of parameters after executing this function.

"Yes": After executing this function, the parameter setting value will be automatically set or adjusted.

"No": After executing this function, the parameter setting value will not be automatically set or adjusted.

Table 7-29 Parameters for anti-resonance control function

| Parameter | Name | Is it possible to change the setting value | Automatic setting |
|-----------|--------------------------------------------------|--------------------------------------------|-------------------|
| Pn160 | Anti-resonance control-related selections | Yes | Yes |
| Pn161 | Anti-resonance frequency | No | Yes |
| Pn162 | Anti-resonance gain correction | Yes | No |
| Pn163 | Anti-resonance damping gain | No | Yes |
| Pn164 | Anti-resonance filter time constant 1 correction | Yes | No |
| Pn165 | Anti-resonance filter time constant 2 correction | Yes | No |

7.8 Vibration suppression function

This section explains the vibration suppression function.

7.8.1 About the vibration suppression function

The vibration suppression function is mainly used to suppress the low-frequency vibration (shaking) of about 1-100 Hz

caused by the vibration of the machine during positioning.

This function will be automatically set by advanced auto-tuning 1 or advanced auto-tuning 2. Only use this function when further fine-tuning and re-adjustment is required due to vibration detection failure.

After executing this function, please perform one-parameter tuning to improve the response.

Note: • After executing this function, related parameters will be set automatically. But the response may change greatly. For safety, please execute this function in a state where an emergency stop is possible at any time.

- Before executing this function, correctly set the moment of inertia ratio (Pn103) by advanced auto tuning, etc. Otherwise, vibration may occur.
- The vibration frequency range that can be detected by using this function is 1~100Hz. Vibration outside the detection range cannot be detected, and "F-----" is displayed.
- Vibration cannot be detected if there is no vibration due to positional deviation, or if the vibration frequency is outside the detection frequency range. In this case, please use a displacement meter or a vibration meter to measure the vibration.
- When the vibration cannot be eliminated with the automatically detected vibration frequency, there may be an error between the actual vibration frequency and the detected frequency, please fine-tune the vibration frequency.

(1) Confirmation items before execution

Before executing the vibration suppression function, be sure to confirm the following settings. When the following items are not set, "NO_OP" will display:

- In position control.
- Set the tuning-less function to be invalid (Pn170.0 = 0) .
- The test without a motor function must be disabled (Pn00C.0 = 0).
- Write prohibition should be disabled(Fn010) .

(2) Items affecting performance

Sufficient vibration suppression effect cannot be obtained by the vibration suppression function for vibrations that continue to occur during a stop. In this case, adjust with the adjust anti-resonance control or one-parameter tuning.

(3) About the detection of vibration frequency

Frequency detection may not be possible if vibration does not appear in the position deviation or the vibration that results from the position deviation is too small. You can adjust the detection sensitivity by changing the setting of the residual vibration detection width (Pn560), which is set as a percentage of the positioning completed width (Pn522). Perform the detection of vibration frequencies again after adjusting the setting of Pn560.

Table 7-30 Parameter settings for vibration frequency detection

| Pn560 | Residual vibration detection width | | Speed | Position | Torque | When enabled | Classification |
|-------|------------------------------------|------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 1-3000 | 0.1% | 400 | | | Immediately | Setup |

Note: As a guideline, change the setting 10% at a time. If the setting of this parameter is lowered, the detection sensitivity will be increased. Vibration may not be detected accurately if the setting is too small. The vibration frequencies that are automatically detected may vary somewhat with each positioning operation. Perform positioning several times and make adjustments while checking the effect of vibration suppression.

7.8.2 Precautions for vibration suppression function

The operation procedure of the vibration suppression function is as follows.

The operation of the vibration suppression function can be performed through HCServoWorks. This function cannot be operated through the operation panel.

Supplements for the vibration suppression function:

Feedforward function:

In the default setting mode, "Feedforward (Pn109)", "Speed feedforward input (V-REF) " and "Torque feedforward (T-REF) input" will become invalid.

According to the system configuration, if you want to use the "Speed feedforward input (V-REF)" and "Torque feedforward input(T-REF) " from the host device and model tracking control at the same time, please set Pn140.3 = 1.

Table 7-31 Parameters for feedforward function

| Parameter | | Contents | When enabled | Classification |
|-----------|----------------------------|-------------------------------------------------------------------------------|--------------|----------------|
| Pn140 | n.0 □□□ (Default value) | Do not use Model tracking control and Speed/torque feedforward simultaneously | Immediately | Tuning |
| | n.1 □□□ | Using Model tracking control and Speed/torque feedforward simultaneously | | |

Note: When using the model following control under this function, the best feedforward will be set inside the servo.

Therefore, generally do not use the "Speed feedforward (V-REF) input" and "Torque feedforward (T-REF) input" from the host device at the same time.

However, Model following control and "Speed feedforward (V-REF) input" and "Torque feedforward (T-REF) input" can be used at the same time as required.

At this time, if the input feedforward is incorrect, it may cause overshoot.

7.8.3 Related parameters

Related parameters are shown in table 7-32 below.

- Parameters related to this function

The parameters used or referenced when executing this function.

- Is it possible to change the setting value of the parameter when executing this function?

"No": When executing this function, parameters cannot be changed through HCServoWorks, etc.

"Yes": Parameters can be changed through HCServoWorks, etc. when executing this function.

- Whether there is automatic setting of parameters after executing this function

"Yes": After executing this function, the parameter setting value will be automatically set or adjusted.

"No": After executing this function, the parameter setting value will not be automatically set or adjusted.

Table 7-32 Parameters for Vibration Suppression Function

| Parameter | Name | Is it possible to change the setting value | Automatic setting |
|-----------|--------------------------------------------------------|--------------------------------------------|-------------------|
| Pn140 | Model following control-related selections | Yes | Yes |
| Pn141 | Model following control gain | No | Yes |
| Pn142 | Model following control gain correction | No | No |
| Pn143 | Model following control bias in the forward direction | No | No |
| Pn144 | Model following control bias in the reverse direction | No | No |
| Pn145 | Vibration suppression 1 frequency A | No | Yes |
| Pn146 | Vibration suppression 1 frequency B | No | Yes |
| Pn147 | Model following control speed feedforward compensation | No | No |
| Pn14A | Vibration suppression 2 frequency | No | No |
| Pn14B | Vibration suppression 2 correction | No | No |

7.9 Adjustment application function

The following describes the functions for further individual adjustments after advanced auto-tuning 1, advanced auto-tuning 2, and one-parameter tuning.

- Gain switching.
- Friction compensation function.
- Current control mode selection.
- Current gain value setting.
- Speed detection method selection.

7.9.1 Gain switching

The gain switching function includes "Manual gain switching" that uses an external input signal and "Auto gain switching".

By using the gain switching function, the gain can be increased during positioning to shorten the positioning time, and the gain can be decreased to suppress vibration when the servo motor is stopped.

Table 7-33 Parameters for gain switching

| Parameter | | Contents | When enabled | Classification |
|-----------|-----------------------------|-----------------------|--------------|----------------|
| Pn139 | n. □□□ 0 (Default value) | Manual gain switching | Immediately | Tuning |
| | n. □□□ 2 | Auto gain switching | | |

Note: 1. n. □□□ 1 is a reserved parameter (Do not set).

2. For gain switching combinations, please refer to "1) Gain switching combinations".
3. For manual gain switching, please refer to "2) Manual gain switching".
4. For the auto gain switching, please refer to "(3) Auto gain switching".

(1) Gain switching combinations

Table 7-34 Gain switching combinations

| Gain switching | Speed loop gain | Speed loop integral time constant | Position loop gain | Torque command filter | Model tracking control gain* | Model tracking control gain correction* | Friction compensation gain |
|----------------|-----------------------------|-----------------------------------------------|--------------------------------|--------------------------------------------------------------|-----------------------------------------|----------------------------------------------------|----------------------------------------------|
| 1st gain | Speed loop gain (Pn100) | Speed loop integral time constant (Pn101) | Position loop gain (Pn102) | Filter time constant of 1st stage 1st torque command (Pn401) | Model tracking control gain (Pn141) | Model tracking control gain correction (Pn142) | Model friction compensation gain (Pn121) |
| 2nd gain | 2nd speed loop gain (Pn104) | 2nd speed loop integral time constant (Pn105) | 2nd position loop gain (Pn106) | Filter time constant of 1st stage 2nd torque command (Pn412) | 2nd model tracking control gain (Pn148) | 2nd model tracking control gain correction (Pn149) | 2nd model friction compensation gain (Pn122) |

*The gain switching of model tracking control gain and model tracking control gain correction is only applicable to "Manual switching gain".

In addition, the gain is switched only when the following conditions are satisfied at the same time and the gain switching signal is input. When the conditions are not met, even if other parameters in the above table are switched, these parameters

will not be switched.

- No command
- The servo motor stops

(2) Auto gain switching

"Auto gain switching " is only valid at position control. The switching conditions are executed with the following settings.

Table 7-35 Parameters for auto gain switching

| Parameter | | Switch condition | Switching gain | Waiting time | Switching time |
|-----------|----------|---------------------------|----------------------|-------------------------|---------------------------|
| Pn139 | n. □□□ 2 | Condition A satisfied | 1st gain 2nd gain | Waiting time 1 Pn135 | Switching time 1 Pn131 |
| | | Condition A not satisfied | 2nd gain 1st gain | Waiting time 2 Pn136 | Switching time 2 Pn132 |

Select "Switching condition A" for auto gain switching from the following settings.


Table 7-36 "Switching condition A" parameters of auto gain switching

| Parameter | | Position control Switching condition A | Other than position control (no switching) | Waiting time | Switching time |
|-----------|------------------------------|--------------------------------------------------------------------------|------------------------------------------------|--------------|----------------|
| Pn139 | n. □□ 0 □ (Default value) | Positioning completion signal (/COIN) ON | Fixed at 1st gain | Immediately | Tuning |
| | n. □□ 1 □ | Positioning completion signal (/COIN) OFF | Fixed at 2nd gain | | |
| | n. □□ 2 □ | Positioning proximity signal (/NEAR) ON | Fixed at 1st gain | | |
| | n. □□ 3 □ | Positioning proximity signal (/NEAR) OFF | Fixed at 2nd gain | | |
| | n. □□ 4 □ | Position command filter output = 0 And the command pulse input is OFF | Fixed at 1st gain | | |
| | n. □□ 5 □ | Position command pulse input ON | Fixed at 2nd gain | | |

*Auto switching mode 1 (Pn139.0=2)

Relationship between waiting time and switching time at gain switching

For example, assume where the position loop gain Pn102 is switched to the 2nd position loop gains Pn106 in the auto gain switching mode conditional on the positioning completion signal (/COIN) ON. The /COIN signal of the switching condition is ON, and the gain is linearly changed from Pn102 to Pn106 during the switching time Pn131 after waiting for the waiting time Pn135 from the time when the switching condition is satisfied.






Figure 7-3 Relationship between waiting time and switching time at gain switch

Note: Gain switching can be executed under PI or IP control mode (Pn10B).

(3) Related parameters

Table 7-37 Parameters for adjustment application function

| Parameter | Meaning | When enabled | Classification |
|-----------|---------------------------------------------------|--------------|----------------|
| Pn100 | Speed loop gain | Immediately | Tuning |
| Pn101 | Speed loop integral time constant | | |
| Pn102 | Position loop gain | | |
| Pn401 | 1st stage 1st torque command filter time constant | | |
| Pn141 | Model following control gain | | |
| Pn142 | Model following control gain correction | | |
| Pn121 | Friction compensation gain | | |
| Pn104 | 2nd speed loop gain | | |
| Pn105 | 2nd speed loop integral time constant | | |
| Pn106 | 2nd position loop gain | | |
| Pn412 | 1st stage 2nd torque command filter time constant | | |
| Pn148 | 2nd model following control gain | | |
| Pn149 | 2nd model following control gain correction | | |
| Pn122 | 2nd friction compensation gain | | |

(4) Related parameters for auto gain switching

Table 7-38 Parameters related to auto gain switching

| Parameter | Meaning | When enabled | Classification |
|-----------|-------------------------------|--------------|----------------|
| Pn131 | Gain switching time 1 | Immediately | Tuning |
| Pn132 | Gain switching time 2 | | |
| Pn135 | Gain switching waiting time 1 | | |
| Pn136 | Gain switching waiting time 2 | | |

(5) Related monitoring

Table 7-39 Monitoring No. related to auto gain switching

| Monitoring No. | Monitoring name | Display value | Content |
|----------------|---------------------|---------------|--------------------------------------|
| Un014 | Active gain monitor | 1 | Displayed when the 1st gain is valid |
| | | 2 | Displayed when the 2nd gain is valid |

Note: "1" is displayed when the tuning-less function is valid.

Table 7-40 Monitoring parameters related to auto gain switching

| Parameter | Analog monitoring | Monitoring name | Output value | Content |
|-----------|-------------------|---------------------|--------------|-----------------------|
| Pn006 | n. □ □ 0B | Active gain monitor | 1V | The 1st gain is valid |
| Pn007 | | | 2V | The 2nd gain is valid |

7.9.2 Manual adjustment of friction compensation

The friction compensation function is to correct viscous friction fluctuations and fixed load fluctuations.

The friction compensation function can be automatically adjusted through advanced auto-tuning 1, advanced auto-tuning 2, and One-parameter tuning. The following describes the procedure when manual adjustment is required.

(1) Parameters to be set

To use the friction compensation function, the following parameters need to be set.

Table 7-41 Parameters for friction compensation function

| Parameter | Meaning | When enabled | Classification |
|-----------|---------------------------|--------------|----------------|
| Pn408 | n.0 □ □ □ (Default value) | Immediately | Tuning |
| | n.1 □ □ □ | | |

Table 7-42 Parameters for friction compensation function

| Parameter | Meaning | When enabled | Classification |
|-----------|--------------------------------------------|--------------|----------------|
| Pn121 | Friction compensation gain | Immediately | Tuning |
| Pn123 | Friction compensation coefficient | | |
| Pn124 | Friction compensation frequency correction | | |
| Pn125 | Friction compensation gain correction | | |

(2) Operation steps of friction compensation function

The operation steps of the friction compensation function are as follows.

Note: When using the friction compensation function, please set the moment of inertia ratio (Pn103) as correctly as possible. If the moment of inertia ratio is incorrect, it may cause vibration.

① Restore the following parameters related to friction compensation to the default settings.

Friction compensation gain (Pn121) → Default value: 100

Friction compensation coefficient (Pn123) → Default value: 0

Friction compensation frequency correction (Pn124) → Default value: 0

Friction compensation gain correction (Pn125) → Factory setting: 100

Note: Please make the friction compensation frequency correction (Pn124) and friction compensation gain correction (Pn125) always be the default settings.

② To confirm the effect of the friction compensation function, please increase the friction compensation coefficient (Pn123) gradually.

Note: Normally, please set the setting value of the friction compensation coefficient (Pn123) below 95%. If the effect is not obvious enough, please increase the setting value of the friction compensation gain (Pn121) by 10% within the range of no vibration

The effect of adjusting parameters:

Pn121: Friction compensation gain

Set parameters of response to external disturbances. The higher the setting value, the better the response to external disturbance, but if the setting value is too high, vibration may occur when the device has a resonance frequency.

Pn123: Friction compensation coefficient

Sets the parameters for the friction compensation effect. The higher the setting value, the better the effect, but if the setting value is too high, the response is more likely to vibrate. Generally, please set the setting value below 95%.

③ Adjustment effect: The adjustment result is shown as follows in the form of waveform diagrams before and after adjustment.




Figure 7-4 Waveforms to adjustment results before and after adjustment

7.9.3 Current control mode selection function

The current control mode selection function can reduce the high-frequency noise during the servo motor stop. The models can use this function are as follows. This function is valid in the default setting mode, and is set as a valid condition in many occasions. When using this function, please set Pn009.1 = 1.

Table 7-43 Parameters for current control mode selection function

| Parameter | Meaning | When enabled | Classification |
|-----------|------------------------------|--------------------------|----------------|
| Pn009 | n. □ □ 0 □ | Restart the power supply | Tuning |
| | n. □ □ 1 □ (Factory setting) | | |

7.9.4 Current gain value setting function

The current gain value setting function is to adjust the current control parameters inside the servo drive according to the speed loop gain (Pn100) to reduce noise. By reducing the current gain value (when Pn13D is 2000, the current gain is the internal setting value), the noise level can be reduced. But at the same time, it will cause the response characteristics of the servo drive. Therefore, please adjust within the range that can ensure the response characteristics. In addition, it is invalid during torque control (Pn000.1 = 2).



Points

- Selecting power supply control mode 2 may increase the load rate which is in stop.

Table 7-44 Parameters for current gain value setting function

| Pn13D | Current gain value | | Speed | Position | Torque | When enabled | Classification |
|-------|--------------------|------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 100~2000 | 1% | 2000 | | | Immediately | Setup |

Note: After changing this function, the response characteristics of the speed loop will also change, so it is necessary to re-adjust the servo.

7.9.5 Speed detection method selection

The speed detection method selection can smooth the servo motor speed during operation. Please set Pn009.2 = 1 and select Speed detection 2 to make the motor speed smooth.

Table 7-45 Parameters for speed detection method selection

| Parameter | Meaning | When enabled | Classification |
|-----------|-------------------------------------------------------------------------------------------------|--------------------------|----------------|
| Pn009 | n. <input type="checkbox"/> 0 <input type="checkbox"/> <input type="checkbox"/> (Default value) | Restart the power supply | Tuning |
| | n. <input type="checkbox"/> 1 <input type="checkbox"/> <input type="checkbox"/> | | |

Note: After changing the speed detection method, the response characteristics of the speed loop will also change, so it is necessary to re-adjust the servo.

7.10 Other adjustments functions

7.10.1 Feedforward

Feedforward is the function of performing feedforward compensation to shorten the positioning time during Position control.

Table 7-46 Parameters for Feedforward

| Pn109 | Feedforward | | Position | When enabled | Classification |
|-------|----------------------------------|--------|---------------|--------------|----------------|
| | Setting range | Unit | Default value | | |
| | 0~100 | 1% | 0 | Immediately | Setup |
| Pn10A | Feedforward filter time constant | | Position | When enabled | Classification |
| | Setting range | Unit | Default value | | |
| | 0~6400 | 0.01ms | 0 | Immediately | Setup |

Note: If the feed-forward setting value is too large, it may cause mechanical vibration. Please lower the setting value to 80% or less.

7.10.2 Setting mode switch (P control/PI control switching)

The Mode switch is a function to automatically switch between P control and PI control.

Set switching conditions through Pn10B.0, and P control starts when the setting values of Pn10C, Pn10D, Pn10E, and Pn10F are exceeded.

If switching conditions and condition values are set, overshoot can be suppressed during acceleration and deceleration and the settling time can be shortened.

(1) Related parameters

Select the switching condition of the Mode switching through Pn10B.0.

Table 7-47 Parameters for setting mode switching

| Parameter | | Select mode switch | Parameters that set conditional values | When enabled | Classification |
|-----------|---------------------------|----------------------------------------|----------------------------------------|--------------|----------------|
| Pn10B | n. □□□ 0 (Default value0) | Conditional on internal torque command | Pn10C | Immediately | Setup |
| | n. □□□ 1 | Conditional on speed command | Pn10D | | |
| | n. □□□ 2 | conditional on acceleration | Pn10E | | |
| | n. □□□ 3 | Conditional on positional deviation | Pn10F | | |
| | n. □□□ 4 | Mode switching not selected | - | | |


Table 7-48 Parameters for setting switching condition

| Parameter | Meaning | When enabled | Classification |
|-----------|---------------------------------------------|--------------|----------------|
| Pn10C | Mode switching level for torque command | Immediately | Tuning |
| Pn10D | Mode switching level for speed command | | |
| Pn10E | Mode switching level for acceleration | | |
| Pn10F | Mode switching level for position deviation | | |

Example: When the switching condition of the mode switching is used as the torque command (default setting)

When the torque command exceeds the torque set in Pn10C, the speed loop will switch to P control.

The torque command value is set to 200% at the factory.



7.10.3 Torque command filter

A delay filter and a notch filter are serially configured in the torque command, and they act independently.

The notch filter is enabled/disabled through Pn408.

(1) Torque command filter

If the vibration of the machine may be caused by the servo drive, if the following torque command filter time parameters are adjusted, the vibration may be eliminated. The smaller the value, the better the response, but it is limited by the mechanical conditions.

Table 7-49 Parameters for torque command filter

| Pn401 | 1st stage 1st torque command filter time constant | | | When enabled | Classification | |
|-------|---------------------------------------------------|--------|---------------|--------------|----------------|--------|
| | | Speed | Position | | | Torque |
| | Setting range | Unit | Default value | | | |
| | 0~65535 | 0.01ms | 100 | | Immediately | Tuning |

Setting standard of torque command filter

- Speed loop gain (Pn100[Hz]) and torque filter time constant (Pn401[ms])
- Adjustment value of stable control range $Pn401[ms] \leq 1000 / (2\pi Pn100[Hz] \cdot 4)$
- Limit adjustment value $Pn401[ms] < 1000 / (2\pi \cdot Pn100[Hz] \cdot 1)$

Table 7-50 Parameters for filter frequency of the 2nd stage 2nd torque command

| Pn40F | 2nd stage 2nd torque command filter frequency | | | When enabled | Classification |
|-------|-----------------------------------------------|------|---------------|--------------|----------------|
| | Setting range | Unit | Default value | | |
| | 100~5000 | 1Hz | 5000 | Immediately | Tuning |

Table 7-51 Parameters for 2nd stage 2nd torque command filter Q value

| Pn410 | 2nd stage 2nd torque command filter Q value | | | When enabled | Classification |
|-------|---------------------------------------------|--------|---------------|--------------|----------------|
| | Setting range | Unit | Default value | | |
| | 50~100 | 0.01ms | 50 | Immediately | Tuning |

Note: When set to 5000, the filter becomes invalid.

2) Notch filter

The notch filter is a filter used to eliminate specific vibration frequency components caused by resonance of the ball screw shaft, etc.

The gain curve is shown in the figure below, and a specific frequency (hereinafter referred to as the notch frequency) is in the shape of a notch, which can reduce or eliminate the notch frequency.

The larger the value of the Q value of the notch filter, the more severe the notch and phase delay.

Note: Select the notch filter to be valid/invalid through Pn408.

Table 7-52 Parameters for the validity/invalidity of notch filter

| Parameter | Meaning | 生效时刻 | Classification | |
|-----------|---------------------------|------------------------------------|----------------|-------|
| Pn408 | n. □□□ 0 (Default value) | Disable the 1st stage notch filter | Immediately | Setup |
| | n. □□□ 1 | Enable the 1st stage notch filter | | |
| | n. □ 0 □□ (Default value) | Disable the 2nd stage notch filter | | |
| | n. □ 1 □□ | Enable the 2nd stage notch filter | | |


Table 7-53 Notch filter parameters by mechanical vibration frequency

| Parameter | Meaning | When enabled | Classification |
|-----------|----------------------------------|--------------|----------------|
| Pn409 | 1st stage notch filter frequency | Immediately | Tuning |
| Pn40A | 1st stage notch filter Q value | | |
| Pn40B | 1st stage notch filter depth | | |
| Pn40C | 2nd stage notch filter frequency | | |
| Pn40D | 2nd stage notch filter Q value | | |
| Pn40E | 2nd stage notch filter depth | | |




Note: 1. Do not set the notch filter frequency (Pn409 or Pn40C) close to the response frequency of the speed loop. At least this frequency should be set as 4 times of the speed loop gain (Pn100) (but Pn103 should be set correctly). Incorrect setting may cause mechanical damage due to vibration.

2. Be sure to change the notch filter frequency (Pn409 or Pn40C) when the servo motor stop. If making changes while the servo motor is running, it may cause vibration.

Q value = 0.7



Q value = 1.0



Chapter 8 Auxiliary Function

| | | |
|------|---------------------------------------------------------------------------------------|-----|
| 8.1 | Auxiliary function list..... | 211 |
| 8.2 | Display of alarm record (Fn000)..... | 211 |
| 8.3 | Simple rigidity selection (Fn001)..... | 212 |
| 8.4 | JOG (Fn002)..... | 214 |
| 8.5 | Origin search (Fn003)..... | 214 |
| 8.6 | JOG program (Fn004)..... | 215 |
| 8.7 | Initialize parameters (Fn005)..... | 217 |
| 8.8 | Clear alarm history (Fn006)..... | 217 |
| 8.9 | Setting (Initialization) of the absolute encoder and encoder alarm reset (Fn008)..... | 218 |
| 8.10 | Auto tuning motor current detection signal offset (Fn00E)..... | 218 |
| 8.11 | Manually adjust motor current detection signal offset (Fn00F)..... | 219 |
| 8.12 | Writing prohibition setting (Fn010)..... | 219 |
| 8.13 | Display servomotor model (Fn011)..... | 220 |
| 8.14 | Display software version (Fn012)..... | 221 |
| 8.15 | Initialize vibration detection Level (Fn01B)..... | 221 |
| 8.16 | Software reset (Fn030)..... | 222 |
| 8.17 | Magnetic pole detection (Fn080)..... | 223 |
| 8.18 | Current JOG (Fn082)..... | 223 |
| 8.19 | Tuning-less level setting (Fn200)..... | 223 |
| 8.20 | Advanced auto tuning 1 (Fn201)..... | 224 |
| 8.21 | Advanced auto tuning 2 (Fn202)..... | 225 |
| 8.22 | One-parameter tuning (Fn203)..... | 226 |
| 8.23 | EasyFFT (Fn206)..... | 226 |

8.1 Auxiliary function list

Auxiliary functions refer to functions related to the operation and adjustment of the servo motor.

Displayed as a number starting with Fn on the operation panel.

In 730W, press the Axis Switch key to change the axis number. The auxiliary functions and operation steps are identical for all axes.

The following table lists the overview and reference items of auxiliary functions.

Table 8-1 List of auxiliary functions

| Fn No. | Function | Operation of the operation panel | By HCServoWorks | Reference chapter |
|--------|--------------------------------------------------------------------------|----------------------------------|-----------------|-------------------|
| Fn000 | Display alarm history | 1 | 1 | 8.2 |
| Fn001 | Simple rigidity selection | 1 | 1 | 8.3 |
| Fn002 | JOG | 1 | 1 | 8.4 |
| Fn003 | Origin search | 1 | 1 | 8.5 |
| Fn004 | Jog program | 1 | 1 | 8.6 |
| Fn005 | Initialize parameters | 1 | 1 | 8.7 |
| Fn006 | Clear alarm history | 1 | 1 | 8.8 |
| Fn008 | Setting (initialization) of the absolute encoder and encoder alarm reset | 1 | 1 | 8.9 |
| Fn00E | Auto tuning motor current detection signal offset | 1 | 1 | 8.10 |
| Fn00F | Manually adjust motor current detection signal offset | 1 | 1 | 8.11 |
| Fn010 | Write prohibition setting | 1 | 0 | 8.12 |
| Fn011 | Display servomotor model | 0 | 1 | 8.13 |
| Fn012 | Display software version | 1 | 1 | 8.14 |
| Fn01B | Initialize vibration detection level | 0 | 1 | 8.15 |
| Fn030 | Software reset | 1 | 1 | 8.16 |
| Fn080 | Magnetic pole detection | 1 | 1 | 8.17 |
| Fn082 | Current JOG | 1 | 1 | 8.18 |
| Fn200 | Tuning-less level setting | 1 | 1 | 8.19 |
| Fn201 | Advanced auto tuning | 1 | 1 | 8.20 |
| Fn202 | Advanced auto tuning with command | 0 | 1 | 8.21 |
| Fn203 | One-parameter tuning | 1 | 1 | 8.22 |
| Fn204 | Adjust anti-resonance control | 0 | 1 | — |
| Fn205 | MFC vibration detection | 0 | 1 | — |
| Fn206 | EasyFFT | 1 | 1 | 8.23 |
| Fn207 | Auto vibration detection | 0 | 1 | — |

1: Operable 0: Not operable

8.2 Display of alarm record (Fn000)

The servo drive has a retroactive display function, which can display up to 10 alarm records that have occurred.

The number and time stamp of the alarm occurrence can be confirmed.

Time stamp is a function that measures the duration after the control power supply and main circuit power supply are turned on in units of 100ms, and displays the total operating time when an alarm occurs.

If it is operated 24 hours a day, 365 days a year, it can be continuously measured for about 13 years.

< Time stamp display example >

When displaying 36000

$$36000 \times 100 \text{ [ms]} = 3600 \text{ [s]} = 60 \text{ [min]} = 1 \text{ [h]}$$

So the total run time is 1 hour.

The procedure for displaying alarm records is as follows:

- ① Press the (M) key to switch to auxiliary function mode "Fn000".
- ② Long-press (S) for 1 sec., and the latest alarm will be displayed.
- ③ After short-pressing (S), the lower 4 digits of the alarm time stamp will be displayed, and short-press (S) to display the middle 4 digits of the alarm time stamp, then short-press (S) once to display the highest 2 digits of the alarm time stamp. Then short-press (S) again to display the alarm record currently viewed.
- ④ Press the (▲) key to display the previous alarm. Press (▼) key to display the new alarm. The higher the number in the leftmost digit, the older the alarm displayed.
- ⑤ Press the (S) for about 1 sec, then return to the auxiliary function "Fn000".

<Supplements>

- When the same alarm occurs continuously, if the interval between error occurrences is less than 1 hour, it will not be saved, and if it exceeds 1 hour, the alarm will be saved.
- "□. _ _ _" is displayed on the operation panel.

CAUTION

- The overtravel prevention function is invalid during JOG operation. While operating, the operating range of the machinery used must be considered.

- Alarm records can only be deleted through "Clear Alarm History (Fn006)". Even if the alarm is reset or the main circuit power of the servo drive is cut off, the alarm history cannot be deleted.

8.3 Simple rigidity selection (Fn001)

The operation steps for the simple rigidity selection (Fn001) are as follows:

- ① Press the (M) on the panel to select the auxiliary function Fn000, and the panel displays "Fn000".
- ② Press the (▲) or (▼), and the panel displays "Fn001".
- ③ Press the (S) for about 1 second, and the panel displays "d.0001".
- ④ Press the (▲) or (▼) to adjust the offset value.
- ⑤ After pressing the (M), the panel displays "done" which flashes for about 1 second, and then the panel displays "d.00xx".
- ⑥ Press the (S) for about 1 second, and return to the auxiliary function panel to display "Fn001".

Table 8-2 Rigidity level comparison table(Pn10B.1=0 PI control)

| level (Rigidity level) | pn100 (Speed gain) | pn101 (Speed integration) | pn102 (Position gain) | pn401 (Torque filtering) |
|------------------------|--------------------|---------------------------|-----------------------|--------------------------|
| 1 | 100 | 4500 | 140 | 300 |
| 2 | 200 | 3000 | 286 | 198 |
| 3 | 300 | 2500 | 428 | 148 |
| 4 | 400 | 2000 | 571 | 99 |
| 5 | 500 | 1666 | 714 | 82 |
| 6 | 600 | 1333 | 857 | 66 |

| | | | | |
|----|------|------|------|----|
| 7 | 700 | 1166 | 1000 | 58 |
| 8 | 800 | 1000 | 1143 | 49 |
| 9 | 900 | 900 | 1286 | 44 |
| 10 | 1000 | 800 | 1429 | 39 |
| 11 | 1100 | 733 | 1571 | 36 |
| 12 | 1200 | 667 | 1714 | 33 |
| 13 | 1300 | 619 | 1857 | 30 |
| 14 | 1400 | 571 | 2000 | 28 |
| 15 | 1500 | 535 | 2143 | 26 |
| 16 | 1600 | 500 | 2286 | 24 |
| 17 | 1700 | 472 | 2428 | 23 |
| 18 | 1800 | 444 | 2571 | 22 |
| 19 | 1900 | 422 | 2714 | 20 |
| 20 | 2000 | 400 | 2857 | 19 |
| 21 | 2100 | 383 | 2940 | 18 |
| 22 | 2200 | 366 | 3080 | 17 |
| 23 | 2300 | 353 | 3220 | 16 |
| 24 | 2400 | 340 | 3370 | 15 |
| 25 | 2500 | 330 | 3500 | 14 |
| 26 | 2600 | 320 | 3650 | 13 |
| 27 | 2700 | 312 | 3800 | 12 |
| 28 | 2800 | 304 | 3930 | 11 |
| 29 | 2900 | 297 | 4118 | 10 |
| 30 | 3000 | 290 | 4250 | 9 |

Table 8-3 Rigidity level comparison table(Pn10B.1=1 I-P control)

| level (Rigidity level) | pn100 (Speed gain) | pn101 (Speed integration) | pn102 (Position gain) | pn401 (Torque filtering) |
|------------------------|--------------------|---------------------------|-----------------------|--------------------------|
| 1 | 100 | 2000 | 100 | 300 |
| 2 | 200 | 1400 | 200 | 200 |
| 3 | 300 | 900 | 300 | 130 |
| 4 | 400 | 700 | 400 | 100 |
| 5 | 500 | 500 | 500 | 80 |
| 6 | 600 | 450 | 600 | 70 |
| 7 | 700 | 400 | 700 | 60 |
| 8 | 800 | 350 | 800 | 50 |
| 9 | 900 | 320 | 900 | 45 |
| 10 | 1000 | 300 | 1000 | 40 |
| 11 | 1100 | 270 | 1100 | 32 |
| 12 | 1200 | 250 | 1200 | 35 |
| 13 | 1300 | 230 | 1300 | 32 |
| 14 | 1400 | 200 | 1400 | 30 |
| 15 | 1500 | 200 | 1500 | 27 |
| 16 | 1600 | 200 | 1600 | 25 |
| 17 | 1700 | 180 | 1700 | 22 |
| 18 | 1800 | 170 | 1800 | 20 |
| 19 | 1900 | 165 | 1900 | 17 |
| 20 | 2000 | 160 | 2000 | 15 |
| 21 | 2000 | 160 | 2000 | 15 |
| 22 | 2000 | 160 | 2000 | 15 |

| | | | | |
|----|------|-----|------|----|
| 23 | 2000 | 160 | 2000 | 15 |
| 24 | 2000 | 160 | 2000 | 15 |
| 25 | 2000 | 160 | 2000 | 15 |
| 26 | 2000 | 160 | 2000 | 15 |
| 27 | 2000 | 160 | 2000 | 15 |
| 28 | 2000 | 160 | 2000 | 15 |
| 29 | 2000 | 160 | 2000 | 15 |
| 30 | 2000 | 160 | 2000 | 15 |

8.4 JOG (Fn002)

JOG operation refers to the function to confirm the servo motor operation through speed control without connecting to the host device.

(1) Setting items before operation

To perform JOG operation, make the following settings in advance.

- When the S-ON input signal is ON, please switch it to OFF.
- input signal parameter is set to "S-ON force valid" (always-ON " valid "), please change it to a value other than " Force valid ".

Table 8-4 Parameters for Jog (JOG) speed

| Pn304 | Jogging speed | | | When enabled | Classification | |
|-------|---------------|-------|---------------|--------------|----------------------|--------|
| | | Speed | Position | | | Torque |
| | Setting range | Unit | Default value | | | |
| | 0 ~ 10000 | 1 rpm | 500 | | Immediately Setup | |

- Please set the JOG operation speed after considering the operation range of the machine used. JOG running speed is set by Pn304.

(2) Operation steps

The following describes the operation steps when the servo motor rotation direction is set to Pn000.0=0 (CCW is forward-rotation). Acceleration and deceleration in the process of FN002 is subject to Pn 305 and Pn 306. For the usage of these two parameters, please refer to " Section 6.9 Soft starting".

JOG operation are as follows:

- ① Press the (M) key to switch to auxiliary function mode "Fn000".
- ② Press the (▲) or (▼) to display "Fn002".
- ③ Press the (S) to display "=JOG".
- ④ Press the (M) key to display "--JOG" to enter into servo-ON.
- ⑤ Press the (▲) key (forward-rotation) to (▼) key (reversed-rotation) and the servo motor rotates at the speed set by Pn304.
- ⑥ Press the (M) key to enter into the servo-OFF. You can also press (S) for about 1 sec to turn off the servo.
- ⑦ Press the (S) key for about 1 sec, then return to "Fn002".

8.5 Origin search (Fn003)

Origin search is a function to determine the position of the origin pulse (phase C) of the incremental encoder and stop at that position. This function is used when the motor shaft and mechanical position need to be positioned.

Origin search can be performed under the following conditions.

- **S-ON is not input.**

The servo motor speed 60rpm.



Points

- Please execute the origin search when the coupling is not connected.
- Forward-rotation drive prohibition (P-OT) and reverse-rotation drive prohibition (N-OT) are invalid when performing origin search,

The operation steps of origin search and positioning are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "**F_n000**".
- ② Press the **(▲)** or **(▼)** key to display "**F_n003**",
- ③ Press the **(S)** for 1 sec, F_n003 (origin search) "**- .CSR**" is displayed for about 1 sec.
- ④ Press the **(M)** key to enable the servo and then long-press **(▲)** (forward-rotation) or **(▼)** (reverse-rotation) to origin search, then search direction changes according to the setting of Pn000.0. Then long-press **(▲)** (forward-rotation) or **(▼)** (reverse-rotation) until the servo motor stops, and the "**- .CSR**" flashes on the panel, at this moment, the origin search is completed.
- ⑤ After the origin search is completed, press **(M)** key to disable the servo motor, and the panel displays "**- .CSR**".
- ⑥ Press the **(S)** for 1 sec and return to the auxiliary function mode "**F_n003**"(origin search).

8.6 JOG program (Fn004)

JOG program refers to the function of setting and executing the continuous operation determined by the preset operation mode, moving distance, moving speed, acceleration and deceleration time, and the number of repeated operations.

This function is the same as JOG operation (Fn002) and no need to connecte the upper device. Confirm the servo motor's operation and have the simple positioning.

(1) Setting items before operation

To perform Program JOG operation, make the following settings in advance.

- Please consider the operating range and safe operating speed of the machine, and set the correct operating distance and operating speed.
- Please make the servo drive ready.
- Switch the S-ON input signal to OFF.

<Supplement>

- Position command filtering, in position control, can be performed.
- The Overtravel prevention function becomes valid.

(2) Related parameters

The parameters that can be set in the program JOG operation are as follows.

Table 8-5 Parameters for Program JOG operation setting

| Pn530 | Program Jogging-related selections | | | When enabled | Classification | |
|-------|------------------------------------|-------|---------------|--------------|----------------|--------|
| | | Speed | Position | | | Torque |
| | Setting range | Unit | Default value | | | |
| | 0000 ~ 0005H | - | 0000 | | Immediately | |

| | | | | | | | | |
|-------|-------------------------------------------------|--------------------|---------------|-------|----------|--------|--------------|----------------|
| Pn531 | Program Jogging travel distance | | | Speed | Position | Torque | When enabled | Classification |
| | Setting range | Unit | Default value | | | | | |
| | 1 ~ 1073741824 (2 ³⁰) | 1 instruction unit | 32768 | | | | | |
| Pn533 | Program jogging travel speed | | | Speed | Position | Torque | When enabled | Classification |
| | Setting range | Unit | Default value | | | | | |
| | 1 ~ 10000 | 1 rpm | 500 | | | | | |
| Pn534 | Program jogging acceleration/ deceleration time | | | Speed | Position | Torque | When enabled | Classification |
| | Setting range | Unit | Default value | | | | | |
| | 2 ~ 10000 | 1 ms | 100 | | | | | |
| Pn535 | Program jogging waiting time | | | Speed | Position | Torque | When enabled | Classification |
| | Setting range | Unit | Default value | | | | | |
| | 0 ~ 10000 | 1 ms | 100 | | | | | |
| Pn536 | Program jogging travel count | | | Speed | Position | Torque | When enabled | Classification |
| | Setting range | Unit | Default value | | | | | |
| | 0 ~ 1000 | 1 | 1 | | | | | |

Table 8-6 Pn530 parameters setting

| Parameter | Meaning | Default value | |
|-----------|----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|
| Pn530 | n. □□□ 0 | (Waiting time Pn535 → Forward travel distance Pn531) × Number of movements Pn536 | 0 |
| | n. □□□ 1 | (Waiting time Pn535 → Reverse travel distance Pn531) × Number of movements Pn536 | |
| | n. □□□ 2 | (Waiting time Pn535 → Forward travel distance Pn531) × Number of movements Pn536 (Waiting time Pn535 → Reverse travel distance Pn531) × Number of movements Pn536 | |
| | n. □□□ 3 | (Waiting time Pn535 → Forward travel distance Pn531) × Number of movements Pn536 (Waiting time Pn535 → Reverse travel distance Pn531) × Number of movements Pn536 | |
| | n. □□□ 4 | (Waiting time Pn535 → Forward travel distance Pn531 → Waiting time Pn535 → Reverse travel distance Pn531) × Number of movements Pn536 | |
| | n. □□□ 5 | (Waiting time Pn535 → Forward travel distance Pn531 → Waiting time Pn535 → Forward travel distance Pn531) × Number of movements Pn536 | |



(3) How to set unlimited operation

- When Pn530.0=0/1/4/5, set the Number of movements (Pn536) to " 0 " to run infinitely.
- The program JOG operation mode follows the setting of Pn530.0. In various operating modes, when Pn536≠0, the maximum number of movements is 1000 times. Please refer to Table 8-3 and Table 8-4 for details.

(4) Operation steps

The operation steps of Program JOG operation are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode " Fn000 ".
- ② Press the **(▲)** or **(▼)** key to display " Fn004 ",
- ③ Press the **(S)** key for about 1 sec or more.
- ④ Press the **(M)** key to enter into servo-ON.

⑤ In accordance with the initial movement direction of the operation mode  or  key, it will start to act after the waiting time.

⑥ If the JOG operation of program finished, "" will flash and then return to the Step 4.

8.7 Initialize parameters (Fn005)















Points

- Parameter setting value initialization must be done with the servo OFF. It cannot be executed while the servo is ON.
- Restart the power supply to make the setting effective.

Function used to restore parameters to default settings.

The parameter setting initialization operation steps are as follows:












- ① Press the  key to switch to auxiliary function mode "".
- ② Press the  or  key to display "".
- ③ Press the  key for more than 1 second and display "".
- ④ Press the  key to start parameter initialization. During initialization, the display will blink.
- ⑤ After initialization is complete, "" will blink for about 1 second.
- ⑥ After displaying "donE", return to displaying "".
- ⑦ Press the  key, return "" is displayed.
- ⑧ To make the setting effective, please turn on the power of the servo drive again.

8.8 Clear alarm history (Fn006)

Function to delete all alarm records recorded in the servo drive.

Alarm records can only be deleted by this function. Even if the alarm is reset or the main circuit power supply of the servo drive is cut off, the alarm history cannot be deleted.

The operation steps to delete the alarm records are as follows:

- ① Press the  key to switch to auxiliary function mode "".
- ② Press the  or  key to display "".
- ③ Press the  key for more than 1 second, the display shows "".
- ④ Press the  key to clear the alarm history. after clearing "" will blink for about 1 second.
- ⑤ "donE" is displayed.
- ⑥ Press the  key to return to "".

8.9 Setting (Initialization) of the absolute encoder and encoder alarm reset (Fn008)

DANGER

- After the setting of the absolute encoder, the rotation amount of data will be within the range of -2 revolutions to +2 revolutions. Since the reference position of the mechanical system will change, please determine the reference position of the upper device according to the position after the setting.
- If the machine is operated without positioning the host device, unexpected mechanical movements may occur, resulting in personal accidents or mechanical damage. Please operate the machine with caution.

The absolute encoder must be initialized and set in the following situations:

When the system is put into use for the first time.

When the "Encoder Backup Alarm (A.810)" occurs.

When the "Encoder Checksum Alarm (A.820)" occurs.

When the serial data of the rotation amount of the absolute encoder needs to be initialized.

Perform the basic initialization setting through Fn008.

- ① Please press the **(M)** on the panel to select the auxiliary function Fn000, and the panel will display "Fn000".
- ② Press the **(▲)** or **(▼)**, and the panel will display "Fn008".
- ③ Press the **(S)** for about 1 second, and the panel will display "PGCLL".
- ④ Press the **(▲)** until the panel displays "PGCLS". (If a wrong key operation is performed halfway, the panel will display "no_op" and flash for about 1 second, and then return to the auxiliary function execution mode. At this time, please start the operation again from the beginning.)
- ⑤ Press the **(M)** to start the initialization setting of the absolute encoder. After the setting is completed, the panel will display "donE" and flash for about 1 second.
- ⑥ Return to the panel display "PGCLS".
- ⑦ To make the setting effective, please turn on the power again.

8.10 Auto tuning motor current detection signal offset (Fn00E)



Points

- The automatic adjustment of the offset value of the motor current detection signal must be operated at servo OFF.
- When the torque fluctuation is significantly larger than other servo drives, perform automatic adjustment of the offset.

This function is only used when higher precision adjustment is required to further reduce torque ripple. Generally no adjustments are required.

The operation steps of the automatic adjustment of the offset value of the motor current detection signal are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "Fn000".
- ② Press the **(▲)** or **(▼)** key to display "Fn00E".
- ③ Press the **(S)** key for more than 1 sec, and "CUR_o".
- ④ Press the **(M)** key to clear the alarm history. after clearing "donE" will blink for about 1 second.
- ⑤ "donE" display and returned.
- ⑥ Press the **(S)** key, and return to "Fn00E".

8.11 Manually adjust motor current detection signal offset (Fn00F)



Points

When performing manual adjustment, if this function executed by mistake, the characteristics may be reduced.

When performing manual adjustments, follow the precautions below.

- Make the servo motor rotate at about 100 rpm,
- Observe the torque command monitoring in the analog monitoring state, and reduce the fluctuation.

This function is only used when higher precision adjustment is required to further reduce torque ripple. Generally no adjustment is required.

The operation steps of manual adjustment of the offset value of the motor current detection signal are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "**Fn000**".
- ② Press the **(▲)** or **(▼)** key to display "**Fn00F**".
- ③ To adjust the U-phase offset, press **(S)** key for about 1 sec, and "**U1_0**" displayed.
- ④ Press the **(S)** key (less than 1 sec), and display U-phase offset.
- ⑤ Press the **(▲)** key or **(▼)** key to change the offset. The torque command must also be carefully adjusted while observing the monitor signal.
- ⑥ Press the **(S)** key (less than 1 sec) to confirm U-phase current offset adjustment.
- ⑦ Adjust the offset of V- phase. Press **(S)** key for about 1 sec, and "**U2_0**" display.
- ⑧ Press the **(S)** key (less than 1 sec), to display the offset value of V- phase.
- ⑨ Press the **(▲)** or **(▼)** key to change the offset. The torque command must also be carefully adjusted while observing the monitor signal.
- ⑩ Press the **(S)** key (less than 1 sec), and "**U2_0**" is displayed, to confirm the W-phase current offset adjustment.
- ⑪ Press the **(S)** key for about 1 sec, and "**Fn00F**" is displayed.

8.12 Writing prohibition setting (Fn010)

Function to prevent accidental writing of parameters.

(1) Operation steps

Table 8-7 Parameter setting

| Parameter value | Functional operation |
|-----------------|---------------------------------------------------------------------------------------|
| 0000 | Writing permission (write prohibition disabled) |
| 0001 | Write prohibition (parameters cannot be written after turning on the power next time) |

The operation steps of the automatic adjustment of the offset value of the motor current detection signal are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "**Fn000**".
- ② Press the **(▲)** or **(▼)** key to display "**Fn010**".
- ③ Press the **(S)** key for about 1 sec or more.
- ④ Press the **(▲)** or **(▼)** key, and set it to any of the following values. Refer to Table 8-6.
- ⑤ "**dOnE**" display and return to "**P000_**".
- ⑥ Press the **(S)** key for about a sec, and return to "**Fn010**".
- ⑦ To make the setting effective, please restart the power of the servo drive.

Note: This function of FN010 cannot be realized in the debugging software now.

(2) Related parameters

All Pn □□□ and auxiliary functions (Fn □□□) listed in " Table 8-9 Auxiliary function list of writing prohibition setting " can be set as write-prohibited or write-permitted.

Table 8-8 Auxiliary function list of writing prohibition setting

| Fn No. | Function | Operation by operation | By HCServoWorks HCServoWorks. |
|--------|--------------------------------------------------------------------------|------------------------|-------------------------------|
| Fn001 | Simple rigidity selection | 1 | 1 |
| Fn002 | JOG | 1 | 1 |
| Fn003 | Origin search | 1 | 1 |
| Fn004 | Jog program | 1 | 1 |
| Fn005 | Initialize parameters | 1 | 1 |
| Fn006 | Clear alarm history | 1 | 1 |
| Fn008 | Setting (initialization) of the absolute encoder and encoder alarm reset | 1 | 1 |
| Fn00E | Auto tuning motor current detection signal offset | 1 | 1 |
| Fn00F | Manually adjust motor current detection signal offset | 1 | 1 |
| Fn01B | Initialize vibration detection level | 0 | 1 |
| Fn080 | Magnetic pole detection | 1 | 1 |
| Fn082 | Current JOG | 1 | 1 |
| Fn200 | Tuning-less level setting | 1 | 1 |
| Fn201 | Advanced auto tuning | 1 | 1 |
| Fn202 | Advanced auto tuning with command | 0 | 1 |
| Fn203 | One-parameter tuning | 1 | 1 |
| Fn204 | Adjust anti-resonance control | 0 | 1 |
| Fn205 | MFC vibration detection | 0 | 1 |
| Fn206 | EasyFFT | 1 | 1 |
| Fn207 | Auto vibration detection | 0 | 1 |

Note: When the Writing Prohibition Setting (Fn010) is valid, if the above auxiliary functions are executed, the display on the panel operator is as follows, and the corresponding operations cannot be performed. To perform these auxiliary functions, the Fn010 must be changed to disabled, and "no op" will be displayed on the panel, flashing for 1 second.

H

• Auxiliary Function

8.13 Display servomotor model (Fn011)

This function displays the model, voltage, capacity, encoder type, and encoder resolution of the servo motor connected to the servo unit. If the servo unit is a special specification product, the special specification number will also be displayed.

The operation steps are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "Fn000".
- ② Press the **(▲)** or **(▼)** key to display "Fn011".
- ③ Press and hold the **(S)** key for about 1 second. The servo motor model and voltage identification data will be displayed, for example, "F0132", where 01 indicates a 220V motor, 3 indicates high inertia, and 2 indicates an X6 motor.
- ④ Press the **(M)** key to display the servo motor capacity. For example, "P0040" indicates 400W.
- ⑤ Press the **(M)** key to display the encoder type and resolution. For example, "E0023" indicates an incremental 23-bit encoder, and "E0123" indicates an absolute 23-bit encoder.
- ⑥ Press the **(M)** key to display the special specification number of the servo unit. "40000" indicates a standard product.
- ⑦ Press and hold the **(S)** key for about 1 second to return to the "Fn011" display.

8.14 Display software version (Fn012)

- ① Press the **(M)** key to switch to auxiliary function mode "Fn000".
- ② Press the **(▲)** or **(▼)** key to display "Fn012".
- ③ Press and hold the **(S)** key for about 1 second to display the host firmware version, e.g., "r.5311".
- ④ Press the **(M)** key to display the host firmware sub-version, e.g., "t.0b00".
- ⑤ Press the **(M)** key to display the Ecat ESC version, e.g., "E.0008".
- ⑥ Press the **(M)** key to display the boot version of the servo unit, e.g., "b.4C12".
- ⑦ Press the **(M)** key to display the slave version of the servo unit, e.g., "C.0724".
- ⑧ Press the **(M)** key to display the Ecat Xml version, e.g., "L.0000".
- ⑨ Press the **(M)** key to display the Ecat Xml version, e.g., "P.5428".
- ⑩ Press the **(S)** key to return to the "Fn012" display.

8.15 Initialize vibration detection Level (Fn01B)

This function is to automatically set the Vibration Detection Level (Pn312) in order to detect the "Vibration Alarm (A.520)" and "Vibration Warning (A.911)" more accurately after detecting the mechanical vibration in the running state.

The vibration detection function can detect the vibration component at a certain speed of the servo motor. When the vibration exceeds the detection value calculated by the following detection formula, an alarm or warning will be displayed through the Vibration Detection Selection (Pn310).

Detection value=Vibration detection

$$\text{Detection value} = \text{Vibration detection value (Pn312[rpm])} \times \text{Detection sensitivity (Pn311 [\%])} / 100$$

<Remarks>

- This function can only be set when the vibration is detected by the factory-set Vibration Detection Level (Pn312) and the "Vibration Alarm (A.520)" or "Vibration Warning (A.911)" is not displayed at the correct time.
- Depending on the state of the machine used, the detection sensitivity of vibration alarms and warnings may vary. In this case, fine-tune the Vibration Detection Sensitivity (Pn311) by referring to the detection formula above.



Points

- If the servo gain is not set properly, it may be difficult to detect vibration. And it may not be possible to detect all vibrations.
- Please set an appropriate Moment of Inertia Ratio (Pn103). If the settings are not correct, vibration alarms and vibration warnings may be falsely detected or may not be detected.
- To set this function, the customer must have the operation with the actual command.
- Execute after changing to the operating state where the vibration detection value is to be set. If the setting is made while the servo motor is rotating at low speed, vibration will be detected immediately after the servo is turned ON. If it is set when the servo motor is running at a speed less than 10% of the maximum speed, "Error" will be displayed.

(1) Steps

The operation steps of the automatic adjustment of the motor current detection offset are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "Fn000".

- ② Press the or key to display "Fn013".
- ③ Press the key for about 1 sec, and "d.INIT" displayed.
- ④ Press the key, then "d.INIT" flashes, it will detect and update the vibration value. The detection and update will continue until the MODE/SET key is pressed again.
- ⑤ Press the again at the appropriate time to finish the detection and updates. "done" displays after the setting is completed normally. "Error" will display when the setting cannot be completed normally.
- ⑥ Press the key to return to "Fn013".

(2) Related parameters

The relevant parameters are as follows:

Table 8-9 Parameters for vibration detection initialization

| Pn311 | Vibration detection sensitivity | | | When enabled | Classification | |
|-------|---------------------------------|-------|---------------|--------------|----------------------|--------|
| | | Speed | Position | | | Torque |
| | Setting range | Unit | Default value | | | |
| | 50 ~ 500 | 1% | 100 | | Immediately Setup | |

| Pn312 | Vibration detection level | | | When enabled | Classification | |
|-------|---------------------------|-------|---------------|--------------|----------------------|--------|
| | | Speed | Position | | | Torque |
| | Setting range | Unit | Default value | | | |
| | 0 ~ 5000 | 1 rpm | 50 | | Immediately Setup | |

Note: Pn312 is set by the detection value of vibration detection, so adjustment is not required. The detection sensitivity is set by Pn311.

Table 8-10 Pn310 Parameter setting

| Parameter | Meaning | When enabled | Classification |
|-----------|----------|------------------------------------------------------|----------------------|
| Pn310 | n. □□□ 0 | Do not detect vibration (Default value) | Immediately Setup |
| | n. □□□ 1 | A warning occur after vibration is detected (A.911). | Immediately Setup |
| | n. □□□ 2 | A warning occur after vibration is detected (A.520). | |

8.16 Software reset (Fn030)

This function resets the servo drive internally by software. Sometimes it is necessary to restart the power supply after changing the parameter setting. Using this function can make the setting effective without restarting the power supply.

| | |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Points | <ul style="list-style-type: none"> • This function must be operated at servo OFF. • This function has nothing to do with the upper device and can reset the servo drive. Be sure to disconnect with the upper device. |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

The operation steps of software reset are as follows:

- ① Press the key to switch to auxiliary function mode "Fn000".
- ② Press the or key to display "Fn030".
- ③ Press the key for about 1 sec to display "Srst1".
- ④ Press the key until "Srst5" displayed.
- ⑤ Press the key, the panel display disappears.

8.17 Magnetic pole detection (Fn080)

The operation steps of magnetic pole detection are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "**Fn000**".
- ② Press the **(▲)** or **(▼)** key to display "**Fn080**".
- ③ Press the **(S)** key for about 1 sec to display "**L0040**".
- ④ Press the **(M)** to display "**-PdEt**".
- ⑤ Press the **(M)** key, the panel display "**-PdEt**", start magnetic pole detection.
- ⑥ Jump to "**Fn080**" after detection is completed.

8.18 Current JOG (Fn082)

Jog operation is a function that allows the servo motor to be operated using torque control without connecting a host device.

(1) Preset items before operation

To perform jog operation, the following settings must be made in advance:

- When the S-ON input signal is ON, switch it to OFF.
- If Pn50A.1 is set to "7" (Always servo ON "enabled"), change it to a value other than "7".

(2) Operation steps

The operation steps for current jog operation are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "**Fn000**".
- ② Press the **(▲)** or **(▼)** key to display "**Fn082**".
- ③ Press and hold the **(S)** key for about 1 second to display "**T.000**".
- ④ Press the **(▲)** or **(▼)** key to adjust the torque command value.
- ⑤ Press and hold the **(S)** key for about 1 second to display "**R.000**".
- ⑥ Press the **(▲)** or **(▼)** key to adjust the electrical angle.
- ⑦ Press and hold the **(S)** key for about 1 second to display "**StoP.0**".
- ⑧ Press the **(M)** key to enter current jog. "**CJOG0**" is displayed.

- When the electrical angle is $< 360^\circ$, the current loop electrical angle is set to the adjusted value. Press the **(▲)** or **(▼)** key to output forward/reverse torque command. The motor holds its angle.

- When the electrical angle is $\geq 360^\circ$, the current loop electrical angle value is determined by the encoder. Press the **(▲)** or **(▼)** key to rotate the motor forward or reverse.

- ⑨ Press the **(M)** key to exit current jog. "**StoP.0**" is displayed.
- ⑩ Press the **(S)** key to return to the "**Fn082**" display.

8.19 Tuning-less level setting (Fn200)

Operation steps using the panel operator:

- ① Press the **(M)** key to switch to auxiliary function mode "Fn000".
- ② Press the **(^)** or **(v)** key to select "Fn200".
- ③ Press and hold the **(S)** key for 1 second to switch to the tuning-less load value setting screen "d 1".
- ④ Press the **(M)** key to switch to the tuning-less rigidity value setting screen "L 4".
- ⑤ Press the **(^)** or **(v)** key to select the rigidity value. The higher the number, the higher the gain and the higher the responsiveness. (Default value : 4)

- If the rigidity value is too high, vibration may occur. In this case, reduce the rigidity value.
- If high-frequency noise occurs, press the **(S)** key to automatically adjust the notch filter frequency to the vibration frequency.

⑥ Press the **(M)** key. The status display will change to "dOnE" and flash for about 1 second, then display "L0004". The setting is saved in the servo unit.

⑦ Press and hold the **(S)** key for about 1 second to return to the "Fn200" display.

Note: If overshoot occurs in the response waveform, or if the equipment is used under a load exceeding the permissible load moment of inertia (outside the product warranty), press the key to set the load value to "2".

8.20 Advanced auto tuning 1 (Fn201)

The operation steps for Advanced Automatic Tuning 1 (Fn201) are as follows:

- ① Press the **(M)** key to switch to auxiliary function mode "Fn000".
- ② Press the **(^)** or **(v)** to display "Fn201".
- ③ Press the **(S)** for about 1 second to enter the pre-start configuration stage and make adjustments according to actual needs.
 - (1) It shows "U. On". At this time, the inertia self - tuning is checked. If it needs to be unchecked, press the **(^)** and it will show "U. OFF".
 - (2) Press the **(M)**, it shows "0030". This is for tuning the moving distance, with the unit of turns. Use the **(^)** or **(v)** to change the moving distance.
 - (3) Press the **(M)**, it shows "L 2". Select the tuning mode ^{*1}. Use the **(^)** or **(v)** to change the mode.
 - (4) Press the **(M)**, it shows "t 2". Select the mechanical structure ^{*2}. Use the **(^)** or **(v)** to change the mode.
 - (5) Press the **(M)**, it shows "GAIN.2". Set the initial gain level for automatic tuning. Use the **(^)** or **(v)** to change the value.
 - (6) Press the **(M)**, it shows "UrAt.2". Set the initial estimated inertia for automatic tuning. Use the **(^)** or **(v)** to change the value.
 - (7) Press the **(M)**, it shows "COIn.4". Set the initial positioning accuracy for automatic tuning. Use the **(^)** or **(v)** to change the value.
 - (8) Press the **(M)**, it shows "6.0070". Set the gain saving ratio. Use the **(^)** or **(v)** to change the value, and use the **(S)** to shift.
 - (9) Press the **(M)**, it shows "Auto". The automation process is enabled by default. Press the **(^)** to change the setting, and it shows "hAnd" to turn off the automation process.
- ④ Press the **(S)** for about 1 second to start the tuning, and the following relevant key operations will be automatically executed. If users need to perform key operations manually, set it to "hAnd" in ③.(9) to turn off the automation process.
- ⑤ It shows "SET-" and the tuning process starts.

- ⑥ Press the to enable the servo, and it shows "SET--" or "SET-_".
- ⑦ Press the or to show "J.1000", and enter the inertia self-estimation stage. The displayed value flashes. After the estimation is completed, the displayed value stops flashing.
- ⑧ Press the or again to show "G.RUNS", and the gain search starts.
- ⑨ After the gain search is completed without errors, it shows "End".
- ⑩ Press the , it shows "donE". Save the tuning results and automatically exit the advanced automatic tuning. It shows "Fn201".

Note:

1. For the details of *1 tuning mode, please refer to 7.3 Advanced automatic tuning table 7-14 Explanation table of tuning modes.
2. For the details of *2 mechanical structure, please refer to 7.3 Advanced automatic tuning table 7-15 Explanation table of mechanism selection.
3. If any error occurs during the tuning process, "Error" will be displayed, and then it will automatically exit the advanced automatic tuning and display the warning code, such as ".9C3". For details, please refer to 7.3.2 "Tuning alarm number correspondence table".

8.21 Advanced auto tuning 2 (Fn202)

The operation steps for Advanced Automatic Tuning 2 (Fn202) are as follows:

- ① Press the key to switch to auxiliary function mode "Fn000".
- ② Press the or to display "Fn202".
- ③ Press the for about 1 second to enter the pre-start configuration stage and make adjustments according to actual needs.
 - (1) It shows "J. On". At this time, the inertia self - tuning is checked.
If it needs to be unchecked, press the and it will show "J. OFF".
 - (2) Press the , it shows "L 2". Select the tuning mode *1. Use the or to change the mode.
 - (3) Press the , it shows "E 2". Select the mechanical structure *2. Use the or to change the mode.
 - (4) Press the , it shows "GAIN.2". Set the initial gain level for automatic tuning. Use the or to change the mode.
 - (5) Press the , it shows "J-AB.2". Set the initial estimated inertia for automatic tuning. Use the or to change the mode.
 - (6) Press the , it shows "COIn.4". Set the initial positioning accuracy for automatic tuning. Use the or to change the mode.
 - (7) Press the , it shows "G.0070". Set the gain saving ratio. Use the or to change the value, and use the to shift.
 - (8) Press the , it shows "Auto". The automation process is enabled by default. Press the to change the setting, and it shows "hAnd" to turn off the automation process.
- ④ Press the for about 1 second to start the tuning, and the following relevant key operations will be automatically executed.

If users need to perform key operations manually, set it to "hAnd" in ③.(8) to turn off the automation process.
- ⑤ It shows "SET-", and the tuning process starts.

⑥ Control servo enable from the host unit, and it shows "SET-" or "SET-".

⑦ Press the \uparrow or \downarrow to show "J.1000", and enter the inertia self-estimation stage. The displayed value flashes.

After the estimation is completed, the displayed value stops flashing and show "G.runS". Input a position command from the host unit (it is recommended that the interval time between position commands be at least 300 ms), and then start the gain search.

⑧ After the gain search is completed without errors, it shows "End".

⑨ Press the S , it shows "donE". Save the tuning results and automatically exit the advanced automatic tuning. It shows "Fn202".

Note:

1. The *2 and *3 modes are the same as those in 8.17 Advanced Automatic Tuning 1 (Fn201).

2. For *1 and *4, when the servo controlled by the host computer unit is already in the running state, it can directly enter or exit the Advanced Automatic Tuning of Fn202. When the motor is running, "WAIT" will be displayed, and it will disappear only when the motor is in a stationary state (it is recommended that the interval time between position commands be at least 300 ms).

3. If any error occurs during the tuning process, "Error" will be displayed, and then it will automatically exit the advanced automatic tuning and display the warning code, such as ".9C3". For details, please refer to 7.4.2 "Tuning alarm number correspondence table".

8.22 One-parameter tuning (Fn203)

① Press the M key to switch to auxiliary function mode "Fn000".

② Press the \uparrow or \downarrow key to display "Fn203".

③ Press and hold the S key for about 1 second to display "A.d 0".

④ Press the \uparrow key to display "A.d 1".

⑤ Press the S key (for less than 1 second) to display "L0042".

⑥ Press the \uparrow or \downarrow key to change the value. Press the M key. "donE" will be displayed and flash three times, then "L0042" remains displayed.

8.23 EasyFFT (Fn206)

After vibration occurs, setting a notch filter according to the vibration frequency can sometimes be effective in suppressing vibration. This function utilizes the mechanical characteristics to detect and set the frequency of the notch filter and then sets this frequency as a parameter. This setting function is called EasyFFT.

EasyFFT transmits the periodic waveform command from the servo unit to the servo motor, causing the servo motor to rotate slightly several times within a certain period of time to make the machinery vibrate. The servo unit detects the resonance frequency based on the vibration generated by the machinery and then sets the corresponding notch filter according to this resonance frequency. The notch filter can effectively eliminate high-frequency vibrations and noises.



① Press the M key to switch to auxiliary function mode "Fn000".



② Press the \uparrow or \downarrow to display "Fn206".


③ Press the S for more than about 1 second, and it will display "In15" (Here, use the up and down keys to modify the vibration amplitude during the test, and keep it as the default without making any changes).




④ Press the S for more than about 1 second, and it will display "F. ".


⑤ Press the M (less than 1 second), and it will display ".run".

⑥ Press the  or , and the motor will run at a very small angle and make a sound. At the same time, "E_FFT" will flash three times.

⑦ After completion, it will display "F.XXXX" (XXXX is the first segment notch filter frequency detected in the current test). If multiple tests need to be performed, stay on this interface and press the  or  again.

After the test is completed, if this frequency needs to be written, press the , and it will display "done", and after flashing three times, it will still display "done".

⑧ Press the  or . Similar to the first segment test process, after displaying "F.XXXX", press the  again to write the second segment frequency.

⑨ When writing the first segment, PN408.0 will be changed to 1, that is, the function of the first segment is turned on, and at the same time, PN409 will be written (similarly for the second segment, change PN408.2 to 1, and write PN40C at the same time). after both segments are written, long press the  to exit the FN206 function.

⑩ After detecting the frequency, if the  is not pressed, the corresponding frequency will not be written.

Chapter 9 Monitoring Display

| | | |
|-------|---------------------------------------------------------|-----|
| 9.1 | Monitoring display list..... | 229 |
| 9.2 | Monitor display operation example..... | 231 |
| 9.3 | How to read 32-bit decimal display | 231 |
| 9.4 | Input signal monitoring..... | 231 |
| 9.4.1 | Input signal status confirmation | 231 |
| 9.4.2 | Input signal display status determination method..... | 231 |
| 9.4.3 | Input signal display example..... | 232 |
| 9.5 | Output signal monitoring | 232 |
| 9.5.1 | Output signal status confirmation | 232 |
| 9.5.2 | Output signal display status determination method | 232 |
| 9.5.3 | Output signal display example..... | 233 |
| 9.6 | Monitoring display at Power-ON | 233 |

9.1 Monitoring display list

Monitoring display is to display the command value, the status of input and output signals, and the internal status of the servo drive. The monitoring display list is as follows.

Table 9-1 Monitoring display list

| Un No. | Display content | Unit | Display description |
|---------|---------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|------------------------|
| Un000 | Motor speed | rpm | 16-bit decimal display |
| Un001 | Speed command | rpm | 16-bit decimal display |
| Un002 | Torque command (Related to rated torque) | % | 16-bit decimal display |
| Un003*3 | Rotation angle 1 | Number of pulses from origin | 32-bit decimal display |
| Un004 | Rotation angle 2 (Angle from origin (Electrical angle)) | deg | 16-bit decimal display |
| Un005*1 | Input signal monitoring | — | 32-bit binary display |
| Un006*2 | Output signal monitoring | — | 32-bit binary display |
| Un007 | Input command pulse speed (Valid only for position control) | rpm | 16-bit decimal display |
| Un008 | Deviation counter (Position deviation) (Valid only for position control) | Command unit | 32-bit decimal display |
| Un009 | Accumulated load ratio (100% rated torque: Display effective torque in 10s cycle) | % | 16-bit decimal display |
| Un00A | Regenerative load ratio (100% handleable regenerative power%: Display regenerative power consumption in 10s cycle) | % | 16-bit decimal display |
| Un00B | Power consumed by DB resistance (100% handleable power with the dynamic brake: DB power consumption in 10s cycle) | % | 16-bit decimal display |
| Un00C | Input command pulse counter (32-bit decimal display) | Command unit | 32-bit decimal display |
| Un00D | Feedback pulse counter (Incremental data of 4 times of the number of encoder pulses: 32-bit decimal display) | Encoder pulse | 32-bit decimal display |
| Un00E | Fully-closed loop feedback pulse counter (Incremental data of 4 times of the number of fully-closed loop feedback pulse : 32-bit decimal display) | External encoder pulse | 32-bit decimal display |
| Un00F | Fully-closed feedback speed | pulse/s | 32-bit decimal display |
| Un012 | Total operation time | 100 ms | 32-bit decimal display |
| Un013*3 | Feedback pulse counter | Command unit | 32-bit decimal display |
| Un014 | Effective gain monitor | — | 16-bit decimal display |
| Un032 | Instantaneous power consumption | [W] | 16-bit decimal display |
| Un033 | Power consumption | [Wh] | 32-bit decimal display |
| Un034 | Cumulative power consumption (integer part) | [Wh] | 32-bit decimal display |
| Un039 | Cumulative power consumption (fractional part) | [0.001Wh] | 32-bit decimal display |
| Un040 | Absolute encoder multiturn value | rev | 32-bit decimal display |
| Un041 | Absolute encoder single-turn value | Pulse | 32-bit decimal display |
| Un042 | Absolute encoder position data (lower word) | Pulse | 32-bit decimal display |
| Un043 | Absolute encoder position data (upper word) | Pulse | 32-bit decimal display |
| Un027 | Built-in fan life monitor | 0.01% | 16-bit decimal display |
| Un028 | Capacitor life monitor | 0.01% | 16-bit decimal display |
| Un029 | Soft-start circuit life monitor | 0.01% | 16-bit decimal display |
| Un02A | DB circuit life monitor | 0.01% | 16-bit decimal display |
| Un02B | Soft-start relay operation count | Count | 32-bit decimal display |
| Un02C | DB relay operation count | Count | 32-bit decimal display |
| Un058 | Coulomb friction identification status | — | 16-bit decimal display |
| Un059 | Coulomb friction identification fitness | — | 32-bit decimal display |
| Un060 | ESC application layer status | — | 16-bit decimal display |
| Un061 | PDI error counter (soft) | — | 16-bit decimal display |
| Un062 | Invalid frame counter of port 0 | — | 16-bit decimal display |

| | | | |
|-------|-----------------------------------------------|---------------|----------------------------|
| Un063 | Receive error counter of port 0 | — | 16-bit decimal display |
| Un064 | Invalid frame counter of port 1 | — | 16-bit decimal display |
| Un065 | Receive error counter of port 1 | — | 16-bit decimal display |
| Un066 | Forwarding error counter of port 0 | — | 16-bit decimal display |
| Un067 | Forwarding error counter of port 1 | — | 16-bit decimal display |
| Un068 | Program unit error counter | — | 16-bit decimal display |
| Un069 | PDI error counter (hw) | — | 16-bit decimal display |
| Un070 | PDI error code | — | 16-bit decimal display |
| Un071 | PDI/MC interface error code | — | 16-bit decimal display |
| Un072 | Port 0 link loss counter | — | 16-bit decimal display |
| Un073 | Port 1 link loss counter | — | 16-bit decimal display |
| Un094 | Advanced auto-tuning feedback | — | 16-bit hexadecimal display |
| Un107 | Residual vibration frequency | 0.1Hz | 16-bit decimal display |
| Un10A | Heatsink temperature monitor | °C | 16-bit decimal display |
| Un10D | Control board temperature monitor | °C | 16-bit decimal display |
| Un10F | Encoder internal temperature | °C | 16-bit decimal display |
| Un110 | Internal signal monitoring | — | 32-bit binary display |
| Un120 | Internal input signal monitoring | — | 32-bit binary display |
| Un130 | Internal output signal monitoring | — | 32-bit binary display |
| Un134 | Adaptive notch filter (Pn466) sweep frequency | Hz | 32-bit decimal display |
| Un138 | Online inertia value | % | 16-bit decimal display |
| Un140 | Main circuit bus voltage | V | 16-bit decimal display |
| Un141 | Current detection value | % | 16-bit decimal display |
| Un142 | Cumulative load rate | % (cycle 2ms) | 16-bit decimal display |
| Un143 | Regenerative load rate | % (cycle 20s) | 16-bit decimal display |
| Un144 | DB resistor power consumption | % (cycle 2ms) | 16-bit decimal display |
| Un145 | Maximum cumulative load rate | % (cycle 10s) | 16-bit decimal display |
| Un146 | Moment of inertia ratio / weight ratio | % | 16-bit decimal display |
| Un148 | T-REF monitor | % | 16-bit decimal display |
| Un149 | V-REF monitor | rpm, mm/s | 16-bit decimal display |
| Un14A | Input command pulse frequency | pps | 32-bit decimal display |
| Un171 | Control board temperature | 0.1°C | 16-bit decimal display |
| Un172 | Power board temperature | 0.1°C | 16-bit decimal display |
| Un203 | Abnormal parameter number setting (A.040) | — | 16-bit hexadecimal display |
| UnC1B | U-phase current AD value | — | 16-bit decimal display |
| UnC1C | V-phase current AD value | — | 16-bit decimal display |
| UnC1D | Motor mechanical angle | deg | 16-bit decimal display |
| UnC1E | Current loop status | — | 16-bit decimal display |
| UnC1F | Current loop control configuration | — | 16-bit decimal display |
| UnC20 | Current number of program jog runs | Count | 16-bit decimal display |
| UnC21 | Torque input P terminal AD | — | 16-bit decimal display |
| UnC22 | Torque input N terminal AD | — | 16-bit decimal display |
| UnC23 | Serial encoder disconnection count | Count | 16-bit decimal display |
| UnC24 | User position feedback | Command unit | 16-bit decimal display |

Note: *1. Refer to "9.4 Input signal monitoring".

*2. Refer to "9.5 Output signal monitoring".

*3. Refer to "9.3 How to read 32-bit decimal display".

9.2 Monitor display operation example

For details, refer to "5.2.8 Monitor display (Un □□□) operation".

9.3 How to read 32-bit decimal display

For details, refer to "5.2.6 Numerical value setting type".

9.4 Input signal monitoring

The status of input signals can be checked using "Input signal monitoring (Un005)". The confirmation procedure, display determination method, and display examples are shown below.


9.4.1 Input signal status confirmation

The steps to check the input signal status via Un005 are as follows:

- (1) Press the key **(M)** to switch to the monitor function mode display "Un005".
- (2) After pressing and holding the key **(S)** for 1 second, the current status is displayed. The status is shown on the panel operator's segments. Refer to "8.4.2 Input signal display status determination method" for how to read the display.
- (3) Press and hold the key **(S)** for about 1 second to return to the "Un005" display.

9.4.2 Input signal display status determination method

The status of the assigned input signal is displayed by the lighting status of the segments (LEDs) on the panel operator. The correspondence between input pins and LED numbers is shown in the table below.




- When the input signal is at H level, the upper segment (LED) lights up.
- When the input signal is at L level, the lower segment (LED) lights up.

| Display LED number | Output pin number | Pin name |
|--------------------|-------------------|----------|
| 1 | CN1-10 | DI1 |
| 2 | CN1-9 | DI2 |
| 3 | CN1-8 | DI3 |
| 4 | CN1-7 | DI4 |
| 5 | CN1-11 | DI5 |
| 6 | — | — |
| 7 | — | — |
| 8 | — | — |


9.4.3 Input signal display example

An example of the input signal display is shown below:

- When DI1 signal is at H level



- When DI1 signal is at L level



9.5 Output signal monitoring

The status of output signals can be checked using "Output signal monitoring (Un006)". The confirmation procedure, display determination method, and display examples are shown below.


9.5.1 Output signal status confirmation

The steps to check the output signal status via Un006 are as follows:

- (1) Press the key **(M)** to switch to the monitor function mode display "`Un006`".
- (2) After pressing and holding the key **(S)** for 1 second, the current status is displayed. The status is shown on the panel operator's segments. Refer to "8.5.2 Determining the display status of output signals" for how to read the display.
- (3) Press and hold the key **(S)** for about 1 second to return to the "`Un006`" display.

9.5.2 Output signal display status determination method

The status of the assigned output signal is displayed by the lighting status of the segments (LEDs) on the panel operator. The correspondence between output pins and LED numbers is shown in the table below.



- When the output signal is at H level, the upper segment (LED) lights up.
- When the output signal is at L level, the lower segment (LED) lights up.

| Display LED number | Output pin number | Pin name |
|--------------------|-------------------|----------|
| 1 | CN1-1, -6 | DO1 |
| 2 | CN1-2, -3 | DO2 |
| 3 | CN1-4, -5 | DO3 |
| 4 | — | — |
| 5 | — | — |
| 6 | — | — |
| 7 | — | — |
| 8 | — | — |

9.5.3 Output signal display example

An example of the output signal display is shown below.

- When the DO1 signal is active (H level active)




图 12-41 Monitor Display at Startup

9.6 Monitoring display at Power-ON

If set Un number through Pn52F, the data of the Un number will be displayed on the operation panel when the power is turned on. However, if it has been set to FFF [Default value], the status (bb, run, etc.) will be displayed when the power is turned on.

Table 9-2 Pn52F parameter setting

| Pn52F | Monitor Display at Startup | | Speed | Position | Torque | When enabled | Classification |
|-------|----------------------------|------|---------------|----------|--------|--------------|----------------|
| | Setting range | Unit | Default value | | | | |
| | 0-FFF | --- | FFF | | | | |

Chapter 10 Alarm & Warning Display

| | |
|----------------------------------------------------------------------------|-----|
| 10.1 Alarm display | 235 |
| 10.1.1 Alarm list..... | 235 |
| 10.1.2 Causes and troubleshooting | 238 |
| 10.2 Warning display..... | 252 |
| 10.2.1 Warning list..... | 252 |
| 10.2.2 Causes and troubleshooting..... | 254 |
| 10.3 Causes and troubleshooting based on the operation and conditions..... | 260 |

10.1 Alarm display

This section explains the processing method when an alarm occurs.

" 10.1.1 Alarm list" explains the 603F error code, the alarm name, the alarm content, the stop method when the alarm occurs, and whether the alarm can be reset.

" 10.1.2 Causes and troubleshooting" explains the causes of alarms and their treatment methods.

10.1.1 Alarm list

How to stop the alarm:

BM.1: Depends on Pn001.0. The default setting decelerates and stops the motor based on the deceleration time of Pn30A, then enters free control mode after stopping.

BM.2: Depends on Pn00B.1. The default setting is configured to stop the motor at the maximum deceleration torque value set for Pn406. After stopping, the motor enters BD control mode.

For torque control, generally use BM.1 to stop. By setting Pn00B.1 = 1, the same stop method as BM.1 can be set. When using multiple servo motors, this stop method can be used to prevent damage to the machine due to different stop methods.

Whether the alarm can be reset:

Yes: The alarm can be cleared by alarm reset. However, if the cause of the alarm is not completely eliminated, the alarm cannot be dismissed.

No: The alarm cannot be cleared by alarm reset .

The alarm list is as follows:

Table 10-1 Alarm list

| Alarm No. | 603F error code | Alert name | Content | How to stop when an alarm occurs | Whether the alarm can be reset (N/Y) |
|-----------|-----------------|----------------------------------|----------------------------------------------------------------------|----------------------------------|--------------------------------------|
| A.020 | 0x0020 | Parameter checksum error | There is an error in the parameter data in the servo drive. | BM.1 | N |
| A.021 | 0x0021 | Parameter format error | There is an error in the parameter data format in the servo drive. | BM.1 | N |
| A.022 | 0x0022 | System checksum error | There is an error in the parameter data in the servo drive. | BM.1 | N |
| A.030 | 0x0030 | Main circuit detector error | There is an error in the detection data for the main circuit. | BM.1 | Y |
| A.040 | 0x0040 | Parameter setting error | A parameter setting is outside of the setting range. | BM.1 | N |
| | 0x0040 | Output pin definition repetition | Output pin definition is repeated. | BM.1 | N |
| A.042 | 0x0042 | Parameter combination error | The combination of some parameters exceeds the setting range. | BM.1 | N |
| A.04A | 0x004A | Parameter setting error 2 | There is an error in parameter setting. | BM.1 | N |
| A.050 | 0x0050 | Combination error | The capacities of the servo drive and servo motor do not match. | BM.1 | Y |
| A.051 | 0x0051 | Unsupported device alarm | An unsupported device is connected. | BM.1 | N |
| A.056 | 0x0056 | Model information mismatch | The model information type is inconsistent with the default setting. | BM.1 | N |

| | | | | | |
|----------------|------------------|-----------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|------|---|
| A.057 | 0x0057 | Program exception or mismatch | The firmware type is inconsistent with the default setting. | BM.1 | N |
| A.080 | 0x0080 | Linear encoder optical scale pitch setting abnormal | The value of the linear encoder grating pitch (Pn282) remains at its default setting. | BM.1 | N |
| A.0B0 | 0x00B0 | Invalid servo ON command alarm | After executing the auxiliary function to power on the motor, the servo ON input (/S-ON) signal is input from the host controller. | BM.1 | Y |
| A.100 | 0x0100 | Overcurrent detection | An overcurrent flows through the power transistor or the heat sink overheated. | BM.1 | N |
| A.102 | 0x0102 | Current detection error | UVW and PE wiring error. | BM.1 | N |
| A.300 | 0x0300 | Regeneration error | There is an error related to regeneration. | BM.1 | Y |
| A.320 | 0x0320 | Regenerative overload | A regenerative overload occurred | BM.2 | Y |
| A.330 | 0x0330 | Main circuit power supply wiring error | The AC power supply input setting or DC power supply input setting is not correct. The power supply wiring is not correct. | BM.1 | Y |
| A.331 | 0x0331 | Power-related input signal abnormality | Power-related input signal abnormality. | BM.1 | N |
| A.400 | 0x0400 | Overvoltage | The main circuit DC voltage is too high. | BM.1 | Y |
| A.410 | 0x0410 | Undervoltage | The main circuit DC voltage is too low. | BM.2 | Y |
| A.520 | 0x0520 | Vibration alarm | Abnormal oscillation is detected in the motor speed. | BM.1 | Y |
| A.521 | 0x0521 | Autotuning alarm | Vibration is detected during autotuning for the tuning-free function. | BM.1 | Y |
| A.710 | 0x0710 | Instantaneous overload | The servo motor is operating for several seconds to several tens of seconds under a torque that largely exceeded the rating. | BM.2 | Y |
| A.720 | 0x0720 | Continuous overload | The servo motor is operating continuously under a torque that exceeded the rating. | BM.1 | Y |
| A.730 A.731 | 0x0730 0x0731 | Dynamic brake overload | When the dynamic brake is applied, the rotational or linear kinetic energy exceeded the capacity of the dynamic brake resistor. | BM.1 | Y |
| A.740 | 0x0740 | Inrush current limiting resistor overload | The main circuit power supply is being switched on too frequently. | BM.1 | Y |
| A.750 | 0x0750 | User-defined torque overload | The torque exceeds the user-set value. | BM.2 | N |
| A.810 | 0x0810 | Encoder backup alarm | The power supplies to the encoder all fails and the position data is lost. | BM.1 | N |
| A.820 | 0x0820 | Encoder checksum alarm | There is an error in the checksum results for encoder memory. | BM.1 | N |
| A.830 | 0x0830 | Encoder battery alarm | The battery voltage is lower than the specified level after the control power supply is turned ON. | BM.1 | Y |
| A.840 | 0x0840 | Encoder data alarm | There is an internal data error in the encoder. | BM.1 | N |
| A.850 | 0x0850 | Encoder overspeed | The encoder was operating at high speed when the power was turned ON. | BM.1 | N |
| A.860 | 0x0860 | Encoder overheating | The internal temperature of the encoder is too high . | BM.1 | N |
| A.891 | 0x0891 | Encoder module failure | The linear encoder is abnormal. | BM.1 | N |
| A.B31 | 0x0B31 | Current detection error 1 | The error of U-phase current detection circuit occur. | BM.1 | N |

| | | | | | |
|--------|--------|----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|---|
| A.B32 | 0x0B32 | Current detection error 2 | The error of V-phase current detection circuit occur. | BM.1 | N |
| A.B33 | 0x0B33 | Current detection error 3 | The error of current detection circuit occur. | BM.1 | N |
| A.BF2 | 0x0BF2 | System alarm 2 | Current control processing unit program malfunction. | BM.1 | N |
| A.BF4 | 0x0BF4 | System alarm 4 | CPU WDT fault. | BM.1 | N |
| A.BF5 | 0x0BF5 | System alarm 5 | Parameter batch transmission error. | BM.1 | N |
| A.C10 | 0x0C10 | Servomotor out of control | The servo motor is out of control. | BM.1 | Y |
| A.C21 | 0x0C21 | Hall sensor signal abnormality | Hall-effect sensor failure. | BM.1 | N |
| A.C50 | 0x0C50 | Polarity detection failure | Polarity detection failure | BM.1 | N |
| A.C51 | 0x0C51 | Polarity detection exceeds positive/negative limit | The overtravel signal is detected during polarity detection. | BM.1 | Y |
| A.C52 | 0x0C52 | Polarity detection not completed | The servo is turned ON before the polarity is detected. | BM.1 | Y |
| A.C53 | 0x0C53 | Out of range of motion for polarity detection | The travel distance exceeds the setting of Pn48E (Polarity detection range). | BM.1 | N |
| A.C54 | 0x0C54 | Polarity detection failure 2 | The polarity detection fails. | BM.1 | N |
| A.C80 | 0x0C80 | Encoder clear error (multiturn upper limit setting error) | The multiturn data for the absolute encoder is not correctly cleared or set. | BM.1 | N |
| A.C90 | 0x0C90 | Encoder communications error | The encoder and servo drive cannot communicate with each other. | BM.1 | N |
| A.C91 | 0x0C91 | Encoder communications position data acceleration rate error | An error occurs in calculating the position data of the encoder. | BM.1 | N |
| A.CA0 | 0x0CA0 | Encoder parameter error | The encoder parameters are corrupted. | BM.1 | N |
| A.CB0 | 0x0CB0 | Encoder feedback checksum abnormality | The contents of communications with the encoder are incorrect. | BM.1 | N |
| A.CC0 | 0x0CC0 | Maximum rotation count mismatch | Different multiturn limits is set in the encoder and the servo drive. | BM.1 | N |
| A.D00 | 0x0D00 | Excessive position deviation | The setting of Pn520 (Excessive position deviation alarm level) is exceeded by the position deviation while the servo is ON. | BM.1 | Y |
| A.D01 | 0x0D01 | Excessive position deviation alarm at servo ON | The servo is turned ON after the position deviation exceeds the setting of Pn526 (Excessive position deviation alarm level at servo ON) while the servo is OFF. | BM.1 | Y |
| A.D02 | 0x0D02 | Excessive position deviation alarm for speed limit at servo ON | If position deviation remains in the deviation counter, the setting of Pn529 or Pn584 (Speed limit level at servo ON) limits the speed when the servo is turned ON. This alarm occurs if reference pulses are input and the setting of Pn520 (Excessive position deviation alarm level) is exceeded before the limit is cleared. | BM.2 | Y |
| A.EB1* | 0x0EB1 | STO input time abnormality | STO input time abnormality. | BM.1 | N |
| A.F10 | 0x0F10 | Power supply line open phase. | The voltage is low for more than one second for phase R, S, or T when the main power supply is ON. | BM.2 | Y |
| A.F20 | 0x0F20 | UVW phase loss | Phase loss in the U, V, W three-phase of the servo motor. | BM.1 | N |

| | | | | | |
|--------|--------|---------------------------------------|---------------------------------------------------------------------|------|---|
| A.F21 | 0x0F21 | UVW phase sequence error | Phase sequence error in the U, V, W three-phase of the servo motor. | BM.1 | N |
| A.F29 | 0x0F29 | Network port reverse connection alarm | Network port reverse connection detected | BM.1 | N |
| A.F30 | 0x0F30 | Collision detection alarm | Alarm detected. | BM.1 | Y |
| A.---- | — | No error display | Normal operation. | — | — |

10.1.2 Causes and troubleshooting

When the error occurs, the panel display will display "A. □□□". The causes of and corrections for the alarms are given in the following table.

If the fault still cannot be eliminated after following the table below, please contact the distributor or our company.

Table 10-2 Alarm causes and troubleshooting measures -1

| Alarm No.: Alarm name | Causes | Confirmation method | Corrections |
|----------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| A.020: Parameter checksum error (There is an error in the parameter data in the servo drive.) | The power supply voltage drops suddenly . | Measure the power supply voltage. | Set the power supply voltage within the specified range, and initialize the parameter settings (Fn005). |
| | The power supply is turned off while writing parameter settings. | Check the timing of cutting off the power supply. | Initialize the parameter settings (Fn005) and then set the parameters again. |
| | The number of times that parameters are written exceeds the limit. | Check to see if the parameters are frequently changed by the host controller. | The servo drive may be faulty. Replace the servo drive. Reconsider the method for writing the parameters. |
| | A malfunction is caused by noise from the AC power supply, ground, static electricity, or other sources. | Turn the power supply to the servo drive OFF and ON again. If the alarm still occurs, it may be due to noise. | Implement countermeasures against noise. |
| | Gas, water drops, or cutting oil enters the servo drive and causes failure of the internal components. | Confirm the installation environment. | The servo drive may be faulty. Replace the Servo drive. |
| | A failure occurs in the servo drive. | Turn the power supply to the servo drive OFF and ON again. If the alarm still occurs, the servo drive may have failed | The servo drive may be faulty. Replace the Servo drive. |
| A.021: Parameter format error (There is an error in the parameter data format in the servo drive.) | The software version of the parameters to be written is newer than that of the servo drive that caused the alarm. | Use Fn012 to see if the software versions are the same. If they are different, it could be the cause of the alarm. | Write the parameters from another servo drive with the same model and the same software version, and then turn the power OFF and ON again. |
| | A failure occurred in the servo drive | — | The servo drive may be faulty. Replace the Servo drive. |
| A.022: System checksum error (There is an error in the parameter data in the servo drive) | The power supply voltage drops suddenly | Measure power supply voltage | The servo drive may be faulty. Replace the Servo drive. |
| | The power supply is turned off while setting auxiliary functions. | Check the timing of turning off the power supply | The servo drive may be faulty. Replace the Servo drive. |
| | A failure occurred in the servo drive | Turn the power supply to the servo drive OFF and ON again. If the alarm still occurs, the servo drive may have failed | The servo drive may be faulty. Replace the Servo drive. |

| | | | |
|---------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| A.030: Main circuit detection part failure (Abnormal detection data of the main circuit) | A failure occurred in the servo drive | — | The servo drive may be faulty. Replace the Servo drive. |
| A.040: Parameter setting error/Duplicate output pin definitions Parameter setting out of the set range/ Duplicate output pin definitions | The capacity of the servo drive does not match the capacity of the servo motor. | Confirm the capacity and combination of the servo drive and servo motor. | Match the capacities of the servo drive and the servo motor. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the Servo drive. |
| | A parameter setting is out of the set range. | Confirm the setting range of the changed parameter. | Make the changed parameter a value within the setting range. |
| | The set value of the electronic gear ratio is out of the set range. | Confirm whether the electronic gear ratio is $0.001 < (Pn78C/ Pn78E) < \text{Encoder resolution} * 0.4$. | Set the electronic gear ratio to $0.001 < (Pn78C/ Pn78E) < \text{Encoder resolution} * 0.4$. |
| A.042 ^{*1} : Parameter combination error (Combination of multiple parameters exceeds the specified range) | The speed of program jogging goes below the setting range when the electronic gear ratio (Pn78C/Pn78E) or the servo motor is changed. | Check to see if the detection conditions*1 are satisfied. | Decrease the setting of the electronic gear ratio (Pn78C/Pn78E). |
| | Due to the change in the program JOG movement speed (Pn533), the speed of program JOG operation (Fn004) is out of the set range. | Check to see if the detection conditions*1 are satisfied. | Increase the setting of Pn533. |
| | Due to changing the electronic gear ratio (Pn78C/Pn78E) or the servo motor, the advanced auto-tuning movement speed is out of the set range. | Check to see if the detection conditions*1 are satisfied. | Decrease the setting of the electronic gear ratio (Pn78C/Pn78E). |
| A.04A: Parameter setting abnormality 2 (Parameter setting abnormality) | When registering 4-byte parameters to the library group, two groups are not consecutively registered. | — | Change the number of bytes of the library group to an appropriate value. |
| | When the total number of library data exceeds 64 (Pn900/Pn901 > 64). | — | Keep the total number of library data below 64. |
| A.050: Combination error(Out of the allowable combined motor capacity range) | The servo drive and servo motor capacities do not match each other. | Confirm(Motor capacity)/(Servo drive capacity) $\leq 1/4$ or(Motor capacity)/(Servo drive capacity) ≤ 4 | Select a proper combination of the servo drive and servo motor capacities. |
| | A failure occurred in the encoder. | Replace with another servo motor, confirm that the alarm does not occur again | Replace servo motor or encoder. |
| | A failure occurred in the servo drive. | — | The servo drive may be faulty. Replace the servo drive. |
| A.051: Non-support of alarm by product | An unsupported serial converter unit or encoder (e.g., an external encoder) is connected to the servo drive | Check the product combination specifications. | Change to a correct combination of models. |
| A.056: Model information mismatch | Model information type is inconsistent with the default setting. | Check whether the drive model in the debugging software matches the nameplate. | Update the model information or contact technical personnel. |
| A.057: Program error or mismatch | Program error or mismatch | — | Return to factory or contact technical personnel. |



| | | | |
|---------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|---------------------------|------------------------------------------------------------------------------------------|
| A.080: Linear encoder grating pitch setting abnormality | Linear encoder grating pitch (pn282) setting remains at default setting. | Verify the value of Pn282 | Set Pn282 correctly. |
| A.0B0: Invalid servo ON command alarm | After executing the auxiliary function to power on the motor, the servo ON input (/SON) signal is sent from the host controller. | — | Turn the power supply to the servo drive OFF and ON again. Or, execute a software reset. |

***Note: 1. An alarm is detected when either of the following two detection condition formulas is satisfied.**

$$\text{Pn533} [\text{min} - 1] \times (\text{Encoder resolution}) / (6 \times 10^5) \leq \text{Pn78C/Pn78E}$$

$$\text{Max. motor speed} [\text{min} - 1] \times (\text{Encoder resolution}) / (\text{approx. } 3.66 \times 10^{12}) \geq \text{Pn78C/Pn78E}$$

Table 10-3 Alarm causes and troubleshooting measures -2

| Alarm No.: Alarm name | Causes | Confirmation method | Corrections |
|------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.100: Overcurrent detection (overcurrent flowing through power transistor or heatsink overheating). | The main circuit cable is not wired correctly or there is faulty contact. | Check if the wiring is correct. | Correct the wiring. |
| | There is a short-circuit or ground fault in a main circuit cable. | Check for short-circuits across the cable's U, V, W phases or between the ground and the cable's U, V, W phases. | The cable may be short circuited. Replace the cable. |
| | There is a short-circuit or ground fault inside the servo motor. | Check for short-circuits across the motor terminals' U, V, W phases or between the ground and the motor terminals' U, V, W phases. | The servo motor may be faulty. Replace the servo motor. |
| | There is a short-circuit or ground fault inside the servo drive. | Check for short-circuits across the servo drive's servomotor connection terminals (U, V, W) or between the ground and these terminals. | The servo motor may be faulty. Replace the servo motor. |
| | The regenerative resistor is not wired correctly or there is faulty contact. | Check if the wiring is correct. | Correct the wiring. |
| | The dynamic brake (DB, emergency stop executed from the servo drive) is frequently activated, or a DB overload alarm occurred. | Use the DB resistor power consumption (Un00B) to confirm the DB utilization frequency. Alternatively, check the alarm display (Fn000) for DB overload alarms (A.730/A.731). | Change the servo drive model, operating methods, or the mechanisms so that the dynamic brake does not need to be used so frequently. |
| | The regenerative processing capacity is exceeded. | Use the regenerative load ratio (Un00A) to confirm the regenerative resistor usage frequency. | Recheck the operating conditions and load. |
| | The servo drive regenerative resistance is too small. | Use the regenerative load ratio (Un00A) to confirm the regenerative resistor usage frequency. | Change the regenerative resistance to a value larger than the servo drive minimum allowable resistance. |
| | A heavy load is applied while the servomotor is stopped or running at a low speed. | Check if the operating conditions exceed the servo drive's specification range. | Reduce the load applied to the servomotor. Or, increase the operating speed. |
| | A malfunction is caused by noise. | Improve the noise environment—e.g., by rerouting wiring or optimizing installation conditions—and check if there's an improvement. | Implement countermeasures against noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVOPACK's main circuit wire size. |
| A.102: Current detection abnormality | Servo drive failure. | — | Turn the power supply to the servo drive OFF and ON again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| | Check for incorrect phase sequence of UVW and PE. | Phase sequence of UVW and PE | Replace with the correct phase sequence of UVW and PE. |

| | | | |
|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.300: Regeneration failure | Set the regenerative resistor capacity (Pn600) to a value other than "0", but there is no external regenerative resistor. | Check the connection of external regenerative resistor and the value of Pn600 | Connect an external regenerative resistor, or set Pn600 to 0 when no regenerative resistor is required. |
| | There is no external regenerative resistor, and the jumper wire between the servo drive's power terminals B2-B3 is disconnected. | Confirm the wiring of the power terminal jumper | Connect the jumper wiring correctly. |
| | Poor wiring, disconnection, or broken wire in the external regenerative resistor. | Check the wiring of the external regenerative resistor | Correctly wire the external regenerative resistor. |
| | Servo drive failure | — | If the control power supply is turned on again without the main circuit power supply being turned on, if the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.320: Regenerative overload | The power supply voltage exceeds the specified range | Measure power supply voltage. | Set the power supply voltage within the specified range. |
| | The external regenerative resistance value or regenerative resistor capacity is too small, or there has been a continuous regeneration state | Check the operating conditions or the capacity. | Change the regenerative resistance value or capacity. Reconsider the operating conditions. |
| | There is a continuous regeneration state because a negative load is continuously applied | Check the load applied to the servo-motor during operation. | Reconsider the system including the servo, machine, and operating conditions. |
| | The setting of Pn600 (regenerative resistor capacity) is smaller than the capacity of the external regenerative resistor | Check to see if a regenerative resistor is connected and check the setting of Pn600. | Correct the setting of Pn600. |
| | External regenerative resistor value is too large | Check if the regenerative resistor value is correct. | Change it to the correct resistor value and capacitance. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |

| | | | |
|---------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.330: Main circuit power wiring error * Detected when the main circuit power supply is turned on | The power supply voltage inside the servo drive is too high, and the regenerative resistor is disconnected | Measure the resistance value of the regenerative resistor with a measuring instrument. | When using the built-in regenerative resistor of the servo drive, replace the servo drive. When using an external regenerative resistor, replace the regenerative resistor. |
| | DC power is supplied when an AC power supply input is specified in the settings | Confirm whether the power supply is DC power supply. | Correct the power supply setting to match the actual power supply. |
| | AC power is supplied when a DC power supply input is specified in the settings | Confirm whether the power supply is AC power supply. | Correct the power supply setting to match the actual power supply. |
| | Set the regenerative resistor capacity (Pn600) to a value other than "0", but there is no external regenerative resistor | Confirm the connection of the external regenerative resistor and the value of Pn600. | Connect an external regenerative resistor, or set Pn600 to 0 when an external regenerative resistor is not required. |
| | The jumper wires of the servo power supply terminals B2-B3 of capacities other than the above are disconnected | Confirm the wiring of the power terminal jumper | Connect the jumper wires correctly. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| A.331: Power-related input signal abnormality (Abnormal rapid discharge during power failure) | DC power input selection (Pn001.2) and rapid discharge selection during DC power input (Pn00E.1) enabled, rapid discharge initiated After CONVINSIGDISCHERRCHK_TIME elapses, voltage drop falls below DCVOLT10V | Measure the voltage drop during discharge. | Replace the servo drive. |

| | | | |
|-----------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.400: Overvoltage (Detected in the main circuit power supply section of the servo drive) | The servo drive for AC200V, the AC power supply voltage is 290V or higher, or the servo drive for AC400V detects a power supply voltage of AC580V or higher. | Measure power supply voltage. | Correct the AC/DC power supply voltage to within specified range. |
| | The power supply is unstable or is affected by a lightning surge. | Measure power supply voltage. | Improve the power supply condition, install a surge suppressor, etc., and turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| | The servo drive accelerates or decelerates when the AC power supply voltage is between 230–270V (for 200V servo drives) or between 480–560V (for 400V servo drives) | Check the power supply voltage and the speed and torque during operation. | Set the AC power supply voltage within the specified range. |
| | The external regenerative resistance is too high for the operating conditions. | Check the operating conditions and the regenerative resistance. | Select a regenerative resistance value that is appropriate for the operating conditions an load. |
| | The moment of inertia ratio or mass ratio exceeds the allowable value. | Check to see if the moment of inertia ratio or mass ratio is within the allowable range. | Increase the deceleration time, or reduce the load. |
| | Servo drive failure | — | If the control power supply is turned on again without the main circuit power supply being turned on, if the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.410: Undervoltage(The undervoltage is detected by the main circuit power supply inside the servo drive) | For the AC200V servo drive, the AC power supply voltage is below 106V; for the AC400V servo drive, the AC power supply voltage is below 240V. | Measure power supply voltage. | Correct the power supply voltage to normal range. |
| | Power supply voltage drops during operation. | Measure power supply voltage. | Increase power supply capacity. |
| | A momentary power interruption occurs. | Measure power supply voltage. | If the momentary power failure holding time (Pn509) is changed, set it to a smaller value. |
| | The fuse of the servo drive is blown out. | — | Replace the servo drive and use the servo drive after connecting the reactor. |
| A.520: Vibration alarm | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| | Abnormal oscillation is detected in the motor speed | Check for abnormal motor noise, and check the speed and torque waveforms during operation. | Reduce the motor speed. Or, reduce the setting of Pn100 (Speed Loop Gain). |
| | The moment of inertia ratio (Pn103) is larger than the actual value or changes greatly. | Check moment of inertia ratio. | Correctly set the moment of inertia ratio (Pn103). |

| | | | |
|-------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.521: Autotuning alarm (Vibration detected during auto-tuning of the tuning-free function) | The servo motor vibrates significantly while performing the tuning-free function. | Check the waveform of the motor speed. | Reduce the load so that the moment of inertia ratio is within the allowable value. Or increase the load level or reduce the rigidity level in the tuning-less level settings. |
| | The motor vibrates significantly during advanced autotuning. | Check the waveform of the motor speed. | Check the operating procedure of corresponding function and implement corrections. |
| A.710: Instantaneous overload A.720: Continuous overload | The wiring is not correct or there is a faulty connection in the motor or encoder wiring. | Check the wiring. | Make sure that the servo motor and encoder are correctly wired. |
| | Motor operation exceeds the overload protection characteristics. | Check the motor overload characteristics and operation command. | Reconsider the load and operating conditions. Or, increase the motor capacity. |
| | Motor fails to drive due to mechanical factors, causing excessive load during operation. | Check the operation reference and motor speed. | Correct the mechanical problem. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| A.730: A.731: Dynamic brake overload (An excessive power consumption by the dynamic brake is detected.) | The servo motor is rotated by an external force. | Check the operation status. | Do not drive the motor with an external force. |
| | Motor rotational energy during DB stop exceeds DB resistor capacity. | Use the DB resistor power consumption (Un00B) to confirm the DB utilization frequency. | Try the following measures: • Reduce the command speed of the servo motor. • Decrease the inertia ratio. • Reduce the number of DB stops. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| A.740: Inrush current limiting resistor overload (The main circuit power supply is frequently turned ON and OFF.) | The allowable frequency of the inrush current limiting resistor is exceeded when the main circuit power supply is turned ON and OFF | Confirm the number of times the power supply is turned ON/OFF. | Reduce the frequency of turning the main circuit power supply ON and OFF. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| A.750: User-defined torque overload (The torque exceeds the user-set value) | When function selection application switch 61F (Pn61F.0) is enabled, the system selects the current integration method depending on whether an independent air cooling coefficient is present—if the integral value exceeds the instantaneous overload alarm level. | Check servo components for overload behavior. | Stop overload. |

| | | | |
|--------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.810: Encoder backup alarm (Detected at the encoder, but only when an absolute encoder is used.) | The power to the absolute encoder is turned ON for the first time | Check to see if the power supply is turned ON for the first time. | Set up the encoder (Fn008). |
| | Reconnected after removing the encoder cable | Check to see if the power supply is turned ON for the first time. | Check the encoder connection and set up the encoder (Fn008). |
| | Power is not being supplied both from the control power supply (+5V) from the servo drive and from the battery power supply | Check the encoder connector battery and the connector status. | Replace the battery or implement similar measures to supply power to the encoder, and set up the encoder (Fn008). |
| | Absolute encoder failure | — | If the alarm cannot be cleared even if the setting operation is performed again, replace the servo motor. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| | Encoder failure | — | For absolute encoder: If alarms still occur frequently after re-setting the encoder (Fn008), the servo unit may be faulty. Replace the servo motor. For rotary absolute encoder or incremental encoder: The servo motor may be faulty. Replace the servo motor. |
| Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. | |
| A.830: Encoder battery alarm (The absolute encoder battery voltage is lower than the specified level.) | The battery connection is faulty or a battery is not connected. | Check the battery connection. | Correct the battery connection. |
| | The battery voltage is lower than the specified value (3.0V). | Measure the voltage of the battery. | Replace the battery. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| A.840: Encoder data alarm * Detected on the encoder side | Encoder malfunction | — | Turn on the power again. If the alarm still occurs, the servo motor may be faulty. Replace the servo motor. |
| | Encoder malfunction due to interference such as noise | — | Correctly perform the wiring around the encoder. (Separation of the encoder cable and the main circuit cable of the servo motor, grounding treatment, etc.). |
| A.850: Encoder over-speed (Detected at the encoder when the control power supply is turned ON.) | When the control power is turned on, the servo motor rotates at a speed of 200rpm or more. | Check the motor speed when the power supply is turned ON. | Reduce the Servomotor speed to a value less than 200 rpm, and turn ON the control power supply. |
| | Encoder failure | — | Turn on the power again. If the alarm still occurs, the servo motor may be faulty. Replace the servo motor. |
| | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |

| | | | |
|---------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------|-------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.860: Encoder over-heating * Only detected when an absolute encoder is connected * Detected on the encoder side | The ambient temperature of the servo motor is too high | Measure the ambient temperature of the servo motor. | Reduce the ambient temperature of the servo motor to 40° C or less. |
| | The servo motor load is greater than the rated load. | Use the accumulated load ratio (Un009) to check the load. | Operate the servo drive so that the motor load remains within the specified range. |
| | Encoder failure | — | Turn on the power again. If the alarm still occurs, the servo motor may be faulty. Replace the servo motor. |
| | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.891: Encoder module fault | Encoder failure | — | Turn on the power again. If the alarm still occurs, the servo motor may be faulty. Repair or replace the servo motor. |
| A.B31: Current detection error 1 | U-phase current detection circuit failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.B32: Current detection error 2 | V-phase current detection circuit failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.B33: Current detection error 3 | Current detection circuit failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| | The main circuit cable of the servo motor is disconnected | Check whether the main circuit cable of the servo motor is disconnected | Repair the motor cable. |
| A. BF2: System alarm 2 (Current control processing unit program malfunction) | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A. BF4: System alarm 4 (CPUwDT fault) | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A. BF5: System alarm 5 (Parameter batch transfer abnormality) | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.C10: Prevent loss of control detection *Detected when servo is ON (servo motor loss of control) | The order of phases U, V, and W in the motor wiring is incorrect. | Confirm the servo motor wiring | Make sure that the servo motor is correctly wired. |
| | Encoder failure | — | If the motor wiring is correct and the alarm still occurs after turning the power supply OFF and ON again, the servo motor may be faulty. Replace the servo motor. |
| | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |

| | | | |
|------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.C21: Hall sensor signal abnormality (Hall sensor fault) | Magnetic pole sensor is exposed outside the motor stator. | Check the magnetic pole sensor | Reinstall the motor rotor or stator. |
| | The wiring of the magnetic pole sensor is incorrect. | Check the wiring of the magnetic pole sensor | Correct the wiring of the magnetic pole sensor. |
| | Magnetic pole sensor fault | — | Replace the magnetic pole sensor. |
| A.C50: Magnetic pole detection failure | Incorrect parameter setting | Check the specifications of the linear encoder and the status of the feedback signal. | The pitch of the linear encoder grating scale (Pn282) and the motor phase sequence selection (Pn080) may not match the device status. Set the parameters correctly. |
| | Grating scale signal interference | Check the connection between the serial conversion unit, the FG of the servo motor and the FG of the servo drive, and the connection between the FG of the servo drive and the FG of the power supply. In addition, confirm that the cable of the linear encoder is properly shielded, and check whether the detection command is repeatedly output in the same direction multiple times. | Take appropriate anti-interference measures for the linear encoder cable. |
| | External force applied to the motor rotor | — | When an external force, such as cable tension, is applied to the motor rotor, even if the detection command is 0, if the speed feedback is not 0, it cannot be detected smoothly. Reduce the external force to make the speed feedback 0. If the external force cannot be reduced, increase the magnetic pole detection speed loop gain (Pn481). |
| | Low resolution of the linear encoder | Check if the pitch of the linear encoder grating scale is within 100 micrometers. | When the pitch of the linear encoder grating scale is 100 micrometers or more, the servo drive cannot detect the correct speed feedback. Use a high-precision linear encoder grating scale with a pitch (recommended within 40 micrometers), or increase the magnetic pole detection command speed (Pn485). However, the motor operation range during magnetic pole detection will increase. |
| A.C51: Pole detection exceeds positive/negative limit ((An overshoot signal is detected during pole detection.)) | Magnetic pole detection speed ratio signal | Confirm speed ratio position | Connect the speed ratio signal. Perform magnetic pole detection at positions where the speed ratio signal cannot be detected. |

| | | | |
|-----------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.C52: Magnetic pole detection incomplete (Servo ON in state where magnetic pole detection is incomplete.) | When using an absolute linear encoder, select a setting (Pn587) that cannot detect magnetic poles via the absolute linear encoder. The servo will turn ON while the magnetic pole detection status is undefined. | — | When using an absolute linear encoder, select the setting (Pn587) to detect magnetic poles via the absolute linear encoder. |
| A.C53: Out of the magnetic pole detection movable range (Movement during magnetic pole detection exceeded the set value (Pn48E).) | Detected distance from center pole exceeds magnetic pole detection range (Pn48E). | — | Expand the magnetic pole detection range (Pn48E), or increase the magnetic pole detection speed loop gain (Pn481). |
| A.C54: Magnetic pole detection failure 2 | Subjected to external forces | — | Increase the value of the pole detection confirmation thrust command (Pn495) and increase the value of the pole detection error tolerance range (Pn498). However, expanding the error tolerance range will cause the motor temperature to rise. |
| A.C80: Encoder clear error or multiturn upper limit setting abnormality | Encoder failure | — | Turn on the power again. If the alarm still occurs, the servo motor may be faulty. Replace the servo motor. |
| | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.C90: Encoder communication fault (The encoder and servo drive cannot communicate with each other.) | There is a faulty contact in the connector, or the connector is not wired correctly for the encoder. | Check the condition of the encoder connector. | Reconnect the encoder connector and check the encoder wiring. |
| | There is a cable disconnection or a short circuit in the encoder. Or, the cable impedance is out of the specified values. | Check the condition of the encoder cable. | Use the encoder cable within the specified specifications. |
| | One of the following occurs: corrosion caused by improper temperature, humidity, or gas; a short circuit caused by the entry of water drops or cutting oil; or faulty contact in a connector caused by vibration. | Check the operating environment. | Improve the operating environment, and replace the cable. If the alarm still occurs, replace the servo drive. |
| | Malfunction due to noise interference | — | Correct the wiring around the encoder by separating the encoder cable from the servo motor main circuit cable or by grounding the encoder. |
| | Servo drive failure | — | If the alarm does not occur when the control power is turned on after connecting the servo motor to another servo drive, the servo drive may be faulty. Replace the servo drive. |

| | | | |
|-------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| A.C91: Encoder communications position data acceleration rate error (A fault occurred in the calculation of the encoder's position data.) | Noise entered on the signal lines because the encoder cable is bent or the sheath is damaged | Check the condition of the encoder cable and connectors. | Check the encoder cable to see if it is installed correctly. |
| | The encoder cable is bundled with a high current line or installed near a high current line | Check the setting condition of the encoder cable. | Confirm that there is no surge voltage on the encoder cable. |
| | There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder. | Check the setting condition of the encoder cable. | Properly ground the machine to separate it from the FG of the encoder. |
| A.CA0: Encoder parameter error (Encoder parameters is corrupted.) | Encoder failure | — | Turn on the power again. If the alarm still occurs, the servo motor may be faulty. Replace the servo motor. |
| | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo motor may be faulty. Replace the servo motor. |
| A.CB0: Encoder feedback checksum abnormality (Error in communication content with the encoder) | Encoder wiring is incorrect or has poor contact. | Check the wiring of the encoder. | Make sure that the encoder is correctly wired. |
| | The encoder cable has different specifications and is subject to noise interference. | - | Use a shielded twisted-pair wire cable or a screened twisted-pair cable with conductors of at least 0.12 mm ² . |
| | The encoder cable has an excessively long wiring distance and is subject to noise interference. | - | The maximum wiring distance is 50m. |
| | The FG potential fluctuates due to the influence of motor-side equipment (e.g., welding machines). | Check the condition of the encoder cable and connectors. | Properly ground the machine to separate it from the FG of the encoder. |
| | The encoder is subject to excessive vibration shock. | Check the operating conditions. | Reduce machine vibration. Correctly install the servo motor. |
| | Encoder failure | - | Turn on the power again. If the alarm still occurs, the servo motor may be faulty. Replace the servo motor. |
| | Servo drive failure | - | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.CC0: Maximum rotation count mismatch (Mismatch between the encoder and servo drive maximum rotation counts) | The DD motor's maximum rotation count (Pn205) differs from the encoder's maximum rotation count. | Check the setting of Pn205 | Correct the setting of Pn205 (0 to 65,535). |
| | The encoder's maximum rotation count differs from the servo drive's, or the maximum rotation count has been changed. | Check the setting of Pn205 in the servo drive | Change the setting Fn013 if the alarm occurs. |
| | Servo drive failure | - | Turn on the power again. If the alarm still occurs, the servo drive may be faulty and replace the servo drive. |

| | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.D00: Excessive position deviation (The setting of Pn520 (Excessive position deviation alarm level) is exceeded by the position deviation while the servo was ON.) | The Servomotor U, V, and W wiring is not correct | Check the wiring of the servomotor's main circuit cables | Make sure that there are no faulty contacts in the wiring for the servomotor and encoder. |
| | The servo drive's gain is too low | Verify whether the servo drive's gain is excessively low | Increase servo gain parameters such as Pn100 and Pn102. |
| | Higher frequency of position commands | Try operating the drive after reducing the command pulse frequency. | Reduce the position reference pulse frequency or the reference acceleration rate, or reconsider the electronic gear ratio. |
| | Acceleration of position command is too large. | Try operating the drive after reducing the command acceleration. | Apply smoothing, i.e., by using Pn216 (Position reference acceleration/ deceleration time constant). |
| | The setting of Pn520 (Excessive position deviation alarm level) is too low for the operating conditions. | Check Pn520 (Excessive position deviation alarm level) to see if it is set to an appropriate value. | Correctly set Pn520. |
| | Servo drive failure | - | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.D01: Excessive position deviation alarm at servo ON | Turn the servo ON if the position deviation exceeds the Pn526 set value while the servo is OFF. | Check the position deviation at servo ON (Un008). | Make settings to clear the position deviation at servo ON, or set the correct excessive position deviation alarm value (Pn526) when the servo is ON. |
| A.D02: Excessive position deviation alarm caused by speed limit at servo ON | When the position deviation is accumulating, turn the servo ON—the speed is limited by the servo ON speed limit (Pn529). If a position command is input in this state, it will exceed the set value of the excessive position deviation alarm (Pn520). | - | Set the position deviation to be cleared while the servo is OFF. Optimize the setting of Pn520 (Excessive position deviation alarm level). Or, adjust the setting of Pn529 or Pn584 (Speed limit level at servo ON) |
| A.EB1: Safety function signal input timing error | The delay between activation of the /HWBB1 and /HWBB2 input signals for the HWBB was ten second or longer. | Measure the time delay between the /HWBB1 and /HWBB2 signals. | The output signal circuits or devices for /HWBB1 and /HWBB2 or the servo drive input signal circuits may be faulty. Alternatively, the input signal cables may be disconnected. Check to see if any of these items are faulty or have been disconnected. |
| A.F10: Power supply line phase loss detection during main circuit power-on (A low voltage state in one of the R, S, T phases lasting for more than 1 second when the main power is ON.) | Poor wiring of the three-phase power supply | Check the power supply wiring. | Make sure that the power supply is correctly wired. |
| | Three-phase power supply imbalance | Measure the voltage for each phase of the three-phase power supply. | Balance the power supply by changing phases. |
| | Directly input single-phase power without setting the single-phase input parameter (Pn00B.2 = 1). | Check the power supply and the parameter setting. | Match the parameter setting to the power supply. |
| | Servo drive failure | - | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |

| | | | |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|---------------------------------------------|---------------------------------------------|
| A.F20: UVW phase loss (Three-phase (U, V, W) phase loss input for the servo motor) | The value of (q-axis current command - q-axis current feedback) (Pn652) falls below the threshold (Pn651) repeatedly. | Check if the UVW cable is disconnected. | Connect the UVW cable. |
| A.F21: UVW phase sequence error (Three-phase (U, V, W) phase sequence error of the servo motor.) | UVW wire sequence error | Check the UVW wire sequence. | Replace with the correct UVW wire sequence. |
| A.F29: Reverse Ethernet port insertion alarm | Ethernet port is inserted backwards. | Verify the Ethernet port wiring. | Connect the wiring correctly. |
| A.F30: Collision detection alarm | Current torque command exceeds maximum collision torque. | Check if servo components are in collision. | Stop collision. |

10.2 Warning display

This section explains how to deal with warnings.

" 10.2.1 Warning list" explains the 603F error code, the warning name, and the warning content.

10.2.1 Warning list

The list of warnings is as follows:

Table 10-4 Warning list

| NO. | 603F error code | Name | Content |
|-------|-----------------|----------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| A.900 | 0x0900 | Excessive position deviation | In the servo ON state, the position deviation has exceeded the position deviation alarm threshold (Pn520). |
| A.901 | 0x0901 | Excessive position deviation at servo ON | When the servo is OFF and the position deviation exceeds the set value at Pn526, the servo turns ON. |
| A.910 | 0x0910 | Overload warning | Operated with torque significantly exceeding rated value. |
| A.911 | 0x0911 | Vibration | Detected abnormal vibration in motor speed. |
| A.912 | 0x0912 | Internal temperature warning 1 | The heat sink temperature of the control circuit is abnormal. |
| A.920 | 0x0920 | Regenerative overload | A regenerative overload occurs. |
| A.921 | 0x0921 | Dynamic brake overload | Due to DB (Dynamic Braking) operation, rotational energy exceeds the capacity of the DB resistor. |
| A.924 | 0x0924 | Regenerative warning | The result of regenerative braking activation does not match the settings. |
| A.930 | 0x0930 | Absolute encoder battery failure | After turning on the control power supply, the battery voltage is below the specified value. |
| A.941 | 0x0941 | Parameter change requiring re-powering | Parameters requiring re-powering is modified. |
| A.942 | 0x0942 | Speed pulse compensation information inconsistency | The speed ripple compensation information stored in the encoder and servo drive differs. |
| A.94A | 0x094A | Data setting warning (User constant number) | Data setting warning (User constant number). |
| A.94B | 0x094B | Data setting warning (Out of data range) | Data setting warning (Outside data range). |
| A.94D | 0x094D | Data setting warning (Data size error) | Data setting warning (Data size error) |
| A.94F | 0x094F | Hardware parameter information anomaly | Hardware information checksum error. |
| A.95A | 0x095A | Command warning (Conditions not met) | Command warning (Conditions not met) |

| | | | |
|-------|--------|----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| A.95D | 0x095D | Command warning (command interference) | Command warning (command interference) |
| A.971 | 0x0971 | Undervoltage | Warning before the Undervoltage (A.410) alarm is triggered. Continuing operation may cause the Undervoltage (A.410) alarm to occur. |
| A.9A0 | 0x09A0 | Overtravel | Positive/Negative limit overtravel. |
| A.9B0 | 0x09B0 | Soft limit error | Soft limit setting error, check 607d. |
| A.9B2 | 0x09B2 | Synchronization frame lost | Synchronization frame data loss. |
| A.9B3 | 0x09B3 | Bus interruption | EtherCAT communication interrupted. |
| A.9B4 | 0x09B4 | Network initialization failure | EtherCAT network initialization failed. |
| A.9C0 | 0x09C0 | Advanced auto-tuning warning 1 | Advanced auto-tuning warning 1 |
| A.9C1 | 0x09C1 | Advanced auto-tuning warning 2 | Advanced auto-tuning warning 2 |
| A.9C2 | 0x09C2 | Advanced auto-tuning warning 3 | Advanced auto-tuning warning 3 |
| A.9C3 | 0x09C3 | Advanced auto-tuning warning 4 | Advanced auto-tuning warning 4 |
| A.9C4 | 0x09C4 | Advanced auto-tuning warning 5 | Advanced auto-tuning warning 5 |
| A.9C5 | 0x09C5 | Advanced auto-tuning warning 6 | Advanced auto-tuning warning 6 |
| A.9C6 | 0x09C6 | Advanced auto-tuning warning 7 | Advanced auto-tuning warning 7 |
| A.9C7 | 0x09C7 | Advanced auto-tuning warning 8 | Advanced auto-tuning warning 8 |
| A.9C8 | 0x09C8 | Advanced auto-tuning warning 9 | Advanced auto-tuning warning 9 |
| A.9C9 | 0x09C9 | Advanced auto-tuning warning 10 | Advanced auto-tuning warning 10 |
| A.9CA | 0x09CA | Advanced auto-tuning warning 11 | Advanced auto-tuning warning 11 |
| A.9CB | 0x09CB | Advanced auto-tuning warning 12 | Advanced auto-tuning warning 12 |
| A.9CC | 0x09CC | Advanced auto-tuning warning 13 | Advanced auto-tuning warning 13 |
| A.9CD | 0x09CD | Advanced auto-tuning warning 14 | Advanced auto-tuning warning 14 |
| A.9CE | 0x09CE | Advanced auto-tuning warning 15 | Advanced auto-tuning warning 15 |
| A.9CF | 0x09CF | Advanced auto-tuning warning 16 | Advanced auto-tuning warning 16 |
| A.9D0 | 0x09D0 | Advanced auto-tuning warning 17 | Advanced auto-tuning warning 17 |
| A.9D1 | 0x09D1 | Advanced auto-tuning warning 18 | Advanced auto-tuning warning 18 |
| A.9D2 | 0x09D2 | Advanced auto-tuning warning 19 | Advanced auto-tuning warning 19 |
| A.9D3 | 0x09D3 | Advanced auto-tuning warning 20 | Advanced auto-tuning warning 20 |

Note: 1. If it is not set to "Output Alarm Code and Warning Code (Pn001.3 = 1)", then no warning code will be output.

2. If it is set to " No Warning (Pn008.2 = 1)" , warnings other than undervoltage warning (A.971) will not be detected.

10.2.2 Causes and troubleshooting

The following table lists the causes of the warnings and the troubleshooting. If the error still cannot be eliminated after handling according to the table below, please contact the distributor or our company.

Table 10-5 Warning causes and troubleshooting

| Alarm No.: Alarm name | Causes | Confirmation method | Corrections |
|-----------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.900: Excessive position deviation | The servo motor U, V, and W wiring is not correct. | Check the wiring of the servo motor's main circuit cables. | Check the motor cable or encoder cable for issues like poor contact. |
| | The gain of the servo drive is too low. | Check the gains of the servo drive. | Increase the servo gain using advanced auto-tuning, etc. |
| | The frequency of the position reference pulse is too high. | Reduce the reference pulse frequency and try operating the servo drive. | Reduce the position instruction pulse frequency or instruction acceleration, or adjust the electronic gear ratio. |
| | The acceleration of the position reference is too high. | Reduce the reference acceleration and try operating the servo drive. | Apply smoothing, i.e., by using Pn216/217 (Position reference acceleration/ Deceleration time constant). |
| | Relative to the operating conditions, the position deviation excessive alarm value (Pn520) is low. | Check if position deviation excessive alarm value (Pn520) is appropriate . | Set correctly Pn520 value. |
| | Servo drive failure | — | Turn on the power again. If the alarm still occurs, the servo drive may be faulty. Replace the servo drive. |
| A.901: Excessive position deviation alarm at servo ON | The position deviation when the servo is turned ON exceeds the percentage set with the following formula: $(Pn520 \times Pn51E) \div 100$ | Check deviation counter Un008 when servo is OFF. | Set the position deviation to be cleared while the servo is OFF. Optimize the setting of Pn528 (Excessive position deviation alarm level at servo ON) |
| A.910: Overload (warning before an A.710 or A.720 alarm occurs) | The wiring is incorrect or there is a faulty connection in the motor or encoder wiring. | Check the wiring | Make sure that the motor and encoder are correctly wired. |
| | The motor's operation exceeds the overload protection characteristic. | Check the motor overload characteristics and operation command. | Reconsider the load and operating conditions. Or, increase the motor capacity. |
| | Due to mechanical factors, the motor fails to drive, leading to excessive load during operation. | Check the operation command and motor speed. | Remove the mechanical problem. |
| | Servo drive failure | — | It may be that the servo drive is faulty. Replace the servo drive. |
| A.911: Vibration | Abnormal vibration is detected during motor operation. | Check the motor's abnormal noise, as well as its operating speed and torque waveform during operation. | Reduce the motor speed or lower the servo gain using single-parameter tuning, etc. |
| | The setting of Pn103 (Moment of Inertia Ratio) is greater than the actual moment of inertia or is greatly changed. | Check the inertia (of the motor). | Correctly set the inertia ratio (Pn103). |

| | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| A.912: Internal temperature warning 1 Abnormal temperature detected in the control circuit's heat sink) | Ambient temperature is too high. | Measure ambient temperature with a thermometer or verify operational status via the servo drive's environmental monitoring settings. | Optimize servo drive settings and reduce ambient temperature. |
| | Operation resumed after repeatedly resetting the overload alarm by turning off the power. | Use the alarm display to confirm whether an overload alarm has occurred. | Modify alarm reset procedures. |
| | Excessive load, or operation exceeding the regenerative processing capacity. | Verify the load during operation through the cumulative load rate and confirm the regenerative processing capacity via the regenerative load rate. | Re-evaluate load conditions and operating parameters. |
| | Unsuitable installation orientation of the servo drive or improper spacing from other servo drives. | Confirm the servo drive's setting status. | Install according to servo drive mounting standards. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| A.920: Regenerative overload (warning before an A.320 alarm occurs) | Power supply voltage out of specification. | Measure the power supply voltage. | Set the power supply voltage within the specified range. |
| | Insufficient external regenerative resistor, servo drive, or regenerative resistor capacity, or continuous regeneration | Check the operating conditions or the capacity using the software HCServoWorks , etc. | regenerative resistance capacity, or servo drive capacity. Recheck the operating conditions using the HCServoWorks. |
| | Continuous negative load or continuous regeneration | Check the load applied to the servo motor during operation. | Recheck the system including the servo, machine, and operating conditions. |
| A.921: Dynamic brake overload (warning before an A.731 alarm occurs) | The servo motor is rotated by an external force. | Check the operation status. | Do not drive the motor with an external force. |
| | Motor rotational energy during DB stop exceeds DB resistor capacity. | Use the DB resistor power consumption (Un00B) to confirm the DB utilization frequency. | Try the following measures: • Reduce the command speed of the servo motor. • Decrease the inertia ratio. • Reduce the number of DB stops. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |
| A.924: Regenerative warning (Regenerative function software settings do not match hardware) | Regenerative processing enabled via macro definition, DC power input disabled (Pn001.2), regenerative anomaly detected, external regeneration function enabled (Pn00E.3), and the built-in regenerative resistor is not selected. | Confirm that the parameters are set correctly. | Set correct parameters. |
| A.930: Absolute encoder battery faulty (The absolute encoder battery voltage is lower than the specified level.) *Detected only when an absolute encoder is connected | Poor or disconnected battery connection | Check the battery connection. | Correct the battery connection. |
| | Battery voltage below specified value (3.0V) | Measure the voltage of the battery. | Replace the battery. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |

| | | | |
|-------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| A.941: Parameter change requiring re-powering | The parameters that requires re-powering are changed. | — | Turn the power supply to the servo drive OFF and ON again. , |
| A.942: Speed ripple compensation inconsistency (The speed ripple compensation information stored in the encoder and servo drive differs.) | The speed ripple compensation information stored within the encoder and servo drive differs. | Verify whether the speed ripple compensation information stored within the encoder and servo drive is consistent. | Modify the parameter information to the correct values. |
| A.94A: Data setting warning (User constant ID) | An invalid parameter is used. | Confirm the command that leads to this result. | Use the correct parameters. |
| A.94B: Data setting warning (Out of data range) | A value outside the specified range is set in the command data. | Confirm the command that leads to this result. | Set values within the specified range for parameters. |
| A.94D: Data setting warning (Data size error) | Incorrect parameter size specified in the command | Confirm the command that leads to this result. | Set the correct parameter size. |
| A.94F: Hardware parameter information anomaly | Hardware information checksum error | Confirm the command that leads to this result. | Return the unit to the factory or contact technical personnel. |
| A.95A: Command warning (Conditions not met) | Instruction conditions are not met | Confirm the command that leads to this result. | Do not transmit unsupported commands. |
| A.95D: Command warning (command interference) | Latch command transmission conditions not met. | Confirm the command that leads to this result. | Send the command only after the transmission conditions are satisfied. |
| A.971: Undervoltage | For 200V servo drive, AC power supply voltage at 140V or less; For 400V servo drive, AC supply voltage at 240V or less. | Measure power supply voltage. | Adjust the power supply voltage to the normal range. |
| | The power supply voltage drops during operation. | Measure power supply voltage. | Increase power supply capacity. |
| | A momentary power interruption occurs. | Measure power supply voltage. | If the setting of Pn509 (Momentary power interruption hold time) is modified, set it to a smaller value. |
| | The fuse of the servo drive is blown out. | — | Replace the servo drive and connect a reactor before reusing it. |
| | Servo drive failure | — | The servo drive may be faulty. Replace the servo drive. |

| | | | |
|------------------------------------------------|----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A.9A0: Overtravel (Overtravel status detected) | Overtravel is detected when the servo is ON. | Check the status of the overtravel signals on the input signal monitor (Un005). | <p>Fault causes and how to address them can be determined from the servo motor's operation and status.</p> <p>Additionally, if the overtravel signal cannot be confirmed via input signal monitoring (Un005), it may indicate that instantaneous overtravel has been detected.</p> <p>Take the following steps:</p> <ul style="list-style-type: none"> · Do not send commands to the overtravel range from the host device. · Check the wiring for the overtravel signal. · Implement anti-interference measures. |
| A.9B0: Soft limit error | Soft limit setting error | Confirm that the value for 607D is set correctly. | Set the value of 607D within the correct range. |
| A.9B2: Synchronization frame loss | Synchronization frame data loss | Check whether shielded twisted-pair communication cables are being used; Confirm that the drive is properly grounded. | <ol style="list-style-type: none"> 1. Use shielded twisted-pair cables with shielding functionality; 2. Follow standard wiring guidelines for connections; 3. After setting the pre-use synchronization cycle, switch the drive's EtherCAT communication state machine to operation mode; 4. If the master station's synchronization cycle itself has significant error, adjust the master station or increase the slave station's synchronization loss fault tolerance Pn785. |
| A.9B3: Bus interrupt | EtherCAT communication interruption | Check whether shielded twisted-pair communication cables are being used; Confirm that the drive is properly grounded. | <ol style="list-style-type: none"> 1. Use shielded twisted-pair cables with shielding functionality; 2. Follow standard wiring guidelines for connections; 3. After setting the pre-use synchronization cycle, switch the drive's EtherCAT communication state machine to operation mode; 4. If the master station's synchronization cycle itself has significant error, adjust the master station or increase the slave station's synchronization loss fault tolerance Pn785. |
| A.9B4: Network initialization failure | EtherCAT network initialization is failed. | Unprogrammed device configuration file Servo drive failure | Program the corresponding XML file. Replace the servo drive. |
| A.9C0 Advanced auto-tuning warning 1 | Operation status error | — | — |

| | | | |
|-------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>A.9C1 Advanced auto-tuning warning 2</p> | <p>When the tuning-free function is active, the rotational inertia estimation is not performed.</p> | <p>—</p> | <p>Set "Estimated Rotational Inertia [Default]" to restart tuning in HCServoWorks startup mode, or set ['J. ON'] in the operation panel startup mode.</p> <hr/> <p>Restart tuning, or disable the tuning-free function (Pn170.0=0).</p> |
| <p>A.9C2 Advanced auto-tuning warning 3</p> | <p>No positioning completion signal [COIN] is detected for over 10 seconds.</p> | <p>—</p> | <p>Increase the advanced auto-tuning initial gain level (Pn6B3) by one step. Or increase the advanced auto-tuning positioning accuracy (Pn6B5) by one step.</p> |
| <p>A.9C3 Advanced auto-tuning warning 4</p> | <p>The speed loop gain search reaches the lower limit.</p> <hr/> <p>Mechanical vibration occurs.</p> | <p>—</p> | <p>Decrease the auto-tuning initial positioning accuracy (Pn6B5) by one step.</p> <hr/> <p>Vibration can be suppressed using the Type A Vibration Suppression Adjustment Function or the Vibration Suppression Function.</p> |
| <p>A.9C4 Advanced auto-tuning warning 5</p> | <p>Position loop or model loop gain search reaches the lower limit.</p> <hr/> <p>Position complete signal (/COIN) is unstable during motor stop, cycling ON/OFF.</p> <hr/> <p>Mechanical vibration occurs.</p> | <p>—</p> | <p>Increase the high-level auto-tuning positioning accuracy (Pn6B5) by one level. In HCServoWorks startup mode, set 'Positioning Correspondence (Focus on Overshoot)' to restart tuning. Alternatively, in the operation panel startup mode, set 'L. 3' to restart tuning.</p> <hr/> <p>Suppress vibration using the Type A vibration suppression adjustment function and vibration suppression function.</p> |
| <p>A.9C5 Advanced auto-tuning warning 6</p> | <p>Rotational inertia self-calibration has started but calibration processing has not been executed.</p> | <p>—</p> | <p>Increase the auto-tuning initial gain level (Pn6B3) by one step.</p> <hr/> <p>Increase the movement distance.</p> |
| <p>A.9C6 Advanced auto-tuning warning 7</p> | <p>Rotational inertia self-calibration result deviation is excessive; deviation persists after 10 retries.</p> | <p>—</p> | <p>Current mechanical inertia cannot be estimated; manually set the rotational inertia ratio (Pn103) directly based on mechanical specifications.</p> <hr/> <p>Set "Do not estimate rotational inertia" in HCServoWorks startup mode to restart tuning, or set 'J. OFF' in the operation panel startup mode to restart tuning.</p> |
| <p>A.9C7 Advanced auto-tuning warning 8</p> | <p>Low-frequency vibration is detected during rotational inertia self-calibration.</p> | <p>—</p> | <p>Increase the advanced auto-tuning initial inertia level (Pn6B4) by one step.</p> |
| <p>A.9C8 Advanced auto-tuning warning 9</p> | <p>Torque limit value is reached.</p> | <p>—</p> | <p>Increase the torque limit value when a torque limit is set.</p> <hr/> <p>Increase the initial inertia level for advanced auto-tuning (Pn6B4) by one step.</p> |

| | | | |
|---------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|---|------------------------------------------------------------------------------|
| A.9C9 Advanced auto-tuning warning 10 | During the automatic inertia estimation process, an external input (/ P-CON) causes the speed loop control mode to switch to P-control. | — | Switch to PI control during inertia auto-estimation. |
| A.9CA Advanced auto-tuning warning 11 | An alarm or warning occurs in the servo during the tuning process. | — | Eliminate the cause of the alarm or warning and retry. |
| A.9CB Advanced auto-tuning warning 12 | The servo's main power is not ready during the tuning process. | — | Turn on the main circuit power and retry. |
| A.9CC Advanced auto-tuning warning 13 | The servo is in the overtravel state during the tuning process. | — | Eliminate the cause of the overtravel and retry. |
| A.9CD Advanced auto-tuning warning 14 | The servo is not enabled during the tuning process. | — | Do not perform servo enable OFF operations during tuning operation. |
| A.9CE Advanced auto-tuning warning 15 | The servo's active gain is not gain 1 during the tuning process. | — | Set automatic gain switching to disabled (Pn139.0=0) and G-SEL to OFF state. |
| A.9CF Advanced auto-tuning warning 16 | The servo is in the STO state during the tuning process. | — | Release the STO state and retry. |
| A.9D0 Advanced auto-tuning warning 17 | Before tuning, pole detection is not performed. | — | Perform pole detection first, then retry. |
| A.9D1 Advanced auto-tuning warning 18 | During the tuning process, the maximum time limit is exceeded. | — | Check the mechanical connections, then retry. |
| A.9D2 Advanced auto-tuning warning 19 | After tuning, the gain results fail to save. | — | Do not perform other parameter write operations during tuning, then retry. |
| A.9D3 Advanced auto-tuning warning 20 | During the tuning process, the host downlink command times out. | — | Check the USB wiring or replace the USB cable, then retry. |

10.3 Causes and troubleshooting based on the operation and conditions

This section provides troubleshooting based on the operation and conditions of the servo motor, including causes and corrections.

Table 10-6 Fault causes and troubleshooting

| Fault content | Cause | Confirmation method | Correction |
|----------------------------------------------------------|-----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------|
| Servo motor start failure | Control power supply is not connected. | Measure the voltage between control power supply terminals. | Ensure correct wiring to turn on the control power supply. |
| | Main circuit power supply is not connected. | Measure the voltage between the main circuit power input terminals. | Ensure correct wiring to turn on the main circuit power supply. |
| | I/O terminals (CN1) have wiring errors and omissions. | Check the wiring condition of the I/O signal connector (CN1) pins. | Ensure correct wiring of the I/O terminals (CN1). |
| | Loose wiring or disconnection in the servo motor main circuit cable and encoder cable. | Check the wiring conditions. | Ensure correct wiring. |
| | Excessive load on the servo motor. | Operate the servo motor with no load and check the load status. | Reduce the load or replace with a higher-capacity servo motor. |
| | The type of encoder used differs from the setting of Pn002.2. | Check the type of the encoder that is being used and the setting of Pn002.2. | Set Pn002.2 based on the encoder in use. |
| | No input of speed/position command. | Check the allocation status of the input signals. | Assign input signals to ensure proper input of speed/position commands. |
| | Incorrect assignment of input signals (Pn590 ~ Pn5A4). | Check the input signal allocations (Pn590 ~ Pn5A4) | Ensure correct assignment of input signals (Pn590 ~ Pn5A4). |
| | The /S-ON input is OFF. | Check the setting of the input signals. | Set the input signals correctly to turn on the /S-ON input. |
| | The function setting for the /P-CON input is incorrect. | Check the setting of Pn000.1. | Set correctly based on the intended function. |
| | Incorrect speed command input (during speed control). | Between V-REF and SG, check if the control mode matches the input. | Set the control mode and input method correctly. |
| | Incorrect torque command input (during torque control). | Between V-REF and SG, check if the control mode matches the input. | Set the control mode and input method correctly. |
| | Incorrect command pulse input (during position control). | Check the command pulse shape and sign + pulse signal of Pn200.0. | Set the control mode and input method correctly. |
| | The position deviation clear (/CLR) input remains ON. | Check the /CLR input signal. | Turn off the /CLR input signal. |
| | The forward drive prohibition (P-OT) and reverse drive prohibition (N-OT) input signals remain OFF. | Check the P-OT or N-OT input signal. | Set the P-OT or N-OT input signal to ON. |
| The safety input signals (/STO1 or /STO2) remain OFF. | Check the /STO1 and /STO2 input signals. | Set the /STO1 and /STO2 input signals to ON. When not using the safety function, install the included safety jumper plug into CN8. | |
| Servo drive failure | - | Replace the servo drive. | |
| Momentary running and subsequent stop of the servo motor | Servo motor wiring error | Check the wiring. | Ensure correct wiring. |
| | Encoder wiring error | Check the wiring. | Ensure correct wiring. |

| | | | | |
|------------------------------------------------------------------------------------------------|---------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------|
| Servo motor operational instability | Servo motor cable wiring defect | Power lines (U, V, W phases) and encoder plug connections may be unstable. Check the wiring. | Tighten any loose terminals or connectors and correct the wiring. | |
| Servo motor rotation without command | Incorrect speed command input (during speed control). | Between V-REF and SG, check if the control mode matches the input. | Set the control mode and input method correctly. | |
| | Incorrect torque command input (during torque control). | Between V-REF and SG, check if the control mode matches the input. | Set the control mode and input method correctly. | |
| | Offset deviation in the speed command. | Improper offset adjustment of the servo drive. | Adjust the offset of the servo drive. | |
| | Servo drive failure | - | Replace the servo drive. | |
| Dynamic brake (DB) non-operation | The setting value of parameter Pn001.0 is incorrect. | Check the setting value of parameter Pn001.0. | Set Pn001.0 correctly. | |
| | DB resistor is disconnected. | Check the moment of inertia, motor speed, and dynamic brake frequency of use. If the moment of inertia, motor speed, or dynamic brake frequency of use is excessive, the dynamic brake resistance may be disconnected. | Replace the servo drive. To prevent disconnection, reduce the load. | |
| | There is a failure in the dynamic brake drive circuit. | - | There is a defective component in the dynamic brake circuit. Replace the servo drive . | |
| The servo motor vibrates significantly while using the tuning-less function (default setting). | The machine mounting is not secure. | Check the waveform of the motor speed. | Reduce the load so that it is below the allowable moment of inertia ratio, or increase the load value of the tuning-free value setting (Fn200), or reduce the rigidity value. | |
| | | Check the installation status of the servo motor | Tighten the mounting screws. | |
| | | Check to see if there is misalignment in the coupling. | Align the coupling. | |
| | | Check to see if the coupling is balanced. | Balance the coupling. | |
| | | Bearing internal fault | Check for noise and vibration around the bearings. | Replace the servo motor. |
| | | Vibration originating from associated machinery | Check for any foreign matter, damage, or deformation in the machine's moving parts. | Consult with the machine manufacturer. |
| | | Noise interference due to specification error in I/O signal cables. | Check if the I/O signal cables meet the specifications. Cable specifications: twisted pair shielded cable or twisted pair overall shielded cable (core wire: 0.12mm ² or thicker, tin-plated soft copper stranded wire). | Use cables meeting the specifications. |
| | | Noise interference due to excessive length of I/O signal cables. | Check the length of the I/O signal cables. | Limit the length of I/O signal cables to 3m less. |

| | | | |
|--------------------------------------------|---------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| Abnormal noise from servo motor | Noise interference due to specification error in encoder cables. | Check if the encoder cables meet the specifications. Cable specifications: twisted pair shielded cable or twisted pair overall shielded cable. (core wire: 0.12mm ² or thicker, tin-plated soft copper stranded wire) | Use cables meeting the specifications. |
| | Noise interference due to excessive length of encoder cables. | Check the length of the encoder cables. | Set the length of encoder cables to within 50m. |
| | Noise interference due to damage to encoder cables. | Check if the encoder cables are pinched or have jacket damage. | Replace encoder cables and alter their installation environment. |
| | Excessive noise interference on encoder cables. | Check if the encoder cables are bundled with high-current wires or too close to them. | Modify the laying environment of encoder cables to avoid surge voltage from high-current wires. |
| | Variation in FG potential due to servo motor-side equipment (e.g., welding machines). | Check the grounding status of servo motor-side equipment (missing grounding, incomplete grounding). | Properly ground servo motor-side equipment to prevent current diversion to the encoder-side FG. |
| | Pulse count error in the servo drive due to noise interference. | Check for noise interference between the encoder and signal lines. | Implement anti-interference measures for encoder wiring. |
| | The encoder is subjected to excessive vibration or shock. | Check to see if vibration from the machine occurs. Check the servo motor installation (mounting surface precision, securing state, and alignment). | Reduce mechanical vibration and improve the installation status of the servo motor. |
| | Encoder failure | - | Replace the servo motor. |
| Motor vibration at approximately 200-400hz | Servo gain balance is poor. | Check if servo gain tuning has been performed. | Perform advanced auto-tuning. |
| | The set value of speed loop gain (Pn100) is too high. | Check the speed loop gain (Pn100) set value (default value: Kv = 40.0Hz). | Set the correct speed loop gain (Pn100) set value. |
| | The set value of position loop gain (Pn102) is too high. | Check the position loop gain (Pn102) set value (default value: Kp = 40.0/s). | Set the correct position loop gain (Pn102) set value. |
| | The speed loop integral time constant (Pn101) is improperly set. | Check the factory default of speed loop integral time constant (Pn101) (Ti = 20.0ms). | Set the correct speed loop integral time constant (Pn101) set value. |
| | The inertia ratio (Pn103) set value is incorrect. | Check the inertia ratio (Pn103) set value. | Set the correct inertia ratio (Pn103) set value. |
| Excessive speed overshoot at start/ stop | Servo gain balance is poor. | Check if servo gain tuning has been performed. | Perform advanced auto-tuning. |
| | The set value of speed loop gain (Pn100) is too high. | Check the speed loop gain (Pn100) set value (default value: Kv = 40.0Hz). | Set the correct speed loop gain (Pn100) set value. |
| | The set value of position loop gain (Pn102) is too high. | Check the position loop gain (Pn102) set value (default value: Kp = 40.0/s). | Set the correct position loop gain (Pn102) set value. |
| | The speed loop integral time constant (Pn101) is improperly set. | Check the factory default of speed loop integral time constant (Pn101) (Ti = 20.0ms). | Set the correct speed loop integral time constant (Pn101) set value. |
| | The inertia ratio (Pn103) set value is incorrect. | Check the inertia ratio (Pn103) set value. | Set the correct inertia ratio (Pn103) set value. |

| | | | |
|-----------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| Absolute encoder position deviation error (deviation between host-stored power-off position and re-power-on position) | Noise interference due to specification error in I/O signal cables. | Check if the I/O signal cables meet the specifications. Cable specifications: twisted pair shielded cable or twisted pair overall shielded cable (core wire: 0.12mm ² or thicker, tin-plated soft copper stranded wire). | Use cables meeting the specifications. |
| | Noise interference due to excessive length of I/O signal cables. | Check the length of the encoder cables. | Set the length of encoder cables to within 50m. |
| | Noise interference due to damage to encoder cables. | Check if the encoder cables are pinched or have jacket damage. | Replace encoder cables and alter their installation environment. |
| | Excessive noise interference on encoder cables. | Check if the encoder cables are bundled with high-current wires or too close to them. | Modify the laying environment of encoder cables to avoid surge voltage from high-current wires. |
| | Variation in FG potential due to servo motor-side equipment (e.g., welding machines). | Check the grounding status of the servo motor-side equipment (missing grounding, incomplete grounding). | Properly ground servo motor-side equipment to prevent current diversion to the encoder-side FG. |
| | Pulse count error in the servo drive due to noise interference. | Check for noise interference between the encoder and signal lines. | Implement anti-interference measures for encoder wiring. |
| | The encoder is subjected to excessive vibration or shock. | Check whether vibration from the machine occurs. Check the servo motor installation (mounting surface precision, securing state, and alignment). | Reduce mechanical vibration and improve the installation status of the servo motor. |
| | Encoder failure | - | Replace the servo motor. |
| | Servo drive failure (Pulses unchanged) | - | Replace the servo drive. |
| | Host device multi-rotation data read error | Check the error detection part of the host controller | Make the error detection unit of the host device work properly. |
| Check to see if the host controller is executing data parity checks | | Perform parity check on the multi-rotation data. | |
| Check for noise interference in the cable between the servo drive and the host controller | | Take anti-interference measures and recheck the parity of the multi-rotation data. | |
| Overtravel (OT) | The forward/reverse drive prohibition signal (P-OT/N-OT) is input. | Check the voltage of the external +24V power supply for input signals. | Set the voltage of the external +24V power supply for input signals to the correct value. |
| | | Check the operating status of the overtravel limit switch. | Ensure the overtravel limit switch operates normally. |
| | | Check the wiring of the overtravel limit switch. | Ensure correct wiring of the overtravel limit switch. |
| | | Check the set value of the parameter. | Set the parameter correctly. |
| | The forward/reverse drive prohibition signal (P-OT/N-OT) malfunctions. | Check for voltage fluctuations in the external +24V power supply for input signals. | Eliminate voltage fluctuations in the external +24V power supply for input signals. |
| | | Check if the operating status of the overtravel limit switch is unstable. | Stabilize the operating status of the overtravel limit switch. |
| | | Check the wiring of the overtravel limit switch (e.g., cable damage, screw tightness). | Ensure correct wiring of the overtravel limit switch. |

| | | | |
|---------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| | Error in parameter assignment for the forward/reverse drive prohibition signal (P-OT/N-OT). | Confirm the P-OT signal is correctly assigned. | If other signals have been assigned to the set parameter, reassign the P-OT signal to that parameter. |
| | | Confirm the N-OT signal is assigned to the correct location. | If other signals have been assigned to the set parameter, reassign the N-OT signal to that parameter. |
| | Incorrect selection of the servo motor stop method. | Confirm Pn001.0 and Pn001.1 when the servo is OFF. | Select a servo motor stop method other than coast to stop. |
| | | Confirm Pn001.0 and Pn001.1 during torque control. | Select a servo motor stop method other than coast to stop. |
| Stop position inaccuracy due to overtravel (OT) | The position of the limit switch and the length of the monitoring device are improper. | - | Set the limit switch to an appropriate position. |
| | The position of the overtravel limit switch is shorter than the inertia run-out. | - | Install the overtravel limit switch in an appropriate position. |
| Position deviation (no alarm) | Noise interference due to specification error in I/O signal cables. | Check if the I/O signal cables meet the specifications. Cable specifications: twisted pair shielded cable or twisted pair overall shielded cable (core wire: 0.12mm ² or thicker, tin-plated soft copper stranded wire). | Use cables meeting the specifications. |
| | Noise interference due to excessive length of I/O signal cables. | Check the length of the encoder cables. | Set the length of encoder cables to within 50m. |
| | Noise interference due to damage to encoder cables. | Check if the encoder cables are pinched or have jacket damage. | Replace encoder cables and alter their installation environment. |
| | Excessive noise interference on encoder cables. | Check if the encoder cables are bundled with high-current wires or too close to them. | Modify the laying environment of encoder cables to avoid surge voltage from high-current wires. |
| | Variation in FG potential due to servo motor-side equipment (e.g., welding machines). | Check the grounding status of the servo motor-side equipment (missing grounding, incomplete grounding). | Properly ground servo motor-side equipment to prevent current diversion to the encoder-side FG. |
| | Pulse count error in the servo drive due to noise interference. | Check for noise interference between the encoder and signal lines. | Implement anti-interference measures for encoder wiring. |
| | The encoder is subjected to excessive vibration or shock. | Check whether vibration from the machine occurs. Check the servo motor installation (mounting surface precision, securing state, and alignment). | Reduce mechanical vibration and improve the installation status of the servo motor. |
| | Coupling fault between the machine and the servo motor. | Check the coupling part between the machine and the servo motor for misalignment. | Correctly fix the coupling between the machine and the servo motor. |
| Noise interference due to specification error in I/O signal cables. | Check if the I/O signal cables meet the specifications. Cable specifications: twisted pair shielded cable or twisted pair overall shielded cable (core wire: 0.12mm ² or thicker, tin-plated soft copper stranded wire). | Use cables that meet the specifications. | |

| | | | |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------|
| | When using the instruction pulse input multiplier switching function, input/output signals for this function (/PSEL, /PSELA) are incorrectly detected due to interference. | Check if the I/O signal cables meet the specifications. Cable specifications: twisted pair shielded cable or twisted pair overall shielded cable (core wire: 0.12mm ² or thicker, tin-plated soft copper stranded wire) . | Use cables that meet the specifications. |
| | Noise interference due to excessive length of I/O signal cables. | Check the length of the I/O signal cables. | Limit the length of I/O signal cables to 3m or less. |
| | Encoder failure (Pulses unchanged) | - | Replace the servo drive. |
| | Servo drive failure | - | Replace the servo drive. |
| Servo motor overheating | Ambient temperature is too high. | Measure the ambient temperature of the servo motor. | Keep ambient temperature below 40°C . |
| | Servo motor surface is dirty. | Visually inspect dirt on the servo motor surface. | Remove dirt, dust, oil, etc., from the servo motor surface. |
| | Servo motor is overloaded. | Check the load status with a monitor. | If overloaded, reduce the load or replace with a higher-capacity servo drive and servo motor. |

Chapter 11 Parameter List

| | |
|---------------------------------------------------------------|-----|
| 11.1 Auxiliary Function List | 267 |
| 11.2 Parameter List..... | 268 |
| 11.3 Parameter List for Object Dictionary 2000H | 306 |
| 11.4 Object dictionary 6000H group common parameter list..... | 319 |
| 11.5 Detailed description of 6000H object dictionary | 321 |

11.1 Auxiliary Function List

Table 11-1 Auxiliary function list

| Fn No. | Function | By operation panel | By HCServoWorks | Reference chapter |
|--------|-----------------------------------------------------------------|--------------------|-----------------|-------------------|
| Fn000 | Display Alarm History | 1 | 1 | 8.2 |
| Fn001 | Simple Rigidity Selection | 1 | 1 | 8.3 |
| Fn002 | Run JOG | 1 | 1 | 8.4 |
| Fn003 | Origin search | 1 | 1 | 8.5 |
| Fn004 | Run JOG Program | 1 | 1 | 8.6 |
| Fn005 | Initialize Parameters | 1 | 1 | 8.7 |
| Fn006 | Clear Alarm History | 1 | 1 | 8.8 |
| Fn008 | Reset Absolute Encoder (initialization) and Reset Encoder Alarm | 1 | 1 | 8.9 |
| Fn00E | Auto Tuning Motor Current Detection Signal Offset | 1 | 1 | 8.10 |
| Fn00F | Manually Adjust Motor Current Detection Signal Offset | 1 | 1 | 8.11 |
| Fn010 | Write Prohibition Setting | 1 | 0 | 8.12 |
| Fn011 | Display Servomotor Model | 1 | 1 | 8.13 |
| Fn012 | Display Software Version | 1 | 1 | 8.14 |
| Fn01B | Initialize Vibration Detection Value | 1 | 1 | 8.15 |
| Fn030 | Software Reset | 1 | 1 | 8.16 |
| Fn080 | Magnetic pole detection | 1 | 1 | 8.17 |
| Fn082 | Current JOG | 1 | 1 | 8.18 |
| Fn200 | Set Auto-tuning Level | 1 | 1 | 8.19 |
| Fn201 | Advanced Auto-tuning without Reference | 1 | 1 | 8.20 |
| Fn202 | Advanced Auto-tuning with Reference | 1 | 1 | 8.21 |
| Fn203 | Single-Parameter Tuning | 1 | 1 | 8.22 |
| Fn204 | Type A vibration suppression control function | 0 | 1 | — |
| Fn205 | MFC vibration detection | 0 | 1 | — |
| Fn206 | EasyFFT | 1 | 1 | 8.23 |
| Fn207 | Auto-vibration detection | 1 | 1 | 8.24 |

1 : Operable 0 :Not operable

Note: When performing auxiliary functions, be sure to use the operation panel or HCServoWorks. If an auxiliary function be performed at the same time, "no_oP" or "NO-OP" will be displayed.

11.2 Parameter List

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|-----------|---------------|----------------------------------------------|-------------------------------------------------------|-----------|-------------------------------------------------------------------|---------------------------------------------------------------------|-----------------------------------------------------|-----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------|
| Pn000 (2000h) | Basic Function Selection 0 | 0000H - 0001H | — | 0000H | After restart | Setup | — | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Rotation Direction Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Take CCW direction as the forward rotation direction.</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Take CW direction as the forward rotation direction. (Reverse Mode)</td> </tr> </tbody> </table> <div style="border: 1px solid black; padding: 5px; margin-top: 10px; text-align: center;">Reserved parameter (Do not change.)</div> </div> </div> | Rotation Direction Selection | | Reference | 0 | Take CCW direction as the forward rotation direction. | — | 1 | Take CW direction as the forward rotation direction. (Reverse Mode) | | | | | | | | | | |
| Rotation Direction Selection | | Reference | | | | | | | | | | | | | | | | | |
| 0 | Take CCW direction as the forward rotation direction. | — | | | | | | | | | | | | | | | | | |
| 1 | Take CW direction as the forward rotation direction. (Reverse Mode) | | | | | | | | | | | | | | | | | | |
| Pn001 (2001h) | Application Function Selection 1 | 0000H-0166H | — | 0036H | After restart | Setup | — | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Stopping Method at Servo OFF</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Stop the motor by applying the dynamic brake</td> <td rowspan="7" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Stop by applying dynamic brake and then release the dynamic brake</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Coast the motor to a stop without the dynamic brake</td> </tr> <tr> <td style="text-align: center;">3</td> <td>Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the DB control state after stop</td> </tr> <tr> <td style="text-align: center;">4</td> <td>Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, terminate the motor through DB, and then release DB</td> </tr> <tr> <td style="text-align: center;">5</td> <td>Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the DB control state after stop</td> </tr> <tr> <td style="text-align: center;">6</td> <td>Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop</td> </tr> </tbody> </table> </div> </div> | Stopping Method at Servo OFF | | Reference | 0 | Stop the motor by applying the dynamic brake | — | 1 | Stop by applying dynamic brake and then release the dynamic brake | 2 | Coast the motor to a stop without the dynamic brake | 3 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the DB control state after stop | 4 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, terminate the motor through DB, and then release DB | 5 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the DB control state after stop | 6 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop |
| | Stopping Method at Servo OFF | | Reference | | | | | | | | | | | | | | | | |
| | 0 | Stop the motor by applying the dynamic brake | — | | | | | | | | | | | | | | | | |
| 1 | Stop by applying dynamic brake and then release the dynamic brake | | | | | | | | | | | | | | | | | | |
| 2 | Coast the motor to a stop without the dynamic brake | | | | | | | | | | | | | | | | | | |
| 3 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the DB control state after stop | | | | | | | | | | | | | | | | | | |
| 4 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, terminate the motor through DB, and then release DB | | | | | | | | | | | | | | | | | | |
| 5 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the DB control state after stop | | | | | | | | | | | | | | | | | | |
| 6 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop | | | | | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Overtravel Stopping Method</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Stop the motor by applying the dynamic brake</td> <td rowspan="7" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Stop by applying dynamic brake and then release the dynamic brake</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Coast the motor to a stop without the dynamic brake</td> </tr> <tr> <td style="text-align: center;">3</td> <td>Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the servo lock state after stop</td> </tr> <tr> <td style="text-align: center;">4</td> <td>Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the free control state after stop</td> </tr> <tr> <td style="text-align: center;">5</td> <td>Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the servo lock state after stop</td> </tr> <tr> <td style="text-align: center;">6</td> <td>Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop</td> </tr> </tbody> </table> </div> </div> | Overtravel Stopping Method | | Reference | 0 | Stop the motor by applying the dynamic brake | — | 1 | Stop by applying dynamic brake and then release the dynamic brake | 2 | Coast the motor to a stop without the dynamic brake | 3 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the servo lock state after stop | 4 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the free control state after stop | 5 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the servo lock state after stop | 6 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop | |
| Overtravel Stopping Method | | Reference | | | | | | | | | | | | | | | | | |
| 0 | Stop the motor by applying the dynamic brake | — | | | | | | | | | | | | | | | | | |
| 1 | Stop by applying dynamic brake and then release the dynamic brake | | | | | | | | | | | | | | | | | | |
| 2 | Coast the motor to a stop without the dynamic brake | | | | | | | | | | | | | | | | | | |
| 3 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the servo lock state after stop | | | | | | | | | | | | | | | | | | |
| 4 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the free control state after stop | | | | | | | | | | | | | | | | | | |
| 5 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the servo lock state after stop | | | | | | | | | | | | | | | | | | |
| 6 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop | | | | | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Main Circuit Power Supply AC/DC Input Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>AC power input: From L1, L2, (L3) terminals</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>DC power input: From B1/(+)! (-), from B1/(+)! (-) or from P/(+)!</td> </tr> </tbody> </table> <div style="border: 1px solid black; padding: 5px; margin-top: 10px; text-align: center;">Reserved parameter (Do not change.)</div> </div> </div> | Main Circuit Power Supply AC/DC Input Selection | | Reference | 0 | AC power input: From L1, L2, (L3) terminals | — | 1 | DC power input: From B1/(+)! (-), from B1/(+)! (-) or from P/(+)! | | | | | | | | | | | |
| Main Circuit Power Supply AC/DC Input Selection | | Reference | | | | | | | | | | | | | | | | | |
| 0 | AC power input: From L1, L2, (L3) terminals | — | | | | | | | | | | | | | | | | | |
| 1 | DC power input: From B1/(+)! (-), from B1/(+)! (-) or from P/(+)! | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | |
|-----------------------------|----------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|----------------|----------------|-----------------------------|----------------------------------------------|-----------|-----------|------------------|-------------------------------------------------|---|-----------------------------------------------------------|-------------------------------------------------------------------------------------------|-------------------------------------------|----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------|
| Pn002 (2002h) | Application Function Selection 2 | 0000H~0211H | — | 0111H | After restart | Basic setting | — | | | | | | | | | | | |
| | n. | Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> | | | | | | | | | | | | | | | | |
| | | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| | | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th colspan="2">Usage of encoder</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Use encoder as the absolute encoder</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>Use encoder as incremental encoder</td> </tr> <tr> <td>2</td> <td>Use encoder as single-turn absolute encoder (rotating)</td> </tr> </tbody> </table> | | | | | Usage of encoder | | Reference | 0 | Use encoder as the absolute encoder | — | 1 | Use encoder as incremental encoder | 2 | Use encoder as single-turn absolute encoder (rotating) | |
| Usage of encoder | | Reference | | | | | | | | | | | | | | | | |
| 0 | Use encoder as the absolute encoder | — | | | | | | | | | | | | | | | | |
| 1 | Use encoder as incremental encoder | | | | | | | | | | | | | | | | | |
| 2 | Use encoder as single-turn absolute encoder (rotating) | | | | | | | | | | | | | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | |
| Pn008 (2008h) | Application Function Selection 8 | 0000H - 4121H | — | 0000H | After restart | Basic setting | — | | | | | | | | | | | |
| | n. | Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> | | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th colspan="2">Battery undervoltage alarm/warning selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Set battery undervoltage to alarm (A.830)</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Set battery undervoltage to warning (A.930)</td> </tr> </tbody> </table> | | | | | Battery undervoltage alarm/warning selection | | Reference | 0 | Set battery undervoltage to alarm (A.830) | — | 1 | Set battery undervoltage to warning (A.930) | | | |
| | Battery undervoltage alarm/warning selection | | Reference | | | | | | | | | | | | | | | |
| | 0 | Set battery undervoltage to alarm (A.830) | — | | | | | | | | | | | | | | | |
| | 1 | Set battery undervoltage to warning (A.930) | | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th colspan="2">Main circuit undervoltage function selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Do not detect main circuit undervoltage warning</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>Detect undervoltage warning of main circuit and implement torque limit at host controller</td> </tr> <tr> <td>2</td> <td>Detect undervoltage warning of main circuit and limit torque with Pn424 and Pn425 (only in servo drive).</td> </tr> </tbody> </table> | | | | | Main circuit undervoltage function selection | | Reference | 0 | Do not detect main circuit undervoltage warning | — | 1 | Detect undervoltage warning of main circuit and implement torque limit at host controller | 2 | Detect undervoltage warning of main circuit and limit torque with Pn424 and Pn425 (only in servo drive). | |
| | Main circuit undervoltage function selection | | Reference | | | | | | | | | | | | | | | |
| | 0 | Do not detect main circuit undervoltage warning | — | | | | | | | | | | | | | | | |
| | 1 | Detect undervoltage warning of main circuit and implement torque limit at host controller | | | | | | | | | | | | | | | | |
| 2 | Detect undervoltage warning of main circuit and limit torque with Pn424 and Pn425 (only in servo drive). | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th colspan="2">Warning detection selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Detect warnings.</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Do not detect warnings (except A.971)</td> </tr> </tbody> </table> | | | | | Warning detection selection | | Reference | 0 | Detect warnings. | — | 1 | Do not detect warnings (except A.971) | | | | |
| Warning detection selection | | Reference | | | | | | | | | | | | | | | | |
| 0 | Detect warnings. | — | | | | | | | | | | | | | | | | |
| 1 | Do not detect warnings (except A.971) | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th colspan="2">Alarm detection selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not used</td> <td rowspan="4">—</td> </tr> <tr> <td>1</td> <td>Do not detect position bias warning when servo ON (A.901)</td> </tr> <tr> <td>2</td> <td>Do not vibration warning detected (A.911)</td> </tr> <tr> <td>4</td> <td>Do not detect Pn change warning requiring re-energization (A.941)</td> </tr> </tbody> </table> | | | | | Alarm detection selection | | Reference | 0 | Not used | — | 1 | Do not detect position bias warning when servo ON (A.901) | 2 | Do not vibration warning detected (A.911) | 4 | Do not detect Pn change warning requiring re-energization (A.941) |
| Alarm detection selection | | Reference | | | | | | | | | | | | | | | | |
| 0 | Not used | — | | | | | | | | | | | | | | | | |
| 1 | Do not detect position bias warning when servo ON (A.901) | | | | | | | | | | | | | | | | | |
| 2 | Do not vibration warning detected (A.911) | | | | | | | | | | | | | | | | | |
| 4 | Do not detect Pn change warning requiring re-energization (A.941) | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | |
|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|----------------|----------------|-----------|---------------------------------------|--|-----------|---|-------------------------------------------------------------------|---|---|-------------------------------------------------------------------|---|-----------------------------------------------------|---|-------------------------------------------------------------------------------------------------------------------------------|---|-----------------------------------------------------------------------------------------------------------------------------------------|---|--------------------------------------------------------------------------------------------------------------------|---|----------------------------------------------------------------------------------------------------------------------|
| Pn009 (2009h) | Application Function Selection 9 | 0000H - 0130H | — | 0010H | After restart | Tuning | — | | | | | | | | | | | | | | | | | | |
| | n. | Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | | | | | |
| | | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th colspan="2">Current control mode selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Select current control mode 1.</td> <td rowspan="4">—</td> </tr> <tr> <td>1</td> <td>Select current control mode 2.</td> </tr> <tr> <td>2</td> <td>Select current control mode 3.</td> </tr> <tr> <td>3</td> <td>Select current control mode 4.</td> </tr> </tbody> </table> | | | | | Current control mode selection | | Reference | 0 | Select current control mode 1. | — | 1 | Select current control mode 2. | 2 | Select current control mode 3. | 3 | Select current control mode 4. | | | | | | |
| | Current control mode selection | | Reference | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | Select current control mode 1. | — | | | | | | | | | | | | | | | | | | | | | | |
| | 1 | Select current control mode 2. | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Select current control mode 3. | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 | Select current control mode 4. | | | | | | | | | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th colspan="2">Velocity detection mode selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Select velocity detection mode 1 (without speed smoothing filter)</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Select velocity detection mode 2 (with speed smoothing filter)</td> </tr> </tbody> </table> | | | | | Velocity detection mode selection | | Reference | 0 | Select velocity detection mode 1 (without speed smoothing filter) | — | 1 | Select velocity detection mode 2 (with speed smoothing filter) | | | | | | | | | | |
| Velocity detection mode selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Select velocity detection mode 1 (without speed smoothing filter) | — | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Select velocity detection mode 2 (with speed smoothing filter) | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| Pn00A | Application Function SelectionA | 0000H - 0062H | — | 0000H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | |
| | n. | Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th colspan="2">Motor Stopping Method for BM.1 alarm</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Motor stop via DB (dynamic brake)</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>Motor stop via DB and then release the DB</td> </tr> <tr> <td>2</td> <td>Set the motor to the free-running state without DB.</td> </tr> </tbody> </table> | | | | | Motor Stopping Method for BM.1 alarm | | Reference | 0 | Motor stop via DB (dynamic brake) | — | 1 | Motor stop via DB and then release the DB | 2 | Set the motor to the free-running state without DB. | | | | | | | | |
| | Motor Stopping Method for BM.1 alarm | | Reference | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | Motor stop via DB (dynamic brake) | — | | | | | | | | | | | | | | | | | | | | | | |
| | 1 | Motor stop via DB and then release the DB | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Set the motor to the free-running state without DB. | | | | | | | | | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th colspan="2">Motor Stopping method for forced stop</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Stop the motor by applying the dynamic brake</td> <td rowspan="6">—</td> </tr> <tr> <td>1</td> <td>Stop by applying dynamic brake and then release the dynamic brake</td> </tr> <tr> <td>2</td> <td>Coast the motor to a stop without the dynamic brake</td> </tr> <tr> <td>3</td> <td>Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the DB control state after stop</td> </tr> <tr> <td>4</td> <td>Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, terminate the motor through DB, and then release DB</td> </tr> <tr> <td>5</td> <td>Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the DB control state after stop</td> </tr> <tr> <td>6</td> <td>Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop</td> </tr> </tbody> </table> | | | | | Motor Stopping method for forced stop | | Reference | 0 | Stop the motor by applying the dynamic brake | — | 1 | Stop by applying dynamic brake and then release the dynamic brake | 2 | Coast the motor to a stop without the dynamic brake | 3 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the DB control state after stop | 4 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, terminate the motor through DB, and then release DB | 5 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the DB control state after stop | 6 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop |
| | Motor Stopping method for forced stop | | Reference | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | Stop the motor by applying the dynamic brake | — | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Stop by applying dynamic brake and then release the dynamic brake | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Coast the motor to a stop without the dynamic brake | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the DB control state after stop | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, terminate the motor through DB, and then release DB | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the DB control state after stop | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop | | | | | | | | | | | | | | | | | | | | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | |
|------------------|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|----------------|----------------|-----------|--|
| Pn00B (200Bh) | Application Function SelectionB | 0000H - 0161H | — | 0031H | After restart | Basic setting | — | |
| | n. | Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> | | | | | | |
| | | | Operator Pn display selection | | Reference | | | |
| | | | 0 | Display only parameters for setting | — | | | |
| | | | 1 | Display all parameters. | — | | | |
| | | | Motor Stopping Method for BM.2 alarm | | Reference | | | |
| | | | 0 | Stop the motor by applying the dynamic brake | — | | | |
| | | | 1 | Stop by applying dynamic brake and then release the dynamic brake | | | | |
| | | | 2 | Coast the motor to a stop without the dynamic brake | | | | |
| | | | 3 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, and enter the DB control state after stop | | | | |
| | | 4 | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque, terminate the motor through DB, and then release DB | | | | | |
| | | 5 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the DB control state after stop | | | | | |
| | | 6 | Decelerate the motor to a stop using the deceleration time set in Pn30A, and enter the free control state after stop | | | | | |
| | | Power input selection of servo unit with three-phase input specification (set servo power under 220V 1KW to value 1) | | Reference | | | | |
| | | 0 | Three-phase power input. | — | | | | |
| | | 1 | single-phase power input. (Use three-phase input specifications) | — | | | | |
| | | Reserved parameter (Do not change.) | | | | | | |
| Pn00C (200Ch) | Application Function SelectionC | 0000H - 0131H | — | 0000H | After restart | Basic setting | — | |
| | n. | Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> | | | | | | |
| | | | No motor test function selection | | Reference | | | |
| | | | 0 | Set test mode without motor to invalid | — | | | |
| | | | 1 | Set test mode without motor to valid | | | | |
| | | | Encoder Resolution for Tests without a Motor | | Reference | | | |
| | | | 0 | 17 bit | — | | | |
| | | | 1 | 20 bit | | | | |
| | | | 2 | 23 bit | | | | |
| | | | 3 | 25 bit | | | | |
| | | Encoder Type Selection for Tests without a Motor | | Reference | | | | |
| | | 0 | Use an incremental encoder. | — | | | | |
| | | 1 | Use an absolute encoder | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | |
|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------|----------------|----------------|---------------------------------------------------------------|-------------------------------------------------|-----------|-----------|------------------------------------------------------------------|------|---|----------------------------------------------------------------------------|--------------------------|
| Pn00D (200Dh) | Application Function SelectionD | 0000H~1100H | — | 0000H | After restart | Basic setting | — | | | | | | | | |
| | Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Reserved parameter (Do not change.) | | | | | | | | | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th colspan="2">Hardware limit signal detection limit selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>N/A</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Detect only when enabled</td> </tr> </tbody> </table> | | | | | | Hardware limit signal detection limit selection | | Reference | 0 | N/A | — | 1 | Detect only when enabled |
| | Hardware limit signal detection limit selection | | Reference | | | | | | | | | | | | |
| 0 | N/A | — | | | | | | | | | | | | | |
| 1 | Detect only when enabled | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Over Travel (OT) Warning Detect Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Over travel warning not detected</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Over travel warning detected</td> </tr> </tbody> </table> | | | | | | Over Travel (OT) Warning Detect Selection | | Reference | 0 | Over travel warning not detected | — | 1 | Over travel warning detected | |
| Over Travel (OT) Warning Detect Selection | | Reference | | | | | | | | | | | | | |
| 0 | Over travel warning not detected | — | | | | | | | | | | | | | |
| 1 | Over travel warning detected | | | | | | | | | | | | | | |
| Pn080 (2080h) | Application Function Selection 80 | 0000H -0101H | — | 0000H | After restart | Basic setting | — | | | | | | | | |
| | Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | <table border="1"> <thead> <tr> <th colspan="2">Pole sensor selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>With</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Without</td> </tr> </tbody> </table> | | | | | | Pole sensor selection | | Reference | 0 | With | — | 1 | Without |
| | Pole sensor selection | | Reference | | | | | | | | | | | | |
| | 0 | With | — | | | | | | | | | | | | |
| | 1 | Without | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Setting Velocity and frequency division calculation Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Calculate the division output setting at the fixed maximum speed</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Calculate the maximum speed at the fixed frequency division output setting</td> </tr> </tbody> </table> | | | | | | Setting Velocity and frequency division calculation Selection | | Reference | 0 | Calculate the division output setting at the fixed maximum speed | — | 1 | Calculate the maximum speed at the fixed frequency division output setting | |
| Setting Velocity and frequency division calculation Selection | | Reference | | | | | | | | | | | | | |
| 0 | Calculate the division output setting at the fixed maximum speed | — | | | | | | | | | | | | | |
| 1 | Calculate the maximum speed at the fixed frequency division output setting | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | |
| Pn100 (2100h) | Velocity loop gain | 10 ~ 20000 | 0.1Hz | 400 | Immediately | Tuning | — | | | | | | | | |
| Pn101 (2101h) | Integral time constant of velocity loop | 15 ~ 51200 | 0.01ms | 2000 | Immediately | Tuning | — | | | | | | | | |
| Pn102 (2102h) | Position loop gain | 10 ~ 20000 | 0.1Hz | 400 | Immediately | Tuning | — | | | | | | | | |
| Pn103 (2103h) | Moment of inertia ratio | 0 ~ 20000 | 1% | 100 | Immediately | Tuning | — | | | | | | | | |
| Pn104 (2104h) | Second Velocity loop gain | 10 ~ 20000 | 0.1Hz | 400 | Immediately | Tuning | — | | | | | | | | |
| Pn105 (2105h) | Integral time constant of second speed loop | 15 ~ 51200 | 0.01ms | 2000 | Immediately | Tuning | — | | | | | | | | |
| Pn106 (2106h) | Second position loop gain | 10 ~ 20000 | 0.1Hz | 400 | Immediately | Tuning | — | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------|----------------|----------------|-------------------------|----------------|-----------|-----------|------------|----------------------------------------------------|---|-------------|--------------------------------------------------|-------------------------------------|----------------------------------------------|-------------------------------------|-----------------------------------------------------|---|------------------|---|--------------------------------------------------------------------------------------|--|
| Pn107 (2107h) | Pseudo differential feed forward control coefficient | 0 ~ 2000 | 0.1% | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn109 (2109h) | Velocity Feedforward | 0 ~ 100 | 1% | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn10A (210Ah) | Feedforward filter time constant | 0 ~ 6400 | 0.01ms | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn10B (210Bh) | Gain type application function Selection | 0000H - 0035H | — | 0000H | After restart | — | — | | | | | | | | | | | | | | | | | |
| | <div style="display: flex; justify-content: space-around; font-size: small;"> Bit 3 Bit 2 Bit 1 Bit 0 </div> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Mode selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Based on internal torque command (value set Pn10C)</td> <td rowspan="5" style="text-align: center; vertical-align: middle;">—</td> </tr> <tr> <td>1</td> <td>Based on velocity command (value setting: Pn10D)</td> </tr> <tr> <td>2</td> <td>Based on acceleration (value setting: Pn10E)</td> </tr> <tr> <td>3</td> <td>Based on position bias pulse (value setting: Pn10F)</td> </tr> <tr> <td>4</td> <td>No mode selected</td> </tr> <tr> <td>5</td> <td>Conditional on the speed loop integral set value (when speed loop integral = 51200).</td> <td></td> </tr> </tbody> </table> | | | | | | Mode selection | | Reference | 0 | Based on internal torque command (value set Pn10C) | — | 1 | Based on velocity command (value setting: Pn10D) | 2 | Based on acceleration (value setting: Pn10E) | 3 | Based on position bias pulse (value setting: Pn10F) | 4 | No mode selected | 5 | Conditional on the speed loop integral set value (when speed loop integral = 51200). | |
| | Mode selection | | Reference | | | | | | | | | | | | | | | | | | | | | |
| | 0 | Based on internal torque command (value set Pn10C) | — | | | | | | | | | | | | | | | | | | | | | |
| 1 | Based on velocity command (value setting: Pn10D) | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Based on acceleration (value setting: Pn10E) | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Based on position bias pulse (value setting: Pn10F) | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | No mode selected | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Conditional on the speed loop integral set value (when speed loop integral = 51200). | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Speed loop control mode</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PI control</td> <td rowspan="4" style="text-align: center; vertical-align: middle;">—</td> </tr> <tr> <td>1</td> <td>I-P control</td> </tr> <tr> <td>2</td> <td>Reserved parameter (Do not change.)</td> </tr> <tr> <td>3</td> <td>Reserved parameter (Do not change.)</td> </tr> </tbody> </table> | | | | | | Speed loop control mode | | Reference | 0 | PI control | — | 1 | I-P control | 2 | Reserved parameter (Do not change.) | 3 | Reserved parameter (Do not change.) | | | | | | |
| Speed loop control mode | | Reference | | | | | | | | | | | | | | | | | | | | | | |
| 0 | PI control | — | | | | | | | | | | | | | | | | | | | | | | |
| 1 | I-P control | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| Pn10C (210Ch) | Mode switch (torque command) | 0 ~ 800 | 1% | 200 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn10D (210Dh) | Mode switch (velocity command) | 0 ~ 10000 | rpm | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn10E (210Eh) | Mode switch (acceleration) | 0 ~ 30000 | rpm/s | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn10F (210Fh) | Mode switch (position bias) | 0 ~ 10000 | 1 Unit | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn119 (2119h) | Torque feedforward | 0~1000 | 1% | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn11A (211Ah) | Feedforward filter time constant | 0 ~ 6400 | 0.01ms | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn11F (211Fh) | Position integral time constant | 0 ~ 50000 | 0.1ms | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn121 (2121h) | Friction compensation gain | 10 ~ 1000 | 1% | 100 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn122 (2122h) | Second friction compensation gain | 10 ~ 1000 | 1% | 100 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |
| Pn123 (2123h) | Friction compensation coefficient | 0 ~ 100 | 1% | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference |
|------------------|-------------------------------------------------|----------------|-------|---------------|----------------|----------------|-----------|
| Pn124 (2124h) | Friction compensation frequency compensation | -10000 ~ 10000 | 0.1Hz | 0 | Immediately | Tuning | — |
| Pn125 (2125h) | Friction compensation gain compensation | 1 ~ 1000 | 1% | 100 | Immediately | Tuning | — |
| Pn127 (2127h) | Velocity Observer Gain | 1 ~ 500 | 1Hz | 40 | Immediately | Tuning | — |
| Pn128 (2128h) | Velocity Observer Position Compensation Gain | 0 ~ 1000 | 1% | 150 | Immediately | Tuning | — |
| Pn131 (2131h) | Gain switching time 1 | 0 ~ 65535 | 1ms | 0 | Immediately | Tuning | — |
| Pn132 (2132h) | Gain switching time 2 | 0 ~ 65535 | 1ms | 0 | Immediately | Tuning | — |
| Pn135 (2135h) | Gain switching waiting time 1 | 0 ~ 65535 | 1ms | 0 | Immediately | Tuning | — |
| Pn136 (2136h) | Gain switching waiting time 2 | 0 ~ 65535 | 1ms | 0 | Immediately | Tuning | — |
| Pn137 (2137h) | Gain switching level 1 | 0 ~ 20000 | - | 0 | Immediately | Tuning | — |
| Pn138 (2138h) | Gain switching level 2 | 0 ~ 20000 | - | 0 | Immediately | Tuning | — |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------|----------------|----------------------------|-----------|--------------------------|---|-------------------------------------------|---|-------------------------------------------------------------|--------------------------------------------|---|------------------------------------------|---|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|---------------------------------------------------------------|---|----------------------------------|---|----------------------------------------------------------------------------|---|-----------------------------------------------------------------------|---|-------------------------------------------------------------------|---|-----------------------------------------------------------------------------------|---|------------------------------------------------------------------|
| | Automatic gain switch 1 | 0000H - 00A2H | — | 0000H | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn139 (2139h) | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <thead> <tr> <th colspan="2">Gain switching selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Use manual gain switching—By external input signal (/G-SEL)</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>Reserved parameter (Do not change.)</td> </tr> <tr> <td>2</td> <td>Automatic gain switching pattern 1 The gain settings 1 switch automatically to 2 when switching condition A is satisfied. The gain settings 2 switch automatically to 1 when switching condition A is not satisfied.</td> </tr> </tbody> </table> | | | | | | Gain switching selection | | Reference | 0 | Use manual gain switching—By external input signal (/G-SEL) | — | 1 | Reserved parameter (Do not change.) | 2 | Automatic gain switching pattern 1 The gain settings 1 switch automatically to 2 when switching condition A is satisfied. The gain settings 2 switch automatically to 1 when switching condition A is not satisfied. | | | | | | | | | | | | | | |
| | Gain switching selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | Use manual gain switching—By external input signal (/G-SEL) | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1 | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Automatic gain switching pattern 1 The gain settings 1 switch automatically to 2 when switching condition A is satisfied. The gain settings 2 switch automatically to 1 when switching condition A is not satisfied. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th colspan="2">Gain Switching Condition A</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Positioning completion signal (/COIN) ON.</td> <td rowspan="10">—</td> </tr> <tr> <td>1</td> <td>Positioning completion signal (/COIN) OFF.</td> </tr> <tr> <td>2</td> <td>Positioning proximity signal (/NEAR) ON.</td> </tr> <tr> <td>3</td> <td>Positioning proximity signal (/NEAR) OFF.</td> </tr> <tr> <td>4</td> <td>Position command filter output=0 and command pulse input OFF.</td> </tr> <tr> <td>5</td> <td>Position command pulse input ON.</td> </tr> <tr> <td>6</td> <td>Use internal torque [%] command as condition (value setting: Pn137, PN138)</td> </tr> <tr> <td>7</td> <td>Use velocity command [rpm] as condition (value setting: Pn137, PN138)</td> </tr> <tr> <td>8</td> <td>Use acceleration [rpm] as condition (value setting: Pn137, PN138)</td> </tr> <tr> <td>9</td> <td>Use position bias pulse [command unit] as condition (value setting: Pn137, PN138)</td> </tr> <tr> <td>A</td> <td>Use position command + actual speed [rpm] (value setting: PN138)</td> </tr> </tbody> </table> | | | | | | Gain Switching Condition A | | Reference | 0 | Positioning completion signal (/COIN) ON. | — | 1 | Positioning completion signal (/COIN) OFF. | 2 | Positioning proximity signal (/NEAR) ON. | 3 | Positioning proximity signal (/NEAR) OFF. | 4 | Position command filter output=0 and command pulse input OFF. | 5 | Position command pulse input ON. | 6 | Use internal torque [%] command as condition (value setting: Pn137, PN138) | 7 | Use velocity command [rpm] as condition (value setting: Pn137, PN138) | 8 | Use acceleration [rpm] as condition (value setting: Pn137, PN138) | 9 | Use position bias pulse [command unit] as condition (value setting: Pn137, PN138) | A | Use position command + actual speed [rpm] (value setting: PN138) |
| Gain Switching Condition A | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Positioning completion signal (/COIN) ON. | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Positioning completion signal (/COIN) OFF. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Positioning proximity signal (/NEAR) ON. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Positioning proximity signal (/NEAR) OFF. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Position command filter output=0 and command pulse input OFF. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Position command pulse input ON. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Use internal torque [%] command as condition (value setting: Pn137, PN138) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Use velocity command [rpm] as condition (value setting: Pn137, PN138) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Use acceleration [rpm] as condition (value setting: Pn137, PN138) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Use position bias pulse [command unit] as condition (value setting: Pn137, PN138) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | Use position command + actual speed [rpm] (value setting: PN138) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn13D (213Dh) | Current gain value | 100 ~ 2000 | 1% | 2000 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | |
|----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------|-------|---------------|----------------|----------------|------------------|------------------|
| Pn140 (2140h) | Model tracking control selection | 0000H - 1121H | — | 0100H | Immediately | Tuning | — | |
| | <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> Bit 3 <input type="checkbox"/> </div> <div style="text-align: center;"> Bit 2 <input type="checkbox"/> </div> <div style="text-align: center;"> Bit 1 <input type="checkbox"/> </div> <div style="text-align: center;"> Bit 0 <input type="checkbox"/> </div> </div> n. | | | | | | | |
| | Model Tracking Control Selection | | | | | | | Reference |
| | 0 | Do not use model tracking control | | | | | | — |
| | 1 | Use model tracking control | | | | | | |
| | Vibration suppression selection | | | | | | | Reference |
| | 0 | No vibration suppression. | | | | | | — |
| | 1 | An additional vibration suppression function for a specific frequency. | | | | | | |
| | 2 | Vibration suppression is added for 2 different frequencies. | | | | | | |
| | Vibration suppression function adjustment selection | | | | | | | Reference |
| 0 | The vibration suppression function is not automatically adjusted by the auxiliary function. | | | | | | — | |
| 1 | The vibration suppression function is automatically adjusted by auxiliary functions. | | | | | | | |
| Velocity Feedforward (VFF)/Torque Feedforward (TFF) Selection | | | | | | | Reference | |
| 0 | Model tracking control and velocity/torque feedforward are not used simultaneously. | | | | | | — | |
| 1 | Both model tracking control and speed/torque feedforward are used. | | | | | | | |
| Pn141 (2141h) | Model Tracking Control Gain | 10 ~ 20000 | 0.1Hz | 500 | Immediately | Tuning | — | |
| Pn142 (2142h) | Model Tracking Control Gain Compensation | 500 ~ 2000 | 0.1% | 1000 | Immediately | Tuning | — | |
| Pn143 (2142h) | Model Tracking Control Offset (forward direction) | 0 ~ 10000 | 0.1% | 1000 | Immediately | Tuning | — | |
| Pn144 (2144h) | Model Tracking Control Offset (Reverse Direction) | 0 ~ 10000 | 0.1% | 1000 | Immediately | Tuning | — | |
| Pn145 (2145h) | Vibration suppression 1 frequency A | 10 ~ 2500 | 0.1Hz | 500 | Immediately | Tuning | — | |
| Pn146 (2146h) | Vibration suppression 1 frequency B | 10 ~ 2500 | 0.1Hz | 700 | Immediately | Tuning | — | |
| Pn147 (2147h) | Model tracking control velocity feedforward compensation | 0 ~ 10000 | 0.1% | 1000 | Immediately | Tuning | — | |
| Pn148 (2148h) | The Second Model Tracking Control Gain | 10 ~ 20000 | 0.1Hz | 500 | Immediately | Tuning | — | |
| Pn149 (2149h) | The Second Model Tracking Control Gain Compensation | 500 ~ 2000 | 0.1% | 1000 | Immediately | Tuning | — | |
| Pn14A (214Ah) | Vibration suppression 2 frequency | 10 ~ 2000 | 0.1Hz | 800 | Immediately | Tuning | — | |
| Pn14B (214Bh) | Vibration suppression 2 compensation | 10 ~ 1000 | 1% | 100 | Immediately | Tuning | — | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | |
|-------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------|----------------|----------------|-------------------------------------------------------|------------------------------------------------|-----------|-----------|--------------------------------------------------------------------------------|--------------------------------------------------|---|--------------------------------------------------------------------------------|-------------------------------------------|---------------------------|
| Pn14F (214Fh) | Control type Selections | 0000H - 0021H | — | 0011H | After restart | Tuning | — | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th colspan="2">Model Tracking Control Type Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Select Model Tracking Control Type 1.</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Select Model Tracking Control Type 2.</td> </tr> </tbody> </table> | | | | | | Model Tracking Control Type Selection | | Reference | 0 | Select Model Tracking Control Type 1. | — | 1 | Select Model Tracking Control Type 2. | |
| | Model Tracking Control Type Selection | | Reference | | | | | | | | | | | | | |
| | 0 | Select Model Tracking Control Type 1. | — | | | | | | | | | | | | | |
| 1 | Select Model Tracking Control Type 2. | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Tuning-less Type Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Select tuning-less type 1</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>Select tuning-less type 2</td> </tr> <tr> <td>2</td> <td>Select tuning-less type 3</td> </tr> </tbody> </table> | | | | | | Tuning-less Type Selection | | Reference | 0 | Select tuning-less type 1 | — | 1 | Select tuning-less type 2 | 2 | Select tuning-less type 3 |
| Tuning-less Type Selection | | Reference | | | | | | | | | | | | | | |
| 0 | Select tuning-less type 1 | — | | | | | | | | | | | | | | |
| 1 | Select tuning-less type 2 | | | | | | | | | | | | | | | |
| 2 | Select tuning-less type 3 | | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Pn160 (2160h) | Vibration suppression control type selection | 0000H - 0011H | — | 0010H | Immediately | Tuning | — | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th colspan="2">Type A vibration suppression control selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Do not use type A vibration suppression control.</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Use type A vibration suppression control.</td> </tr> </tbody> </table> | | | | | | Type A vibration suppression control selection | | Reference | 0 | Do not use type A vibration suppression control. | — | 1 | Use type A vibration suppression control. | |
| | Type A vibration suppression control selection | | Reference | | | | | | | | | | | | | |
| | 0 | Do not use type A vibration suppression control. | — | | | | | | | | | | | | | |
| 1 | Use type A vibration suppression control. | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Type A vibration suppression control tuning selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Type A vibration suppression control is not auto-tuned by auxiliary functions.</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>The type A vibration suppression control is auto-tuned by auxiliary functions.</td> </tr> </tbody> </table> | | | | | | Type A vibration suppression control tuning selection | | Reference | 0 | Type A vibration suppression control is not auto-tuned by auxiliary functions. | — | 1 | The type A vibration suppression control is auto-tuned by auxiliary functions. | | |
| Type A vibration suppression control tuning selection | | Reference | | | | | | | | | | | | | | |
| 0 | Type A vibration suppression control is not auto-tuned by auxiliary functions. | — | | | | | | | | | | | | | | |
| 1 | The type A vibration suppression control is auto-tuned by auxiliary functions. | | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Pn161 (2161h) | Type A vibration suppression frequency | 10 ~ 20000 | 0.1Hz | 1000 | Immediately | Tuning | — | | | | | | | | | |
| Pn162 (2162h) | Type A vibration suppression gain compensation | 1 ~ 1000 | 1% | 100 | Immediately | Tuning | — | | | | | | | | | |
| Pn163 (2163h) | Type A vibration damping gain | 0 ~ 300 | 1% | 0 | Immediately | Tuning | — | | | | | | | | | |
| Pn164 (2164h) | Type A vibration suppression filter time constant 1 compensation | -1000 ~ 1000 | 0.01ms | 0 | Immediately | Tuning | — | | | | | | | | | |
| Pn165 (2165h) | Type A vibration suppression filter time constant 2 compensation | -1000 ~ 1000 | 0.01ms | 0 | Immediately | Tuning | — | | | | | | | | | |
| Pn166 (2166h) | A-type vibration suppression attenuation gain 2 | 0 ~ 1000 | 1% | 0 | Immediately | Tuning | — | | | | | | | | | |
| Pn167 (2167h) | Cut-off frequency of Type A damped high-pass filter | 10 ~ 50000 | 0.1Hz | 20000 | Immediately | Tuning | — | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | |
|------------------|--------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|---------------|----------------|----------------|------------------|------------------|
| Pn170 (2170h) | Tuning-less type selections | 0000H - 2711H | — | 1400H | After restart | Basic setting | — | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | | | | | | | |
| | | Tuning-less Selection | | | | | | Reference |
| | | 0 | Disable tuning-less function | | | | | — |
| | | 1 | Enable tuning-less function | | | | | |
| | Control mode for velocity control | | | | | | Reference | |
| | 0 | Use as velocity control | | | | | — | |
| | 1 | Use as velocity control and the upper device is used as position control. | | | | | | |
| | Tuning-less Value | | | | | | Reference | |
| | 0 ~ 7 | Set tuning-less value | | | | | — | |
| | Tuning-less Load Value | | | | | | Reference | |
| | 0 ~ 2 | Set tuning-less value | | | | | — | |
| Pn207 (2207h) | Position control function switch | 0000H~2000H | — | 0000H | After restart | Basic setting | — | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | | | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | |
| | | Reserved parameter (Do not change.) | | | | | | |
| | COIN (Positioning Completion Output)) signal output timing | | | | | | Reference | |
| | 0 | Output when the absolute value of position bias is less than the width of positioning completion (Pn522) | | | | | — | |
| | 1 | Output when the absolute value of position bias is less than the width of position completion (Pn522) and the filtered position command is 0 | | | | | | |
| | 2 | Output when the absolute value of position bias is less than the positioning completion width (Pn522) and the position command input is 0 | | | | | | |
| Pn216 (2216h) | Position command acceleration/deceleration time parameter | 0 ~ 65535 | 0.1ms | 0 | Immediately | Basic setting | — | |
| Pn217 (2217h) | Average time of position command movement | 0 ~ 10000 | 0.1ms | 0 | Immediately | Basic setting | — | |
| Pn219 (2219h) | Position command 2nd order low-pass filter cutoff frequency | 0 ~ 10000 | 0.1Hz | 0 | Immediately | Basic setting | — | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | |
|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|--------------------------|--------------------------|----------------|----------------|-----------|--------------------------------------------|-------|-----------|-------|----------------------------------------------------------------------------|--------------------------|--------------------------|-------------------------------------------------------------------|
| Pn230 (2230h) | Position control extended function switch | 0000H - 0001H | — | 0000H | After restart | Basic setting | — | | | | | | | | |
| | n. <table border="1"> <tr> <td>Bit 3</td> <td>Bit 2</td> <td>Bit 1</td> <td>Bit 0</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> </table> | | | | | | | Bit 3 | Bit 2 | Bit 1 | Bit 0 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| | Bit 3 | Bit 2 | Bit 1 | Bit 0 | | | | | | | | | | | |
| | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Mechanical backlash compensation direction</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Non-mechanical backlash compensation by commands in the positive direction</td> <td>—</td> </tr> <tr> <td>1</td> <td>Non-mechanical backlash compensation by reverse direction command</td> <td>—</td> </tr> </tbody> </table> | | | | | | | Mechanical backlash compensation direction | | Reference | 0 | Non-mechanical backlash compensation by commands in the positive direction | — | 1 | Non-mechanical backlash compensation by reverse direction command |
| Mechanical backlash compensation direction | | Reference | | | | | | | | | | | | | |
| 0 | Non-mechanical backlash compensation by commands in the positive direction | — | | | | | | | | | | | | | |
| 1 | Non-mechanical backlash compensation by reverse direction command | — | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Pn231 (2231h) | Backlash compensation value | -500000-500000 | 0.1 Unit | 0 | Immediately | Basic setting | — | | | | | | | | |
| Pn233 (2233h) | Time parameter of backlash compensation | 0 ~ 65535 | 0.01ms | 0 | Immediately | Basic setting | — | | | | | | | | |
| Pn260 (2260h) | Low-frequency vibration suppression mode selection | 0~1 | — | 0 | Immediately | Basic setting | — | | | | | | | | |
| | n. <table border="1"> <tr> <td>Bit 3</td> <td>Bit 2</td> <td>Bit 1</td> <td>Bit 0</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> </table> Bit0=0: Set parameters manually Bit0=1: Set parameters automatically | | | | | | | Bit 3 | Bit 2 | Bit 1 | Bit 0 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| Bit 3 | Bit 2 | Bit 1 | Bit 0 | | | | | | | | | | | | |
| <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Pn261 (2261h) | Low-frequency resonance frequency A | 0 ~ 5000 | 0.1Hz | 0 | Immediately | Basic setting | — | | | | | | | | |
| Pn262 (2262h) | Suppression width of low-frequency resonance frequency A | 0 ~ 10 | — | 2 | Immediately | Basic setting | — | | | | | | | | |
| Pn263 (2263h) | Suppression depth of low-frequency resonance frequency A | 0~1000 | — | 5 | Immediately | Basic setting | — | | | | | | | | |
| Pn290 (2290h) | Enable cutting vibration | 0000-0001 | — | 0000H | Immediately | Basic setting | — | | | | | | | | |
| Pn291 (2291h) | Maximum limit of cutting vibration | 0 ~ 300 | 0.1%rev | 100 | Immediately | Basic setting | — | | | | | | | | |
| Pn292 (2292h) | Cutting vibration amplitude | 0 ~ 32767 | Unit | 0 | Immediately | Basic setting | — | | | | | | | | |
| Pn293 (2293h) | Cutting vibration frequency | 10 ~ 500 | 0.1Hz | 100 | Immediately | Basic setting | — | | | | | | | | |
| Pn304 (2304h) | JOG Velocity | 0 ~ 1000000 | 0.01rpm | 50000 | Immediately | Basic setting | — | | | | | | | | |
| Pn305 (2305h) | Soft start acceleration time | 0~65535 | 1ms | 0 | Immediately | Basic setting | — | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|-----------|---------------|----------------|----------------|-----------|-------------------------------|--|-----------|---|--------------------------|---|---|-------------------------------------------|---|-------------------------------------------|
| Pn306 (2306h) | Soft start deceleration time | 0~65535 | 1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn307 (2307h) | Velocity command filter time parameter | 0 ~ 65535 | 0.01ms | 0 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn308 (2308h) | Velocity Feedback Filter Time Parameters | 0 ~ 65535 | 0.01ms | 0 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn30A (230Ah) | Shutdown deceleration time | 0 ~ 10000 | ms | 100 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn30C (230Ch) | Moving average time of velocity feedforward | 0 ~ 5100 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn310 (2310h) | Vibration Detection Selection | 0000H - 0002H | — | 0000H | Immediately | Basic setting | — | | | | | | | | | | |
| | <div style="display: flex; justify-content: space-around; font-size: small;"> Bit 3 Bit 2 Bit 1 Bit 0 </div> <div style="margin-top: 5px;"> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> | | | | | | | | | | | | | | | | |
| | <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Vibration Detection Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Do not detect vibration.</td> <td rowspan="3" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Warns when vibration is detected (A.911).</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Alarm when vibration is detected (A.520).</td> </tr> </tbody> </table> | | | | | | | Vibration Detection Selection | | Reference | 0 | Do not detect vibration. | — | 1 | Warns when vibration is detected (A.911). | 2 | Alarm when vibration is detected (A.520). |
| | Vibration Detection Selection | | Reference | | | | | | | | | | | | | | |
| 0 | Do not detect vibration. | — | | | | | | | | | | | | | | | |
| 1 | Warns when vibration is detected (A.911). | | | | | | | | | | | | | | | | |
| 2 | Alarm when vibration is detected (A.520). | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | |
| Pn311 (2311h) | Vibration detection sensitivity | 50 ~ 500 | 1% | 100 | Immediately | Tuning | — | | | | | | | | | | |
| Pn312 (2312h) | Vibration detection value | 0 ~ 5000 | rpm | 50 | Immediately | Tuning | — | | | | | | | | | | |
| Pn316 (2316h) | Motor Maximum Velocity Limit | 0 ~ 65535 | rpm | 10000 | After restart | Basic setting | — | | | | | | | | | | |
| Pn324 (2324h) | Starting value of moment of inertia calculation | 0 ~ 20000 | 1% | 300 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn325 (2325h) | Vibration Detection Level in Moment of Inertia Identification | 0 ~ 5000 | rpm | 250 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn401 (2401h) | The first Segment 1st Torque Command Filter Time Constant | 0 ~ 65535 | 0.01ms | 100 | Immediately | Tuning | — | | | | | | | | | | |
| Pn402 (2402h) | Forward torque limit | 0 ~ 800 | 1% | 800 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn403 (2403h) | Reverse torque limit | 0 ~ 800 | 1% | 800 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn404 (2404h) | Forward rotating external torque limit | 0 ~ 800 | 1% | 100 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn405 (2405h) | Reverse rotating external torque limit | 0 ~ 800 | 1% | 100 | Immediately | Basic setting | — | | | | | | | | | | |
| Pn406 (2406h) | Emergency stop torque | 0 ~ 800 | 1% | 800 | Immediately | Basic setting | — | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|-----------|---------------|----------------|----------------|-----------|--------------------------|--|-----------|---|-----------------------------------------|---|---|----------------------------------------|--------------------------|--|-----------|---|----------------------------------------------------------------------------------------|---|---|--------------------------------------------------------------------------------------------------------|--------------------------|--|-----------|---|-------------------------------------------|---|---|------------------------------------------|------------------------------------------|--|-----------|---|--------------------------------|---|---|-------------------------------|
| Pn407 (2407h) | Velocity limit at torque control | 0 ~ 10000 | rpm | 10000 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn408 (2408h) | Torque type function selection | 0000H~1111H | — | 0000H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Bit 3 Bit 2 Bit 1 Bit 0 </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Notch filter selection 1</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="width: 30px;">0</td> <td>Disable the first segment notch filter.</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td>1</td> <td>Enable the first segment notch filter.</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Velocity limit selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="width: 30px;">0</td> <td>Set the smaller of the maximum motor velocity or Pn407 setpoint as the velocity limit.</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td>1</td> <td>Set the smaller of the over velocity alarm detection velocity or Pn407 setpoint as the velocity limit.</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Notch filter selection 2</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="width: 30px;">0</td> <td>Disable the second segment notch filter..</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td>1</td> <td>Enable the second segment notch filter..</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Friction compensation function selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="width: 30px;">0</td> <td>Disable friction compensation.</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td>1</td> <td>Enable friction compensation.</td> </tr> </tbody> </table> </div> </div> | | | | | | | Notch filter selection 1 | | Reference | 0 | Disable the first segment notch filter. | — | 1 | Enable the first segment notch filter. | Velocity limit selection | | Reference | 0 | Set the smaller of the maximum motor velocity or Pn407 setpoint as the velocity limit. | — | 1 | Set the smaller of the over velocity alarm detection velocity or Pn407 setpoint as the velocity limit. | Notch filter selection 2 | | Reference | 0 | Disable the second segment notch filter.. | — | 1 | Enable the second segment notch filter.. | Friction compensation function selection | | Reference | 0 | Disable friction compensation. | — | 1 | Enable friction compensation. |
| | Notch filter selection 1 | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | Disable the first segment notch filter. | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1 | Enable the first segment notch filter. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Velocity limit selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Set the smaller of the maximum motor velocity or Pn407 setpoint as the velocity limit. | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Set the smaller of the over velocity alarm detection velocity or Pn407 setpoint as the velocity limit. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Notch filter selection 2 | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Disable the second segment notch filter.. | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Enable the second segment notch filter.. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Friction compensation function selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Disable friction compensation. | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Enable friction compensation. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn409 (2409h) | The first segment notch filter frequency | 50 ~ 5000 | 1Hz | 5000 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn40A (240Ah) | Q value of the first segment notch filter | 50 ~ 1000 | 0.01 | 70 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn40B (240Bh) | Notch depth of the first segment notch filter | 0 ~ 1000 | 0.001 | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn40C (240Ch) | The second segment notch filter frequency | 50 ~ 5000 | 1Hz | 5000 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn40D (240Dh) | Q value of the second segment notch filter | 50 ~ 1000 | 0.01 | 70 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn40E (240Eh) | Notch depth of the second segment notch filter | 0 ~ 1000 | 0.001 | 0 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn40F (240Fh) | The second Segment 2 nd Torque Command Filter Frequency | 100 ~ 5000 | 1Hz | 5000 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn410 (2410h) | Q value of the second segment torque command filter | 50 ~ 100 | 0.01 | 50 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn412 (2412h) | The first Segment 2 nd Torque Command Filter Time Constant | 0 ~ 65535 | 0.01ms | 100 | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | |
|------------------|--------------------------------------------------------------------------------------------------------|----------------------------------------|------------------------------------------|---------------|----------------|----------------|-----------|------------------|
| Pn416 (2416h) | Torque type function selection 2 | 0000H - 0111H | — | 0000H | Immediately | — | — | |
| | n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | | | | | | | |
| | | Notch filter selection 3 | | | | | | Reference |
| | | 0 | Disable the third segment notch filter. | | | | | — |
| | | 1 | Enable the third segment notch filter. | | | | | |
| | | Notch filter selection 4 | | | | | | Reference |
| | | 0 | Disable the fourth segment notch filter. | | | | | — |
| | | 1 | Enable the fourth segment notch filter. | | | | | |
| | | Notch filter selection 5 | | | | | | Reference |
| | | 0 | Disable the fifth segment notch filter. | | | | | — |
| | 1 | Enable the fifth segment notch filter. | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | |
| Pn417 (2417h) | The third segment notch filter frequency | 50 ~ 5000 | Hz | 5000 | Immediately | Tuning | — | |
| Pn418 (2418h) | Q value of the third segment notch filter | 50 ~ 1000 | 0.01 | 70 | Immediately | Tuning | — | |
| Pn419 (2419h) | The third segment notch filter depth | 0 ~ 1000 | 0.001 | 0 | Immediately | Tuning | — | |
| Pn41A (241Ah) | The fourth segment notch filter frequency | 50 ~ 5000 | Hz | 5000 | Immediately | Tuning | — | |
| Pn41B (241Bh) | Q value of the fourth segment notch filter | 50 ~ 1000 | 0.01 | 70 | Immediately | Tuning | — | |
| Pn41C (241Ch) | The fourth segment notch filter depth | 0 ~ 1000 | 0.001 | 0 | Immediately | Tuning | — | |
| Pn41D (241Dh) | The fifth segment notch filter frequency | 50 ~ 5000 | Hz | 5000 | Immediately | Tuning | — | |
| Pn41E (241Eh) | Q value of the fifth segment notch filter | 50 ~ 1000 | 0.01 | 70 | Immediately | Tuning | — | |
| Pn41F (241Fh) | The fifth segment notch filter depth | 0 ~ 1000 | 0.001 | 0 | Immediately | Tuning | — | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | |
|------------------|--------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|-----------------------------------------------|-----------------------------------------------|----------------|----------------|------------------|------------------|
| Pn423 (2423h) | Velocity ripple compensation switch (rotary) | 0000H - 1111H | — | 0000H | Immediately | — | — | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | | | | | | | |
| | | | Velocity ripple compensation Selection | | | | | Reference |
| | | | 0 | Disable velocity ripple compensation function | | | | — |
| | | | 1 | Enable velocity ripple compensation function | | | | |
| | | Alarm detection for inconsistent velocity pulse compensation information Selection | | | | | Reference | |
| | | 0 | Detected A.942 | | | | — | |
| | | 1 | Do not detect A.942 | | | | | |
| | | Effective Conditions for Velocity Pulse Compensation Selection | | | | | Reference | |
| | | 0 | Velocity command | | | | — | |
| | | 1 | motor velocity | | | | | |
| | | compensation angle selection | | | | | Reference | |
| | | 0 | Mechanical angle | | | | — | |
| | | 1 | Electrical angle | | | | | |
| Pn424 (2424h) | Torque limit when main circuit voltage drops | 0 ~ 100 | 1% | 50 | Immediately | Basic setting | — | |
| Pn425 (2425h) | Torque limit release time when main circuit voltage drops | 0 ~ 1000 | 1ms | 100 | Immediately | Basic setting | — | |
| Pn426 (2426h) | Shifting average time of torque feedforward | 0 ~ 5100 | 0.1ms | 0 | Immediately | Basic setting | — | |
| Pn427 (2427h) | Velocity ripple compensation effective velocity (rotation) | 0 ~ 10000 | rpm | 0 | Immediately | Basic setting | — | |
| Pn453 (2453h) | Scan start frequency | 1 ~ 5000 | Hz | 400 | Immediately | Basic setting | — | |
| Pn454 (2454h) | Scan End Frequency | 50 ~ 5000 | Hz | 4000 | Immediately | Basic setting | — | |
| Pn455 (2455h) | Detection of lower limit of resonance frequency | 50 ~ 5000 | Hz | 500 | Immediately | Basic setting | — | |
| Pn456 (2456h) | Sweep torque command amplitude | 1 ~ 800 | 1% | 15 | Immediately | Tuning | — | |
| Pn457 (2457h) | FFT related function switch | 0000H - 2742H | — | 0210H | After restart | Tuning | — | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|--------------------------|--------------------------|----------------|----------------|---------------------------------|--------------------------------------|-----------|-----------|-------------------------------------------------------------------------------|------------------------------------------------------------------------------|--------------------------|-----------------------------------------------------------------------|----------------------------------------------------------------------|---|---------------------------------------------------------------------------------|---|-----------------------------------------|---|-----------------------------------------------------------------------------------------------------|---|---------------------------------------------------------|---|---------------------------------------------------------------------------------------|---|---------------------------------------------------------------------------------------------------------------------|
| Pn460 (2460h) | Notch filter adjustment switch | 0000H - 0101H | — | 0101H | Immediately | Tuning | — | | | | | | | | | | | | | | | | | | | | |
| | n. <table border="1"> <tr> <td>Bit 3</td> <td>Bit 2</td> <td>Bit 1</td> <td>Bit 0</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> </table> | | | | | | | Bit 3 | Bit 2 | Bit 1 | Bit 0 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | | |
| | Bit 3 | Bit 2 | Bit 1 | Bit 0 | | | | | | | | | | | | | | | | | | | | | | | |
| | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Notch filter tuning selection 1</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>The first segment notch filter is not auto-tuning by the auxiliary function.</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>The first segment notch filter auto-tuned by the auxiliary function.</td> </tr> </tbody> </table> | | | | | | | Notch filter tuning selection 1 | | Reference | 0 | The first segment notch filter is not auto-tuning by the auxiliary function. | — | 1 | The first segment notch filter auto-tuned by the auxiliary function. | | | | | | | | | | | | |
| | Notch filter tuning selection 1 | | Reference | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | The first segment notch filter is not auto-tuning by the auxiliary function. | — | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | The first segment notch filter auto-tuned by the auxiliary function. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th colspan="2">Notch filter tuning selection 2</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>The second segment notch filter is not auto-tuning by the auxiliary function.</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>The second segment notch filter auto-tuned by the auxiliary function.</td> </tr> </tbody> </table> | | | | | | | Notch filter tuning selection 2 | | Reference | 0 | The second segment notch filter is not auto-tuning by the auxiliary function. | — | 1 | The second segment notch filter auto-tuned by the auxiliary function. | | | | | | | | | | | | | |
| Notch filter tuning selection 2 | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | The second segment notch filter is not auto-tuning by the auxiliary function. | — | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | The second segment notch filter auto-tuned by the auxiliary function. | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn466 (2466h) | Adaptive notch filter mode selection | 0000H - 0007H | — | 0004H | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | |
| | n. <table border="1"> <tr> <td>Bit 3</td> <td>Bit 2</td> <td>Bit 1</td> <td>Bit 0</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> </table> | | | | | | | Bit 3 | Bit 2 | Bit 1 | Bit 0 | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | | |
| | Bit 3 | Bit 2 | Bit 1 | Bit 0 | | | | | | | | | | | | | | | | | | | | | | | |
| | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | | | | | | | | | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Self-adaption limiter mode selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>DO not update the adaptive filter.</td> <td rowspan="8">—</td> </tr> <tr> <td>1</td> <td>One group of adaptive filters is active (The 3rd group notch filter)</td> </tr> <tr> <td>2</td> <td>Two groups of adaptive filters are active (The 3rd and 4th group notch filters)</td> </tr> <tr> <td>3</td> <td>Only test resonance point (Pn417/Pn41A)</td> </tr> <tr> <td>4</td> <td>Clear the adaptive notch and restore the values of the 3rd and 4th group notch to the factory state</td> </tr> <tr> <td>5</td> <td>Type A vibration suppression is effective (Pn672/Pn675)</td> </tr> <tr> <td>6</td> <td>Type A vibration suppression and the 3rd and 4th group adaptive filters are effective</td> </tr> <tr> <td>7</td> <td>Type A vibration suppression and the 3rd and 4th group adaptive filters are invalid and return to the factory state</td> </tr> </tbody> </table> | | | | | | | Self-adaption limiter mode selection | | Reference | 0 | DO not update the adaptive filter. | — | 1 | One group of adaptive filters is active (The 3rd group notch filter) | 2 | Two groups of adaptive filters are active (The 3rd and 4th group notch filters) | 3 | Only test resonance point (Pn417/Pn41A) | 4 | Clear the adaptive notch and restore the values of the 3rd and 4th group notch to the factory state | 5 | Type A vibration suppression is effective (Pn672/Pn675) | 6 | Type A vibration suppression and the 3rd and 4th group adaptive filters are effective | 7 | Type A vibration suppression and the 3rd and 4th group adaptive filters are invalid and return to the factory state |
| | Self-adaption limiter mode selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | DO not update the adaptive filter. | — | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | One group of adaptive filters is active (The 3rd group notch filter) | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Two groups of adaptive filters are active (The 3rd and 4th group notch filters) | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Only test resonance point (Pn417/Pn41A) | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Clear the adaptive notch and restore the values of the 3rd and 4th group notch to the factory state | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Type A vibration suppression is effective (Pn672/Pn675) | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Type A vibration suppression and the 3rd and 4th group adaptive filters are effective | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Type A vibration suppression and the 3rd and 4th group adaptive filters are invalid and return to the factory state | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn471 (2471h) | Forward Coulomb friction compensation torque | 0 ~ 1000 | 0.1% | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | |
| Pn472 (2472h) | Negative Coulomb friction compensation torque | 0 ~ 1000 | 0.1% | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | |
| Pn473 (2473h) | Viscous friction compensation torque | 0 ~ 3000 | 0.1% | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | |
| Pn474 (2474h) | Internal set speed hysteresis | 0 ~ 100 | 0.1rpm | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | |
| Pn476 (2476h) | Gravity compensation | -1000 ~ 1000 | 0.1% | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | |
|----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------|----------------|----------------|----------------------------------------------------|------------------------------------------------------------|-----------|-----------|------------------------------------------------------|---------|---|--------------------------------------------------|--------|--------------------------------------------------|
| Pn477 (2477h) | Friction recognition selection | 0000H ~ 1121H | — | 0000H | Immediately | Basic setting | — | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th colspan="2">Automatic friction force identification function selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disable</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Enable</td> </tr> </tbody> </table> | | | | | | Automatic friction force identification function selection | | Reference | 0 | Disable | — | 1 | Enable | |
| | Automatic friction force identification function selection | | Reference | | | | | | | | | | | | | |
| | 0 | Disable | — | | | | | | | | | | | | | |
| 1 | Enable | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Friction recognition mode selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Forward and backward Coulomb friction identification</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>Quadrant compensation automatic identification 1</td> </tr> <tr> <td>2</td> <td>Quadrant compensation automatic identification 2</td> </tr> </tbody> </table> | | | | | | Friction recognition mode selection | | Reference | 0 | Forward and backward Coulomb friction identification | — | 1 | Quadrant compensation automatic identification 1 | 2 | Quadrant compensation automatic identification 2 |
| Friction recognition mode selection | | Reference | | | | | | | | | | | | | | |
| 0 | Forward and backward Coulomb friction identification | — | | | | | | | | | | | | | | |
| 1 | Quadrant compensation automatic identification 1 | | | | | | | | | | | | | | | |
| 2 | Quadrant compensation automatic identification 2 | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Friction identification tuning selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Auto-tuning according to the identified quantity</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Set value according to Pn47B/Pn47C</td> </tr> </tbody> </table> | | | | | | Friction identification tuning selection | | Reference | 0 | Auto-tuning according to the identified quantity | — | 1 | Set value according to Pn47B/Pn47C | | |
| Friction identification tuning selection | | Reference | | | | | | | | | | | | | | |
| 0 | Auto-tuning according to the identified quantity | — | | | | | | | | | | | | | | |
| 1 | Set value according to Pn47B/Pn47C | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Torque selection for friction force identification</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Moment selection mode 1 (optimum value)</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Moment selection mode 2 (maximum value)</td> </tr> </tbody> </table> | | | | | | Torque selection for friction force identification | | Reference | 0 | Moment selection mode 1 (optimum value) | — | 1 | Moment selection mode 2 (maximum value) | | |
| Torque selection for friction force identification | | Reference | | | | | | | | | | | | | | |
| 0 | Moment selection mode 1 (optimum value) | — | | | | | | | | | | | | | | |
| 1 | Moment selection mode 2 (maximum value) | | | | | | | | | | | | | | | |
| Pn478 (2478h) | Forward Coulomb friction compensation filter time constant | 0 ~ 12800 | 0.01ms | 0 | Immediately | Basic setting | — | | | | | | | | | |
| Pn479 (2479h) | Inverse Coulomb friction compensation filter time constant | 0 ~ 12800 | 0.01ms | 0 | Immediately | Basic setting | — | | | | | | | | | |
| Pn47A (247Ah) | Detection velocity of friction force identification | 10 ~ 100 | rpm | 40 | Immediately | Basic setting | — | | | | | | | | | |
| Pn47B (247Bh) | Auto-tuning of friction identification torque | 1 ~ 50 | 0.1% | 5 | Immediately | Basic setting | — | | | | | | | | | |
| Pn47C (247Ch) | Auto-tuning value of friction identification filtering time | 10~300 | 1% | 100 | Immediately | Basic setting | — | | | | | | | | | |
| Pn481 (2481h) | Gain of magnetic pole detection speed loop | 10-20000 | 0.1Hz | 40 | Immediately | Tuning | — | | | | | | | | | |
| Pn482 (2482h) | Integral time of magnetic pole detection velocity loop | 15-51200 | 0.01ms | 30000 | Immediately | Tuning | — | | | | | | | | | |
| Pn486 (2486h) | Pole detection command acceleration/deceleration time | 0-100 | ms | 25 | Immediately | Tuning | — | | | | | | | | | |
| Pn487 (2487h) | Constant velocity time of magnetic pole detection command | 0-300 | ms | 0 | Immediately | Tuning | — | | | | | | | | | |
| Pn488 (2488h) | Waiting time of magnetic pole detection command | 50-500 | ms | 100 | Immediately | Tuning | — | | | | | | | | | |
| Pn490 (2490h) | Load value of magnetic pole detection | 0-20000 | % | 0 | Immediately | Tuning | — | | | | | | | | | |
| Pn493 (2493h) | Pole detection command velocity | 0-1000 | rpm | 50 | Immediately | Tuning | — | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|----------|---------------|----------------|----------------|-----------|---|----------|---|-------------------|--|--|--|--|--|
| Pn494 (2494h) | Moving range of magnetic pole detection | 1-65535 | 0.001rev | 250 | Immediately | Tuning | — | | | | | | | | | |
| Pn495 (2495h) | Pole detection confirmation torque command | 0-200 | % | 100 | Immediately | Tuning | — | | | | | | | | | |
| Pn498 (2498h) | Allowable range of magnetic pole detection error | 0-30 | deg | 10 | Immediately | Tuning | — | | | | | | | | | |
| Pn4A0 (24A0h) | Pole detection mode selection | 0-5 | — | 0 | Immediately | Tuning | — | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Bit 3 Bit 2 Bit 1 Bit 0 </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Polarity detection mode selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Standard mode</td> <td rowspan="3" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Jog mode</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Pre-location mode</td> </tr> </tbody> </table> </div> </div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: 100px;"> Reserved parameter (Do not change.) </div> | Polarity detection mode selection | | Reference | 0 | Standard mode | — | 1 | Jog mode | 2 | Pre-location mode | | | | | |
| Polarity detection mode selection | | Reference | | | | | | | | | | | | | | |
| 0 | Standard mode | — | | | | | | | | | | | | | | |
| 1 | Jog mode | | | | | | | | | | | | | | | |
| 2 | Pre-location mode | | | | | | | | | | | | | | | |
| Pn502 (2502h) | Rotational detected value | 1 ~ 10000 | rpm | 20 | Immediately | Basic setting | — | | | | | | | | | |
| Pn503 (2503h) | Detection width of signal at the same velocity | 0 ~ 100 | rpm | 10 | Immediately | Basic setting | — | | | | | | | | | |
| Pn506 (2506h) | Brake command - servo OFF delay time | 0 ~ 100 | 10ms | 20 | Immediately | Basic setting | — | | | | | | | | | |
| Pn507 (2507h) | Output velocity value of brake command | 0 ~ 10000 | rpm | 100 | Immediately | Basic setting | — | | | | | | | | | |
| Pn508 (2508h) | Servo OFF - Brake command waiting time | 1 ~ 100 | 10ms | 50 | Immediately | Basic setting | — | | | | | | | | | |
| Pn509 (2509h) | Instantaneous outage holding time | 20 ~ 50000 | 1ms | 20 | Immediately | Basic setting | — | | | | | | | | | |
| Pn51E (251Eh) | Position bias too large warning value | 10 ~ 100 | 1% | 100 | Immediately | Basic setting | — | | | | | | | | | |
| Pn520 (2520h) | Position bias too large alarm value | 1 ~ 1073741823 | 1 Unit | 52428800 | Immediately | Basic setting | — | | | | | | | | | |
| Pn522 (2522h) | Positioning finished width | 0 ~ 1073741824 | 1 Unit | 5872 | Immediately | Basic setting | — | | | | | | | | | |
| Pn524 (2524h) | NEAR signal range | 1 ~ 1073741824 | 1 Unit | 1073741824 | Immediately | Basic setting | — | | | | | | | | | |
| Pn526 (2526h) | Position bias too large alarm value when servo ON | 1 ~ 1073741823 | 1 Unit | 524288000 | Immediately | Basic setting | — | | | | | | | | | |
| Pn528 (2528h) | Excessive position bias warning value when servo is ON | 10 ~ 100 | 1% | 100 | Immediately | Basic setting | — | | | | | | | | | |
| Pn529 (2529h) | Velocity limit when servo ON | 0 ~ 10000 | rpm | 10000 | Immediately | Basic setting | — | | | | | | | | | |
| Pn52B (252Bh) | Overload warning value | 1 ~ 100 | 1% | 20 | Immediately | Basic setting | — | | | | | | | | | |
| Pn52C (252Ch) | Motor overload detection base current reduced rated value | 10 ~ 100 | 1% | 100 | After restart | Basic setting | — | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | |
|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|--------------|---------------|----------------|----------------|-----------|--------------------------------------|--|-----------|---|---------------------------------------------------------------------------|---|---|---------------------------------------------------------------------------|---|---------------------------------------------------------------------------|---|---------------------------------------------------------------------------|---|---------------------------------------------------------------------------|---|---------------------------------------------------------------------------|
| Pn52D (252Dh) | Default power of single-phase power supply | 10 ~ 100 | 1% | 100 | After restart | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn52F (252Fh) | Monitoring display when power is on | 0000H - 0FFFH | — | 0FFFH | After restart | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn530 (2530h) | Program JOG operation type selection | 0000H - 0005H | - | 0000H | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 Bit 2 Bit 1 Bit 0 n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Program JOG operating mode selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Waiting time Pn535 → forward movement Pn531) × number of movements Pn536.</td> <td rowspan="6" style="text-align: center; vertical-align: middle;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536.</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Waiting time Pn535 → forward movement Pn531) × number of movements Pn536.</td> </tr> <tr> <td style="text-align: center;">3</td> <td>Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536.</td> </tr> <tr> <td style="text-align: center;">4</td> <td>Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536.</td> </tr> <tr> <td style="text-align: center;">5</td> <td>Waiting time Pn535 → forward movement Pn531) × number of movements Pn536.</td> </tr> </tbody> </table> </div> </div> | | | | | | | Program JOG operating mode selection | | Reference | 0 | Waiting time Pn535 → forward movement Pn531) × number of movements Pn536. | — | 1 | Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536. | 2 | Waiting time Pn535 → forward movement Pn531) × number of movements Pn536. | 3 | Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536. | 4 | Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536. | 5 | Waiting time Pn535 → forward movement Pn531) × number of movements Pn536. |
| | Program JOG operating mode selection | | Reference | | | | | | | | | | | | | | | | | | | | |
| | 0 | Waiting time Pn535 → forward movement Pn531) × number of movements Pn536. | — | | | | | | | | | | | | | | | | | | | | |
| | 1 | Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536. | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Waiting time Pn535 → forward movement Pn531) × number of movements Pn536. | | | | | | | | | | | | | | | | | | | | | |
| 3 | Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536. | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Waiting time Pn535 → reverse movement Pn531) × number of movements Pn536. | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Waiting time Pn535 → forward movement Pn531) × number of movements Pn536. | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | |
| Pn531 (2531h) | Program JOG Travel Distance | 1 ~ 1073741824 | 1 Uint | 32768 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn533 (2533h) | Program JOG Movement Velocity | 1 ~ 10000 | rpm | 500 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn534 (2534h) | Program JOG acceleration and deceleration time | 2 ~ 10000 | 1ms | 100 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn535 (2535h) | Program JOG Wait Time | 0 ~ 10000 | 1ms | 100 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn536 (2536h) | Program JOG Movements Count | 0 ~ 1000 | 1 time | 1 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn560 (2560h) | Residual vibration detection amplitude | 1 ~ 3000 | 0.1% | 400 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn561 (2561h) | Overshoot detection value | 0 ~ 100 | 1% | 100 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn562 (2562h) | Viscous friction compensation | 0 ~ 5000 | 0.1%/1000rpm | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn563 (2563h) | Percentage friction compensation | 0 ~ 1000 | 0.1% | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |
| Pn564 (2564h) | Friction compensation smoothing constant(deceleration) | 0 ~ 1000 | 0.1rpm | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|-----------|---------------|----------------|----------------|------------------|----------------------|-----------|-----------|----------|-----------|---|--------|-------------------------------|----------------|----------------------------------|--------------|-----------------------|----|---------------------------|----|-----------------------------|----|-----------------------------|----|-----------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|
| Pn565 (2565h) | Friction compensation smoothing constant (acceleration) | 0 ~ 1000 | 0.1rpm | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn566 (2566h) | Friction compensation smoothing selection | 0 ~ 100 | - | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn590 (2590h) | DI1 input signal setting | 0000H - 53FFH | — | 1001H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Signal configuration</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>00</td><td>Undefined</td><td rowspan="17" style="text-align: center; vertical-align: middle;">—</td></tr> <tr><td>01</td><td>Forward Override Switch (POT)</td></tr> <tr><td>02</td><td>Reverse over-travel switch (NOT)</td></tr> <tr><td>03</td><td>Home switch DEC (DEC)</td></tr> <tr><td>06</td><td>Emergency Shutdown (FSTP)</td></tr> <tr><td>07</td><td>Forward Torque Limit (P_CL)</td></tr> <tr><td>08</td><td>Reverse torque limit (N_CL)</td></tr> <tr><td>0F</td><td>Alarm reset signal (ALMCLR)</td></tr> <tr><td>11</td><td>User-defined signal 0 (USER0)</td></tr> <tr><td>12</td><td>User-defined signal 1 (USER1)</td></tr> <tr><td>13</td><td>User-defined signal 2 (USER2)</td></tr> <tr><td>14</td><td>User-defined Signal 3 (USER3)</td></tr> <tr><td>15</td><td>User-defined Signal 4 (USER4)</td></tr> <tr><td>16</td><td>User-defined signal 5 (USER5)</td></tr> <tr><td>17</td><td>User-defined signal 6 (USER6)</td></tr> </tbody> </table> </div> </div> | | | | | | | Signal configuration | | Reference | 00 | Undefined | — | 01 | Forward Override Switch (POT) | 02 | Reverse over-travel switch (NOT) | 03 | Home switch DEC (DEC) | 06 | Emergency Shutdown (FSTP) | 07 | Forward Torque Limit (P_CL) | 08 | Reverse torque limit (N_CL) | 0F | Alarm reset signal (ALMCLR) | 11 | User-defined signal 0 (USER0) | 12 | User-defined signal 1 (USER1) | 13 | User-defined signal 2 (USER2) | 14 | User-defined Signal 3 (USER3) | 15 | User-defined Signal 4 (USER4) | 16 | User-defined signal 5 (USER5) | 17 | User-defined signal 6 (USER6) |
| | Signal configuration | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 00 | Undefined | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 01 | Forward Override Switch (POT) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 02 | Reverse over-travel switch (NOT) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 03 | Home switch DEC (DEC) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 06 | Emergency Shutdown (FSTP) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 07 | Forward Torque Limit (P_CL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 08 | Reverse torque limit (N_CL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0F | Alarm reset signal (ALMCLR) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | User-defined signal 0 (USER0) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | User-defined signal 1 (USER1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | User-defined signal 2 (USER2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | User-defined Signal 3 (USER3) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | User-defined Signal 4 (USER4) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 16 | User-defined signal 5 (USER5) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 17 | User-defined signal 6 (USER6) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Polarity control</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>0</td><td>Open</td><td rowspan="4" style="text-align: center; vertical-align: middle;">—</td></tr> <tr><td>1</td><td>Close</td></tr> <tr><td>2</td><td>Forced invalid</td></tr> <tr><td>3</td><td>Forced valid</td></tr> </tbody> </table> </div> </div> | | | | | | | Polarity control | | Reference | 0 | Open | — | 1 | Close | 2 | Forced invalid | 3 | Forced valid | | | | | | | | | | | | | | | | | | | | | | | |
| Polarity control | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Open | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Close | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Forced invalid | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Forced valid | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Axes selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>0</td><td>Not used</td><td rowspan="3" style="text-align: center; vertical-align: middle;">—</td></tr> <tr><td>1</td><td>Axis A</td></tr> <tr><td>5</td><td>All Axes</td></tr> </tbody> </table> </div> </div> | | | | | | | Axes selection | | Reference | 0 | Not used | — | 1 | Axis A | 5 | All Axes | | | | | | | | | | | | | | | | | | | | | | | | | |
| Axes selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Not used | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Axis A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | All Axes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn591 (2592h) | DI2 input signal setting | 0000H - 53FFH | — | 1002H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | |
|----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|------|---------------|----------------|----------------|------------------|------------------|
| Pn592 (2592h) | DI3 input signal setting | 0000H~53FFH | — | 1004H | After restart | Basic setting | — | |
| | <div style="display: flex; align-items: center; margin-bottom: 5px;"> <div style="margin-right: 10px;">n.</div> <div style="display: flex; gap: 5px;"> <div style="border: 1px solid black; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; font-size: 8px;">Bit 3</div> <div style="border: 1px solid black; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; font-size: 8px;">Bit 2</div> <div style="border: 1px solid black; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; font-size: 8px;">Bit 1</div> <div style="border: 1px solid black; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; font-size: 8px;">Bit 0</div> </div> </div> <div style="margin-left: 100px;"> </div> | | | | | | | |
| | Signal configuration | | | | | | | Reference |
| | 00 | Undefined | | | | | | — |
| | 01 | Forward Override Switch (POT) | | | | | | |
| | 02 | Reverse over-travel switch (NOT) | | | | | | |
| | 03 | Home switch DEC (DEC) | | | | | | |
| | 04 | Probe 0 (LATCH_0) | | | | | | |
| | 05 | Probe 1 (LATCH_1) | | | | | | |
| | 06 | Emergency Shutdown (FSTP) | | | | | | |
| | 07 | Forward torque limit (P_CL) | | | | | | |
| | 08 | Reverse torque limit (N_CL) | | | | | | |
| | 0F | Alarm reset signal (ALMCLR) | | | | | | |
| | 11 | User-defined signal 0 (USER0) | | | | | | |
| | 12 | User-defined signal 1 (USER1) | | | | | | |
| | 13 | User-defined signal 2 (USER2) | | | | | | |
| | 14 | User-defined Signal 3 (USER3) | | | | | | |
| 15 | User-defined Signal 4 (USER4) | | | | | | | |
| 16 | User-defined signal 5 (USER5) | | | | | | | |
| 17 | User-defined signal 6 (USER6) | | | | | | | |
| Polarity control | | | | | | | Reference | |
| 0 | Open | | | | | | — | |
| 1 | Close | | | | | | | |
| 2 | Forced invalid | | | | | | | |
| 3 | Forced valid | | | | | | | |
| Axes selection | | | | | | | Reference | |
| 0 | Not used | | | | | | — | |
| 1 | Axis A | | | | | | | |
| 5 | All Axes | | | | | | | |
| Pn593 (2593h) | DI4 input signal setting | 0000H~53FFH | — | 1005H | After restart | Basic setting | — | |
| Same as PN592 DI3 input signal setting signal allocation | | | | | | | | |
| Pn594 (2594h) | DI5 input signal setting | 0000H~53FFH | — | 1003H | After restart | Basic setting | — | |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | | |
| Pn595 (2595h) | DI6 input signal setting | 0000H - 53FFH | — | 2001H | After restart | Basic setting | — | |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | | |
| Pn596 (2596h) | DI7 input signal setting | 0000H - 53FFH | — | 2002H | After restart | Basic setting | — | |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | | |
| Pn597 (2597h) | DI8 input signal setting | 0000H~53FFH | — | 2004H | After restart | Basic setting | — | |
| Same as PN592 DI3 input signal setting signal allocation | | | | | | | | |
| Pn598 (2598h) | DI9 input signal setting | 0000H~53FFH | — | 2005H | After restart | Basic setting | — | |
| Same as PN592 DI3 input signal setting signal allocation | | | | | | | | |
| Pn599 (2599h) | DI10 input signal setting | 0000H - 53FFH | — | 2003H | After restart | Basic setting | — | |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference |
|----------------------------------------------------------|---------------------------|---------------|------|---------------|----------------|----------------|-----------|
| Pn59A (259Ah) | DI11 input signal setting | 0000H - 53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | |
| Pn59B (259Bh) | DI12 input signal setting | 0000H - 53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | |
| Pn59C (259Ch) | DI13 input signal setting | 0000H~53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN592 DI3 input signal setting signal allocation | | | | | | | |
| Pn59D (259Dh) | DI14 input signal setting | 0000H~53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN592 DI3 input signal setting signal allocation | | | | | | | |
| Pn59E (259Eh) | DI15 input signal setting | 0000H - 53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | |
| Pn59F (259Fh) | DI16 input signal setting | 0000H - 53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | |
| Pn5A0 (25A0h) | DI17 input signal setting | 0000H - 53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | |
| Pn5A1 (25A1h) | DI18 input signal setting | 0000H~53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN592 DI3 input signal setting signal allocation | | | | | | | |
| Pn5A2 (25A2h) | DI19 input signal setting | 0000H~53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN592 DI3 input signal setting signal allocation | | | | | | | |
| Pn5A3 (25A3h) | DI20 input signal setting | 0000H - 53FFH | — | 0000H | After restart | Basic setting | — |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | |
| Pn5A4 (25A4h) | DI21 input signal setting | 0000H - 53FFH | — | 5006H | After restart | Basic setting | — |
| Same as PN590 DI1 input signal setting signal allocation | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|-----------|---------------|----------------|----------------|--------------------|----------------------|-----------|-----------|----------|-----------|---|--------|-------------------------------|----------------|----------------------------------|--------------|-------------------------|----|-------------------|----|-------------------|----|---------------------------|----|-----------------------------|----|-----------------------------|----|-----------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|----|-------------------------------|
| Pn5B0 (25AFh) | DO1 output signal setting | 0000H - 53FFH | — | 1004H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> n. </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Signal configuration</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>00</td><td>Undefined</td><td rowspan="17" style="text-align: center; vertical-align: middle;">—</td></tr> <tr><td>01</td><td>Forward Override Switch (POT)</td></tr> <tr><td>02</td><td>Reverse over-travel switch (NOT)</td></tr> <tr><td>03</td><td>Origin switch DEC (DEC)</td></tr> <tr><td>04</td><td>Probe 1 (LATCH_1)</td></tr> <tr><td>05</td><td>Probe 2 (LATCH_1)</td></tr> <tr><td>06</td><td>Emergency Shutdown (FSTP)</td></tr> <tr><td>07</td><td>Forward Torque Limit (P_CL)</td></tr> <tr><td>08</td><td>Reverse torque limit (N_CL)</td></tr> <tr><td>0F</td><td>Alarm reset signal (ALMCLR)</td></tr> <tr><td>11</td><td>User-defined signal 0 (USER0)</td></tr> <tr><td>12</td><td>User-defined signal 1 (USER1)</td></tr> <tr><td>13</td><td>User-defined signal 2 (USER2)</td></tr> <tr><td>14</td><td>User-defined Signal 3 (USER3)</td></tr> <tr><td>15</td><td>User-defined Signal 4 (USER4)</td></tr> <tr><td>16</td><td>User-defined signal 5 (USER5)</td></tr> <tr><td>17</td><td>User-defined signal 6 (USER6)</td></tr> </tbody> </table> </div> </div> | | | | | | | Signal configuration | | Reference | 00 | Undefined | — | 01 | Forward Override Switch (POT) | 02 | Reverse over-travel switch (NOT) | 03 | Origin switch DEC (DEC) | 04 | Probe 1 (LATCH_1) | 05 | Probe 2 (LATCH_1) | 06 | Emergency Shutdown (FSTP) | 07 | Forward Torque Limit (P_CL) | 08 | Reverse torque limit (N_CL) | 0F | Alarm reset signal (ALMCLR) | 11 | User-defined signal 0 (USER0) | 12 | User-defined signal 1 (USER1) | 13 | User-defined signal 2 (USER2) | 14 | User-defined Signal 3 (USER3) | 15 | User-defined Signal 4 (USER4) | 16 | User-defined signal 5 (USER5) | 17 | User-defined signal 6 (USER6) |
| | Signal configuration | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 00 | Undefined | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 01 | Forward Override Switch (POT) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 02 | Reverse over-travel switch (NOT) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 03 | Origin switch DEC (DEC) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 04 | Probe 1 (LATCH_1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 05 | Probe 2 (LATCH_1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 06 | Emergency Shutdown (FSTP) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 07 | Forward Torque Limit (P_CL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 08 | Reverse torque limit (N_CL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0F | Alarm reset signal (ALMCLR) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | User-defined signal 0 (USER0) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | User-defined signal 1 (USER1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | User-defined signal 2 (USER2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | User-defined Signal 3 (USER3) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | User-defined Signal 4 (USER4) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 16 | User-defined signal 5 (USER5) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 17 | User-defined signal 6 (USER6) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Polarity Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>0</td><td>Open</td><td rowspan="4" style="text-align: center; vertical-align: middle;">—</td></tr> <tr><td>1</td><td>Close</td></tr> <tr><td>2</td><td>Forced invalid</td></tr> <tr><td>3</td><td>Forced valid</td></tr> </tbody> </table> </div> | | | | | | | Polarity Selection | | Reference | 0 | Open | — | 1 | Close | 2 | Forced invalid | 3 | Forced valid | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Polarity Selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Open | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Close | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Forced invalid | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Forced valid | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Axis selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>0</td><td>Not used</td><td rowspan="3" style="text-align: center; vertical-align: middle;">—</td></tr> <tr><td>1</td><td>Axis A</td></tr> <tr><td>5</td><td>All Axes</td></tr> </tbody> </table> </div> | | | | | | | Axis selection | | Reference | 0 | Not used | — | 1 | Axis A | 5 | All Axes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Axis selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Not used | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Axis A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | All Axes | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5B1 (25B1h) | DO2 output signal setting | 0000H - 53FFH | — | 1014H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Same as PN5B0 DO1 input signal setting signal allocation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5B2 (25B2h) | DO3 output signal setting | 0000H - 53FFH | — | 2004H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Same as PN5B0 DO1 input signal setting signal allocation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5B3 (25B3h) | DO4 output signal setting | 0000H - 53FFH | — | 2014H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Same as PN5B0 DO1 input signal setting signal allocation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5B4 (25B4h) | DO5 output signal setting | 0000H - 53FFH | — | 3004H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Same as PN5B0 DO1 input signal setting signal allocation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5B5 (25B5h) | DO6 output signal setting | 0000H - 53FFH | — | 3014H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Same as PN5B0 DO1 input signal setting signal allocation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5B6 (25B6h) | DO7 output signal setting | 0000H - 53FFH | — | 4004H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Same as PN5B0 DO1 input signal setting signal allocation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5B7 (25B7h) | DO8 output signal setting | 0000H - 53FFH | — | 4014H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Same as PN5B0 DO1 input signal setting signal allocation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|-------|---------------|----------------|----------------|-----------|---|------|---|------|---|-------|---|-------|---|-------|---|-------|---|-------|---|-------|---|-------|---|-------|---|-------|---|-------|---|-------|---|-------|---|-------|--|--|--|--|--|
| Pn5C0 (25C0h) | Total DI filter parameter (used when common IO filter time is 0) | 0-5000 | 0.1ms | 10 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C1 (25C1h) | DI1 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C2 (25C2h) | DI2 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C3 (25C3h) | DI3 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Bit 3 Bit 2 Bit 1 Bit 0 </div> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th colspan="2">Probe filter time (probe function only, common IO manual input)</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>0</td><td>0ns</td><td rowspan="16" style="text-align: center; vertical-align: middle;">—</td></tr> <tr><td>1</td><td>25ns</td></tr> <tr><td>2</td><td>50ns</td></tr> <tr><td>3</td><td>100ns</td></tr> <tr><td>4</td><td>150ns</td></tr> <tr><td>5</td><td>200ns</td></tr> <tr><td>6</td><td>300ns</td></tr> <tr><td>7</td><td>400ns</td></tr> <tr><td>8</td><td>600ns</td></tr> <tr><td>9</td><td>800ns</td></tr> <tr><td>A</td><td>1.0us</td></tr> <tr><td>B</td><td>1.2us</td></tr> <tr><td>C</td><td>1.6us</td></tr> <tr><td>D</td><td>2.0us</td></tr> <tr><td>E</td><td>2.4us</td></tr> <tr><td>F</td><td>3.2us</td></tr> </tbody> </table> </div> | Probe filter time (probe function only, common IO manual input) | | Reference | 0 | 0ns | — | 1 | 25ns | 2 | 50ns | 3 | 100ns | 4 | 150ns | 5 | 200ns | 6 | 300ns | 7 | 400ns | 8 | 600ns | 9 | 800ns | A | 1.0us | B | 1.2us | C | 1.6us | D | 2.0us | E | 2.4us | F | 3.2us | | | | | |
| Probe filter time (probe function only, common IO manual input) | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0ns | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 25ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | 50ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | 100ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 150ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | 200ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | 300ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | 400ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | 600ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | 800ns | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | 1.0us | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B | 1.2us | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| C | 1.6us | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| D | 2.0us | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| E | 2.4us | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| F | 3.2us | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C4 (25C4h) | DI4 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Same as Pn5C3 DI3 filter parameter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C5 (25C5h) | DI5 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C6 (25C6h) | DI6 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C7 (25C7h) | DI7 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C8 (25C8h) | DI8 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Same as Pn5C3 DI3 filter parameter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5C9 (25C9h) | DI9 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Same as Pn5C3 DI3 filter parameter | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5CA (25CAh) | DI10 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5CB (25CBh) | DI11 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn5CC (25CCh) | DI12 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference |
|------------------------------------|--------------------------------------------------|-----------------------------|----------------------|---------------|----------------|----------------|-----------|
| Pn5CD (25CDh) | DI13 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Same as Pn5C3 DI3 filter parameter | | | | | | | |
| Pn5CE (25CEh) | DI14 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Same as Pn5C3 DI3 filter parameter | | | | | | | |
| Pn5CF (25CFh) | DI15 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Pn5D0 (25CD0) | DI16 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Pn5D1 (25CD1) | DI17 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Pn5D2 (25CD2) | DI18 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Same as Pn5C3 DI3 filter parameter | | | | | | | |
| Pn5D3 (25CD3) | DI19 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Same as Pn5C3 DI3 filter parameter | | | | | | | |
| Pn5D4 (25CD4) | DI20 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Pn5D5 (25CD5) | DI21 filter parameter | 0-5000 | 0.1ms | 0 | Immediately | Basic setting | — |
| Pn5F6 (25CF6) | Lifting value at BK | -25000-25000 | 0.0001rev /0.01mm | 0 | Immediately | Basic setting | — |
| Pn5F7 (25CF7) | Maximum lifting velocity at BK | 0-65535 | 1rpm | 0 | Immediately | Basic setting | — |
| Pn5F8 (25CF8) | Lifting acceleration and deceleration time at BK | 0-65535 | 1ms | 0 | Immediately | Basic setting | — |
| Pn600 (2600h) | Brake resistance capacity *1 | Based on model 0-65536*2 | 10W | 0 | Immediately | Basic setting | — |

Note: * 1 Generally set to "0". When the external brake resistor is used, set the capacity value (W) of the resistor.

2. The upper limit is the maximum output capacity (W) of the applicable servo unit.

| | Motor type selection | 0000H~0100H | — | 0000H | After restart | — | — | | | | | | | | | |
|------------------|-------------------------------------------|-------------------------------------|---|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|---|---|-------------------------------------------|--|-----------|---|-----------------------------|---|---|-------------------|---|
| Pn602 (2602h) | Bit 3 | <input type="checkbox"/> | | Reserved parameter (Do not change.) | | | | | | | | | | | | |
| | Bit 2 | <input type="checkbox"/> | | Reserved parameter (Do not change.) | | | | | | | | | | | | |
| | Bit 1 | <input type="checkbox"/> | | <table border="1"> <thead> <tr> <th colspan="2">Motor type (Source of motor parameters)</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>HCFA Motor (Electronic Tag)</td> <td>—</td> </tr> <tr> <td>1</td> <td>Third party Motor</td> <td>—</td> </tr> </tbody> </table> | | | | Motor type (Source of motor parameters) | | Reference | 0 | HCFA Motor (Electronic Tag) | — | 1 | Third party Motor | — |
| | Motor type (Source of motor parameters) | | | Reference | | | | | | | | | | | | |
| 0 | HCFA Motor (Electronic Tag) | — | | | | | | | | | | | | | | |
| 1 | Third party Motor | — | | | | | | | | | | | | | | |
| Bit 0 | <input type="checkbox"/> | Reserved parameter (Do not change.) | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------|----------------|----------------|-----------|-----------------------------------------------------------------------|--|---------------------------------------------------------------------------------------------------------------------------------------------------------|---|-------------------------------------|---|---|-----------------------------------|-------------------------------------|-------------|-------------------------------------------------|-------------------------------------|-----------|---|-------------------------------------|---|---|----|---|----|---|----|---|----|---|----|---|----|-----------------------------------|--|-----------|-------------------------------------------------------------------|--|---|
| Pn603 (2603h) | Natural frequency of motor selection | 0000H - FFFFH | — | 0001H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <thead> <tr> <th colspan="2">Natural frequency of motor selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Use frequency in PnE29</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Use frequency in motor parameters</td> </tr> <tr> <td colspan="3">Reserved parameter (Do not change.)</td> </tr> <tr> <td colspan="3">Reserved parameter (Do not change.)</td> </tr> <tr> <td colspan="3">Reserved parameter (Do not change.)</td> </tr> </tbody> </table> | | | | | | Natural frequency of motor selection | | Reference | 0 | Use frequency in PnE29 | — | 1 | Use frequency in motor parameters | Reserved parameter (Do not change.) | | | Reserved parameter (Do not change.) | | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | |
| | Natural frequency of motor selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | Use frequency in PnE29 | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Use frequency in motor parameters | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn605 (2605h) | First Encoder Configuration | 0000H - FFFFH | — | 0000H | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <thead> <tr> <th colspan="2">The first encoder type selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>HCFA encoder</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>BISS encoder</td> </tr> <tr> <td>6</td> <td>INV encoder</td> </tr> <tr> <td colspan="2">First encoder communication frequency selection</td> <td>Reference</td> </tr> <tr> <td>0</td> <td>2.5M</td> <td rowspan="7">—</td> </tr> <tr> <td>1</td> <td>1M</td> </tr> <tr> <td>2</td> <td>2M</td> </tr> <tr> <td>3</td> <td>3M</td> </tr> <tr> <td>4</td> <td>4M</td> </tr> <tr> <td>5</td> <td>5M</td> </tr> <tr> <td>6</td> <td>8M</td> </tr> <tr> <td colspan="2">The first encoder shift selection</td> <td>Reference</td> </tr> <tr> <td colspan="2">Represented by 2ⁿ, such as 23bit, directly write 17H</td> <td>—</td> </tr> </tbody> </table> | | | | | | The first encoder type selection | | Reference | 0 | HCFA encoder | — | 1 | BISS encoder | 6 | INV encoder | First encoder communication frequency selection | | Reference | 0 | 2.5M | — | 1 | 1M | 2 | 2M | 3 | 3M | 4 | 4M | 5 | 5M | 6 | 8M | The first encoder shift selection | | Reference | Represented by 2 ⁿ , such as 23bit, directly write 17H | | — |
| | The first encoder type selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | HCFA encoder | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | BISS encoder | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | INV encoder | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| First encoder communication frequency selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 2.5M | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1M | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | 2M | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | 3M | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | 4M | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | 5M | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | 8M | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| The first encoder shift selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Represented by 2 ⁿ , such as 23bit, directly write 17H | | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| The first encoder shift selection | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Represented by 2 ⁿ , such as 23bit, directly write 17H | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn609 (2609h) | Application function selection | 0000H - FFFFH | — | 0000H | After restart | — | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <tr> <td colspan="2">Bit0: Ground overcurrent (A.102) detection switch (0: open, 1: close)</td> </tr> <tr> <td colspan="2">Bit4: Phase loss detection switch (0: off, 1: on) Bit5: gravity compensation switch (0: off, 1: on) Bit7: delay off enable switch (0: off, 1: on)</td> </tr> <tr> <td colspan="2">Reserved parameter (Do not change.)</td> </tr> </table> | | | | | | Bit0: Ground overcurrent (A.102) detection switch (0: open, 1: close) | | Bit4: Phase loss detection switch (0: off, 1: on) Bit5: gravity compensation switch (0: off, 1: on) Bit7: delay off enable switch (0: off, 1: on) | | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Bit0: Ground overcurrent (A.102) detection switch (0: open, 1: close) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Bit4: Phase loss detection switch (0: off, 1: on) Bit5: gravity compensation switch (0: off, 1: on) Bit7: delay off enable switch (0: off, 1: on) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn60D (260Dh) | Alarm delay disable time | 0~500 | ms | 0 | After restart | — | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | |
|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|-------|---------------|----------------|----------------|-----------|---|--------------------|---|--------------------|---|--------------------|--|--|--|--|--|
| Pn60E (260Eh) | User torque overload threshold | 0-65535 | % | 0 | After restart | — | — | | | | | | | | | | | |
| Pn60F (260Fh) | User torque overload time | 0-1000 | 10ms | 0 | After restart | — | — | | | | | | | | | | | |
| Pn610 (2610h) | Position comparison output function | 0-3 | — | 0 | After restart | — | — | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 Bit 2 Bit 1 Bit 0 n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Position comparison output function</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="width: 30px; text-align: center;">0</td> <td>Close</td> <td rowspan="4" style="text-align: center; vertical-align: middle;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Forward comparison</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Reverse comparison</td> </tr> <tr> <td style="text-align: center;">3</td> <td>Two-way comparison</td> </tr> </tbody> </table> </div> </div> <div style="border: 1px solid black; padding: 5px; width: 100%;"> Reserved parameter (Do not change.) </div> | Position comparison output function | | Reference | 0 | Close | — | 1 | Forward comparison | 2 | Reverse comparison | 3 | Two-way comparison | | | | | |
| Position comparison output function | | Reference | | | | | | | | | | | | | | | | |
| 0 | Close | — | | | | | | | | | | | | | | | | |
| 1 | Forward comparison | | | | | | | | | | | | | | | | | |
| 2 | Reverse comparison | | | | | | | | | | | | | | | | | |
| 3 | Two-way comparison | | | | | | | | | | | | | | | | | |
| Pn611 (2611h) | First set position | -1073741824 ~ 1073741823 | Unit | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn613 (2613h) | Second set position | -1073741824 ~ 1073741823 | Unit | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn615 (2615h) | Third set position | -1073741824 ~ 1073741823 | Unit | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn617 (2617h) | Fourth set position | -1073741824 ~ 1073741823 | Unit | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn619 (2619h) | Effective time of the first set position output signal | 0-65535 | ms | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn61A (261Ah) | Effective time of second set position output signal | 0-65535 | ms | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn61B (261Bh) | Effective time of the third set position output signal | 0-65535 | ms | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn61C (261Ch) | Effective time of the fourth set position output signal | 0-65535 | ms | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn61D (261Dh) | Position comparison delay compensation | 0-625 | 0.1us | 0 | Immediately | — | — | | | | | | | | | | | |
| Pn61F (261Fh) | Application function selection 61F | 0000H~FFFFH | — | 0000H | After restart | Basic setting | — | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 Bit 2 Bit 1 Bit 0 n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Torque overload function switch</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="width: 30px; text-align: center;">0</td> <td>close</td> <td rowspan="2" style="text-align: center; vertical-align: middle;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>open</td> </tr> </tbody> </table> </div> </div> <div style="border: 1px solid black; padding: 5px; width: 100%;"> Reserved parameter (Do not change.) </div> | Torque overload function switch | | Reference | 0 | close | — | 1 | open | | | | | | | | | |
| Torque overload function switch | | Reference | | | | | | | | | | | | | | | | |
| 0 | close | — | | | | | | | | | | | | | | | | |
| 1 | open | | | | | | | | | | | | | | | | | |
| Pn630 (2630h) | Resistance of external brake resistor | 0~65535 | 10mΩ | 0 | After restart | Basic setting | — | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | |
|------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----------------------------------------------------------|----------------|------------------------------------------------------------------------------------|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|------------------------------------|----------------------|-----------|------------------|----------------------------------------|---|---|-------------------------------------------------|---|----------------------------------|-------------------------------------|--|
| Pn631 (2631h) | Gravity compensation function switch | 0000H - 0002H | - | 0000H | Immediately | — | — | | | | | | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <thead> <tr> <th colspan="2">Automatic update of gravity compensation value selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Auto Update Off</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>value not persistent</td> </tr> <tr> <td>2</td> <td>Persistent value</td> </tr> </tbody> </table> | | Automatic update of gravity compensation value selection | | Reference | 0 | Auto Update Off | — | 1 | value not persistent | 2 | Persistent value | Reserved parameter (Do not change.) | | | | | | | |
| | Automatic update of gravity compensation value selection | | Reference | | | | | | | | | | | | | | | | | | |
| 0 | Auto Update Off | — | | | | | | | | | | | | | | | | | | | |
| 1 | value not persistent | | | | | | | | | | | | | | | | | | | | |
| 2 | Persistent value | | | | | | | | | | | | | | | | | | | | |
| Pn640 (2640h) | Black box function configuration | 0000H - FFFFH | - | 0011H | After restart | — | — | | | | | | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <tbody> <tr> <td colspan="2">Bit0 black box switch 0 :OFF, 1 :ON</td> </tr> <tr> <td colspan="2">Bit1 Trigger mode 0 : Triggered by any alarm 1 : Triggered by specific alarm</td> </tr> </tbody> </table> | | Bit0 black box switch 0 :OFF, 1 :ON | | Bit1 Trigger mode 0 : Triggered by any alarm 1 : Triggered by specific alarm | | <table border="1"> <thead> <tr> <th colspan="2">Black box latch alarm code setting</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Latch the data of the first ten alarms</td> <td rowspan="3">—</td> </tr> <tr> <td>1</td> <td>Data of five times before and after latch alarm</td> </tr> <tr> <td>2</td> <td>Latch data ten times after alarm</td> </tr> </tbody> </table> | | Black box latch alarm code setting | | Reference | 0 | Latch the data of the first ten alarms | — | 1 | Data of five times before and after latch alarm | 2 | Latch data ten times after alarm | Reserved parameter (Do not change.) | |
| | Bit0 black box switch 0 :OFF, 1 :ON | | | | | | | | | | | | | | | | | | | | |
| Bit1 Trigger mode 0 : Triggered by any alarm 1 : Triggered by specific alarm | | | | | | | | | | | | | | | | | | | | | |
| Black box latch alarm code setting | | Reference | | | | | | | | | | | | | | | | | | | |
| 0 | Latch the data of the first ten alarms | — | | | | | | | | | | | | | | | | | | | |
| 1 | Data of five times before and after latch alarm | | | | | | | | | | | | | | | | | | | | |
| 2 | Latch data ten times after alarm | | | | | | | | | | | | | | | | | | | | |
| Pn641 (2641h) | Black box latch alarm code setting | 0000H - FFFFH | — | 0000H | After restart | — | — | | | | | | | | | | | | | | |
| Pn645 (2645h) | The variable trace function tracks the 16-bit variable actual address assignment | 00000000-FFFFFFF | — | 00000000 | Immediately | Basic setting | — | | | | | | | | | | | | | | |
| Pn646 (2646h) | The variable trace function tracks the 32-bit variable actual address assignment | 00000000-FFFFFFF | — | 00000000 | Immediately | Basic setting | — | | | | | | | | | | | | | | |
| Pn660 (2660h) | Current command setting | 0-10000 | - | 0 | After restart | Basic setting | — | | | | | | | | | | | | | | |
| Pn661 (2661h) | Phase angle setting | 0-500 | - | 0 | After restart | Basic setting | — | | | | | | | | | | | | | | |
| Pn66F (266Fh) | Online inertia update time | 0-65535 | min | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | |
| Pn670 (2670h) | Online inertia identification setting | 0-3 | - | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | |
| Pn676 (2676h) | Internal brake configuration | 0~8203 | - | 0 | After restart | Basic setting | — | | | | | | | | | | | | | | |
| Pn678 (2678h) | Auto-tuning rigid setting | 0-41 | — | 4 | Immediately | Basic setting | — | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | |
|-------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|-----------|---------------|----------------|----------------|-----------|------------------|--|-----------|---|---------------------------------------------------------------------------------|---|---|--------------------------------------------------------------------------|---|-------------------------------------------------------------|---|------------------------------------------------------|---|-------------------------------------------------|---|--------------|---|----------------------------------------------------------|
| Pn679 (2679h) | Auto-tuning mode | 0000-0006H | — | 0000H | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> Bit 3 Bit 2 Bit 1 Bit 0 </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Auto-tuning mode</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>The parameter auto-tuning is invalid, and the gain parameter is manually tuning</td> <td rowspan="7" style="text-align: center; vertical-align: middle;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Parameter auto-tuning mode, auto-tuning gain parameters with rigid meter</td> </tr> <tr> <td style="text-align: center;">2</td> <td>Position mode, auto-tuning gain parameters with rigid meter</td> </tr> <tr> <td style="text-align: center;">3</td> <td>Interpolation mode, automatic inertia identification</td> </tr> <tr> <td style="text-align: center;">4</td> <td>Ordinary mode, automatic inertia identification</td> </tr> <tr> <td style="text-align: center;">5</td> <td>Stune Mode 5</td> </tr> <tr> <td style="text-align: center;">6</td> <td>Quick positioning mode, automatic inertia identification</td> </tr> </tbody> </table> </div> </div> | | | | | | | Auto-tuning mode | | Reference | 0 | The parameter auto-tuning is invalid, and the gain parameter is manually tuning | — | 1 | Parameter auto-tuning mode, auto-tuning gain parameters with rigid meter | 2 | Position mode, auto-tuning gain parameters with rigid meter | 3 | Interpolation mode, automatic inertia identification | 4 | Ordinary mode, automatic inertia identification | 5 | Stune Mode 5 | 6 | Quick positioning mode, automatic inertia identification |
| | Auto-tuning mode | | Reference | | | | | | | | | | | | | | | | | | | | | | |
| 0 | The parameter auto-tuning is invalid, and the gain parameter is manually tuning | — | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Parameter auto-tuning mode, auto-tuning gain parameters with rigid meter | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Position mode, auto-tuning gain parameters with rigid meter | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Interpolation mode, automatic inertia identification | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Ordinary mode, automatic inertia identification | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Stune Mode 5 | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Quick positioning mode, automatic inertia identification | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn67A (267Ah) | Auto-tuning vibration treatment time | 0-65535 | s | 300 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | |
| Pn67F (267Fh) | Probe delay compensation | -32768~32767 | 0.1us | 0 | Immediately | Basic setting | | | | | | | | | | | | | | | | | | | |
| Pn6A8 (26A8h) | Manual BK control | 0~1 | - | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | |
| Pn6A9 (26A9h) | Collision detection torque | 0-300 | 1% | 0 | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | |
| Pn6AA (26AAh) | Collision detection time | 0-5000 | ms | 1 | After restart | Basic setting | — | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|-----------|---------------|----------------|----------------|-----------|--|-----------------------------------------------|--|-----------|----|----------------------------|---|----|--------------------------------------------------------------------|----|-----------------------------------------------------------------------|----|---------------------------------------------------------------|----|-----------------------------------------------------------------|----|--------------------------------------------------------------------|----|------------------------------------------------------------|----|------------------------------------------------------------------|----|---------------------------------------------------------------------|----|-------------------------------------------------------------|----|--------------------------------------------|----|-----------------------------------------------|----|---------------------------------------|----|-----------------------------------------|----|--------------------------------------------|----|------------------------------------|----|------------------------------------------|----|---------------------------------------------|----|-------------------------------------|
| Pn6B0 (26B0h) | Advanced auto-tuning one-touch control (Fn202) | 0~20 | - | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 Bit 2 Bit 1 Bit 0 n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Advanced auto-tune one-touch control (Fn2 02)</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>00</td><td>Invalid tuning</td><td rowspan="13">—</td></tr> <tr><td>01</td><td>Inertia Self-Indicated, Medium Rigid Structural Interpolation Mode</td></tr> <tr><td>02</td><td>Inertia Self-Indicated, Medium Rigid Structural fast positioning Mode</td></tr> <tr><td>03</td><td>Inertia Self-Indicated, Medium Rigid Structural Standard Mode</td></tr> <tr><td>04</td><td>Inertia Self-Indicated, Low Rigid Structural Interpolation Mode</td></tr> <tr><td>05</td><td>Inertia Self-Indicated, Low Rigid Structural fast positioning Mode</td></tr> <tr><td>06</td><td>Inertia Self-Indicated, Low Rigid Structural Standard Mode</td></tr> <tr><td>07</td><td>Inertia Self-Indicated, High Rigid Structural Interpolation Mode</td></tr> <tr><td>08</td><td>Inertia Self-Indicated, High Rigid Structural fast positioning Mode</td></tr> <tr><td>09</td><td>Inertia Self-Indicated, High Rigid Structural Standard Mode</td></tr> <tr><td>0B</td><td>Medium Rigid Structural Interpolation Mode</td></tr> <tr><td>0C</td><td>Medium Rigid Structural fast positioning Mode</td></tr> <tr><td>0D</td><td>Medium Rigid Structural Standard Mode</td></tr> <tr><td>0E</td><td>Low Rigid Structural Interpolation Mode</td></tr> <tr><td>0F</td><td>Low Rigid Structural fast positioning Mode</td></tr> <tr><td>10</td><td>Low Rigid Structural Standard Mode</td></tr> <tr><td>11</td><td>High Rigid Structural Interpolation Mode</td></tr> <tr><td>12</td><td>High Rigid Structural fast positioning Mode</td></tr> <tr><td>13</td><td>High Rigid Structural Standard Mode</td></tr> </tbody> </table> </div> </div> | | | | | | | | Advanced auto-tune one-touch control (Fn2 02) | | Reference | 00 | Invalid tuning | — | 01 | Inertia Self-Indicated, Medium Rigid Structural Interpolation Mode | 02 | Inertia Self-Indicated, Medium Rigid Structural fast positioning Mode | 03 | Inertia Self-Indicated, Medium Rigid Structural Standard Mode | 04 | Inertia Self-Indicated, Low Rigid Structural Interpolation Mode | 05 | Inertia Self-Indicated, Low Rigid Structural fast positioning Mode | 06 | Inertia Self-Indicated, Low Rigid Structural Standard Mode | 07 | Inertia Self-Indicated, High Rigid Structural Interpolation Mode | 08 | Inertia Self-Indicated, High Rigid Structural fast positioning Mode | 09 | Inertia Self-Indicated, High Rigid Structural Standard Mode | 0B | Medium Rigid Structural Interpolation Mode | 0C | Medium Rigid Structural fast positioning Mode | 0D | Medium Rigid Structural Standard Mode | 0E | Low Rigid Structural Interpolation Mode | 0F | Low Rigid Structural fast positioning Mode | 10 | Low Rigid Structural Standard Mode | 11 | High Rigid Structural Interpolation Mode | 12 | High Rigid Structural fast positioning Mode | 13 | High Rigid Structural Standard Mode |
| | Advanced auto-tune one-touch control (Fn2 02) | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 00 | Invalid tuning | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 01 | Inertia Self-Indicated, Medium Rigid Structural Interpolation Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 02 | Inertia Self-Indicated, Medium Rigid Structural fast positioning Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 03 | Inertia Self-Indicated, Medium Rigid Structural Standard Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 04 | Inertia Self-Indicated, Low Rigid Structural Interpolation Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 05 | Inertia Self-Indicated, Low Rigid Structural fast positioning Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 06 | Inertia Self-Indicated, Low Rigid Structural Standard Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 07 | Inertia Self-Indicated, High Rigid Structural Interpolation Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 08 | Inertia Self-Indicated, High Rigid Structural fast positioning Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 09 | Inertia Self-Indicated, High Rigid Structural Standard Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0B | Medium Rigid Structural Interpolation Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0C | Medium Rigid Structural fast positioning Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0D | Medium Rigid Structural Standard Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0E | Low Rigid Structural Interpolation Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0F | Low Rigid Structural fast positioning Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Low Rigid Structural Standard Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | High Rigid Structural Interpolation Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | High Rigid Structural fast positioning Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | High Rigid Structural Standard Mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn6B1 (26B1h) | Advanced auto-tuning one-touch control (Fn201) | 0~20 | - | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Same as PN6B0 Advanced auto-tuning one-touch control (Fn202) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn6B2 (26B2h) | Travel distance of advanced automatic tuning | -32767-32767 | — | 0 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn6B3 (26B3h) | Advanced auto-tuning initial gain level | 0~5 | — | 2 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> Bit 3 Bit 2 Bit 1 Bit 0 n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> </div> <div style="flex-grow: 1;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Advanced auto-tuning initial gain level</th> <th>Reference</th> </tr> </thead> <tbody> <tr><td>0</td><td>No setting, refer to Pn100</td><td rowspan="6">—</td></tr> <tr><td>1</td><td>Level 1</td></tr> <tr><td>2</td><td>Level 2 (default recommendation)</td></tr> <tr><td>3</td><td>Level 3</td></tr> <tr><td>4</td><td>Level 4</td></tr> <tr><td>5</td><td>Level 5</td></tr> </tbody> </table> </div> </div> | | | | | | | | Advanced auto-tuning initial gain level | | Reference | 0 | No setting, refer to Pn100 | — | 1 | Level 1 | 2 | Level 2 (default recommendation) | 3 | Level 3 | 4 | Level 4 | 5 | Level 5 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Advanced auto-tuning initial gain level | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0 | No setting, refer to Pn100 | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1 | Level 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | Level 2 (default recommendation) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 | Level 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Level 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Level 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----------------------------------------|----------------|----------------|-----------|-----------------------------------------------------------------------------|---|-----------|----------------------------------------------------------------------------------|----------------------------|---|---|-----------------------|-------------------------------------|---------------------------------------------------|---|------------------------|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|----------------------------------------|---|-----------|---|---------------------------------------------------------------|---|---------|----------------------------------------------------------------------------------|-------------------------------------|-------------------------------------|--|--|--|--|--|--|
| Pn6B4 (26B4h) | Advanced auto-tuning initial inertia level | 0~3 | — | 2 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <thead> <tr> <th colspan="2">Advanced auto-tuning initial inertia level</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No setting, refer to Pn324</td> <td rowspan="4">—</td> </tr> <tr> <td>1</td> <td>Low moment of inertia</td> </tr> <tr> <td>2</td> <td>Medium moment of inertia (default recommendation)</td> </tr> <tr> <td>3</td> <td>High moment of inertia</td> </tr> <tr> <td colspan="3">Reserved parameter (Do not change.)</td> </tr> </tbody> </table> | | | | | | Advanced auto-tuning initial inertia level | | Reference | 0 | No setting, refer to Pn324 | — | 1 | Low moment of inertia | 2 | Medium moment of inertia (default recommendation) | 3 | High moment of inertia | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | |
| | Advanced auto-tuning initial inertia level | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | No setting, refer to Pn324 | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Low moment of inertia | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Medium moment of inertia (default recommendation) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | High moment of inertia | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn6B5 (26B5h) | Advanced auto-tuning initial positioning accuracy | 0~9 | — | 4 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <thead> <tr> <th colspan="2">Advanced auto-tuning initial positioning accuracy</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No setting, refer to Pn522</td> <td rowspan="10">—</td> </tr> <tr> <td>1</td> <td>Level 1</td> </tr> <tr> <td>2</td> <td>Level 2</td> </tr> <tr> <td>3</td> <td>Level 3</td> </tr> <tr> <td>4</td> <td>Level 4 (default recommendation)</td> </tr> <tr> <td>5</td> <td>Level 5</td> </tr> <tr> <td>6</td> <td>Level 6</td> </tr> <tr> <td>7</td> <td>Level 7</td> </tr> <tr> <td>8</td> <td>Level 8</td> </tr> <tr> <td>9</td> <td>Level 9</td> </tr> <tr> <td colspan="3">Reserved parameter (Do not change.)</td> </tr> </tbody> </table> | | | | | | Advanced auto-tuning initial positioning accuracy | | Reference | 0 | No setting, refer to Pn522 | — | 1 | Level 1 | 2 | Level 2 | 3 | Level 3 | 4 | Level 4 (default recommendation) | 5 | Level 5 | 6 | Level 6 | 7 | Level 7 | 8 | Level 8 | 9 | Level 9 | Reserved parameter (Do not change.) | | | | | | |
| | Advanced auto-tuning initial positioning accuracy | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | No setting, refer to Pn522 | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Level 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Level 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Level 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Level 4 (default recommendation) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Level 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Level 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Level 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Level 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Level 9 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn6B6 (26B6h) | Advanced Auto-tuning Gain Results Saved Percent | 1-100 | 1% | 70 | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pn6B7 (26B7h) | Advanced auto-tuning configuration function | 0000H-1111H | — | 0001H | Immediately | Basic setting | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | <table border="1"> <thead> <tr> <th colspan="2">Initial selection of "Auto-tuning related functions" when tuning is started</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No initialization</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Forced initialization</td> </tr> <tr> <td colspan="3">Reserved parameter (Do not change.)</td> </tr> <tr> <td colspan="2"></td> <td colspan="2"> <table border="1"> <thead> <tr> <th colspan="2">Fn201 Motion distance source selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Pn6B2 is taken as increment distance in the movement of Pn201</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Pn6B8 and Pn6BA are taken as the maximum distance in the movement range of Pn201</td> </tr> </tbody> </table> </td> </tr> <tr> <td colspan="8">Reserved parameter (Do not change.)</td> </tr> </tbody> </table> | | | | | | Initial selection of "Auto-tuning related functions" when tuning is started | | Reference | 0 | No initialization | — | 1 | Forced initialization | Reserved parameter (Do not change.) | | | | | <table border="1"> <thead> <tr> <th colspan="2">Fn201 Motion distance source selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Pn6B2 is taken as increment distance in the movement of Pn201</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Pn6B8 and Pn6BA are taken as the maximum distance in the movement range of Pn201</td> </tr> </tbody> </table> | | Fn201 Motion distance source selection | | Reference | 0 | Pn6B2 is taken as increment distance in the movement of Pn201 | — | 1 | Pn6B8 and Pn6BA are taken as the maximum distance in the movement range of Pn201 | Reserved parameter (Do not change.) | | | | | | | |
| | Initial selection of "Auto-tuning related functions" when tuning is started | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | No initialization | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Forced initialization | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th colspan="2">Fn201 Motion distance source selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Pn6B2 is taken as increment distance in the movement of Pn201</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Pn6B8 and Pn6BA are taken as the maximum distance in the movement range of Pn201</td> </tr> </tbody> </table> | | Fn201 Motion distance source selection | | Reference | 0 | Pn6B2 is taken as increment distance in the movement of Pn201 | — | 1 | Pn6B8 and Pn6BA are taken as the maximum distance in the movement range of Pn201 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Fn201 Motion distance source selection | | Reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Pn6B2 is taken as increment distance in the movement of Pn201 | — | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Pn6B8 and Pn6BA are taken as the maximum distance in the movement range of Pn201 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|-----------|---------------|----------------|----------------|-----------------------------------|--------------------------------------|-----------|-----------|---------------------------------|----------------------------------|---|--------------------------------------|----------------------------------|
| Pn6B8 | Advanced auto-tuning _ start of motion interval (Negative limit) | -2147483648~2147483647 | Unit | 0 | Immediately | Basic setting | — | | | | | | | | |
| Pn6BA | Advanced auto-tuning _ end of motion interval (Positive limit) | -2147483648~2147483647 | Unit | 0 | Immediately | Basic setting | — | | | | | | | | |
| Pn6C0 (26C0h) | Main switch of gantry function | 0000H-0011H | — | 0010H | After restart | Basic setting | — | | | | | | | | |
| | <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> n. Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> </div> <div> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Main switch of gantry function</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Disable</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Enable</td> </tr> </tbody> </table> </div> </div> | | | | | | | Main switch of gantry function | | Reference | 0 | Disable | — | 1 | Enable |
| | Main switch of gantry function | | Reference | | | | | | | | | | | | |
| | 0 | Disable | — | | | | | | | | | | | | |
| 1 | Enable | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> n. Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> </div> <div> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Gantry homing mode</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Master-slave independent homing</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Slave axis follow master axis homing</td> </tr> </tbody> </table> </div> </div> | | | | | | | Gantry homing mode | | Reference | 0 | Master-slave independent homing | — | 1 | Slave axis follow master axis homing | |
| Gantry homing mode | | Reference | | | | | | | | | | | | | |
| 0 | Master-slave independent homing | — | | | | | | | | | | | | | |
| 1 | Slave axis follow master axis homing | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> n. Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> </div> <div> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="text-align: center; width: 50px;">Bit8: Test</td> <td></td> </tr> </table> </div> </div> | | | | | | | Bit8: Test | | | | | | | | |
| Bit8: Test | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Pn6C1 (26C1h) | Gantry slave axis function switch | 0000H-0011H | — | 0000H | Immediately | Basic setting | — | | | | | | | | |
| | <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> n. Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> </div> <div> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Position compensation meter function</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Disable</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Enable</td> </tr> </tbody> </table> </div> </div> | | | | | | | Position compensation meter function | | Reference | 0 | Disable | — | 1 | Enable |
| | Position compensation meter function | | Reference | | | | | | | | | | | | |
| | 0 | Disable | — | | | | | | | | | | | | |
| 1 | Enable | | | | | | | | | | | | | | |
| <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> n. Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> </div> <div> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Synchronous compensation function</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Disable</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Enable</td> </tr> </tbody> </table> </div> </div> | | | | | | | Synchronous compensation function | | Reference | 0 | Disable | — | 1 | Enable | |
| Synchronous compensation function | | Reference | | | | | | | | | | | | | |
| 0 | Disable | — | | | | | | | | | | | | | |
| 1 | Enable | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Pn6C2 (26C2h) | Gantry coordinated stop mode | 0000H-0002H | — | 0000H | Immediately | Basic setting | — | | | | | | | | |
| | <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> n. Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 <input type="checkbox"/> </div> <div> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Coordination stop function selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0</td> <td>Coordinated Stop Function Mode 1</td> <td rowspan="2" style="text-align: center;">—</td> </tr> <tr> <td style="text-align: center;">1</td> <td>Coordinated Stop Function Mode 2</td> </tr> </tbody> </table> </div> </div> | | | | | | | Coordination stop function selection | | Reference | 0 | Coordinated Stop Function Mode 1 | — | 1 | Coordinated Stop Function Mode 2 |
| | Coordination stop function selection | | Reference | | | | | | | | | | | | |
| | 0 | Coordinated Stop Function Mode 1 | — | | | | | | | | | | | | |
| 1 | Coordinated Stop Function Mode 2 | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |
| Pn6C3 (26C3h) | Warning value of excessive position bias between gantry shafts | 10-100 | % | 100 | Immediately | Basic setting | — | | | | | | | | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference |
|------------------|---------------------------------------------------------------------|------------------------|-------|---------------|----------------|----------------|-----------|
| Pn6C4 (26C4h) | Alarm value for excessive position bias between gantry shafts | 0-1073741823 | Unit | 1048576 | Immediately | Basic setting | — |
| Pn6C5 (26C5h) | Alarm value for excessive differential torque between gantry shafts | 0-6000 | % | 1000 | Immediately | Basic setting | — |
| Pn6C6 (26C6h) | Gantry coordinated stop speed FF feedforward | 0-100 | % | 0 | Immediately | Basic setting | — |
| Pn6C7 (26C7h) | Proportional gain of gantry synchronous position loop | 10-20000 | 0.1/s | 400 | Immediately | Basic setting | — |
| Pn6C8 (26C8h) | Integral time of synchronous position loop of gantry | 0-50000 | 0.1ms | 2000 | Immediately | Basic setting | — |
| Pn6C9 (26C9h) | Gantry synchronous velocity limiting | 0-1000 | 0.1% | 20 | Immediately | Basic setting | — |
| Pn6CA (26CAh) | Differential velocity limit between gantry coordinated stop axes | 0-3000 | rpm | 300 | Immediately | Basic setting | — |
| Pn6CB (26CBh) | Gantry coordination stop completion velocity threshold | 0-1000 | rpm | 15 | Immediately | Basic setting | — |
| Pn700 | 603F-Error code | 0000H-FFFFH | — | 0000H | Immediately | — | — |
| Pn701 | 6040-Control word | 0000H-FFFFH | — | 0000H | Immediately | — | — |
| Pn702 | 6041-Status word | 0000H-FFFFH | — | 0000H | Immediately | — | — |
| Pn703 | 605A-Quick shutdown mode selection | 0-7 | — | 2 | Immediately | — | — |
| Pn706 | 605D- Pause mode selection | 0-4 | — | 1 | Immediately | — | — |
| Pn707 | 605E- Fault Reaction Option Code | 0-0 | — | 0 | Immediately | — | — |
| Pn708 | 6060-Control mode | 0-10 | — | 0 | Immediately | — | — |
| Pn709 | 6061- Control mode display | 0-10 | — | 0 | — | — | — |
| Pn70A | 6062-User position command | -2147483648-2147483647 | cnt | 0 | Immediately | — | — |
| Pn70C | 6063-Motor position feedback | -2147483648-2147483647 | cnt | 0 | Immediately | — | — |
| Pn70E | 6064- User position feedback | -2147483648-2147483647 | cnt | 0 | Immediately | — | — |
| Pn710 | 6065- User position bias exceeded threshold | 0-4294967295 | cnt | 0 | Immediately | — | — |
| Pn712 | 6066- Position bias time window | 0-65535 | ms | 0 | Immediately | — | — |
| Pn713 | 6067- Position reached threshold | 0-4294967295 | cnt | 50 | Immediately | — | — |
| Pn715 | 6068- Position reached time | 0-65535 | ms | 0 | Immediately | — | — |
| Pn716 | 606B- User Velocity Command Value | -2147483648-2147483647 | cnt/s | 0 | Immediately | — | — |
| Pn718 | 606C-User actual velocity feedback | -2147483648-2147483647 | cnt/s | 0 | Immediately | — | — |
| Pn71A | 606D- Velocity reached threshold | 0-65535 | rpm | 10 | Immediately | — | — |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference |
|--------|-------------------------------------------------------------|------------------------|--------------------|---------------|----------------|----------------|-----------|
| Pn71B | 606E- Velocity reached time | 0-65535 | ms | 0 | Immediately | — | — |
| Pn71C | 6071- Torque target value | -32768-32767 | 0.1% | 0 | Immediately | — | — |
| Pn71D | 6072- Maximum torque | 0-65535 | 0.1% | 8000 | Immediately | — | — |
| Pn71E | 6074- User defined torque value | -32768-32767 | 0.1% | 0 | Immediately | — | — |
| Pn71F | 6076- Motor RPM Torque | 0-4294967295 | mN | 0 | Immediately | — | — |
| Pn721 | 6077- Actual torque feedback | -32768-32767 | 0.1% | 0 | Immediately | — | — |
| Pn722 | 607A- Target Position Value | -2147483648-2147483647 | cnt | 0 | Immediately | — | — |
| Pn724 | 607C- Origin offset | -2147483648-2147483647 | cnt | 0 | Immediately | — | — |
| Pn726 | 607D- Software Limit: Minimum Position Limit | -2147483648-2147483647 | cnt | -2147483648 | Immediately | — | — |
| Pn728 | 607D- Software Limit: Maximum Position Limit | -2147483648-2147483647 | cnt | 2147483647 | Immediately | — | — |
| Pn72A | 607E- Command polarity | 0-255 | - | 0 | Immediately | — | — |
| Pn72B | 607F- Maximum profile velocity | 0-4294967295 | cnt/s | 2147483647 | Immediately | — | — |
| Pn72D | 6080- Maximum Motor velocity | 0-4294967295 | cnt/s | 10000 | Immediately | — | — |
| Pn72F | 6081- Profile Velocity | 0-4294967295 | cnt/s | 0 | Immediately | — | — |
| Pn731 | 6083- Profile acceleration velocity | 0-4294967295 | cnt/s ² | 10485760 | Immediately | — | — |
| Pn733 | 6084- Profile deceleration velocity | 0-4294967295 | cnt/s ² | 10485760 | Immediately | — | — |
| Pn735 | 6085- Quick stop deceleration | 0-4294967295 | cnt/s ² | 10485760 | Immediately | — | — |
| Pn738 | 6087- Torque ramp | 0-4294967295 | - | 1000 | Immediately | — | — |
| Pn73A | 6098- Homing mode | 0-35 | - | 0 | Immediately | — | — |
| Pn73B | 6099- Velocity of search deceleration signal in homing mode | 0-4294967295 | - | 10485760 | Immediately | — | — |
| Pn73D | 6099- Velocity of search original signal in homing mode | 0-4294967295 | - | 524288 | Immediately | — | — |
| Pn73F | 609A- Homing acceleration | 0-4294967295 | cnt/s ² | 10485760 | Immediately | — | — |
| Pn741 | 60B0- Position offset | -2147483648-2147483647 | cnt | 0 | Immediately | — | — |
| Pn743 | 60B1- Velocity offset | -2147483648-2147483647 | cnt/s | 0 | Immediately | — | — |
| Pn745 | 60B2- Torque offset | -32768~32767 | 0.1% | 0 | Immediately | — | — |
| Pn747 | 60B8- Probe Function | 0000H-FFFFH | - | 0000H | Immediately | — | — |
| Pn748 | 60B9- Probe status word | 0000H-FFFFH | - | 0000H | Immediately | — | — |
| Pn749 | 60BA- Probe 1 Rising Edge Position Feedback | -2147483648-2147483647 | - | 0 | Immediately | — | — |
| Pn74A | 60BB- Probe 1 falling edge position feedback | -2147483648-2147483647 | - | 0 | Immediately | — | — |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference |
|--------|----------------------------------------------|------------------------|-------|---------------|----------------|----------------|-----------|
| Pn74B | 60BC- probe 2 rising edge position feedback | -2147483648-2147483647 | - | 0 | Immediately | — | — |
| Pn74C | 60BD- Probe 2 falling edge position feedback | -2147483648-2147483647 | - | 0 | Immediately | — | — |
| Pn74D | 60C0- Interpolated sub-mode selection | -3-0 | - | 0 | Immediately | — | — |
| Pn74E | 60C1- Interpolated data record | 0-4294967295 | - | 0 | Immediately | — | — |
| Pn750 | 60C2- Interpolation time period | -6- -3 | - | 0 | Immediately | — | — |
| Pn751 | 60C2- Interpolation time point | 1-250 | - | 0 | Immediately | — | — |
| Pn752 | 60E0- Forward Maximum Torque Limit | 0-65535 | - | 8000 | Immediately | — | — |
| Pn753 | 60E1- Reverse Maximum Torque Limit limit | 0-65535 | - | 8000 | Immediately | — | — |
| Pn754 | 60F4-User position bias | -2147483648-2147483647 | - | 0 | Immediately | — | — |
| Pn756 | 60FC-Motor position command feedback | -2147483648-2147483647 | - | 0 | Immediately | — | — |
| Pn758 | 60FD-DI input status | 00000000H-FFFFFFFFH | - | 00000000H | Immediately | — | — |
| Pn75A | 60FE-DO Output Status | 00000000H-FFFFFFFFH | - | 00000000H | Immediately | — | — |
| Pn75C | 60FE-Bit mask | 00000000H-FFFFFFFFH | - | 00000000H | Immediately | — | — |
| Pn75E | 60FF-Target velocity | -2147483648-2147483647 | cnt/s | 0 | Immediately | — | — |
| Pn760 | 6502-Servo operation mode supported | 00000000H-FFFFFFFFH | - | 000003ADH | Immediately | — | — |
| Pn761 | 60D5-Probe 1 Rising edge Count | 0-65535 | - | 0 | Immediately | — | — |
| Pn762 | 60D6-Probe 1 falling edge count | 0-65535 | - | 0 | Immediately | — | — |
| Pn763 | 60D7- Probe 2 Rising edge Count | 0-65535 | - | 0 | Immediately | — | — |
| Pn764 | 60D8- Probe 2 falling edge count | 0-65535 | - | 0 | Immediately | — | — |
| Pn776 | System position 31:00 upper limit L | 0-4294967295 | - | 0 | Immediately | — | — |
| Pn778 | System position 63:32 upper limit H | 0-4294967295 | - | 0 | Immediately | — | — |
| Pn77F | Homing timeout time | 0-4294967295 | 100ms | 10000 | Immediately | — | — |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | |
|--------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|------------------------------|-----------------------------|------------------|----------------|----------------|-----------|--|
| Pn781 | Function conversion selection 0 | 0000H~1111H | — | 0000H | Immediately | — | — | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | Software limit switch | | Reference | | | | |
| | | 0 | No software limit is used | | | 6.5 | | |
| | | 1 | Use software limit | | | | | |
| | | Unit transfer switch | | Reference | | | | |
| 0 | No analog-digital function used | | | 6.6 | | | | |
| 1 | Use analog-digital function | | | | | | | |
| Unit transfer switch | | Reference | | | | | | |
| 0 | Unit/s | | | — | | | | |
| 1 | rpm | | | | | | | |
| Homing mark persistent switch | | Reference | | | | | | |
| 0 | Homing mark not persistent | | | 5.10.6 | | | | |
| 1 | Homing mark persistent | | | | | | | |
| Pn785 | Synchronization Error Count Limits | 2-32767 | - | 9 | Immediately | — | — | |
| Pn786 | Station address setting | 0-65535 | - | 0 | After restart | — | — | |
| Pn787 | Function conversion selection 1 | 0000H~0010H | - | 0000H | After restart | — | — | |
| | n. <input type="checkbox"/> Bit 3 <input type="checkbox"/> Bit 2 <input type="checkbox"/> Bit 1 <input type="checkbox"/> Bit 0 | Master station type | | | | | | |
| | | Master station type | | Reference | | | | |
| | | 0 | Codesys and other platforms | | | — | | |
| | | 1 | Omron platform | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | |
| Reserved parameter (Do not change.) | | | | | | | | |
| Pn788 | Low 32 bits of analog-digital homing offset position | 0-4294967295 | - | 0 | Immediately | — | — | |
| Pn789 | High 32 bits of analog-digital homing offset position | 0-4294967295 | - | 0 | Immediately | — | — | |
| Pn78A | Setting of upper limit value of analog-digital function position | 0-4294967296 | - | 0 | After restart | — | — | |
| Pn78C | 6091-Electronic gear ratio numerator | 1-4294967295 | - | 1 | Immediately | — | — | |
| Pn78E | 6091-Electronic gear ratio denominator | 1-4294967295 | - | 1 | Immediately | — | — | |

| Pn No. | Signal | Setting range | Unit | Default Value | When effective | Classification | Reference | | | | | | | | | |
|---------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------------|----------------|----------------|---------------------------------------|----------------------------|--------------|-----------|-----------------------------------------------|-----------------------------------|---|--------------------------------------------|-------------|------------------------------------|
| Pn790 | EtherCAT function conversion Selection 0 | 0000H~2100H | — | 0000H | Immediately | — | — | | | | | | | | | |
| | Bit 3 Bit 2 Bit 1 Bit 0 n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Reserved parameter (Do not change.) | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th colspan="2">Node ID function selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>controller</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Servo drive</td> </tr> </tbody> </table> | | | | | | Node ID function selection | | Reference | 0 | controller | — | 1 | Servo drive | |
| | Node ID function selection | | Reference | | | | | | | | | | | | | |
| 0 | controller | — | | | | | | | | | | | | | | |
| 1 | Servo drive | | | | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th colspan="2">Parameter writing to EEPROM Selection</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Parameter writing to EEPROM (except group 60)</td> <td rowspan="3">5.15</td> </tr> <tr> <td>1</td> <td>All parameters are not written into EEPROM</td> </tr> <tr> <td>2</td> <td>All parameters writing into EEPROM</td> </tr> </tbody> </table> | | | | | | Parameter writing to EEPROM Selection | | Reference | 0 | Parameter writing to EEPROM (except group 60) | 5.15 | 1 | All parameters are not written into EEPROM | 2 | All parameters writing into EEPROM |
| Parameter writing to EEPROM Selection | | Reference | | | | | | | | | | | | | | |
| 0 | Parameter writing to EEPROM (except group 60) | 5.15 | | | | | | | | | | | | | | |
| 1 | All parameters are not written into EEPROM | | | | | | | | | | | | | | | |
| 2 | All parameters writing into EEPROM | | | | | | | | | | | | | | | |
| Pn793 | EtherCAT function conversion selection 3 | 0000H~0001H | — | 0000H | After restart | — | — | | | | | | | | | |
| | Bit 3 Bit 2 Bit 1 Bit 0 n. <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> | Manual homing | | | | | | Reference | | | | | | | | |
| | | <table border="1"> <tbody> <tr> <td>0</td> <td>Homing state</td> <td rowspan="2">—</td> </tr> <tr> <td>1</td> <td>Manual homing in current position</td> </tr> </tbody> </table> | | | | | | 0 | Homing state | — | 1 | Manual homing in current position | | | | |
| | 0 | Homing state | — | | | | | | | | | | | | | |
| 1 | Manual homing in current position | | | | | | | | | | | | | | | |
| | Reserved parameter (Do not change.) | | | | | | | | | | | | | | | |

11.3 Parameter List for Object Dictionary 2000H

| Index | Pn | Name | Unit | Data Type | Data range | Default value | When to set | When effective |
|-------|-------|-----------------------------------|------|-----------|------------|---------------|-------------|----------------|
| 2000h | Pn000 | Basic Function Selection 0 | — | UINT | 0~1 | 0 | Set at stop | After restart |
| 2001h | Pn001 | Application Function Selection 1 | — | UINT | 0~358 | 54 | Set at stop | After restart |
| 2002h | Pn002 | Application Function Selection 2 | — | UINT | 0~529 | 273 | Set at stop | After restart |
| 2008h | Pn008 | Application Function Selection 8 | — | UINT | 0~16673 | 0 | Set at stop | After restart |
| 2009h | Pn009 | Application Function Selection 9 | — | UINT | 0~304 | 16 | Set at stop | After restart |
| 200Ah | Pn00A | Application Function Selection A | — | UINT | 0~98 | 0 | Set at stop | After restart |
| 200Bh | Pn00B | Application Function Selection B | — | UINT | 0~353 | 49 | Set at stop | After restart |
| 200Ch | Pn00C | Application Function Selection C | — | UINT | 0~305 | 0 | Set at stop | After restart |
| 200Dh | Pn00D | Application Function Selection D | — | UINT | 0~4352 | 0 | Set at stop | After restart |
| 2080h | Pn080 | Application Function Selection 80 | — | UINT | 0~257 | 0 | Set at stop | After restart |

| | | | | | | | | |
|-------|-------|-----------------------------------------------------|--------|------|--------------|------|------------------|---------------|
| 2100h | Pn100 | Velocity Loop Gain | 0.1Hz | UINT | 10-20000 | 400 | Set at operation | Immediately |
| 2101h | Pn101 | Velocity Loop Integral Time Constant | 0.01ms | UINT | 15-51200 | 2000 | Set at operation | Immediately |
| 2102h | Pn102 | Position Loop Gain | 0.1/s | UINT | 10-20000 | 400 | Set at operation | Immediately |
| 2103h | Pn103 | Moment of Inertia Ratio | % | UINT | 0-20000 | 100 | Set at operation | Immediately |
| 2104h | Pn104 | Second Velocity Loop Gain | 0.1hz | UINT | 10-20000 | 400 | Set at operation | Immediately |
| 2105h | Pn105 | Second Velocity Loop Integral Time Constant | 0.01ms | UINT | 15-51200 | 2000 | Set at operation | Immediately |
| 2106h | Pn106 | Second Position Loop Gain | 0.1/s | UINT | 10-20000 | 400 | Set at operation | Immediately |
| 2107h | Pn107 | Pseudo-differential feedforward control coefficient | 0.1% | UINT | 0~2000 | 0 | Set at operation | Immediately |
| 2109h | Pn109 | Speed feedforward | % | UINT | 0-100 | 0 | Set at operation | Immediately |
| 210Ah | Pn10A | Feedforward filter time constant | 0.01ms | UINT | 0-6400 | 0 | Set at operation | Immediately |
| 210Bh | Pn10B | Gain type application switch | — | UINT | 0-21300 | 0 | Set at stop | After restart |
| 210Ch | Pn10C | Mode switch (torque command) | % | UINT | 0-800 | 200 | Set at operation | Immediately |
| 210Dh | Pn10D | Mode switch (velocity command) | rpm | UINT | 0-10000 | 0 | Set at operation | Immediately |
| 210Eh | Pn10E | Mode switch (acceleration) | rpm/s | UINT | 0-30000 | 0 | Set at operation | Immediately |
| 210Fh | Pn10F | Mode switch (position bias) | Unit | UINT | 0-10000 | 0 | Set at operation | Immediately |
| 2119h | Pn119 | Torque feedforward | % | UINT | 0~1000 | 0 | Set at operation | Immediately |
| 211Ah | Pn11A | Feedforward filter time constant | 0.01ms | UINT | 0~6400 | 0 | Set at operation | Immediately |
| 211Fh | Pn11F | Position integral time constant | 0.1ms | UINT | 0-50000 | 0 | Set at operation | Immediately |
| 2121h | Pn121 | Friction compensation gain | % | UINT | 10-1000 | 100 | Set at operation | Immediately |
| 2122h | Pn122 | Second friction compensation gain | % | UINT | 10-1000 | 100 | Set at operation | Immediately |
| 2123h | Pn123 | Friction compensation coefficient | % | UINT | 0-100 | 0 | Set at operation | Immediately |
| 2124h | Pn124 | Friction compensation frequency compensation | 0.1Hz | INT | -10000-10000 | 0 | Set at operation | Immediately |
| 2125h | Pn125 | Friction compensation gain compensation | % | UINT | 1-1000 | 100 | Set at operation | Immediately |
| 2127h | Pn127 | Velocity Observer Gain | Hz | UINT | 1-500 | 40 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|-------------------------------------------------------|-------|------|----------|-------|------------------|---------------|
| 2128h | Pn128 | Velocity Observer Position Compensation Gain | % | UINT | 1-1000 | 150 | Set at operation | Immediately |
| 2131h | Pn131 | Gain switching time 1 | ms | UINT | 0-65535 | 0 | Set at operation | Immediately |
| 2132h | Pn132 | Gain switching time 2 | ms | UINT | 0-65535 | 0 | Set at operation | Immediately |
| 2135h | Pn135 | Gain switching waiting time 1 | ms | UINT | 0-65535 | 0 | Set at operation | Immediately |
| 2136h | Pn136 | Gain switching waiting time 2 | ms | UINT | 0-65535 | 0 | Set at operation | Immediately |
| 2137h | Pn137 | Gain switching level 1 | — | UINT | 0-20000 | 0 | Set at operation | Immediately |
| 2138h | Pn138 | Gain switching level 2 | — | UINT | 0-20000 | 0 | Set at operation | Immediately |
| 2139h | Pn139 | Automatic gain type change-over switch 1 | — | UINT | 0~162 | 0000H | Set at operation | Immediately |
| 213Dh | Pn13D | Current gain value | % | UINT | 100~2000 | 2000 | Set at operation | Immediately |
| 2140h | Pn140 | Model tracking control switch | — | UINT | 0~4385 | 0100H | Set at operation | Immediately |
| 2141h | Pn141 | Model Tracking Control Gain | 0.1/s | UINT | 10-20000 | 500 | Set at operation | Immediately |
| 2142h | Pn142 | Model following control gain compensation | 0.1% | UINT | 500-2000 | 1000 | Set at operation | Immediately |
| 2143h | Pn143 | Model Tracking Control Offset (Forward Direction) | 0.1% | UINT | 0-10000 | 1000 | Set at operation | Immediately |
| 2144h | Pn144 | Model Tracking Control Offset (Reverse Direction) | 0.1% | UINT | 0-10000 | 1000 | Set at operation | Immediately |
| 2145h | Pn145 | Vibration suppression 1 frequency A | 0.1Hz | UINT | 10-2500 | 500 | Set at operation | Immediately |
| 2146h | Pn146 | Vibration suppression 1 frequency B | 0.1Hz | UINT | 10-2500 | 700 | Set at operation | Immediately |
| 2147h | Pn147 | Model tracking control speed feedforward compensation | 0.1% | UINT | 0-10000 | 1000 | Set at operation | Immediately |
| 2148h | Pn148 | Model 2 Tracking Control Gain | 0.1/s | UINT | 10-20000 | 500 | Set at operation | Immediately |
| 2149h | Pn149 | Model 2 Tracking Control Gain Correction | 0.1% | UINT | 500-2000 | 1000 | Set at operation | Immediately |
| 214Ah | Pn14A | Vibration suppression 2 frequency | 0.1Hz | UINT | 10-2000 | 800 | Set at operation | Immediately |
| 214Bh | Pn14B | Vibration suppression 2 correction | % | UINT | 10-1000 | 100 | Set at operation | Immediately |
| 214Fh | Pn14F | Control type selection | — | UINT | 0-33 | 33 | Set at stop | After restart |
| 2160h | Pn160 | Vibration suppression control switch | — | UINT | 0-17 | 16 | Set at operation | Immediately |
| 2161h | Pn161 | Type A vibration suppression frequency | 0.1Hz | UINT | 10-20000 | 1000 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|----------------------------------------------------------------|---------|------|----------------|-------|------------------|---------------|
| 2162h | Pn162 | Type A vibration suppression gain correction | % | UINT | 1-1000 | 100 | Set at operation | Immediately |
| 2163h | Pn163 | Attenuation gain of type A vibration suppression | % | UINT | 0-300 | 0 | Set at operation | Immediately |
| 2164h | Pn164 | Type A vibration suppression filter time constant 1 correction | 0.01ms | INT | -1000-1000 | 0 | Set at operation | Immediately |
| 2165h | Pn165 | Type A vibration suppression filter time constant 2 correction | 0.01ms | INT | -1000-1000 | 0 | Set at operation | Immediately |
| 2166h | Pn166 | A-type vibration suppression attenuation gain 2 | — | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 2167h | Pn167 | Cut-off frequency of Type A damped high-pass filter | — | UINT | 10-50000 | 20000 | Set at operation | Immediately |
| 2170h | Pn170 | Non-tuning type switch | — | UINT | 0-10001 | 5120 | Set at stop | After restart |
| 2207h | Pn207 | Position control function switch | — | UINT | 0~8192 | 0 | Set at stop | After restart |
| 2216h | Pn216 | Position command acceleration/deceleration time parameter | 0.1ms | UINT | 0-65535 | 0 | Set at operation | Immediately |
| 2217h | Pn217 | Average time of position command movement | 0.1ms | UINT | 0-10000 | 0 | Set at operation | Immediately |
| 2219h | Pn219 | Position command 2nd-order low-pass filter cutoff frequency | 0.1Hz | UINT | 0~10000 | 0 | Set at operation | Immediately |
| 2230h | Pn230 | Position control extended function switch | — | UINT | 0-1 | 0 | Set at stop | After restart |
| 2231h | Pn231 | Backlash compensation amount | 0.1Unit | DINT | -500000-500000 | 0 | Set at operation | Immediately |
| 2233h | Pn233 | Time parameter of backlash compensation | 0.01ms | UINT | 0-65535 | 0 | Set at operation | Immediately |
| 2260h | Pn260 | Low-frequency vibration suppression mode selection | — | UINT | 0-1 | 0 | Set at operation | Immediately |
| 2261h | Pn261 | Low frequency resonance frequency A | 0.1Hz | UINT | 0-5000 | 0 | Set at operation | Immediately |
| 2262h | Pn262 | Suppression width of low-frequency resonance frequency A | — | UINT | 0-10 | 2 | Set at operation | Immediately |
| 2263h | Pn263 | Suppression depth of low-frequency resonance frequency A | — | UINT | 0-1000 | 5 | Set at operation | Immediately |
| 2290h | Pn290 | Cutting vibration enable | — | UINT | 0~1 | 0 | Set at operation | Immediately |
| 2291h | Pn291 | Cutting vibration maximum limit | 0.1%rev | UINT | 0~300 | 100 | Set at operation | Immediately |
| 2292h | Pn292 | Cutting vibration amplitude | Unit | UINT | 0~32767 | 0 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|---------------------------------------------------------------|---------|------|-----------|-------|------------------|---------------|
| 2293h | Pn293 | Cutting vibration frequency | 0.1Hz | UINT | 10~500 | 100 | Set at operation | Immediately |
| 2304h | Pn304 | JOG Velocity | 0.01rpm | UINT | 0~1000000 | 50000 | Set at operation | Immediately |
| 2305h | Pn305 | Soft start acceleration time | ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 2306h | Pn306 | Soft start deceleration time | ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 2307h | Pn307 | Velocity command filter time parameters | 0.01ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 2308h | Pn308 | Velocity Feedback Filter Time Parameters | 0.01ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 230Ah | Pn30A | Stop deceleration time | ms | UINT | 0~10000 | 100 | Set at operation | Immediately |
| 230Ch | Pn30C | Moving average time of velocity feedforward | 0.1ms | UINT | 0~5100 | 0 | Set at operation | Immediately |
| 2310h | Pn310 | Vibration detection switch | — | UINT | 0~2 | 0 | Set at operation | Immediately |
| 2311h | Pn311 | Vibration detection sensitivity | % | UINT | 50~500 | 100 | Set at operation | Immediately |
| 2312h | Pn312 | Vibration detection value | rpm | UINT | 0~5000 | 50 | Set at operation | Immediately |
| 2316h | Pn316 | Maximum motor velocity | rpm | UINT | 0~65535 | 10000 | Set at stop | After restart |
| 2324h | Pn324 | Calculated initial value of moment of inertia | % | UINT | 0~20000 | 300 | Set at operation | Immediately |
| 2325h | Pn325 | Vibration Detection Level in Moment of Inertia Identification | rpm | UINT | 0~5000 | 250 | Set at operation | Immediately |
| 2401h | Pn401 | The first segment 1st torque command filter time constant | 0.01ms | UINT | 0~65535 | 100 | Set at operation | Immediately |
| 2402h | Pn402 | Forward torque limit | % | UINT | 0~800 | 800 | Set at operation | Immediately |
| 2403h | Pn403 | Reverse torque limit | % | UINT | 0~800 | 800 | Set at operation | Immediately |
| 2404h | Pn404 | External torque limit of forward rotating side | % | UINT | 0~800 | 100 | Set at operation | Immediately |
| 2405h | Pn405 | External torque limit on reverse side | % | UINT | 0~800 | 100 | Set at operation | Immediately |
| 2406h | Pn406 | Emergency stop torque | % | UINT | 0~800 | 800 | Set at operation | Immediately |
| 2407h | Pn407 | Velocity limit at torque control | rpm | UINT | 0~10000 | 10000 | Set at operation | Immediately |
| 2408h | Pn408 | Torque type function switch | — | UINT | 0~4369 | 0 | Set at stop | After restart |
| 2409h | Pn409 | The first segment notch filter frequency | Hz | UINT | 50~5000 | 5000 | Set at operation | Immediately |
| 240Ah | Pn40A | Q value of the first segment notch filter | 0.01 | UINT | 50~1000 | 70 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|------------------------------------------------------------|--------|------|----------|------|------------------|-------------|
| 240Bh | Pn40B | The first segment notch filter depth | 0.001 | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 240Ch | Pn40C | The second segment notch filter frequency | Hz | UINT | 50-5000 | 5000 | Set at operation | Immediately |
| 240Dh | Pn40D | Q value of the second segment notch filter | 0.01 | UINT | 50-1000 | 70 | Set at operation | Immediately |
| 240Eh | Pn40E | The second segment notch filter depth | 0.001 | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 240Fh | Pn40F | The second Segment 2nd torque command filter frequency | Hz | UINT | 100-5000 | 5000 | Set at operation | Immediately |
| 2410h | Pn410 | Q value of the second segment torque command filter | 0.01 | UINT | 50-100 | 50 | Set at operation | Immediately |
| 2412h | Pn412 | The first segment 2nd torque command filter time constant | 0.01ms | UINT | 0-65535 | 100 | Set at operation | Immediately |
| 2416h | Pn416 | Torque type function switch 2 | Hz | UINT | 0~273 | 0 | Set at operation | Immediately |
| 2417h | Pn417 | The third segment notch filter frequency | Hz | UINT | 50~5000 | 5000 | Set at operation | Immediately |
| 2418h | Pn418 | Q value of the third segment notch filter | 0.01 | UINT | 50-1000 | 70 | Set at operation | Immediately |
| 2419h | Pn419 | The third segment notch filter depth | 0.001 | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 241Ah | Pn41A | The fourth segment notch filter frequency | Hz | UINT | 50-5000 | 5000 | Set at operation | Immediately |
| 241Bh | Pn41B | Q value of the fourth segment notch filter | 0.01 | UINT | 50-1000 | 70 | Set at operation | Immediately |
| 241Ch | Pn41C | The fourth segment notch filter depth | 0.001 | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 241Dh | Pn41D | The fifth segment notch filter frequency | Hz | UINT | 50-5000 | 5000 | Set at operation | Immediately |
| 241Eh | Pn41E | Q value of the fifth segment notch filter | 0.01 | UINT | 50-1000 | 70 | Set at operation | Immediately |
| 241Fh | Pn41F | The fifth segment notch filter depth | 0.001 | UINT | 0~1000 | 0 | Set at operation | Immediately |
| 2423h | Pn423 | Velocity ripple compensation switch (rotary) | — | UINT | 0-4369 | 0 | Set at operation | Immediately |
| 2424h | Pn424 | Torque limit at main circuit voltage drop | % | UINT | 0-100 | 50 | Set at operation | Immediately |
| 2425h | Pn425 | Release time for torque limit at main circuit voltage drop | ms | UINT | 0-1000 | 100 | Set at operation | Immediately |
| 2426h | Pn426 | Torque feedforward moving average time | 0.1ms | UINT | 0-5100 | 0 | Set at operation | Immediately |
| 2427h | Pn427 | Velocity ripple compensation effective velocity (rotary) | rpm | UINT | 0-10000 | 0 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|------------------------------------------------------------------------|--------|------|------------|-------|------------------|---------------|
| 2453h | Pn453 | Sweep start frequency | Hz | UINT | 1-5000 | 400 | Set at operation | Immediately |
| 2454h | Pn454 | Sweep end frequency | Hz | UINT | 50-5000 | 4000 | Set at operation | Immediately |
| 2455h | Pn455 | Detected resonance frequency lower limit | Hz | UINT | 50-5000 | 500 | Set at operation | Immediately |
| 2456h | Pn456 | Sweep torque command amplitude | % | UINT | 1-800 | 15 | Set at operation | Immediately |
| 2457h | Pn457 | FFT-related function switch | — | UINT | 0-10050 | 528 | Set at stop | After restart |
| 2460h | Pn460 | Notch filter adjustment switch | — | UINT | 0-257 | 257 | Set at operation | Immediately |
| 2466h | Pn466 | Adaptive notch filter mode selection | — | UINT | 0-7 | 4 | Set at operation | Immediately |
| 2471h | Pn471 | Forward coulomb friction compensation torque | 0.1% | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 2472h | Pn472 | Reverse coulomb friction compensation torque | 0.1% | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 2473h | Pn473 | Viscous friction compensation torque | 0.1% | UINT | 0-3000 | 0 | Set at operation | Immediately |
| 2474h | Pn474 | Internally set speed hysteresis | 0.1rpm | UINT | 0-100 | 0 | Set at operation | Immediately |
| 2476h | Pn476 | Gravity compensation torque | 0.1% | INT | -1000~1000 | 0 | Set at operation | Immediately |
| 2477h | Pn477 | Friction identification switch | — | UINT | 0-4385 | 0 | Set at operation | Immediately |
| 2478h | Pn478 | Filtering time for forward coulomb friction compensation | ms | UINT | 0-12800 | 0 | Set at operation | Immediately |
| 2479h | Pn479 | Filtering time for reverse coulomb friction compensation | ms | UINT | 0-12800 | 0 | Set at operation | Immediately |
| 247Ah | Pn47A | Detection speed for friction identification | rpm | UINT | 10-100 | 40 | Set at operation | Immediately |
| 247Bh | Pn47B | Self-adjustment quantity of torque for friction identification | 0.1% | UINT | 1-50 | 5 | Set at operation | Immediately |
| 247Ch | Pn47C | Self-adjustment quantity of filtering time for friction identification | 0.1% | UINT | 10-300 | 100 | Set at operation | Immediately |
| 2481h | Pn481 | Polarity detection velocity loop gain | 0.1HZ | UINT | 10-20000 | 40 | Set at operation | Immediately |
| 2482h | Pn482 | Polarity detection velocity loop integral time constant | 0.01ms | UINT | 15-51200 | 30000 | Set at operation | Immediately |
| 2486h | Pn486 | Polarity detection command acceleration/ deceleration time | ms | UINT | 0-100 | 25 | Set at operation | Immediately |
| 2487h | Pn487 | Polarity detection constant velocity time | ms | UINT | 0-300 | 0 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|--------------------------------------------------------|----------|-------|--------------|------------|------------------|---------------|
| 2488h | Pn488 | Polarity detection command waiting time | ms | UINT | 50-500 | 100 | Set at operation | Immediately |
| 2490h | Pn490 | Polarity detection load value | % | UINT | 0-20000 | 0 | Set at operation | Immediately |
| 2493h | Pn493 | Polarity detection command velocity | rpm | UINT | 0-1000 | 50 | Set at operation | Immediately |
| 2494h | Pn494 | Polarity detection range | 0.001rev | UINT | 1-65535 | 250 | Set at operation | Immediately |
| 2495h | Pn495 | Polarity detection confirmation force command | % | UINT | 0-200 | 100 | Set at operation | Immediately |
| 2498h | Pn498 | Polarity detection allowable error range | deg | UINT | 0-30 | 10 | Set at operation | Immediately |
| 24A0h | Pn4A0 | Polarity detection mode selection | — | UINT | 0~5 | 0 | Set at operation | Immediately |
| 2502h | Pn502 | Rotation detection value | rpm | UINT | 1-10000 | 20 | Set at operation | Immediately |
| 2503h | Pn503 | Velocity coincidence detection signal output width | rpm | UINT | 0-100 | 10 | Set at operation | Immediately |
| 2506h | Pn506 | Brake command-servo OFF delay time | 10ms | UINT | 0~100 | 20 | Set at operation | Immediately |
| 2507h | Pn507 | Brake command output velocity value | rpm | UINT | 0-10000 | 100 | Set at operation | Immediately |
| 2508h | Pn508 | Servo OFF-brake command waiting time | 10ms | UINT | 1~100 | 50 | Set at operation | Immediately |
| 2509h | Pn509 | Momentary power interruption hold time | ms | UINT | 20~50000 | 20 | Set at operation | Immediately |
| 251Eh | Pn51E | Excessive position deviation warning value | % | UINT | 10-100 | 100 | Set at operation | Immediately |
| 2520h | Pn520 | Excessive position deviation alarm value | Unit | UDINT | 1-1073741823 | 524288000 | Set at operation | Immediately |
| 2522h | Pn522 | Positioning completed width | Unit | UDINT | 0-1073741824 | 5872 | Set at operation | Immediately |
| 2524h | Pn524 | Near signal width | Unit | UDINT | 1-1073741824 | 1073741824 | Set at operation | Immediately |
| 2526h | Pn526 | Excessive position deviation alarm value at servo ON | Unit | UDINT | 1-1073741823 | 524288000 | Set at operation | Immediately |
| 2528h | Pn528 | Excessive position deviation warning value at servo ON | % | UINT | 10-100 | 100 | Set at operation | Immediately |
| 2529h | Pn529 | Velocity limit value at servo ON | rpm | UINT | 0-10000 | 10000 | Set at operation | Immediately |
| 252Bh | Pn52B | Overload warning value | % | UINT | 1-100 | 20 | Set at operation | Immediately |
| 252Ch | Pn52C | Base current derating at motor overload detection | % | UINT | 10-100 | 100 | Set at stop | After restart |
| 252Dh | Pn52D | Default single-phase power supply | % | UINT | 10-100 | 100 | Set at stop | After restart |

| | | | | | | | | |
|-------|-------|--------------------------------------------------------|--------------|-------|--------------|-------|------------------|---------------|
| 252Fh | Pn52F | Monitor display at startup | — | UINT | 0-4095 | 4095 | Set at operation | Immediately |
| 2530h | Pn530 | Program JOG type switch | — | UINT | 0-5 | 0 | Set at operation | Immediately |
| 2531h | Pn531 | Program JOG travel distance | Unit | UDINT | 1-1073741824 | 32768 | Set at operation | Immediately |
| 2533h | Pn533 | Program JOG movement velocity | rpm | UINT | 1-10000 | 500 | Set at operation | Immediately |
| 2534h | Pn534 | Program JOG acceleration/deceleration time | ms | UINT | 2~10000 | 100 | Set at operation | Immediately |
| 2535h | Pn535 | Program JOG waiting time | ms | UINT | 0-10000 | 100 | Set at operation | Immediately |
| 2536h | Pn536 | Program JOG travel count | 回 | UINT | 0-1000 | 1 | Set at operation | Immediately |
| 2560h | Pn560 | Residual vibration detection width | 0.1% | UINT | 1-3000 | 400 | Set at operation | Immediately |
| 2561h | Pn561 | Overshoot detection level | % | UINT | 0-100 | 100 | Set at operation | Immediately |
| 2562h | Pn562 | Viscous friction compensation | 0.1%/1000rpm | UINT | 0-5000 | 0 | Set at operation | Immediately |
| 2563h | Pn563 | Friction compensation percentage | 0.1% | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 2564h | Pn564 | Friction compensation smoothing constant(deceleration) | 0.1rpm | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 2565h | Pn565 | Friction compensation smoothing constant(acceleration) | 0.1rpm | UINT | 0-1000 | 0 | Set at operation | Immediately |
| 2566h | Pn566 | Friction compensation smoothing selection | — | UINT | 0~100 | 0 | Set at operation | Immediately |
| 2590h | Pn590 | DI1 input signal setting | — | UINT | 0-21503 | 4097 | Set at stop | After restart |
| 2591h | Pn591 | DI2 input signal setting | — | UINT | 0-21503 | 4098 | Set at stop | After restart |
| 2592h | Pn592 | DI3 input signal setting | — | UINT | 0-21503 | 4100 | Set at stop | After restart |
| 2593h | Pn593 | DI4 input signal setting | — | UINT | 0-21503 | 4101 | Set at stop | After restart |
| 2594h | Pn594 | DI5 input signal setting | — | UINT | 0-21503 | 4099 | Set at stop | After restart |
| 2595h | Pn595 | DI6 input signal setting | — | UINT | 0-21503 | 8193 | Set at stop | After restart |
| 2596h | Pn596 | DI7 input signal setting | — | UINT | 0-21503 | 8194 | Set at stop | After restart |
| 2597h | Pn597 | DI8 input signal setting | — | UINT | 0-21503 | 8196 | Set at stop | After restart |
| 2598h | Pn598 | DI9 input signal setting | — | UINT | 0-21503 | 8197 | Set at stop | After restart |
| 2599h | Pn599 | DI10 input signal setting | — | UINT | 0-21503 | 8195 | Set at stop | After restart |
| 259Ah | Pn59A | DI11 input signal setting | — | UINT | 0-21503 | 12289 | Set at stop | After restart |
| 259Bh | Pn59B | DI12 input signal setting | — | UINT | 0-21503 | 12290 | Set at stop | After restart |
| 259Ch | Pn59C | DI13 input signal setting | — | UINT | 0-21503 | 12292 | Set at stop | After restart |
| 259Dh | Pn59D | DI14 input signal setting | — | UINT | 0-21503 | 12293 | Set at stop | After restart |
| 259Eh | Pn59E | DI15 input signal setting | — | UINT | 0-21503 | 12291 | Set at stop | After restart |
| 259Fh | Pn59F | DI16 input signal setting | — | UINT | 0-21503 | 16385 | Set at stop | After restart |
| 25A0h | Pn5A0 | DI17 input signal setting | — | UINT | 0-21503 | 16386 | Set at stop | After restart |
| 25A1h | Pn5A1 | DI18 input signal setting | — | UINT | 0-21503 | 16388 | Set at stop | After restart |
| 25A2h | Pn5A2 | DI19 input signal setting | — | UINT | 0-21503 | 16389 | Set at stop | After restart |
| 25A3h | Pn5A3 | DI20 input signal setting | — | UINT | 0-21503 | 16387 | Set at stop | After restart |

| | | | | | | | | |
|-------|-------|------------------------------------------------------------------------|-------|------|---------|-------|---------------------|---------------|
| 25A4h | Pn5A4 | DI21 input signal setting | — | UINT | 0~21503 | 20486 | Set at stop | After restart |
| 25B0h | Pn5B0 | DO1 output signal setting | — | UINT | 0~21503 | 4100 | Set at stop | After restart |
| 25B1h | Pn5B1 | DO2 output signal setting | — | UINT | 0~21503 | 4116 | Set at stop | After restart |
| 25B2h | Pn5B2 | DO3 output signal setting | — | UINT | 0~21503 | 8196 | Set at stop | After restart |
| 25B3h | Pn5B3 | DO4 output signal setting | — | UINT | 0~21503 | 8212 | Set at stop | After restart |
| 25B4h | Pn5B4 | DO5 output signal setting | — | UINT | 0~21503 | 12292 | Set at stop | After restart |
| 25B5h | Pn5B5 | DO6 output signal setting | — | UINT | 0~21503 | 12308 | Set at stop | After restart |
| 25B6h | Pn5B6 | DO7 output signal setting | — | UINT | 0~21503 | 16388 | Set at stop | After restart |
| 25B7h | Pn5B7 | DO8 output signal setting | — | UINT | 0~21503 | 16404 | Set at stop | After restart |
| 25C0h | Pn5C0 | Total DI filter parameter (used when common IO filter time is 0) | 0.1ms | UINT | 0~5000 | 10 | Set at operation | Immediately |
| 25C1h | Pn5C1 | DI1 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25C2h | Pn5C2 | DI2 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25C3h | Pn5C3 | DI3 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25C4h | Pn5C4 | DI4 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25C5h | Pn5C5 | DI5 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25C6h | Pn5C6 | DI6 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25C7h | Pn5C7 | DI7 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25C8h | Pn5C8 | DI8 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25C9h | Pn5C9 | DI9 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25CAh | Pn5CA | DI10 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25CBh | Pn5CB | DI11 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25CCh | Pn5CC | DI12 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25CDh | Pn5CD | DI13 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25CEh | Pn5CE | DI14 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25CFh | Pn5CF | DI15 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25D0h | Pn5D0 | DI16 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25D1h | Pn5D1 | DI17 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25D2h | Pn5D2 | DI18 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25D3h | Pn5D3 | DI19 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|---------------------------------------------------------|-------------------|------|-------------------------|---|------------------|---------------|
| 25D4h | Pn5D4 | DI20 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25D5h | Pn5D5 | DI21 filter parameter | 0.1ms | UINT | 0~5000 | 0 | Set at operation | Immediately |
| 25F6h | Pn5F6 | Lifting value at BK | 0.0001rev /0.01mm | INT | -25000~25000 | 0 | Set at operation | Immediately |
| 25F7h | Pn5F7 | Maximum lifting velocity at BK | 1rpm | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 25F8h | Pn5F8 | Lifting acceleration and deceleration time at BK | 1ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 2600h | Pn600 | Brake resistance capacity * 1 | 10W | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 2601h | Pn601 | DB resistance capacity | 10W | UINT | 0~65535 | 0 | Set at stop | After restart |
| 2602h | Pn602 | Motor type selection | — | UINT | 0~256 | 0 | Set at stop | After restart |
| 2603h | Pn603 | Natural frequency of motor selection | — | UINT | 0~65535 | 0 | Set at stop | After restart |
| 2605h | Pn605 | First Encoder Configuration | — | UINT | 0~65535 | 0 | Set at stop | After restart |
| 2609h | Pn609 | Application-specific function selection switch 609 | — | UINT | 0~65535 | 0 | Set at stop | After restart |
| 260Dh | Pn60D | Alarm delay disable time | ms | UINT | 0~500 | 0 | Set at stop | After restart |
| 260Eh | Pn60E | User torque overload threshold | % | UINT | 0~65535 | 0 | Set at stop | After restart |
| 260Fh | Pn60F | User torque overload time | 10ms | UINT | 1000 | 0 | Set at stop | After restart |
| 2610h | Pn610 | Position comparison output function | — | UINT | 0~3 | 0 | Set at stop | After restart |
| 2611h | Pn611 | First set position | Unit | DINT | -1073741824 ~1073741823 | 0 | Set at operation | Immediately |
| 2613h | Pn613 | Second set position | Unit | DINT | -1073741824 ~1073741823 | 0 | Set at operation | Immediately |
| 2615h | Pn615 | Third set position | Unit | DINT | -1073741824 ~1073741823 | 0 | Set at operation | Immediately |
| 2617h | Pn617 | Fourth set position | Unit | DINT | -1073741824 ~1073741823 | 0 | Set at operation | Immediately |
| 2619h | Pn619 | Effective time of the first set position output signal | ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 261Ah | Pn61A | Effective time of the second set position output signal | ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 261Bh | Pn61B | Effective time of the third set position output signal | ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 261Ch | Pn61C | Effective time of the fourth set position output signal | ms | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 261Dh | Pn61D | Position comparison delay compensation | 0.1us | UINT | 0~625 | 0 | Set at stop | After restart |
| 261Fh | Pn61F | Application Function Selection61F | — | UINT | 0~65535 | 0 | Set at stop | After restart |

| | | | | | | | | |
|-------|-------|---------------------------------------------------------------------------------------|-------|-------|--------------|-----|------------------|---------------|
| 2630h | Pn630 | Resistance of external brake resistor | 10mΩ | UINT | 0~65535 | 0 | Set at stop | After restart |
| 2631h | Pn631 | Gravity compensation function switch | — | UINT | 0-2 | 0 | Set at operation | Immediately |
| 2640h | Pn640 | Black box function configuration | — | UINT | 0~65535 | 0 | Set at stop | After restart |
| 2641h | Pn641 | Black box latch alarm code setting | — | UINT | 0~65535 | 0 | Set at stop | After restart |
| 2645h | Pn645 | The variable trace function tracks the 16-bit variable actual address assignment | - | UDINT | 0~4294967295 | — | Set at operation | Immediately |
| 2646h | Pn646 | The variable trace function tracks the actual address assignment of a 32-bit variable | - | UDINT | 0~4294967295 | — | Set at operation | Immediately |
| 2660h | Pn660 | Current command setting | — | UINT | 0-10000 | 0 | Set at stop | After restart |
| 2661h | Pn661 | Phase angle setting | — | UINT | 0-500 | 0 | Set at stop | After restart |
| 266Fh | Pn66F | Online inertia update time | min | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 2670h | Pn670 | Online inertia identification setting | — | UINT | 0-3 | 0 | Set at stop | After restart |
| 2676h | Pn676 | Internal brake configuration | — | UINT | 0-8203 | 0 | Set at stop | After restart |
| 2678h | Pn678 | Self-adjusting rigid setting | — | UINT | 0-41 | 4 | Set at operation | Immediately |
| 2679h | Pn679 | Self-adjusting mode | — | UINT | 0-6 | 0 | Set at operation | Immediately |
| 267Ah | Pn67A | Self-adjusting vibration treatment time | s | UINT | 0~65535 | 300 | Set at operation | Immediately |
| 267Fh | Pn67F | Probe delay compensation | 0.1us | INT | -32768~32767 | 0 | Set at operation | Immediately |
| 26A8h | Pn6A8 | Manual BK control | — | UINT | 0-1 | 0 | Set at operation | Immediately |
| 26A9h | Pn6A9 | Collision detection torque | 1% | UINT | 0-300 | 0 | Set at stop | After restart |
| 26AAh | Pn6AA | Collision detection time | ms | UINT | 0~5000 | 1 | Set at stop | After restart |
| 26B0h | Pn6B0 | Advanced auto-tune one-touch control (Fn202) | — | UINT | 0-20 | 0 | Set at operation | Immediately |
| 26B1h | Pn6B1 | Advanced auto-tune one-touch control (Fn201) | — | UINT | 0-20 | 0 | Set at operation | Immediately |
| 26B2h | Pn6B2 | Travel distance of advanced automatic tuning | - | INT | -32768~32767 | 0 | Set at operation | Immediately |
| 26B3h | Pn6B3 | Advanced auto-tuning initial gain level | — | UINT | 0-5 | 2 | Set at operation | Immediately |
| 26B4h | Pn6B4 | Advanced auto-tuning initial inertia level | — | UINT | 0-3 | 2 | Set at operation | Immediately |
| 26B5h | Pn6B5 | Advanced auto-tuning initial positioning accuracy | — | UINT | 0-9 | 4 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|-------------------------------------------------------------------|-------|-------|----------------------------|---------|------------------|---------------|
| 26B6h | Pn6B6 | Percent of Advanced Autotune Gain Results Saved | 1% | UINT | 1-100 | 70 | Set at operation | Immediately |
| 26B7h | Pn6B7 | Advanced auto-tune configuration function | — | UINT | 0-4396 | 1 | Set at operation | Immediately |
| 26B8h | Pn6B8 | Advanced auto-tuning_ start of motion interval (Negative limit) | Unit | DINT | -2147483648 ~2147483647 | 0 | Set at operation | Immediately |
| 26BAh | Pn6BA | Advanced auto-tuning_ end of motion interval (Positive limit) | Unit | DINT | -2147483648 ~2147483647 | 0 | Set at operation | Immediately |
| 26C0h | Pn6C0 | Gantry function switch | — | UINT | 0~17 | 16 | Set at stop | After restart |
| 26C1h | Pn6C1 | Gantry slave shaft function switch | — | UINT | 0-17 | 0 | Set at operation | Immediately |
| 26C2h | Pn6C2 | Gantry coordinated stop mode | — | UINT | 0-2 | 0 | Set at operation | Immediately |
| 26C3h | Pn6C3 | Warning value of excessive position deviation between gantry axes | 1% | UINT | 10-100 | 100 | Set at operation | Immediately |
| 26C4h | Pn6C4 | Alarm value for excessive position deviation between gantry axes | Uint | UINT | 0-1073741823 | 1048576 | Set at operation | Immediately |
| 26C5h | Pn6C5 | Alarm value for excessive differential torque between gantry axes | 1% | UINT | 0~6000 | 1000 | Set at operation | Immediately |
| 26C6h | Pn6C6 | Gantry coordinated stop speed FF feedforward | 1% | UINT | 0-100 | 0 | Set at operation | Immediately |
| 26C7h | Pn6C7 | Proportional gain of gantry synchronous position loop | 0.1/s | UINT | 10-20000 | 400 | Set at operation | Immediately |
| 26C8h | Pn6C8 | Integral time of synchronous position loop of gantry | 0.1ms | UINT | 0-50000 | 2000 | Set at operation | Immediately |
| 26C9h | Pn6C9 | Gantry synchronous velocity limiting | 0.1% | UINT | 0-1000 | 20 | Set at operation | Immediately |
| 26CAh | Pn6CA | Differential velocity limit between gantry coordinated stop axes | rpm | UINT | 0-3000 | 300 | Set at operation | Immediately |
| 26CBh | Pn6CB | Gantry coordination stop completion speed threshold | rpm | UINT | 0-1000 | 15 | Set at operation | Immediately |
| 2776h | Pn776 | System position 31:00 upper limit L | — | UDINT | 0-4294967296 | 0 | Set at operation | Immediately |
| 2778h | Pn778 | System position 63:32 upper limit H | — | UDINT | 0-4294967296 | 0 | Set at operation | Immediately |
| 277Fh | Pn77F | Homing timeout time | 100ms | UDINT | 0~4294967295 | 10000 | Set at operation | Immediately |
| 2781h | Pn781 | Function selection switch 0 | — | UINT | 0~4369 | 0 | Set at operation | Immediately |

| | | | | | | | | |
|-------|-------|------------------------------------------------------------------|---|-------|--------------|---|------------------|---------------|
| 2785h | Pn785 | Synchronous frame error count limit | — | UDINT | 2~32767 | 9 | Set at operation | Immediately |
| 2786h | Pn786 | Node ID address setting | — | UINT | 0~65535 | 0 | Set at operation | Immediately |
| 2787h | Pn787 | Function selection switch 1 | — | UINT | 0~16 | 0 | Set at operation | Immediately |
| 2788h | Pn788 | Low 32 bits of analog-digital homing offset position | — | UDINT | 0~4294967296 | 0 | Set at operation | Immediately |
| 2789h | Pn789 | High 32 bits of analog-digital homing offset position | — | UDINT | 0~4294967296 | 0 | Set at operation | Immediately |
| 278Ah | Pn78A | Setting of upper limit value of analog-digital function position | — | UDINT | 0~4294967295 | 0 | Set at stop | After restart |
| 278Ch | Pn78C | 6091-Electronic gear ratio numerator | — | UDINT | 1~4294967295 | 1 | Set at operation | Immediately |
| 278Eh | Pn78E | 6091-Electronic gear ratio denominator | — | UDINT | 1~4294967295 | 1 | Set at operation | Immediately |
| 2790h | Pn790 | EtherCAT function conversion switch 0 | — | UINT | 0~8448 | 0 | Set at operation | Immediately |
| 2793h | Pn793 | EtherCAT function conversion switch 3 | — | UINT | 0~1 | 0 | Set at operation | Immediately |

11.4 Object dictionary 6000H group common parameter list

| Index | Sub-Index | Type | Name | Data Type | Access type | Mapping type | Unit |
|-------|-----------|------|---------------------------------------|-----------|-------------|--------------|------------------|
| 603Fh | | VAR | Error Code | UINT | ro | T | — |
| 6040h | | VAR | Control Word | UINT | rw | R | — |
| 6041h | | VAR | Status word | UINT | ro | T | — |
| 605Ah | | VAR | Selection of fast shutdown mode | INT | rw | R | — |
| 605Dh | | VAR | Selection of pause mode | INT | rw | R | — |
| 605Eh | | VAR | Fault reaction option code | INT | rw | R | — |
| 6060h | | VAR | control mode | SINT | rw | R | — |
| 6061h | | VAR | Control mode display | SINT | ro | T | — |
| 6062h | | VAR | User position command | DINT | ro | T | User Unit |
| 6063h | | VAR | Motor position feedback | DINT | ro | T | Encoder Unit |
| 6064h | | VAR | User position feedback | DINT | ro | T | User Unit |
| 6065h | | VAR | Threshold value of user position bias | UDINT | rw | R | User Unit |
| 6066h | | VAR | Position bias Time Window | UINT | rw | R | ms |
| 6067h | | VAR | Position reached threshold | UDINT | rw | R | User Unit |
| 6068h | | VAR | Position arrival time | UINT | rw | R | ms |
| 606Bh | | VAR | User velocity Command Value | DINT | ro | T | User Instruction |
| 606Ch | | VAR | User actual velocity feedback | DINT | ro | T | User Instruction |
| 606Dh | | VAR | Velocity arrival threshold | UINT | rw | R | User Instruction |
| 606Eh | | VAR | Velocity arrival time | UINT | rw | R | ms |
| 6071h | | VAR | Target torque value | INT | rw | R | 0.1% |
| 6072h | | VAR | Max. torque | UINT | rw | R | 0.1% |

| | | | | | | | |
|-------|---|-------|-------------------------------------------------------------|-------|----|---|---------------------------------|
| 6074h | | VAR | User defined torque value | INT | ro | T | 0.1% |
| 6076h | | VAR | Motor velocity torque | UDINT | ro | T | — |
| 6077h | | VAR | Actual torque feedback | INT | ro | T | 0.1% |
| 607Ah | | VAR | Target position value | DINT | rw | R | User Instruction |
| 607Ch | | VAR | Origin Offset | DINT | rw | R | User Instruction |
| 607Dh | 1 | ARRAY | Software limit: minimum position limit | DINT | rw | R | User Instruction |
| | 2 | ARRAY | Software limit: maximum position limit | DINT | rw | R | User Instruction |
| 607Eh | | VAR | Polarity of instruction | USINT | rw | R | — |
| 607Fh | | VAR | Max Contour Velocity | UDINT | rw | T | User Instruction |
| 6080h | | VAR | Maximum Motor Velocity | UDINT | rw | T | rpm |
| 6081h | | VAR | Velocity of contour | UDINT | rw | R | User Instruction/s |
| 6083h | | VAR | Acceleration of contour | UDINT | rw | R | User Instruction/s ² |
| 6084h | | VAR | Deceleration of contour | UDINT | rw | R | User Instruction/s ² |
| 6085h | | VAR | Quick Stop Deceleration | UDINT | rw | R | User Instruction/s ² |
| 6087h | | VAR | Torque Ramp | UDINT | rw | R | 0.1%/s |
| 6091h | 1 | ARRAY | Electronic gear ratio: Numerator | UDINT | rw | R | — |
| | 2 | ARRAY | Electronic gear ratio: Denominator | UDINT | rw | R | — |
| 6098h | | VAR | Homing mode | SINT | rw | R | — |
| 6099h | 1 | ARRAY | Velocity of search deceleration point signal in homing mode | UDINT | rw | R | User Instruction/s |
| | 2 | ARRAY | Velocity of search origin switch signal in homing mode | UDINT | rw | R | User Instruction/s |
| 609Ah | | VAR | Homing acceleration | UDINT | rw | R | User Instruction/s ² |
| 60B0h | | VAR | Position bias | DINT | rw | R | User Instruction |
| 60B1h | | VAR | Velocity offset | DINT | rw | R | User Instruction/s |
| 60B2h | | VAR | Torque offset | INT | rw | R | 0.1% |
| 60B8h | | VAR | Probe function | UINT | rw | R | — |
| 60B9h | | VAR | Probe status word | UINT | ro | T | — |
| 60BAh | | VAR | Probe 1 rising edge position feedback | DINT | ro | T | — |
| 60BBh | | VAR | Probe 1 falling edge position feedback | DINT | ro | T | — |
| 60BCh | | VAR | Probe 2 Rising Edge Position Feedback | DINT | ro | T | — |
| 60BDh | | VAR | Probe 2 falling edge position feedback | DINT | ro | T | — |
| 60C0h | | VAR | Interpolation sub-mode selection | INT | rw | R | — |
| 60C1h | | VAR | Interpolation data recording | UDINT | rw | R | — |
| 60C2h | 1 | ARRAY | Interpolation time period | USINT | rw | R | — |
| | 2 | ARRAY | Interpolation time point | SINT | rw | R | — |
| 60D5h | | VAR | Probe 1 rising edge count value | UINT | ro | T | — |
| 60D6h | | VAR | Probe 1 falling edge count value | UINT | ro | T | — |
| 60D7h | | VAR | Probe 2 rising edge count value | UINT | ro | T | — |
| 60D8h | | VAR | Probe 2 falling edge count value | UINT | ro | T | — |
| 60E0h | | VAR | Forward Maximum Torque Limit | UINT | rw | R | 0.1% |
| 60E1h | | VAR | Reverse Maximum Torque Limit | UINT | rw | R | 0.1% |
| 60F4h | | VAR | User position bias | DINT | ro | T | User Instruction |
| 60FCh | | VAR | Motor position command feedback | DINT | ro | T | User Instruction |
| 60FDh | | VAR | DI input status | UDINT | ro | T | — |
| 60FEh | 1 | ARRAY | DO output Status | UDINT | rw | R | — |
| | 2 | ARRAY | Bit mask | UDINT | rw | R | — |
| 60FFh | | VAR | Target velocity | DINT | rw | R | User Instruction/s |
| 6502h | | VAR | Supporting servo operation mode | UDINT | ro | T | — |

11.5 Detailed description of 6000H object dictionary

Object 213F_h: Servo Drive Internal Error Code

| Object description | | Object entry description | |
|--------------------|-------------------|--------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 213F _h | Sub-index | 00 _h |
| Name | Error Code | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Uint32 | Data range | 0~4294967295 |
| Operation mode | — | Default value | 0 |

Displays servo drive error code, consistent with the error code numeric value shown on the panel.

Object 603F_h: Error code

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 603F _h | Sub-index | 00 _h |
| Name | Error Code | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | ALL | Default value | 0 |

Displays protocol fault code.

Note: This is not the servo internal fault alarm code. For servo fault alarm codes, refer to 213F_h.

Object 6040_h: Control word

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6040 _h | Sub-index | 00 _h |
| Name | Control word | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | ALL | Default value | 0 |

Used for enabling, clearing alarms, and initiating commanded operations in various operation modes, etc.

| bit | Definition | |
|------|--------------------------|-----------------------------------------------------------------------------------|
| 0 | Servo ready | 0: invalid 1: valid |
| 1 | Main circuit power on | 0: invalid 1: valid |
| 2 | Quick stop | 0: invalid 1: valid |
| 3 | Servo operation | 0: invalid 1: valid |
| 4 | Operation mode dependent | |
| 5 | Operation mode dependent | |
| 6 | Operation mode dependent | |
| 7 | Fault rese | Rising edge valid (when this bit is set to 1, other control commands are invalid) |
| 8 | Halt | 0: invalid 1: valid |
| 9~15 | | Reserved |

Object 6041_h: Status word

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6041 _h | Sub-index | 00 _h |
| Name | Status word | Access type | ro |

| | | | |
|----------------|----------|------------------|---------|
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | ALL | Default value | 0 |

| bit | Definition | |
|-----|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Servo fault-free | 0: Invalid 1: Valid. When valid, indicates the servo can be enabled |
| 1 | Waiting for servo enable | 0: Invalid 1: Valid. When valid, indicates the servo can be enabled |
| 2 | Servo operation status | 0: Not running 1: Running. When valid, indicates the servo is enabled |
| 3 | Servo fault | 0: Fault present 1: No fault |
| 4 | Main circuit voltage on | 0: Not on 1: On. When valid, indicates the servo can be enabled |
| 5 | Quick stop | 0: Quick stop invalid 1: Quick stop valid |
| 6 | Servo disabled | 0: Invalid 1: Valid. When valid, indicates the servo cannot be enabled |
| 7 | Warning | 0: No warning 1: Warning present |
| 8 | Manufacturer-specific | Not used |
| 9 | Remote control | 0: Invalid 1: Valid. When valid, indicates the control word is active |
| 10 | Position reached | 60400010h bit8 (Halt) =0, 0: Position not reached 1: Position reached 60400010h bit8 (Halt) =1, 0: Decelerating 1: Speed is zero |
| 11 | Software internal position limit exceeded | 0: Soft limit not reached 1: Soft limit reached |
| 12 | Operation mode dependent | 0: Not following target position 1: Following target position |
| 13 | Operation mode dependent | 0: No position deviation alarm 1: Position deviation alarm occurred |
| 14 | Manufacturer-specific | Not used |
| 15 | Homing completed | 0: Invalid 1: Homing completed For absolute systems, after Pn781.3=1, the value of bit15 will be stored after successful homing (power-down retention) |

Note: Assigning values to individual bits of the status word is meaningless; they must form specific control instructions together with other bits. The following are basic status word examples (X represents any value).

| | |
|----------------------------------------------------------------------|--------------------------------------------------------------------|
| Initialization failure (not ready to switch on): XXXX XXXX X0XX 0000 | Servo start failure (switch on disable): XXXX XXXX X0XX 0000 |
| Servo ready (ready to switch on): XXXX XXXX X01X 0001 | Servo start (switch on): XXXX XXXX X01X 0011 |
| Quick stop (quick stop active): XXXX XXXX X00X 0111 | Servo operation enable (operation enable): XXXX XXXX X01X 0111 |
| Servo fault (fault): XXXX XXXX X0XX 1000 | Fault reaction active (fault reaction active): XXXX XXXX X0XX 1111 |

Object 605A_n: Quick stop mode selection

| Objects description | | Objects entry description | |
|---------------------|---------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 605A _n | Sub-index | 00 _n |
| Name | Quick stop mode selection | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint16 | Data range | 0~7 |
| Operation mode | ALL | Default value | 2 |

When bit 2 of control word 6040h is 0, the quick stop mode is determined by the setting of object 605Ah.

| Set value | Stop mode |
|-----------|-----------------------------------------------------------------------------------------------|
| 0 | Coast to stop, and remain free. |
| 1 | Ramp stop with deceleration from object 6084, and remain free. |
| 2 | Emergency ramp stop with emergency deceleration from object 6085, and remain free. |
| 3 | Maximum torque braking stop, and remain free. |
| 4 | Not defined, and cannot be set. |
| 5 | Ramp stop with deceleration from object 6084, and remain position locked. |
| 6 | Emergency ramp stop with emergency deceleration from object 6085, and remain position locked. |
| 7 | Maximum torque braking stop, and remain position locked. |

Object 605D_n: Halt mode selection

| Objects description | | Objects entry description | |
|---------------------|---------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 605D _n | Sub-index | 00 _h |
| Name | Halt mode selection | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint16 | Data range | 0~4 |
| Operation mode | ALL | Default value | 1 |

When bit 8 of the control word 6040h is active (halt function enabled), the halt behavior is determined by object 605Dh.

| Set value | Stop mode |
|-----------|-------------------------------------------------------------------------------------|
| 0 | Not supported, cannot be set. If forced to set, the halt behavior is unpredictable. |
| 1 | Decelerate using the deceleration time from object 6084h, remain position locked. |
| 2 | Decelerate using the deceleration time from object 6085h, remain position locked. |

When decelerating with 6084h: in homing mode, the deceleration time from object 609Ah is used; in torque mode, the deceleration time from object 6087h is used.

Object 605E_n: Fault reaction option code

| Objects description | | Objects entry description | |
|---------------------|----------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 605E _n | Sub-index | 00 _h |
| Name | Fault reaction option code | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint16 | Data range | 0~0 |
| Operation mode | ALL | Default value | 0 |

Fault reaction option code

Object 6060_n: Control mode

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6060 _n | Sub-index | 00 _h |
| Name | Control mode | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint8 | Data range | 0~10 |
| Operation mode | ALL | Default value | 0 |

Selects the control mode for operation.

| Value | Definition | Remarks |
|-------|----------------------------------------|----------------------------------------------|
| 0 | Reserved | Reserved |
| 1 | Profile position mode (PP) | Refer to "5.7 Profile Position Mode (PP)". |
| 2 | Velocity mode | Not supported. |
| 3 | Profile velocity mode (PV) | Refer to "5.8 Profile Position Mode (PV)". |
| 4 | Profile torque mode (PT) | Refer to "5.9 Profile Position Mode (PT)". |
| 5 | Reserved | Reserved |
| 6 | Homing mode (HM) | Refer to "5.10 Profile Position Mode (HM)". |
| 7 | Interpolated position mode (IP) | Not supported. |
| 8 | Cyclic synchronous position mode (CSP) | Refer to "5.11 Profile Position Mode (CSP) " |
| 9 | Cyclic synchronous velocity mode (CSV) | Refer to "5.12 Profile Position Mode (CSV) " |
| 10 | Cyclic synchronous torque mode (CST) | Refer to "5.13 Profile Position Mode (CST) " |

Object 6061_h: Control mode display

| Objects description | | Objects entry description | |
|---------------------|----------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6061 _h | Sub-index | 00 _h |
| Name | Control mode display | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint8 | Data range | 0~10 |
| Operation mode | ALL | Default value | 0 |

Selects the control mode for operation.

| Value | Definition | Remarks |
|-------|----------------------------------------|----------------------------------------------|
| 0 | Reserved | Reserved |
| 1 | Profile position mode (PP) | Refer to "5.7 Profile Position Mode (PP)". |
| 2 | Velocity mode | Not supported. |
| 3 | Profile velocity mode (PV) | Refer to "5.8 Profile Position Mode (PV)". |
| 4 | Profile torque mode (PT) | Refer to "5.9 Profile Position Mode (PT)". |
| 5 | Reserved | Reserved |
| 6 | Homing mode (HM) | Refer to "5.10 Profile Position Mode (HM)". |
| 7 | Interpolated position mode (IP) | Not supported. |
| 8 | Cyclic synchronous position mode (CSP) | Refer to "5.11 Profile Position Mode (CSP) " |
| 9 | Cyclic synchronous velocity mode (CSV) | Refer to "5.12 Profile Position Mode (CSV) " |
| 10 | Cyclic synchronous torque mode (CST) | Refer to "5.13 Profile Position Mode (CST) " |

Object 6062_h: User position command

| Objects description | | Objects entry description | |
|---------------------|-----------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 6062 _h | Sub-index | 00 _h |
| Name | User position command | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | PP, HM, CSP | Default value | 0 |

Reflects real-time position command (user units).

Object 6063_h: Motor position feedback

| Objects description | | Objects entry description | |
|---------------------|-------------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 6063 _h | Sub-index | 00 _h |
| Name | Motor position feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | ALL | Default value | 0 |

Reflects real-time motor absolute position feedback.

Object 6064_h: User position feedback

| Objects description | | Objects entry description | |
|---------------------|------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6064 _h | Sub-index | 00 _h |
| Name | User position feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |

| | | | |
|----------------|--------|---------------|------------------------|
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | ALL | Default value | 0 |

Reflects real-time user absolute position feedback.

Object 6065_n: User position deviation excess threshold

| Objects description | | Objects entry description | |
|---------------------|------------------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6065 _n | Sub-index | 00 _n |
| Name | User position deviation excess threshold | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | PP/CSP/HM | Default value | 0 |

When the difference between the user position command (from object 6062h) and the user position feedback (from object 6064h) exceeds $\pm 6065h$, an excessive position deviation fault occurs.

Object 6066_n: Position bias time window

| Objects description | | Objects entry description | |
|---------------------|---------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6066 _n | Sub-index | 00 _n |
| Name | Position bias time window | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0-65535 |
| Operation mode | PP/CSP/HM | Default value | 0 |

Position bias time window

Object 6067_n: Position arrival threshold

| Objects description | | Objects entry description | |
|---------------------|----------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6067 _n | Sub-index | 00 _n |
| Name | Position arrival threshold | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | PP/CSP/HM | Default value | 50 |

When the difference between the user position command (from object 6062h) and the user actual position feedback (from object 6064h) is within $\pm 6067h$ and the duration reaches 6068h, position arrival is recognized. In profile position mode, bit 10 of status word 6041h is set to 1. This flag is valid only when servo enable is active in profile position mode, otherwise it is invalid.

Object 6068_n: Position arrival time

| Objects description | | Objects entry description | |
|---------------------|-----------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6068 _n | Sub-index | 00 _n |
| Name | Position arrival time | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | PP/CSP/HM | Default value | 0 |

When the difference between the user position command (from object 6062h) and the user actual position feedback (from object 6064h) is within $\pm 6067h$ and the duration reaches 6068h, position arrival is recognized. In profile position mode, bit 10 of status word 6041h is set to 1. This flag is valid only when servo enable is active in profile position mode, otherwise it is invalid.

Object 606B_n: User velocity command value

| Objects description | | Objects entry description | |
|---------------------|-----------------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 606B _n | Sub-index | 00 _h |
| Name | User velocity command value | Access type | ro |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | ALL | Default value | 0 |

Reflect user velocity command value

Object 606C_n: User actual speed feedback

| Objects description | | Objects entry description | |
|---------------------|----------------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 606C _n | Sub-index | 00 _h |
| Name | User actual speed feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | ALL | Default value | 0 |

Reflects the user actual speed feedback value.

Object 606D_n: Speed arrival threshold

| Objects description | | Objects entry description | |
|---------------------|-------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 606D _n | Sub-index | 00 _h |
| Name | Speed arrival threshold | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | PV/CSV | Default value | 0 |

When the difference between the target speed (from object 60FFh) and the user actual speed (from object 606Ch) is within $\pm 606Dh$ and the duration reaches 606Eh, speed arrival is recognized. In profile velocity mode, bit 10 of status word 6041h is set to 1.

This flag is valid only when servo enable is active in profile velocity mode, otherwise it is invalid.

Object 606E_n: Speed arrival time

| Objects description | | Objects entry description | |
|---------------------|--------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 606E _n | Sub-index | 00 _h |
| Name | Speed arrival time | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | PV/CSV | Default value | 0 |

When the difference between the target speed (from object 60FFh) and the user actual speed (from object 606Ch) is within $\pm 606Dh$ and the duration reaches 606Eh, speed arrival is recognized. In profile velocity mode, bit 10 of status word 6041h is set to 1.

This flag is only valid when servo enable is active in profile velocity mode, otherwise it has no meaning.

Object 6071_n: Torque target value

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6071 _n | Sub-index | 00 _h |

| | | | |
|----------------|---------------------|------------------|--------------|
| Name | Torque target value | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint16 | Data range | -32768~32767 |
| Operation mode | PT/CST | Default value | 0 |

Torque reference in PT/CST mode, unit 0.1%.

100% corresponds to 1 times the motor rated torque.

Object 6072_h: Maximum torque

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6072 _h | Sub-index | 00 _h |
| Name | Maximum torque | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | ALL | Default value | 8000 |

Maximum torque command, unit 0.1%.

Sets the maximum torque of the motor.

Object 6074_h: User defined torque value

| Objects description | | Objects entry description | |
|---------------------|---------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6074 _h | Sub-index | 00 _h |
| Name | User defined torque value | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint16 | Data range | -32768~32767 |
| Operation mode | ALL | Default value | 0 |

Reflect the real-time user given torque value; 100% corresponds to 1 times the motor rated torque.

Object 6076_h: Motor velocity torque

| Objects description | | Objects entry description | |
|---------------------|-----------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6076 _h | Sub-index | 00 _h |
| Name | Motor velocity torque | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | ALL | Default value | 0 |

Motor velocity torque

Object 6077_h: Actual torque feedback

| Objects description | | Objects entry description | |
|---------------------|------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6077 _h | Sub-index | 00 _h |
| Name | Actual torque feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint16 | Data range | -32768~32767 |
| Operation mode | ALL | Default value | 0 |

Reflects real-time servo internal torque feedback. 100% corresponds to 1 times the motor rated torque.

Object 607A_n: Target positionValue

| Objects description | | Objects entry description | |
|---------------------|----------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 607A _n | Sub-index | 00 _h |
| Signal | Target positionValue | Access | rw |
| Data structure | Variable | PDO mapping type | RxPDO |
| Data type | Sint32 | Data range | -2147483648~2147483647 |
| Control mode | PP/CSP | Default value | 0 |

Sets the servo target position in profile position mode and cyclic synchronous position mode;

When using absolute commands, after positioning is complete, the user absolute position (from object 6064h) equals 607Ah.

When using relative commands, after positioning is complete, the user displacement increment (from object 607Ah) equals 607Ah.

Object 607C_n: Home offset

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 607C _n | Sub-index | 00 _h |
| Name | Home offset | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | HM | Default value | 0 |

After homing is complete, the motor stops at the mechanical home position. By configuring object 607Ch, the relationship between the mechanical home and mechanical zero point is defined as: Mechanical Home = Mechanical Zero Point + 607Ch (Home Offset). When 607Ch = 0, the mechanical home coincides with the mechanical zero point.

The home offset takes effect under these conditions: the drive is powered and running, homing has been completed, and bit 15 of status word 6041h is set to 1.

In homing mode, the host controller first selects the homing method (object 6098h), configures homing speeds (objects 6099-1h and 6099-2h), and sets homing acceleration (object 609Ah). After sending the homing trigger signal, the servo automatically locates the mechanical home per the settings and establishes the relative position between the mechanical home and the mechanical zero point. The servo drive internally manages position, speed, and torque control.

Alternatively, using homing method 35, the current position can be defined as the mechanical home. After triggering homing (control word 6040h: 0x0F → 0x1F), the user current position (from object 6064h) equals 607Ch (Note: the motor shaft does not physically rotate).

Mechanical home: A fixed physical position on the machine (e.g., aligned with home switches, limit switches, or motor Z signals). Mechanical Zero Point: The absolute zero position on the machine (e.g., encoder zero reference).

Object 607D_n: Software limit

| Objects description | | Objects entry description | |
|---------------------|--------------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 607D _n | Sub-index | 00 _h |
| Name | Number of software limit sub-indexes | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint8 | Data range | 0~512 |
| Operation mode | ALL | Default value | 2 |

| Objects description | | Objects entry description | |
|---------------------|--|---------------------------|--|
|---------------------|--|---------------------------|--|

| Attribute | Value | Attribute | Value |
|----------------|---------------------------------|------------------|------------------------|
| Index | 607D _n | Sub-index | 01 _h |
| Name | Minimum software position limit | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | ALL | Default value | -2147483648 |

Software limit function:

Pn781 Bit 0 is the software limit switch:

0: Software limits are disabled;

1: The software limit function is enabled when the drive is powered on;

This parameter sets the minimum software absolute position limit. When this parameter is set to -2147483648, it indicates no negative direction limit. The minimum software absolute position limit equals (object 607D-01h).

| Objects description | | Objects entry description | |
|---------------------|---------------------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 607D _n | Sub-index | 02 _h |
| Name | Maximum software position limit | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | ALL | Default value | -2147483648 |

Software limit function:

Pn781 Bit 0 is the software limit switch:

0: Software limits disabled;

1: The software limit function is enabled when the drive powers up;

This parameter sets the maximum software absolute position limit. When set to 2147483647, it indicates no positive direction limit. The maximum software absolute position limit equals (object 607D-02h).

Object 607E_n: Polarity of commands

| Objects description | | Objects entry description | |
|---------------------|----------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 607E _n | Sub-index | 00 _h |
| Name | Polarity of commands | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint8 | Data range | 0~255 |
| Operation mode | ALL | Default value | 0 |

Set the polarity for torque commands, torque feedback, position commands, position feedback, speed commands, speed feedback, and the external limit signal bits (bit1 (POT) of object 60FDh-00h, bit2 (NOT) of object 60FDh-01h). These settings only take effect after the servo state machine transitions back through the Init-PreOP-SafeOP-OP sequence to state 0.

During operation, the speed, position, and torque polarities must be set to 0 (with Bits 5-7 all 0) or 224 (with Bits 5-7 all 1).

| Bit | Definition |
|-----|-----------------------------------------------------------------------------------------------------------------------------|
| 0 | Reserved |
| 1 | Reserved |
| 2 | Reserved |
| 3 | Reserved |
| 4 | Reserved |
| 5 | Multiplies torque command 6071h/60B2h × (-1) and torque feedback 6074h/6077h × (-1), reversing motor rotation direction |
| 6 | Multiplies speed command 60FFh/60B1h × (-1) and speed feedback 606Bh/606Bh × (-1), reversing motor rotation direction |
| 7 | Multiplies position command 607Ah/60B0h × (-1) and position feedback 6062h/6064h × (-1), reversing motor rotation direction |

Object 607F_n: Maximum profile speed

| Objects description | | Objects entry description | |
|---------------------|-----------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 607F _n | Sub-index | 00 _h |
| Name | Maximum profile speed | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | ALL | Default value | 2147483647 |

Sets the maximum user operating speed, primarily serving as a protective limit.

Object 6080_n: Maximum motor speed

| Objects description | | Objects entry description | |
|---------------------|---------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6080 _n | Sub-index | 00 _h |
| Name | Maximum motor speed | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | ALL | Default value | 10000 |

Sets the maximum motor operating speed to protect the motor, and also serves as the maximum speed limit in CST mode.

Object 6081_n: Profile speed

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6081 _n | Sub-index | 00 _h |
| Name | Profile speed | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | PP | Default value | 0 |

Speed during constant velocity operation of displacement commands in profile position mode.

Object 6083_n: Profile acceleration

| Objects description | | Objects entry description | |
|---------------------|----------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6083 _n | Sub-index | 00 _h |
| Name | Profile acceleration | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | PP/PV | Default value | 10485760 |

User command units/S²

Object 6084_n: Profile deceleration

| Objects description | | Objects entry description | |
|---------------------|----------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6084 _n | Sub-index | 00 _h |
| Name | Profile deceleration | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |

| | | | |
|-----------------------------------|---------------|---------------|----------|
| Operation mode | PP/PV/CSP/CSV | Default value | 10485760 |
| User command units/S ² | | | |

Object 6085_h: Quick stop deceleration

| Objects description | | Objects entry description | |
|---------------------|-------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6085 _h | Sub-index | 00 _h |
| Name | Quick stop deceleration | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | PP/PV/CSP/CSV | Default value | 10485760 |

User command units/S²

Object 6087_h: Torque ramp

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6087 _h | Sub-index | 00 _h |
| Name | Torque ramp | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | PT/CST | Default value | 1000 |

Torque command acceleration in profile torque mode, defined as the incremental torque command per second (unit: 1‰/s).

Object 6091_h: Electronic gear ratio

| Objects description | | Objects entry description | |
|---------------------|-----------------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6091 _h | Sub-index | 00 _h |
| Name | Number of electronic gear ratio indexes | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint8 | Data range | 0~512 |
| Operation mode | ALL | Default value | 2 |

| Attribute | Value | Attribute | Value |
|----------------|----------------------------------|------------------|-----------------|
| Index | 6091 _h | Sub-index | 01 _h |
| Name | Electronic gear ratio: Numerator | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 1-4294967295 |
| Operation mode | ALL | Default value | 1 |

| Attribute | Value | Attribute | Value |
|----------------|------------------------------------|------------------|-----------------|
| Index | 6091 _h | Sub-index | 02 _h |
| Name | Electronic gear ratio: Denominator | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 1-4294967295 |
| Operation mode | ALL | Default value | 1 |

Servo electronic gear ratio= object 6091h=object 6091h: 01 (motor revolutions) / object 6091h: 02 (drive shaft revolutions)

Object 6098_n: Homing mode

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6098 _n | Sub-index | 00 _h |
| Name | Homing mode | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint8 | Data range | 0~35 |
| Operation mode | Hm | Default value | 0 |

In the CANopen protocol, 31 homing methods are defined based on home switch signals, limit switch signals, and encoder Z signals.

Object 6099_n: Homing speed

| Objects description | | Objects entry description | |
|---------------------|-----------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6099 _n | Sub-index | 01 _h |
| Name | Number of sub-indexes | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | HM | Default value | 1048576 |

| Attribute | Value | Attribute | Value |
|----------------|---------------------------------------------------------------|------------------|-----------------|
| Index | 6099 _n | Sub-index: | 02 _h |
| Name | Search for deceleration point signal speed during homing mode | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | HM | Default value | 1048576 |

| Attribute | Value | Attribute | Value |
|----------------|--------------------------------------------------------|------------------|-----------------|
| Index | 6099 _n | Sub-index: | 02 _h |
| Name | Search for home switch signal speed during homing mode | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | HM | Default value | 524288 |

Object 609A_n: Homing acceleration

| Objects description | | Objects entry description | |
|---------------------|---------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 609A _n | Sub-index | 00 _h |
| Name | Homing acceleration | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | HM | Default value | 10485760 |

User command units/S²

Object 60B0_n: Position offset

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 60B0 _n | Sub-index | 00 _n |
| Name | Position offset | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | CSP | Default value | 0 |

Sets the position offset in Cyclic Synchronous Position Mode. Servo target position = 607Ah + 60B0h.

Object 60B1_n: Speed offset

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 60B1 _n | Sub-index | 00 _n |
| Name | Speed offset | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | CSP/CSV | Default value | 0 |

Sets the speed offset in Cyclic Synchronous Velocity Mode. Servo target speed = (object 60FFh + object 60B1h).

Object 60B2_n: Torque offset

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60B2 _n | Sub-index | 00 _n |
| Name | Torque offset | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint16 | Data range | -32768~32767 |
| Operation mode | CSP/CSV/CST | Default value | 0 |

Sets the torque offset in Cyclic Synchronous Torque Mode. Servo target torque = (object 6071h + object 60B2h).

Object 60B8_n: Probe function

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60B8 _n | Sub-index | 00 _h |
| Name | Probe function | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | — | Default value | 0 |

| Bit | Definition |
|-----|------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Probe 1 enable 0: Disable Probe 1 function. 1: Enable Probe 1 function. |
| 1 | Probe 1 trigger mode 0: Single trigger 1: Continuous trigger |
| 2 | Probe 1 trigger signal selection 0: DI4 trigger 1: Z signal trigger |
| 3 | Reserved |
| 4 | Probe 1 rising edge latch 0: Rising edge latching not executed for Probe 1. 1: Rising edge latching executed for Probe 1. |
| 5 | Probe 1 falling edge latch 0: Falling edge latching not executed for Probe 1. 1: Falling edge latching executed for Probe 1. |
| 6 | Reserved |
| 7 | Reserved |
| 8 | Probe 2 enable 0: Disable Probe 2 function. 1: Enable Probe 2 function. |
| 9 | Probe 2 trigger mode 0: Single trigger 1: Continuous trigger |
| 10 | Probe 2 trigger signal selection 0: DI4 trigger 1: Z signal trigger |
| 11 | Reserved |
| 12 | Probe 2 rising edge latch 0: Rising edge latching not executed for Probe 2. 1: Rising edge latching executed for Probe 2. |
| 13 | Probe 2 falling edge latch 0: Falling edge latching not executed for Probe 2. 1: Falling edge latching executed for Probe 2. |
| 14 | Reserved |
| 15 | Reserved |

Object 60B9_h: Probe status word

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60B9 _h | Sub-index | 00 _h |
| Name | Probe status word | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | — | Default value | 0 |

| Bit | Description |
|-----|------------------------------------------------------------------------------------------------------------------------------------|
| 0 | Probe 1 enable 0: Disable Probe 1 function. 1: Enable Probe 1 function. |
| 1 | Probe 1 rising edge latch 0: Rising edge latching not executed for Probe 1. 1: Rising edge latching executed for Probe 1. |
| 2 | Probe 1 falling edge latch 0: Falling edge latching not executed for Probe 1. 1: Falling edge latching executed for Probe 1. |
| 3 | Reserved |
| 4 | Reserved |
| 5 | Reserved |
| 6 | Probe 1 trigger signal selection 0: DI4 trigger 1: Z signal trigger |
| 7 | Probe 1 trigger DI level selection 0: DI4 low level trigger 1: DI4 high level trigger |
| 8 | Probe 2 enable 0: Disable Probe 2 function. 1: Enable Probe 2 function. |
| 9 | Probe 2 rising edge latch 0: Rising edge latching not executed for Probe 2. 1: Rising edge latching executed for Probe 2. |
| 10 | Probe 2 falling edge latch 0: Falling edge latching not executed for Probe 2. 1: Falling edge latching executed for Probe 2. |
| 11 | Reserved |
| 12 | Reserved |
| 13 | Reserved |
| 14 | Probe 2 trigger signal selection 0: DI5 trigger 1: Z signal trigger |
| 15 | Probe 2 trigger DI level selection 0: DI5 low level trigger 1: DI5 high level trigger |

Object 60BA_h: Probe 1 rising edge position feedback

| Objects description | | Objects entry description | |
|---------------------|---------------------------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 60BA _h | Sub-index | 00 _h |
| Name | Probe 1 rising edge position feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | — | Default value | 0 |

Records the position feedback (command units, 6064h) when Probe 1 rising edge is active.

Object 60BB_h: Probe 1 falling edge position feedback

| Objects description | | Objects entry description | |
|---------------------|-------|---------------------------|-------|
| Attribute | Value | Attribute | Value |

| | | | |
|----------------|----------------------------------------|------------------|------------------------|
| Index | 60BB _n | Sub-index | 00 _h |
| Name | Probe 1 falling edge position feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | — | Default value | 0 |

Records the position feedback (command units, 6064h) when Probe 1 falling edge is active.

Object 60BC_n: Probe 2 rising edge position feedback

| Objects description | | Objects entry description | |
|---------------------|---------------------------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 60BC _n | Sub-index | 00 _h |
| Name | Probe 2 rising edge position feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | — | Default value | 0 |

Records the position feedback (command units, 6064h) when Probe 2 rising edge is active.

Object 60BD_n: Probe 2 falling edge position feedback

| Objects description | | Objects entry description | |
|---------------------|----------------------------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 60BD _n | Sub-index | 00 _h |
| Name | Probe 2 falling edge position feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | — | Default value | 0 |

Records the position feedback (command units, 6064h) when Probe 2 falling edge is active.

Object 60C0_n: Interpolation sub-mode selection

| Objects description | | Objects entry description | |
|---------------------|----------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60C0 _n | Sub-index | 00 _h |
| Name | Interpolation sub-mode selection | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint16 | Data range | -3~0 |
| Operation mode | — | Default value | 0 |

Interpolation sub-mode selection

Object 60C1_n: Interpolation data recording

| Objects description | | Objects entry description | |
|---------------------|------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60C1 _n | Sub-index | 00 _h |
| Name | Interpolation data recording | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0~4294967295 |

| | | | |
|----------------|---|---------------|---|
| Operation mode | — | Default value | 0 |
|----------------|---|---------------|---|

Interpolation data recording

Object 60C2_n: Interpolation time period

| Objects description | | Objects entry description | |
|---------------------|---------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60C2 _n | Sub-index | 01 _h |
| Name | Interpolation time period | Access type | rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | UInt8 | Data range | 1~250 |
| Operation mode | — | Default value | 125 |

Interpolation time period

| Objects description | | Objects entry description | |
|---------------------|--------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60C2 _n | Sub-index | 02 _h |
| Name | Interpolation time point | Access type | rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Sint8 | Data range | -6~-3 |
| Operation mode | — | Default value | -3 |

Interpolation time point

Object 60D5_n: Probe 1 rising edge count value

| Objects description | | Objects entry description | |
|---------------------|---------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60D5 _n | Sub-index | 00 _h |
| Name | Probe 1 rising edge count value | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | UInt16 | Data range | 0~65535 |
| Operation mode | — | Default value | 0 |

Probe 1 rising edge count value

Object 60D6_n: Probe 1 falling edge count value

| Objects description | | Objects entry description | |
|---------------------|----------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60D6 _n | Sub-index | 00 _h |
| Name | Probe 1 falling edge count value | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | UInt16 | Data range | 0~65535 |
| Operation mode | — | Default value | 0 |

Probe 1 falling edge count value

Object 60D7_n: Probe 2 rising edge count value

| Objects description | | Objects entry description | |
|---------------------|---------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60D7 _n | Sub-index | 00 _h |
| Name | Probe 2 rising edge count value | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |

| | | | |
|----------------|--------|---------------|---------|
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | — | Default value | 0 |

Probe 2 rising edge count value

Object 60D8_n: Probe 2 falling edge count value

| Objects description | | Objects entry description | |
|---------------------|----------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60D8 _n | Sub-index | 00 _n |
| Name | Probe 2 falling edge count value | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | — | Default value | 0 |

Probe 2 falling edge count value

Object 60E0_n: Forward maximum torque limit

| Objects description | | Objects entry description | |
|---------------------|------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60E0 _n | Sub-index | 00 _n |
| Name | Forward maximum torque limit | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | ALL | Default value | 8000 |

Limits the servo's forward maximum torque, unit: 0.1%.

Object 60E1_n: Negative maximum torque limit

| Objects description | | Objects entry description | |
|---------------------|-------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60E1 _n | Sub-index | 00 _n |
| Name | Negative maximum torque limit | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Uint16 | Data range | 0~65535 |
| Operation mode | ALL | Default value | 8000 |

Limits the servo's negative maximum torque, unit: 0.1%.

Object 60F4_n: User position bias

| Objects description | | Objects entry description | |
|---------------------|--------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 60F4 _n | Sub-index | 00 _n |
| Name | User position bias | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | PP/HM/CSP | Default value | 0 |

Reflects real-time position bias (user position units).

Object 60FC_n: Motor position command feedback

| Objects description | | Objects entry description | |
|---------------------|-------|---------------------------|-------|
| Attribute | Value | Attribute | Value |

| | | | |
|----------------|---------------------------------|------------------|------------------------|
| Index | 60FC _n | Sub-index | 00 _h |
| Name | Motor position command feedback | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | PP/HM/CSP | Default value | 0 |

Reflects real-time motor position command.

User position command (object 6062h) × Position Factor (object 6093h) = Motor position command (object 60FC_h, encoder units)

Object 60FD_n: DI input status

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60FD _n | Sub-index | 00 _h |
| Name | DI input status | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | ALL | Default value | 00000000 |

Displays DI input status.

| Bit | Definition |
|-------|-----------------------------------------------------------------------------------------|
| 0 | Negative limit switch (drive's DI pin 43, defaults to 0 when no input level is applied) |
| 1 | Positive limit switch (drive's DI pin 42, defaults to 0 when no input level is applied) |
| 2 | Home switch (drive's DI pin 40, defaults to 0 when no input level is applied) |
| 3~9 | Reserved (defaults to low level, value 0) |
| 10 | Z pulse (no configuration required) |
| 11 | Probe 1 (default value: 1) |
| 12 | Probe 2 (default value: 1) |
| 13 | Reserved (defaults to low level, value 0) |
| 14 | Reserved (defaults to low level, value 0) |
| 15 | Reserved (defaults to low level, value 0) |
| 16 | DI0 (default value: 1) |
| 17 | DI1 (default value: 1) |
| 18 | DI2 (default value: 1) |
| 19 | DI3 (default value: 1) |
| 20 | DI4 (default value: 1) |
| 21 | DI5 (default value: 1) |
| 22 | DI6 (default value: 1) |
| 23 | Reserved (defaults to low level, value 0) |
| 24 | Reserved (defaults to low level, value 0) |
| 25~30 | Reserved (defaults to low level, value 0) |

Object 60FE_n: Force DO output

| Objects description | | Objects entry description | |
|---------------------|------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 60FE _n | Sub-index: | 01 _h |
| Name | Force DO output status | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |
| Operation mode | ALL | Default value | 0 |

| Attribute | Value | Attribute | Value |
|----------------|-------------------|------------------|-----------------|
| Index | 60FE _n | Sub-index: | 02 _h |
| Name | Bit mask | Access type | Rw |
| Data structure | / | PDO Mapping type | RxPDO |
| Data Type | Uint32 | Data range | 0-4294967295 |

K

• Parameter List

| | | | |
|----------------|-----|---------------|---|
| Operation mode | ALL | Default value | 0 |
|----------------|-----|---------------|---|

This function forces DO output (EtherCAT servos currently provide only 4 DO outputs).

| Bit | Definition |
|-------|----------------------------------|
| 0 | 0: DO0 not output; 1: DO0 output |
| 1 | 0: DO1 not output; 1: DO1 output |
| 2 | 0: DO2 not output; 1: DO2 output |
| 3 | 0: DO3 not output; 1: DO3 output |
| 4~15 | Reserved |
| 16~24 | Reserved |

Object 60FF_n: Target speed

| Objects description | | Objects entry description | |
|---------------------|-------------------|---------------------------|------------------------|
| Attribute | Value | Attribute | Value |
| Index | 60FF _n | Sub-index | 00 _h |
| Name | Target speed | Access type | rw |
| Data structure | Variable | PDO Mapping type | RxPDO |
| Data Type | Sint32 | Data range | -2147483648~2147483647 |
| Operation mode | PV/CSV | Default value | 0 |

Sets the user speed command in Profile Velocity/Cyclic Synchronous Velocity Mode.

Object 6502_n: Supported servo operation modes

| Objects description | | Objects entry description | |
|---------------------|---------------------------------|---------------------------|-----------------|
| Attribute | Value | Attribute | Value |
| Index | 6502 _n | Sub-index | 00 _h |
| Name | Supported servo operation modes | Access type | ro |
| Data structure | Variable | PDO Mapping type | TxPDO |
| Data Type | Uint32 | Data range | 0~4294967295 |
| Operation mode | ALL | Default value | 941 |

Displays the servo operation modes supported by the drive.

| bit | Definition | Remarks |
|-------|----------------------------------------|---------------|
| 0 | Profile position mode (PP) | |
| 1 | Velocity mode | Not supported |
| 2 | Profile velocity mode (PV) | |
| 3 | Profile torque mode (PT) | |
| 4 | Reserved | |
| 5 | Homing mode (HM) | |
| 6 | Interpolated position mode (IP) | Not supported |
| 7 | Cyclic synchronous position mode (CSP) | |
| 8 | Cyclic synchronous velocity mode (CSV) | |
| 9 | Cyclic synchronous torque mode (CST) | |
| 10~31 | Reserved | |

Chapter 12 Application examples

| | |
|---------------------------------------------------------|-----|
| 12.1 Connection example with HCFA Q series..... | 342 |
| 12.1.1 Project creation | 342 |
| 12.1.2 Host communication settings..... | 343 |
| 12.1.3 Project editing..... | 344 |
| 12.1.4 Trial operation | 349 |
| 12.2 Connection example with Omron PLC NJ-501-1300..... | 350 |
| 12.2.1 Connecting to Omron PLC..... | 350 |
| 12.2.2 Adding HCFA servo drive..... | 352 |
| 12.2.3 Setting EtherCAT related parameters..... | 353 |
| 12.2.4 Trial operation..... | 358 |
| 12.3 Connection example with Beckhoff PLC CX5130..... | 361 |
| 12.3.1 Creating connection..... | 361 |
| 12.3.2 Setting EtherCAT related parameters..... | 366 |

12.1 Connection example with HCFA Q series

12.1.1 Project creation

1. Open the HCP Work3 software and click [New Project].




Figure 12-1 New project

2. This example uses the Q5P PLC, so select HCQ5P-1500. The default language is Structured Text (ST). After editing the name and selecting the storage location, click [OK].




Figure 12-2 Project details

12.1.2 Host communication settings

1. The default IP address of HCQ5P-1500 PORT1 is 192.168.188.100, and the default IP address of PORT2 is 192.168.88.100. This experiment uses PORT2. Open Ethernet settings, click [Properties] → [Internet Protocol Version 4 (TCP/IPv4)] → modify the host PC IP address so that it is on the same subnet as the Q5P-1500 IP address (the IP address set here must not be exactly the same as the IP address of Q5P-1500), and finally click [OK].



Figure 12-3 Project details

2. Double-click [Device]. After the page pops up, click [Scan Network]. After the controller network selection pops up, select the PLC to be used and click [OK].




Figure 12-4 Network connection

12.1.3 Project editing

1. Check whether an XML file matching the drive version exists in the device repository. If not, it needs to be added manually.




Figure 12-5 Adding XML

2. Return to the software, right-click [EtherCAT_Master_Softmotion] and select [Add Device].




Figure 12-6 Add device

3. Select HCFA_SV730W. In the pop-up page, select [HCFA_SV730W_4Axis] and click [Add Device].




Figure 12-7 Select [HCFA_SV730W_4Axis]

4. To observe parameters in CoE, double-click [HCFA_SV730W_4Axis] and check [Expert Settings].




Figure 12-8 Observing parameters in CoE

5. Right-click [HCFA_SV730W_4Axis] and select [Add SoftMotion CiA402 Axis] (add 4 times).




Figure 12-9 Adding SoftMotion CiA402 axis

6. To make axes easier to understand and correspond, they can be renamed.




Figure 12-10 Rename

7. Double-click to open [axis1]. In increments, enter [8388608], which means one motor revolution corresponds to 8,388,608 pulses. In units in application, enter [60], which means one motor revolution corresponds to a load movement of 60 units. (Same setting applies to other axes.)




Figure 12-11 Scaling configuration

8. Double-click [EtherCAT_Master_SoftMotion]. In the pop-up page, click [Browse]. In the next pop-up page, select the MAC address named [port3] and click [OK].




Figure 12-12 Network configuration selection

9. Go to the menu bar, right-click MainTask, and select [Delete].




Figure 12-13 Deleting Main Task

10. Go to the menu bar, under task configuration, right-click EtherCAT(POU) under EtherCAT_Port3, and select [Delete].




Figure 12-14 Deleting EtherCAT POU

11. Left-click and drag PLC_PRG (PRG) under Application to EtherCAT_Port3





Figure 12-15 Moving PLC_PRG (PRG)

12.1.4 Trial operation

1. After writing the relevant code, compile, log in, and click the relevant enable module.



2. After completing the corresponding operations, the corresponding motor movements can be observed.

12.2 Connection example with Omron PLC NJ-501-1300

12.2.1 Connecting to Omron PLC

1. PLC connection includes USB connection and network connection. When using USB connection, select "USB Direct Connection" → Connect.




Figure 12-16 USB connection of PLC

2. When the PLC is connected via network (EtherCAT port): Set the computer IP address to the same subnet as the PLC. Go to Computer → Local Connection → Properties → Internet Protocol Version 4 (TCP/IPv4) Properties → Use the following IP address, as shown in the figure below: The default is 192.168.250.X (X is a value from 2 to 255; the factory default address of the Omron CPU is 192.168.250.1).



3. Open the Sysmac Studio software, select "Connect to Device" → select "Ethernet-Hub Connection" as the connection type → enter the IP address in "Connection Settings": 192.168.250.1 → finally click "Connect" to enter the PLC programming page.




Figure 12-17 Connecting to PLC

12.2.2 Adding HCFA servo drive

1. Add the HCFA 730W EtherCAT servo drive XML file: Expand "Configuration and Setup" → double-click "EtherCAT" → right-click and select "Master Device" → display ESI library and open "This Folder" → copy the HCFA 730W EtherCAT XML file into this folder. Restart Sysmac Studio to make the 730W EtherCAT XML file effective.

Note: The XML file of the HCFA 730W is continuously maintained and updated without prior notice to users.








Figure 12-18 Installing the 730W XML file

12.2.3 Setting EtherCAT related parameters

1. Add the 730W slave station (the PLC must be online): After reconnecting the PLC, expand "Configuration and Setup" → double-click "EtherCAT" → right-click and select "Master Device" → Compare and merge with physical network configuration → an error message "Node address out of range" appears → click "Show dialog for writing slave node address" → the "Writing slave node address" dialog pops up → write node address "1" → click "Write" → then disconnect the power of the 730W servo → power on the 730W servo again. The node address is successfully written.







Figure 12-19 Adding 730W

3. Click Node 4–Servo Driver and drag the corresponding options under the input keyword into the module (4 groups).




Figure 12-20 Configuring node

4. Adding a motion axis (PLC needs to be offline): Main menu "Controller" → Offline → Expand "Motion Control Settings" → Axis Settings → Add "Motion Control Axis". (4 groups)




Figure 12-21 Adding motion control axis

5. Setting motion control axis parameters

(1) Adding a servo axis: On the axis basic settings page, set the axis type to Servo Axis. Configure "Output Device 1" as Slot 0 (M1) (corresponding to the first axis). Configure the other three axes in the same way. The configuration is shown in the figure below:




Figure 12-22 Adding servo axis

(2) Mapping motion control axis PDO parameters:

The 730W servo drive must have PDO parameters configured manually. Double-click MC_Axis000 (0) to enter the axis basic settings page → Click Detailed Settings → Configure the relevant parameters for Output (Controller to Device), Input (Controller to Device), and Digital Input respectively. An example is shown below (the other three axes are configured in the same way).




Figure 12-23 Mapping motion axis PDO parameters

Note: Due to limitations in the Omron background configuration, all 730W servo axis configurations need to be completed manually.

(3) Unit conversion settings:

On the MC_Axis000 (0) page → go to the unit conversion settings page → set the appropriate parameters. An example is shown below:

Work travel per motor revolution: Currently, HCFA commonly uses a 23-bit resolution encoder, so it should be set to 8388608.

Command per motor revolution: Can be set according to requirements. Command per motor revolution = 8388608 means that 60 command units correspond to one motor revolution.




Figure 12-24 Unit conversion

(4) Set appropriate speed, acceleration, and deceleration.




Figure 12-25 Setting speed

(5) Select the required homing mode, homing speed, and other parameters.




Figure 12-26 Selecting homing mode

12.2.4 Trial operation

1. Write the relevant program. In this example, a JOG test program is used.




Figure 12-27 Adding program

(1) Write the JOG test program.




Figure 12-28 Writing the JOG test program

(2) Add the corresponding program name in the task settings.





Figure 12-29 Adding program name

2. Compile, go online, and synchronize to the PLC.



Figure 12-30 Online, compile, synchronize

Click Transfer to Controller.






Figure 12-31 Transfer to controller

3. After enabling, JOG can be used to see the motor complete the corresponding rotation.




Figure 12-32 Operation

12.3 Connection example with Beckhoff PLC CX5130

12.3.1 Creating connection

1. Place the 730W XML file in the TwinCAT3 root directory: C:\TwinCAT\3.1\Config\Io\EtherCAT. Right-click the TwinCAT3 icon in the bottom right corner, select System → Config to switch the TwinCAT3 state to ensure that the description file is updated successfully.





Figure 12-33 Storing the description file

2. Create a new TwinCAT3 solution

After completing the connection between the PC (or Beckhoff controller/industrial PC) and the 730W servo drive, click the TwinCAT3 icon and select TwinCAT XAE. After opening the TwinCAT3 software, select the menu File → New → Project. In the New Project dialog box, select TwinCAT Project under Templates on the left side, enter the solution name and storage path, then click OK to complete the creation.







Figure 12-34 Creating a new solution

3. Connect the Beckhoff PLC CX5130.






Figure 12-35 Connecting to Beckhoff PLC

4. Scanning the drive

Switch TwinCAT3 to configuration mode, then scan the I/O.






Figure 12-36 Scanning the drive


A dialog box will appear indicating that not all device types can be scanned automatically. Click "OK".




After scanning the EtherCAT bus, click "OK".



When motion control devices are scanned, the system will ask whether to link the scanned axes to the NC configuration. Click "OK" to complete the mapping.



Click "Yes" to activate Freerun debug mode. In debug mode, users can test I/O without a program.



After completing the above operations, you can see that the 730W drive has been successfully scanned under the left tree menu "I/O" → "Devices".




Figure 12-37 Scan completed

12.3.2 Setting EtherCAT related parameters

1. Modify the drive to operate in DC mode. If DC is the default setting, no modification is required. Make the changes sequentially.




Figure 12-38 Modifying the operating mode

2. Select the required PDO mapping

Click on the scanned 730W drive and find "Process Data" in the configuration interface.





Figure 12-39 Selecting PDO mapping

3. Setting encoder parameters (In this example, the encoder is set for Axis 1. The same procedure applies to other axes.)

Find "Motion" → "Axes" → "Axis1" → "Enc" → "Parameter" in the left tree menu and set the encoder parameters.



- Scaling Factor: Indicates the distance corresponding to the encoder pulse of each position feedback.
- Scaling Factor Numerator: Represents the displacement of the actuator when the motor rotates one revolution.
- Scaling Factor Denominator: Represents the number of encoder pulses sent when the motor rotates one revolution.
- Encoder Sub Mask (absolute range maximum value): The encoder sub mask is related to the maximum feedback value. For example, for a 16-bit incremental encoder, exceeding 65535 in the forward direction will reset to 0. At this point, the NC will handle the rollover issue, recognizing that the position is steadily increasing rather than experiencing an actual position

jump. In this case, the Sub Mask should be set to 0x0000FFFF. It is important to note that many third-party drives (including the 730W) typically set the position feedback increment per motor revolution to 36000. If single-turn reset is also enabled, the Sub Mask should be set to 35999; otherwise, the NC may miscalculate the cumulative position.

| Parameter | Offline Value | Online Value | Ty... | Unit |
|-------------------------------------------------|---------------|--------------|-------|--------|
| Encoder Evaluation: | | | | |
| Invert Encoder Counting Direction | FALSE | | B | |
| Scaling Factor Numerator | 60.0 | | F | mm/INC |
| Scaling Factor Denominator (default: 1.0) | 8388608.0 | | F | |
| Position Bias | 0.0 | | F | mm |
| Modulo Factor (e.g. 360.0°) | 360.0 | | F | mm |
| Tolerance Window for Modulo Start | 0.0 | | F | mm |
| Encoder Mask (maximum encoder value) | 0xFFFFFFFF | | D | |
| Encoder Sub Mask (absolute range maximum value) | 0x000FFFFF | | D | |
| Reference System | 'INCREMENTAL' | | E | |
| Limit Switches: | | | | |
| Soft Position Limit Minimum Monitoring | FALSE | | B | |
| Minimum Position | 0.0 | | F | mm |
| Soft Position Limit Maximum Monitoring | FALSE | | B | |
| Maximum Position | 0.0 | | F | mm |
| + Filter: | | | | |
| + Homing: | | | | |
| + Other Settings: | | | | |

Download Upload Expand All Collapse All Select All

A dialog box will appear indicating that the parameter download is temporary and the data will still be lost after restart. Click "OK" to confirm, and then you can see that the offline values will be written into the online values.




Figure 12-40 Parameter download

Innovation Integrity Service



LinkedIn



YouTube



Zhejiang Hechuan Technology Co., Ltd.

No.5, Qinshan Road, Longyou Industrial Zone, Quzhou City, Zhejiang Province

R&D Center (Hangzhou)

No. 299, Lixin Road, Qingshanhu Road, Lin'an District, Hangzhou City, Zhejiang Province, P.R. China

 **HCFA Official Website - www.hcfaglobal.com**

This manual may include information about other products, their names, trademarks, or registered trademarks, which are the property of other companies and not owned by HCFA. The information provided in this manual is subject to change without prior notice.